


-> Disadvantages -
-> Communication channel must have very large BW.
large BW.
1. to a madulation and was to
-> Large number of modulators & filters
required.
-> Applications -
Jelephone networks, cellular networks,
· 1-11 to again in
(Shazing over Cu/coaxial/Of cable) is mandatory
- Multiplexing Hierarchy in FDIVI-
Level 1 -> Basic Group [12 roice channels]  Mux'ed together]  Tueto 5 basic groups 7
Level 2 > Super Group [upto 5 basic groups]  [mux'ed together]
Level 2 > Super Group [mux'ed together]
Level 3 -> Master Group [upto 10 super groups]  Level 4 -> Jambo Group [upto 6 mastergroups]  Level 4 -> Jambo Group [mux'ed together]
Level 3 -> Master 4 p [ myxed together ]
Jupto 6 mastergroups
Level 4 > Jambo Group [ mux'ed together ]



81. 5 channels, each with a 100 kHZ BW are to be multiplexed together using FDM. What is the minimum BW requirement what is the minimum BW requirement of the link (channel) if there is a need of the link (channel) if there is a need for a guard band of 10 kHZ between the for a guard band of 10 kHZ between the channels to prevent interference. Channels to prevent interference. Draw the pictorial Representation of the Same.

Solni BW requirement = (5×100 kHz) + (5-1)×10 kHz = 500 kHz + 40 kHz = 540 kHz

Chl
100k 10K 100K 10K 100K 10K 100K 100K

Grand Bands

BW = 540 KHZ

92' A cellular system was two bands.

First band of 824-849 MHZ is used for uplink and 869-894 MHZ is used for donorlink. Each user needs a BW of 25 kHZ in each direction. How many users can use their cell phones simultaneously.


Soln uplinte BW = 849 - 824 = 25 MHZ
Dononline BW = 894 - 869 = 25 MHZ
No. of channels in uplink = $\frac{25 \text{ MHz}}{25 \text{ KHz}}$
No of channels in donaline = 25 MHZ 25 kHZ
= 1000 ch
Each user regnired one pair of uplinte &
1 did clampeli
i. 1000 users can simultaneoutly use
their cell phones.  Time Division Multiplexing (TDM) Lec 5  Works on the concept of Time sharing
-> Time Division Multiplexing (1010)
> Works on the concept of time sharing or works on the concept of time sharing or only varying original on Not suitable for continuously varying original used for digital communication systems.
Usel Wer 2 User 3 User 4 User 1 User 2 User 3 User 4 Time  TSI TS2 TS3 TS4 TS5 TS6 TS7 TS8 TS9 TS10  Frame

TS -> Time Slot

→ TDM System -

User	A3 A2 A1	Fro	me 3 Fra	me 2 Fr B2 A2 [C]	RI AI
User 2	B3 B2 B1	Mux	8 83 A3 C2 A EI [] []		
Wes 3_	C3 C2 C1			ANNEL	
	Data flow is	dirided	into u	nits (g	· A1, A2, A
-> d Bl	1, B2, B3,	c1, c2, c3.	)	· +1.	and
-> Or	re unit from	n each o	Lame		
con	nbined to (	h unit c	an be	1-617	or several
[ 8 k	nts]		0.45	· 1	a land in
$\rightarrow$	Data late	of the	multip	obexed. ata la	te of
(	nouviewas			n is	the
(	number of	Lources		nt	
	BW regn	IT COME	,		

> multiplexes 24 voice channels (SI-524)  > Each channel is bandlimited to 3.3 kHZ  > Each channel is bandlimited to 3.3 kHZ
Each channel is bandlimited to 3.3 KHZ
$\alpha$
-> Sampling is done at $fs(>2fm) = 8 kHZ$ -> Sampling is done at $fs(>2fm) = 8 kHZ$
a l'une done
pcm transmitter which converts it into a
pcm transmiller of
digital signal.
-> Periodically, after every 6000 gebeaters
Jeriodically, after every 6000 feet, pcm- Tom signal is regenerated using repeaters  to make a signal is decoded and
-> At PCNI PX, 181
1 lb ex-ea
a man Time In Carrotte
different LPF via commutator switch
different
-> Synchronization between 1x and 1x
-> Synchronization between Tx and Rx commutator switch is essential.



-> Bits/Frame -
-> Commutator sweeps from SI-S24 @
8000 rev/sec.
2 I was his part of the second
-> Each sample encoded into a
> Each sample encoded into a 8-bit digital (code) word
-> In 1 Frame = 1 Revolution = 24 channels (Time 8 lots)
$= 24 \times 8 = 192 \text{ bits}$
-> for synchronization, one bit called F-bit also transmitted per frame.
F-bit also transmitted per ( int)
- 1 Frame = 192 + 1 (0)
=193  bits
Extract.
-> Bit Rate -
0 1 to 1000.
such signal is sampled out
Frame =   Revolution = _1 = 125 Msec .
-> But, I Frame = 193 bit (Transmitted in)

193 bits -> 125 Mg. We know, Bit Rate = no. of bits/sec. = 193 = 1.544 Mbits/sec. 125 Msec BW = 1 x Bit Rate = 1.544 Mbits/sec = 772 KHZ -> Duration of each bit -193 bits -> 125 Msec 1 bit = 125 Mec 193 = 0.6476 Msec. Q1" Four channels are multiplexed using TDM. If each channel sends 100 bytes/sec and we multiplex I byte/channel, calculate -Size of frame, frame rate, Bit rate and Duration of frame. Soln Each frame carries 1 byte / channel : Size of frame = 1 byfe/channel x 4 channels = 4 bytes = 4x8 = 32 bits Frame late = frames/sec = 100 frames/sec Bit rate = 100 frames/sec x 32 bits/frame = 3200 bps Duration of frame = 1 = 0.01 sec.


# **Module V**

## **Lecture**

Orthogonal Frequency Division Multiplexing (OFDM)


# Orthogonal Frequency Division Multiplexing (OFDM)

- The same harmless channel for low rate communication becomes harsh for high rate communication due to ISI
- Use of OFDM can help solve this issue...
- OFDM scheme differs from traditional FDM in the following interrelated ways:
  - Multiple carriers (called subcarriers) carry the information stream
  - Subcarriers are orthogonal to each other
  - A guard interval is added to each symbol to minimize the channel delay spread and intersymbol interference



https://www.electronics-notes.com/articles/radio/multicarrier-modulation/ofdm-orthogonal-frequency-division-multiplexing-what-is-tutorial-basics.php

- OFDM consists of a number of closely spaced modulated carriers that are orthogonal to each another
  - Although the sidebands from each carrier overlap, they can still be received without the interference
- Achieved by having the carrier spacing equal to the reciprocal of the symbol period



https://www.electronics-notes.com/articles/radio/multicarrier-modulation/ofdm-orthogonal-frequency-division-multiplexing-what-is-tutorial-basics.php

## Principle of working

- In FDM...
- Different streams of information are mapped onto separate parallel frequency channels
- Data is sent over a radio channel serially, one bit after another
- Each FDM channel is separated from others by a guard band to reduce interference between adjacent channels
- Since, this relies on a single channel and any interference on that single frequency can disrupt the whole transmission

#### In OFDM...

- We break one serial fast bit stream into many parallel slow bit streams
- ie. extend the concept of single subcarrier modulation by using multiple subcarriers within the same single channel
- So, rather than transmit a high-rate stream of data with a single subcarrier, it uses a large number of closely spaced orthogonal subcarriers that are transmitted in parallel
- Each subcarrier is modulated with a conventional digital modulation scheme (such as QPSK, 16QAM, etc.) at low symbol rate
- This reduces interference among symbols and makes it easier to receive each symbol accurately while maintaining the same throughput
- Being split into a number of parallel "substreams" the overall data rate is that of the original stream, but that of each of the substreams is much lower, and the symbols are spaced further apart in time

## Advantages of OFDM

- Immunity to selective fading: More resistant to frequency selective fading than single carrier systems because it divides the overall channel into multiple narrowband signals that are affected individually as flat fading sub-channels
- Resilience to interference: Interference appearing on a channel may be bandwidth limited and in this way will not affect all the sub-channels. This means that not all the data is lost.
- Spectrum efficiency: Using close-spaced overlapping sub-carriers, OFDM makes efficient use of the available spectrum.
- Resilient to ISI: It is very resilient to inter-symbol and inter-frame interference because of low data rate on each of the sub-channels.
- Resilient to narrow-band effects: Using adequate channel coding and interleaving it is possible to recover symbols lost due to frequency selectivity of channel and narrow band interference. Not all data is lost.
- Simpler channel equalisation: Since OFDM uses multiple sub-channels, channel equalization becomes much simpler.

## Disadvantages of OFDM

- High peak to average power ratio: OFDM signal has a noise like amplitude variation and has a relatively high large dynamic range (peak to average power ratio). This impacts RF amplifier efficiency as amplifiers need to be linear and accommodate large amplitude variations
- Sensitive to carrier offset and drift: OFDM is sensitive to carrier frequency offset and drift as compared to single carrier systems that are less sensitive

## Applications

- OFDM is the technology behind many high speed systems such as
  - WiFi (IEEE 802.11a, g, n, ac)
  - WiMAX (IEEE 802.16)
  - 4G mobile communications (3GPP LTE)
  - DSL internet access
  - Digital television

#### References

- http://rfmw.em.keysight.com/wireless/helpfiles/89600B/WebHelp/Subsyste ms/wlan-ofdm/content/ofdm basicprinciplesoverview.htm
- https://www.tutorialspoint.com/orthogonal-frequency-division-multiplexingofdm
- https://www.electronics-notes.com/articles/radio/multicarriermodulation/ofdm-orthogonal-frequency-division-multiplexing-what-istutorial-basics.php
- https://www.dsprelated.com/showarticle/1046.php