


## - - Pages - -


PCIE_Slot	eMMC1
File: PCI_SLOT.kicad_sch	File: eMMC1.kicad_sch
PCIE_POWER	eMMC2
File: PCIE_POWER.kicad_sch	File: eMMC2.kicad_sch
PCIE_USB	еММСЗ
File: PCIE_USB.kicad_sch	File: eMMC3.kicad_sch
PCIE_CONFIG_GPIO	eMMC4
File: PCIE_GPIO.kicad_sch	File: eMMC4.kicad_sch
LEDs	Greebles
File: LEDs.kicad_sch	File: greebles.kicad_sch


## **HTML Accelerator**

















## Mode Selection


MCS9990 supports following four functional modes, selectable through device mode select pins at board level. The I2C EEPROM is also required to be used in these modes.

Mode Selection	TEST_EN	MODE_SEL2	MODE_SEL1	MODE_SEL0	OTG_EN_N
4 USB Host	0	0	0	0	1
2 USB Host + OTG	0	0	0	1	0
2 USB Host + OTG + ISA	0	0	1	0	0
2 USB Host + OTG + GPIO	0	0	1	1	0

## 5. Bootstrap Options

In MCS9990, six bootstrap options are present.

Pin Name	Bootstrap	Internal PU/PD	Default External PU/PD	Description  To mask PCIe error bits. By default logic 'Low' is present to mask error reporting	
LN_STATO	PCIEXP_ERR_MSK	PD	PU		
LN_STAT1	MAXRD_128BYTES	PD	Open	To set maximum read request size from EP to be 128 bytes by passing high logic on the line. By default logic 'Low' is present	
LN_STAT2	AUX_POWER	PD	PU	For auxiliary power detection, connected to 'Vaux' detect circuit at board level. By default logic 'Low' is present	
GPIO19	ASPM_CNTRL	PU	PD	To Provide ASPM suppor controllability. By defaul logic 'High' is present to enable ASPM	
GPIO20	ADV_ERROR_REPORT	PU	Open	To provide Advance Erro Report suppor controllability. By defaul logic 'High' is present to enable the feature.	
GPIO21	WAKE_HIB_EN	PU	Open	To provide wake from DS Cold (Hibernate) state through device connected under USB host. By default logic 'High' is present to disable this feature. To enable the feature provide weak pul down at board level.	



TOdo: place PCB and see how much space left for all the LEDs

