```
from DRV8833 import *
 1
 2
   from Encoder import *
 3
   class MotorController:
4
5
 6
        def __init__(self, motor, encoder):
            '''Controller for a single motor
7
            motor: motor driver (DRV8833)
8
            encoder: motor encoder (Encoder)
9
10
            self.mot = motor
11
12
            self.end = encoder
13
            self.integ = 0
14
        def p_control(self, desired_cps, P=1):
15
            '''Set motor control to rotate at desired_cps'''
16
            actual_cps = self.end.get_cps()
17
            error = desired cps - actual cps
18
            self.mot.set_speed(P*error)
19
20
            # return speed (e.g. for plotting)
            return actual_cps
21
22
23
        # add new method:
        def pi_control(self, desired_cps, Ts, P=1, I=1):
24
25
            actual cps = self.end.get cps()
26
            error = desired_cps - actual_cps
27
            self.integ += error * Ts
            # clamp integrator, e.g. if desired_cps exceeds maximum motor speed
28
            self.integ = max(-150, min(self.integ, 150))
29
            self.mot.set speed(P*error + I*self.integ)
30
            return actual cps
31
```