# **Arithmetic Instructions**

Instruction	Example	Meaning	Comments
add	add \$1,\$2,\$3	\$1=\$2+\$3	
subtract	sub \$1,\$2,\$3	\$1=\$2-\$3	
add immediate	addi \$1,\$2,100	\$1=\$2+100	"Immediate" means a constant number
add unsigned	addu \$1,\$2,\$3	\$1=\$2+\$3	Values are treated as unsigned integers, not two's complement integers
subtract unsigned	subu \$1,\$2,\$3	\$1=\$2-\$3	Values are treated as unsigned integers, not two's complement integers
add immediate unsigned	addiu \$1,\$2,100	\$1=\$2+100	Values are treated as unsigned integers, not two's complement integers
Multiply (without overflow)	mul \$1,\$2,\$3	\$1=\$2*\$3	Result is only 32 bits!
Multiply	mult \$2,\$3	\$hi,\$low=\$2*\$3	Upper 32 bits stored in special register hi Lower 32 bits stored in special register 10
Divide	div \$2,\$3	\$hi,\$low=\$2/\$3	Remainder stored in special register hi Quotient stored in special register 10
Unsigned Divide	divu \$2,\$3	\$hi,\$low=\$2/\$3	\$2 and \$3 store unsigned values.  Remainder stored in special register hi Quotient stored in special register 10

Logical

_09.04.			
Instruction	Example	Meaning	Comments
and	and \$1,\$2,\$3	\$1=\$2&\$3	Bitwise AND
or	or \$1,\$2,\$3	\$1=\$2 \$3	Bitwise OR
and immediate	andi \$1,\$2,100	\$1=\$2&100	Bitwise AND with immediate value
or immediate	or \$1,\$2,100	\$1=\$2 100	Bitwise OR with immediate value
shift left logical	sll \$1,\$2,10	\$1=\$2<<10	Shift left by constant number of bits
shift right logical	srl \$1,\$2,10	\$1=\$2>>10	Shift right by constant number of bits

# **Data Transfer**

Instruction	Example	Meaning	Comments
load word	lw \$1,100(\$2)	\$1=Memory[\$2+100 ]	Copy from memory to register
store word	sw \$1,100(\$2)	Memory[\$2+100]=\$ 1	Copy from register to memory
load upper immediate	lui \$1,100	\$1=100x2^16	Load constant into upper 16 bits. Lower 16 bits are set to zero.
load address	la \$1,label	\$1=Address of label	Pseudo-instruction (provid ed by assembler, not processor!) Loads computed address of label (not its contents) into register
load immediate	li \$1,100	\$1=100	Pseudo-instruction (provid ed by assembler, not processor!) Loads immediate value into register
move from hi	mfhi \$2	\$2=hi	Copy from special

			register hi to general register
move from lo	mflo \$2	\$2=lo	Copy from special register 10 to general register
move	move \$1,\$2	\$1=\$2	Pseudo-instruction (provid ed by assembler, not processor!) Copy from register to register.

Variations on load and store also exist for smaller data sizes:

• 16-bit halfword: 1h and sh

• 8-bit byte: 1b and sb

### **Conditional Branch**

All conditional branch instructions compare the values in two registers together. If the comparison test is true, the branch is taken (i.e. the processor jumps to the new location). Otherwise, the processor continues on to the next instruction.

Instruction	Example	Meaning	Comments
branch on equal	beq \$1,\$2,100	if(\$1==\$2) go to PC+4+100	Test if registers are equal
branch on not equal	bne \$1,\$2,100	if(\$1!=\$2) go to PC+4+100	Test if registers are not equal
branch on greater than	bgt \$1,\$2,100	if(\$1>\$2) go to PC+4+100	Pseduo-instruction
branch on greater than or equal	bge \$1,\$2,100	if(\$1>=\$2) go to PC+4+100	Pseduo-instruction
branch on less than	blt \$1,\$2,100	if(\$1<\$2) go to PC+4+100	Pseduo-instruction
branch on less than or equal	ble \$1,\$2,100	if(\$1<=\$2) go to PC+4+100	Pseduo-instruction

Note 1: It is much easier to use a label for the branch instructions instead of an absolute number. For example: beq \$t0, \$t1, equal. The label "equal" should be defined somewhere else in the code.

Note 2: There are **many variations** of the above instructions that will **simplify writing programs**! Consult the <u>Resources</u> for further instructions, particularly H&P Appendix A.

## Comparison

Instruction	Example	Meaning	Comments
set on less than	slt \$1,\$2,\$3	if(\$2<\$3)\$1=1; else \$1=0	Test if less than. If true, set \$1 to 1. Otherwise, set \$1 to 0.
set on less than immediate	slti \$1,\$2,100	if(\$2<100)\$1=1; else \$1=0	Test if less than. If true, set \$1 to 1. Otherwise, set \$1 to 0.

Note: There are **many variations** of the above instructions that will **simplify writing programs**! Consult the <u>Resources</u> for further instructions, particularly H&P Appendix A.

### **Unconditional Jump**

Instruction	Example	Meaning	Comments
jump	j 1000	go to address 1000	Jump to target address
jump register	jr \$1	go to address stored in \$1	For switch, procedure return
jump and link	jal 1000	\$ra=PC+4; go to address 1000	Use when making procedure call. This saves the return address in \$ra

Note: It is much easier to use a label for the jump instructions instead of an absolute number. For example: j loop. That label should be defined somewhere else in the code.

# **System Calls**

The SPIM simulator provides a number of useful system calls. These are **simulated**, and **do not represent MIPS processor instructions**. In a real computer, they would be implemented by the operating system and/or standard library.

System calls are used for input and output, and to exit the program. They are initiated by the syscall instruction. In order to use this instruction, you must first supply the appropriate arguments in registers \$v0, \$a0-\$a1, or \$f12, depending on the specific call desired. (In other words, not all registers are used by all system calls). The syscall will return the result value (if any) in register \$v0 (integers) or \$f0 (floating-point).

Available syscall services in SPIM:

Service	Operation	Code (in \$v0)	Arguments	Results
print_int	Print integer number (32 bit)	1	\$a0 = integer to be printed	None
print_float	Print floating-point number (32 bit)	2	\$f12 = float to be printed	None
print_double	Print floating-point number (64 bit)	3	\$f12 = double to be printed	None
print_string	Print null-terminated character string	4	\$a0 = address of string in memory	None
read_int	Read integer number from user	5	None	Integer returned in \$v0
read_float	Read floating-point number from user	6	None	Float returned in \$f0
read_double	Read double floating-point number from user	7	None	Double returned in \$f0
read_string	Works the same as Standard C Library fgets () function.	8	\$a0 = memory address of string input buffer \$a1 = length of string buffer (n)	None
sbrk	Returns the address to a block of memory containing n additional bytes. (Useful for dynamic memory allocation)	9	\$a0 = amount	address in \$v0
exit	Stop program from running	10	None	None
print_char	Print character	11	\$a0 = character to be printed	None

read_char	Read character from user	12	None	Char returned in \$v0
exit2	Stops program from running and returns an integer	17	\$a0 = result (integer number)	None

#### Notes:

- The print\_string service expects the address to start a null-terminated character string. The directive .asciiz creates a null-terminated character string.
- The read\_int, read\_float and read\_double services read an entire line of input up to and including the newline character.
- The read\_string service has the same semantics as the C Standard Library routine fgets().
  - The programmer must first allocate a buffer to receive the string
  - The read\_string service reads up to *n-1* characters into a buffer and terminates the string with a null character.
  - If fewer than *n-1* characters are in the current line, the service reads up to and including the newline and terminates the string with a null character.
- There are a few additional system calls not shown above for file I/O:
   open, read, write, close (with codes 13-16)

#### **Assembler Directives**

An assembler directive allows you to request the assembler to do something when converting your source code to binary code.

Directive	Result
.word w1,, wn	Store <i>n</i> 32-bit values in successive memory words
.half h1,,	Store <i>n</i> 16-bit values in successive memory words
.byte b1,, bn	Store <i>n</i> 8-bit values in successive memory words
.ascii str	Store the ASCII string str in memory. Strings are in double-quotes, i.e. "Computer Science"
.asciiz str	Store the ASCII string str in memory and <b>null-terminate</b> it Strings are in double-quotes, i.e. "Computer Science"

.space n	Leave an empty <i>n</i> -byte region of memory for later use
.align n	Align the next datum on a 2 <sup>n</sup> byte boundary. For example, .align 2 aligns the next value on a word boundary

## **Registers**

MIPS has 32 general-purpose registers that could, technically, be used in any manner the programmer desires. However, by convention, registers have been divided into groups and used for different purposes. Registers have both a *number* (used by the hardware) and a *name* (used by the assembly programmer). This table **omits special-purpose registers** that will not be used in ECPE 170.

Register Number	Register Name	Description
0	\$zero	The value 0
2-3	\$v0 - \$v1	( <b>v</b> alues) from expression evaluation and function results
4-7	\$a0 - \$a3	(arguments) First four parameters for subroutine
8-15, 24-25	\$t0 - \$t9	Temporary variables
16-23	\$s0 - \$s7	Saved values representing final computed results
31	\$ra	Return address