The tikzdotncross Package Marking Coordinates and Crossing Paths Version 1.3

Alceu Frigeri*

October 2025

Abstract

This package offers a few alternative ways for declaring and marking coordinates and drawing a line with "jumps over" an already given path, which is a quite common issue when drawing, for instance, Electronics Circuits, e.g. CircuitikZ.

1 Introduction

One recurring problem when drawing circuits in general is how to interpret a crossing line. There are many conventions, notably, for the old school (like the author of this) a jump denotes "non touching lines" while a simple cross is a connection, more recently (like the past 25 years), the winning convention has been that a dot marks a connection, whilst a simple cross denotes "non touching lines". Many, for the sake of staying in the safe side of the wall, mark a connection with dots and non touching lines with a jump, which is a bit overkill, but at least there is no margin for interpretation errors.

And that's it, this package defines some commands to mark/pin a connection, declaring a coordinate and node at the same spot, for later reference, and a command to draw a line jumping over crossing lines of a pre-existent path.

2 Package Options

```
pinsize pin (circle) size (default: 1.2), in pt.
    pinang pin angle (default: 45).
 pincolor pin color (default: blue).
 pinlength pin length (default: 4), in pt.
coordcolor coordinate color (default: red), used if \showcoordstrue.
```

Those can also be set, middle code, via:

\setpindefaults \setpindefaults {\langle options as above \rangle}

2024/10/22

3 Declaring and Marking Coordinates/Nodes

Those are based on some ideas from Redaelli et al. (CircuiTikZ). Main differences: a variable number of parameters (see below) and it always also adds an empty node n(coord).

\showcoordstrue \shoocoordsfalse

\showcoordstrue \showcoordsfalse

These will affect how \ncoord, \dotcoord and \odotcoord will behave, with \showcoordstrue a red pin will also be added to the newly defined coordinate/node. The initial state is \showcoordsfalse. It can be turned on/off as needed.

^{*}https://github.com/alceu-frigeri/tikzdotncross

\showcoords

\showcoords $\{\langle val \rangle\}$

new: 2025/10/29

Alternative form to set newly defined coordinates visibility. If $\langle val \rangle$ is either on or true this will be equivalent to \showcoordstrue, otherwise if $\langle val \rangle$ is either off or false this will be equivalent to \showcoordsfalse.

\ncoord \pincoord

```
\ncoord(\langle coord\rangle)
\pincoord(\langle coord\rangle, \langle color\rangle)
\pincoord(\langle coord\rangle, \langle color\rangle, \langle color\rangle.
```

The \ncoord always expects a single parameter $\langle \texttt{coord} \rangle$. A coordinate named $\langle \texttt{coord} \rangle$ and node named $n\langle \texttt{coord} \rangle$ (a "n" is added as a prefix) will be created for later use/reference. If \showcoordstrue is en force, it will also add a pin.

The \pincoord always draws a pin, besides declaring a coordinate and node as \ncoord. It expects one to 4 parameters, as listed. If omitted, the default length is 4 (unit: pt), the default angle is -45 (degrees), the default color is blue. Likewise, if \showcoordstrue, \ncoord(name) is just a short cut for \pincoord (name,red,45).

Note: Those defaults can be changed via package options, see 2, or \setpindefaults.

\dotcoord \dotpincoord

```
\dotcoord(\( \langle coord \rangle \rangle \)
\dotpincoord(\( \langle coord \rangle \rangle \rangle \rangle \)
\dotpincoord(\( \langle coord \rangle \ran
```

These are the same as \ncoord and friends, just adding a dot (a filled in, small circle) at the coordinate.

\odotcoord \odotpincoord

```
\label{eq:coord_coord} $$ \odotpincoord(\langle coord\rangle) $$ \odotpincoord(\langle coord\rangle, \langle color\rangle) $$ \odotpincoord(\langle coord\rangle, \langle color\rangle, \langle angle\rangle) $$ \odotpincoord(\langle coord\rangle, \langle color\rangle, \langle angle\rangle, \langle length\rangle) $$
```

These are the same as \ncoord and friends, just adding an open dot (a small circle filled with white) at the coordinate.

4 Crossing Paths

\pathcross

This will draw a line from \(\coordA \) to \(\coordB \) "jumping over" any pre-existent (soft) path named \(\path-name \). First of, the reference path \(\path-name \) has to be defined using the name path key \((name path=\path-name \)).

Then this will "calculate" the intersections between the line (defined by the coordinates ($\langle coordA \rangle$) and ($\langle coordB \rangle$) and the path named $\langle path-name \rangle$. At each intersection a coordinate named ($\langle cross-name \rangle$ -i) and a node ($n\langle cross-name \rangle$ -i) will be defined (i goes from 1 up to the number of crossings detected.) A macro named $\langle cross-name \rangle T$ will have the number of crossings found.

At each intersection a semi-circle will be drawn, and finally a line will be draw connecting $\langle coordA \rangle$ to $\langle coordB \rangle$ over all intermediate nodes.

The star version flips the semi-circles orientation.

Note: The default $\langle cross-name \rangle$ is "cross". It may contain only characters, as any valid TFX macro name. The default $\langle width \rangle$ of the semi-circle is 7pt.

Note: This is based on the *tikz* library *intersetions*, inheriting it's limitations. The main one: It only detects crossings over "soft paths", this means, if the line defined by $\langle \texttt{coordA} \rangle$ and $\langle \texttt{coordB} \rangle$ crosses over a node, it will, in most cases, miss it (depends on how the node is draw and interacts with the soft path system).

Note: When using the crossing coordinates, like ($\langle cross-name \rangle -i$), be aware that in some ill-defined cases, *intersections* might detect a crossing either at the starting and/or ending points. **\pathcross** accounts for that, but you will be left with some extra reference coordinates, either the first one, last one or both.

5 Some Examples

Note: In the examples below, the circuit doesn't make much/any sense, it is just a way to show the commands possibilities.

A first example with \showcoords{true} (showing all coordinates defined with \ncoord).

LATEX Code:


```
\resizebox{0.5\textwidth}{!}{
    \begin{tikzpicture}
           \mbox{\%} This is the reference, named path
           %%
           \draw[name path=base circ]
         (0,0) \dotcoord(A) to [V,invert,l=$v_i(t)$] ++(0,2) -- ++(0,1) \ncoord(Y)
           to[C] ++(1,0) \pincoord(A1) ++(1,0) \ncoord(B)
        ++(1,0) node[pnp,anchor=B] (T1){}

(A) -- (A -| B) to [R=$R_{b_2}$] ++(0,2) \ncoord(Bb) (B) ++(0,1) \ncoord(Cb) to [R=$R_{b_1}$] ++(0,2) \ncoord(C)

(T1.C) to [R,1_=$R_c$] (T1.C |- A) -- (A)


(T1.E) to [R,1=$R_e$] (T1.E |- C) -- (C -| A) -- ++(-2,0) \ncoord(X) to [V,1=$V_{cc}$] (X |- A) -- (A)
11
         13
16
        %% These are just a few, marked, coords (they could be part of the previous path
17
      \path (T1.E) ++(1,0)
                                       \pincoord(B1)
18
                                                            ++(-10,2)
                                                                            \pincoord(B2)
              (B1) ++(0,-1)
                                       \pincoord(D1) (B2) ++(0,-1)
19
                                                                            \pincoord(D2)
20
              (T1.C) ++(0.5,-0.5) \pincoord(C1) (T1.C) ++(-9,0) \pincoord(C2)
21
             (T1.B) \odotpincoord(A2,blue,225)
22
      \% And that's all, a few crossing lines
23
24
      \(\)\pathcross{A1}{A2}{\base circ}[4pt] \\draw (Y) +(0,1.7) node(){\n.cross A:\crossT};
\\\pathcross*{B1}{B2}{\base circ}[3pt] \\draw (Y) +(0,1.3) node(){\n.cross B:\crossT};
\end{align*}
\]
25
      \pathcross*[sec]{C1}{C2}{base circ}[6pt] \draw (Y) +(0,0.9) node(){N.cross C:\secT};
29
    \end{tikzpicture}
```

LaTeX Result:



And the same with \showcoords{false}

LATEX Result:



As said, the main limitation (derived from how *intersections* works) is that crossings between the line and nodes might not be detected at all. For example, if someone tries to connect the nodes D1 and D2, it will, unfortunately, fail detecting the node (pnp transistor) entirely:

L⁴TEX Code:

```
\resizebox{0.5\textwidth}{!}{
     \begin{tikzpicture}
              \mbox{\%} This is the reference, named path
              \draw[name path=base circ]
           (0,0) \dotcoord(A) to[V,invert,l=$v_i(t)$] ++(0,2) -- ++(0,1) \ncoord(Y)
              to[R=$R_i$] ++(2,0)
          to[C] ++(1,0) \pincoord(A1) ++(1,0) \ncoord(B) 
++(1,0) node[pnp,anchor=B] (T1){} 
(A) -- (A - | B) to[R=$R_{b_2}$] ++(0,2) \ncoord(Bb) (B) ++(0,1) \ncoord(Cb) to[R=$R_{b_1}$] ++(0,2) \ncoord(C) 
(T1.C) to[R,1_=$R_c$] (T1.C |- A) -- (A) 
(T1.E) to[R,1=$R_e$] (T1.E |- C) -- (C - | A) -- ++(-2,0) \ncoord(X) to[V,1=$V_{cc}$] (X |- A) -- (A) 
(T1.C) -- ++(1,0) node[ocirc]{} \ncoord(k) to[open,v=$v_o(t)$] (k |- A) node[ocirc]{} -- (A) 
(Bb) -- (Cb)
13
14
15
16
           \ensuremath{\mbox{\%}}\xspace These are just a few, marked, coords (they could be part of the previous path
17
        \path (T1.E) ++(1,0)
                                                   \pincoord(B1)
                                                                                                  \pincoord(B2)
18
                                                                             ++(-10,2)
                  (H1) ++(0,-1) \pincoord(D1) (B2) ++(0,-1) \pincoord(D2) (T1.C) ++(0.5,-0.5) \pincoord(C1) (T1.C) ++(-9,0) \pincoord(C2)
19
20
                  (T1.B) \pincoord(A2,blue,225)
21
23
        \mbox{\ensuremath{\mbox{\%}}} And that's all, a few crossing lines
24
        \pathcross{A1}{A2}{base circ}[4pt]
                                                                              \draw (Y) +(0,2) node(){N.cross A:\crossT};
25
                                                                              \draw (Y) +(0,1.6) node(){N.cross D:\secT};
        \pathcross[sec]{D2}{D1}{base circ}[6pt]
26
     \end{tikzpicture}
```

LATEX Result:

