Analytic magnetic field around picture-frame coils

Alexander Prokopyszyn

May 2024

1 Magnetic field around a vertical wire

Consider a vertical wire at the origin with current pointing the in the $\hat{\mathbf{z}}$ direction and extends from $z=z_{min}$ to $z=z_{max}$. Using a formula which is derived in for example:

https://www.youtube.com/watch?v=BlIEavkDUF8&t=400s

we know that the magnetic field around this wire is given by:

$$\mathbf{B}_{vwire}(R, \phi, z) = \frac{\mu_0 I}{4\pi} \frac{1}{R} \left[\sin(\theta_1) + \sin(\theta_2) \right] \hat{\phi}.$$

Using

$$\sin(\theta_1) = \frac{z_{max} - z}{\sqrt{R^2 + (z_{max} - z)^2}},$$

$$\sin(\theta_2) = \frac{z - z_{min}}{\sqrt{R^2 + (z - z_{min})^2}},$$

gives

$$\mathbf{B}_{vwire}(R,\phi,z) = \frac{\mu_0 I}{4\pi} \frac{1}{R} \left[\frac{z_{max} - z}{\sqrt{R^2 + (z_{max} - z)^2}} + \frac{z - z_{min}}{\sqrt{R^2 + (z - z_{min})^2}} \right] \hat{\phi}.$$

Using

$$R = \sqrt{x^2 + y^2},$$

$$\hat{\phi} = \frac{-y\hat{\mathbf{x}} + x\hat{\mathbf{y}}}{\sqrt{x^2 + y^2}},$$

we can convert this to Cartesian coordinates to give

$$\mathbf{B}_{vwire}(x, y, z; z_{min}, z_{max}, I) = \frac{\mu_0 I}{4\pi} \frac{1}{x^2 + y^2} \left[\frac{z_{max} - z}{\sqrt{x^2 + y^2 + (z_{max} - z)^2}} + \frac{z - z_{min}}{\sqrt{x^2 + y^2 + (z - z_{min})^2}} \right] (-y\hat{\mathbf{x}} + x\hat{\mathbf{y}}).$$

Let

$$A_{vwire}(x,y,z;z_{min},z_{max},I) = \frac{\mu_0 I}{4\pi} \frac{1}{x^2 + y^2} \left[\frac{z_{max} - z}{\sqrt{x^2 + y^2 + (z_{max} - z)^2}} + \frac{z - z_{min}}{\sqrt{x^2 + y^2 + (z - z_{min})^2}} \right].$$

In vector notation \mathbf{B}_{vwire} is given by

$$\mathbf{B}_{vwire}(x, y, z; z_{min}, z_{max}, I) = A_{vwire}(x, y, z; z_{min}, z_{max}, I) \begin{pmatrix} -y \\ x \\ 0 \end{pmatrix}$$

2 Magnetic field around a horizontal wire

We can use the formula for the magnetic field around a vertical wire to calculate the magnetic field around a wire that points in the $\hat{\mathbf{R}}_k = \cos(\phi_k)\hat{\mathbf{x}} + \sin(\phi_k)\hat{\mathbf{y}}$ direction and extends from $R = R_{inner}$ to R_{outer} at $z = z_0$. We do this by taking a vertical wire which points in the z-direction and is centred at the then apply a 90 degree rotation around the y-axis, and then a ϕ_k rotation around the z-axis.

Using the formula for the rotation matrix about the y and z axes

$$R_y(\theta) = \begin{pmatrix} \cos(\theta) & 0 & \sin(\theta) \\ 0 & 1 & 0 \\ -\sin(\theta) & 0 & \cos(\theta) \end{pmatrix},$$

$$R_z(\theta) = \begin{pmatrix} \cos(\theta) & -\sin(\theta) & 0\\ \sin(\theta) & \cos(\theta) & 0\\ 0 & 0 & 1 \end{pmatrix}.$$

Our full rotation matrix is given by

$$R = R_z(\phi_k)R_y(\pi/2)$$

$$= \begin{pmatrix} \cos(\phi_k) & -\sin(\phi_k) & 0\\ \sin(\phi_k) & \cos(\phi_k) & 0\\ 0 & 0 & 1 \end{pmatrix} \begin{pmatrix} 0 & 0 & 1\\ 0 & 1 & 0\\ -1 & 0 & 0 \end{pmatrix}$$

$$= \begin{pmatrix} 0 & -\sin(\phi_k) & \cos(\phi_k)\\ 0 & \cos(\phi_k) & \sin(\phi_k)\\ -1 & 0 & 0 \end{pmatrix}.$$

The inverse rotation matrix is given by

$$R^{-1} = R_y(-\pi/2)R_z(-\phi_k)$$

$$= \begin{pmatrix} 0 & 0 & -1 \\ 0 & 1 & 0 \\ 1 & 0 & 0 \end{pmatrix} \begin{pmatrix} \cos(\phi_k) & \sin(\phi_k) & 0 \\ -\sin(\phi_k) & \cos(\phi_k) & 0 \\ 0 & 0 & 1 \end{pmatrix}$$

$$= \begin{pmatrix} 0 & 0 & -1 \\ -\sin(\phi_k) & \cos(\phi_k) & 0 \\ \cos(\phi_k) & \sin(\phi_k) & 1 \end{pmatrix}.$$

Let

$$\begin{pmatrix} x' \\ y' \\ z' \end{pmatrix} = R^{-1} \begin{pmatrix} x \\ y \\ z \end{pmatrix}$$

$$= \begin{pmatrix} -z \\ y \cos(\phi_k) - x \sin(\phi_k) \\ x \cos(\phi_k) + y \sin(\phi_k) \end{pmatrix}.$$

$$\implies \begin{pmatrix} x \\ y \\ z \end{pmatrix} = R \begin{pmatrix} x' \\ y' \\ z' \end{pmatrix}$$

$$= \begin{pmatrix} z' \cos(\phi_k) - y' \sin(\phi_k) \\ y' \cos(\phi_k) + z' \sin(\phi_k) \\ -x' \end{pmatrix}.$$

Hence, the formula for the magnetic field due to the upper wires in the picture-frame coils is given by

$$\mathbf{B}_{upper} = R\mathbf{B}_{vwire}(x' + h'/2, y', z'; R_{inner}, R_{outer}, I)$$

3 Magnetic field in picture-frame coils

The current design has $N_{coil} = 16$ picture-frame TF coils. The k^{th} coil is composed of four wires:

- 1. A vertical wire at $R = R_{outer}$, $\phi = \phi_k = 2\pi k/N_{coil}$ with current in the negative $\hat{\mathbf{z}}$ direction and extends from z = -h/2 to z = +h/2, where h is the height of the TF coil.
- 2. A vertical wire at $R = R_{inner}$, $\phi = \phi_k$ with current in the positive $\hat{\mathbf{z}}$ direction and extends from z = -h/2 to z = +h/2.
- 3. A horizontal wire with current which points in the $\hat{\mathbf{R}}_k = \cos(\phi_k)\hat{\mathbf{x}} + \sin(\phi_k)\hat{\mathbf{y}}$ direction and extends from $R = R_{inner}$ to R_{outer} at z = h/2.
- 4. A horizontal wire with current that points in the negative $\hat{\mathbf{R}}_k$ direction and extends from $R = R_{inner}$ to R_{outer} at z = -h/2.

We can model the magnetic field from the vertical wires with

$$\mathbf{B}_{inner,k}(x,y,z) = \mathbf{B}_{wire}(x - R_{inner}\cos\phi_k, y - R_{inner}\sin\phi_k, z; -h/2, h/2, I),$$

$$\mathbf{B}_{outer,k}(x,y,z) = \mathbf{B}_{wire}(x - R_{outer}\cos\phi_k, y - R_{outer}\sin\phi_k, z; -h/2, h/2, -I).$$

For the horizontal wires, we can use a trick where we transform our coordinate system using the following:

$$\hat{\mathbf{x}}' = \hat{\phi}_k = -\sin(\phi_k)\hat{\mathbf{x}} + \cos(\phi_k)\hat{\mathbf{y}},$$

$$\hat{\mathbf{y}}' = \hat{\mathbf{z}},$$

$$\hat{\mathbf{z}}' = \hat{\mathbf{R}}_k = \cos(\phi_k)\hat{\mathbf{x}} + \sin(\phi_k)\hat{\mathbf{y}},$$

$$x' = y\cos(\phi_k) - x\sin(\phi_k),$$

$$y' = z,$$

$$z' = x\cos(\phi_k) + y\sin(\phi_k).$$

Hence, we can model the horizontal wires using:

$$\mathbf{B}_{lower,k}(x,y,z) = \mathbf{B}_{wire}(x',y'+h/2,z';R_{inner},R_{outer},-I),$$

$$\mathbf{B}_{upper,k}(x,y,z) = \mathbf{B}_{wire}(x',y'-h/2,z';R_{inner},R_{outer},I).$$

Hence, the full magnetic field from all the TF coils is given by

$$\mathbf{B}(x, y, z) = \sum_{k=0}^{N_{coil}-1} \mathbf{B}_{inner, k} + \mathbf{B}_{outer, k} + \mathbf{B}_{lower, k} + \mathbf{B}_{upper, k}.$$