Tock Embedded OS Tutorial

Octopi Kickoff 2018

Please make sure you have completed all of the tutorial pre-requisites. If you prefer, you can download a virtual machine image with all the pre-requisites already installed.

https://github.com/alevy/tock-chalmers/tree/master/doc/courses/chalmers/README.md aka

https://goo.gl/Fztjgv

Agenda Today

- 1. Intro to hardware, tools and development environment
- 2. Write an end-to-end Bluetooth Low Energy environment sensing application
- 3. Add functionality to the Tock kernel

Part 1: Hardware, tools and development environment

TI LaunchXL CC26x2



- ▶ Bluetooth/802.15.14 System on a Chip
- ▶ ARM Cortex-M4 (with a Cortex-M0 for the radio, but we can't access it)
- ▶ 80KB RAM, 352KB Flash

Binaries on-board

Bootloader

Kernel

Processes

Tools

- make (just instrumenting cargo and the bootloader tool)
- ▶ Rust (nightly for asm!, compiling core, etc)
- tockloader to interact with the board

Tools

Program the kernel

\$ make program

Program a process in Tock Binary Format¹:

\$ make APP=../app/app.tbf program-app

Connect to the debug console:

\$ tockloader listen

¹TBFs are relocatable process binaries prefixed with headers like the package name.

Check your understanding

- 1. What kinds of binaries exist on a Tock board? Hint: There are three, and only two can be programmed using tockloader.
- 2. Can you point to the chip on the LaunchXL that runs the Tock kernel? How about the processes?
- 3. What steps would you follow to program a processes onto LaunchXL? What about to replace the kernel?

Hands-on: Set-up development environment

- 1. Compile and flash the kernel
 - ▶ Head to https://goo.gl/4VBvnd> to get started!
 - (https://github.com/alevy/tock-chalmers/blob/master/doc/courses/chalmers/environment.md)

Part 2: User space

System calls

Call	Target	Description
command	Capsule	Invoke an operation on a capsule
allow	Capsule	Share memory with a capsule
subscribe	Capsule	Register an upcall
memop	Core	Modify memory break
yield	Core	Block until next upcall is ready

C System Calls: command & allow

C System Calls: subscribe

C System Calls: yield & yield_for


```
void yield(void);

void yield_for(bool *cond) {
   while (!*cond) {
      yield();
   }
}
```

Example: printing to the debug console

```
static void putstr_cb(int _x, int _y, int _z, void* ud) {
  putstr_data_t* data = (putstr_data_t*)ud;
 data->done = true;
int putnstr(const char *str, size_t len) {
  putstr_data_t data;
  data.buf = str:
  data.done = false;
  allow(DRIVER NUM CONSOLE, 1, str, len);
  subscribe(DRIVER NUM CONSOLE, 1, putstr cb, &data);
  command(DRIVER NUM CONSOLE, 1, len, 0);
  yield for(&data.done);
  return ret;
```

Inter Process Communication (IPC)



Tock Inter Process Communication Overview

Servers

- Register as an IPC service
- Call notify to trigger callback in connected client
- Receive a callback when a client calls notify

Clients

- Discover IPC services by application name
- ▶ Able to share a buffer with a connected service
- ▶ Call notify to trigger callback in connected service
- Receive a callback when service calls notify

Inter Process Communication API

```
// discover IPC service by name
// returns error code or PID for service
int ipc_discover(const char* pkg_name);
// shares memory slice at address with IPC service
int ipc share(int pid, void* base, int len);
// register for callback on server `notify`
int ipc register client cb(int pid, subscribe cb cb,
                           void* userdata);
// trigger callback in service
int ipc_notify_svc(int pid);
// trigger callback in a client
int ipc_notify_client(int pid);
```

Check your understanding

- How does a process perform a blocking operation? Can you draw the flow of operations when a process calls delay_ms(1000)?
- 2. How would you write an IPC service to print to the console? Which functions would the client need to call?

Hands-on: Write a simple application

- 1. Get an application running on LaunchXL
- 2. Print "Hello World" every second
- 3. Toggle an LED every second every second
 - Head to <https://goo.gl/hoxAP6> to get started!
 - (github.com/alevy/tock-chalmers/blob/master/doc/courses/chalmers/application.md)

Part 3: The kernel

Trusted Computing Base (unsafe allowed)

- Hardware Abstraction Layer
- ▶ Board configuration
- ▶ Event & Process scheduler
- Rust core library
- Core Tock primitives

```
kernel/chips/
```

Capsules (unsafe not allowed)

- ▶ Virtualization
- ▶ Peripheral drivers
- ► Communication protocols (IP, USB, etc)
- Application logic

capsules/

Constraints

Small isolation units

Breaking a monolithic component into smaller ones should have low/no cost

Avoid memory exhaustion in the kernel

No heap. Everything is allocated statically.

Low communication overhead

Communicating between components as cheap as an internal function call. Ideally inlined.

Event-driven execution model

```
pub fn main<P, C>(platform: &P, chip: &mut C,
                  processes: &mut [Process]) {
    loop {
        chip.service pending interrupts();
        for (i, p) in processes.iter mut().enumerate() {
            sched::do process(platform, chip, process);
        if !chip.has_pending_interrupts() {
            chip.prepare_for_sleep();
            support::wfi();
```

Event-driven execution model

```
fn service_pending_interrupts(&mut self) {
    while let Some(interrupt) = get_interrupt() {
        match interrupt {
            ASTALARM => ast::AST.handle_interrupt(),
            USARTO => usart::USARTO.handle_interrupt(),
            USART1 => usart::USART1.handle interrupt(),
            USART2 => usart::USART2.handle interrupt(),
```

Event-driven execution model

```
impl Ast {
   pub fn handle interrupt(&self) {
        self.clear alarm();
        self.callback.get().map(|cb| { cb.fired(); });
impl time::Client for MuxAlarm {
    fn fired(&self) {
        for cur in self.virtual_alarms.iter() {
            if cur.should_fire() {
                cur.armed.set(false);
                self.enabled.set(self.enabled.get() - 1);
                cur.fired();
```




Figure 1: Capsules reference each other directly, assisting inlining

The mutable aliases problem

```
enum NumOrPointer {
  Num(u32),
  Pointer(&mut u32)
// n.b. will not compile
let external : &mut NumOrPointer;
match external {
  Pointer(internal) => {
    // This would violate safety and
    // write to memory at Oxdeadbeef
    *external = Num(0xdeadbeef);
    *internal = 12345; // Kaboom
  },
```

Interior mutability to the rescue

Туре	Copy-only	Mutual exclusion	Opt.	Mem Opt.
Cell	✓	Х	√	✓
VolatileCell	✓	X	X	✓
TakeCell	×	✓	X	✓
MapCell	X	✓	✓	X

```
pub struct Fxos8700cq<`a> {
  i2c: &`a I2CDevice,
  state: Cell<State>,
  buffer: TakeCell<`static, [u8]>,
  callback:
    Cell<Option<&`a hil::ninedof::NineDofClient>>,
}
impl<`a> I2CClient for Fxos8700cq<`a> {
  fn cmd complete(&self, buf: &`static mut [u8]) { ... }
}
impl<`a> hil::ninedof::NineDof for Fxos8700cg<`a> {
  fn read accelerometer(&self) -> ReturnCode { ... }
pub trait NineDofClient {
  fn callback(&self, x: usize, y: usize, z: usize);
```

Check your understanding

- What is a VolatileCell? Can you find some uses of VolatileCell, and do you understand why they are needed? Hint: look inside chips/sam41/src.
- What is a TakeCell? When is a TakeCell preferable to a standard Cell?

Hands-on: Write and add a capsule to the kernel

- 1. Read the Hail boot sequence in boards/hail/src/main.rs
- 2. Write a new capsule that prints "Hello World" to the debug console.
- 3. Extend your capsule to print "Hello World" every second
 - ▶ Head to https://goo.gl/FXw6xg to get started!
 - (github.com/alevy/tock-chalmers/blob/master/doc/courses/chalmers/capsule.md)

https://www.tockos.org

https://github.com/tock/tock

tock-dev@googlegroups.com

#tock on Freenode