# Contents

1	$\operatorname{Intr}$	Introduction							
	1.1	Transit right now							
	1.2	Funding							
	1.3	Traditional Arguments Supporting Transit							
	1.4	Critical assessment							
	1.5	Future influences							
	1.6	Ingredients for future success							
<b>2</b>	Dat	Data Collection Techniques and Program Design							
	2.1	Summary of current practice							
	2.2	Passenger counting techniques							
	2.3	Sampling							
	2.4	Tolerance and confidence level							
3	Mod	dal Characteristics and Roles							
	3.1	Spectrum of services							
	3.2	Transit categories							
	3.3	Basics of train control							
	3.4	Levels of automated protection							
	3.5	What is a bus?							
	3.6	Examples of bus systems							
	3.7	Light Rail							
	3.8	Heavy Rail							
	3.9	Commuter Rail							
	0.0	Traditional and new service concepts							
		Increasing diversity							
		Bus vs rail comparison							

### 1 Introduction

### 1.1 Transit right now

- Ridership is increasing, but small
- Strong financial support from
- Trends in modal split
  - Auto is above 80%
  - Transit 2-3%
  - Biking and walking are the same as transit

### 1.2 Funding

- In North America, it's divided into captial and operating expenses
- Fares only pay ~1/3 of operational expenses
- Lots of federal support for capital expenses almost 40%
  - Since operating expenses are funded less, this encourages more building and less maintenance
- Fuel taxes in NA are 10-20% of what they are in Europe

### 1.3 Traditional Arguments Supporting Transit

- Equity: travel for those who can't drive
- Congestion
  - Not such a good argument, papers don't support it. The capacity released it quickly filled again
- Better for the environment
  - Actually, effort it better spent making cars cleaner since they're like 80% of transport

#### 1.4 Critical assessment

- Transport has been stabilized
- Success stories (NYC, Houston(?), Seattle)
- Institutional changes are occurring slowly

#### 1.5 Future influences

- Urban form
- More old people
- Better tech to improve performance
- Public has higher expectation (you know exactly when the bus is coming)

# 1.6 Ingredients for future success

- Maintain supportive coalition
- Expand the definition of public transport
- Greater private sector involvement
- Aggressive implementation of new technology

# 2 Data Collection Techniques and Program Design

# 2.1 Summary of current practice

- Used to be manual
- Now is collected with IoT devices
- Automated Data Collection Systems (ADCS)
  - Automated Fare Collection Systems (AFC)
    - \* Tapping your card on/off the vehicle
  - Automatic Vehicle Location Systems (AVL)
    - \* GPS tracking for buses, train tracking based on circuit occupancy
  - Automatic Passenger Counting Systems (APC)
    - \* Sensors in bus doors
      - · Use break beam sensors to tell if you're getting on or off (out of 2 beams which do you break first)
    - \* Counts from fare barriers
    - \* Load weight calculators on trains
      - · In trains the brakes apply force proportional to the load in each car (lighter cars need less braking, heavier cars need more, so they dont run into each other)

# 2.2 Passenger counting techniques

- Manual checker (a person)
  - Ride check (on the bus, on/off counts and running time)
  - Point check (load on board, headway time between buses)

#### 2.3 Sampling

- Simple random sampling
- Systematic sampling every 6 days, etc
- Cluster sampling do as much data collection as possible
- Ratio estimation/Conversion factors
- Stratified sampling sample sizes for each thing separately
  - E.g. you want information about students: get a large sample size on routes that serve universities

#### 2.4 Tolerance and confidence level

- Accuracy has 2 dimensions
  - Relative tolerance:  $\pm 10\%$
  - Absolute tolerance:  $\pm 3.3$

# 3 Modal Characteristics and Roles

# 3.1 Spectrum of services

	increa	asing ve	ehicle cap	acity &	passeng	jer nows
Vehicle Type Operating Arrangements	Car	Van	Minibus	Bus	Light Rail	Heavy Rail
Drivers	Free		Low Cost	High Cost (conventional transit)		Low Cost (automated)
Right of way	Shared			Dual Mode		Dedicated
Routing and Scheduling	Flexible		Hybrid		Fixed	

### 3.2 Transit categories

- Rights of way degree of separation
  - Surface with mixed traffic (light rail/buses)
  - Longitudinal separation by at grade crossing (light rail/bus rapid transit)
  - Full separation (at grade/tunnel/elevated)
- Technologies
  - Support (how they contact the groups)
    - \* Rubber tire on concrete (cars, buses, some rail like Paris Metro)
    - \* Steel wheel on steel rail
    - \* Maglev
    - \* Suspended cars
    - \* Water
    - \* Others
  - Guidance (lateral control)
    - \* Steered by driver
    - \* Guided by track
    - \* Others
  - Energy and propulsion
    - \* Combustion engine
    - \* Electric
    - \* Compressed natural gas (CNG)
    - \* Hybrid
    - \* Others
  - Control (longitudinal)
    - \* Manual/visual
    - \* Manual/signal
    - \* Automatic

### 3.3 Basics of train control

- Divide the system into blocks
  - If a train is occupying a section, do not let any trains in the section immediately before
  - For each block further, slowly increase speed limit in that block from nothing (0, 10, 25, 40,...)
- Block system constrains the frequency of service
- Moving block system increases capacity, usually used with automatic driving systems

#### 3.4 Levels of automated protection

- None advisory way signals
- Manual setting of speed below speed limit train will be automatically braked if over speed limit
- Automatic train supervision/regulation
- Full automation sometimes has operators, needs to have platform screen doors to keep people off of track
- Capacity increased through moving block or communication based train control

#### 3.5 What is a bus?

- Vehicle size 10-250 passengers
- Floor height (high floor/low floor)
  - Low floor is better for accessibility, has lower dwell time
- Right of way all options available
- Guidance often manual, sometimes systems
- Propulsion all options available
- Fare payment pay outside, or pay in the bus

#### 3.6 Examples of bus systems

- Bi-articulated buses are a thing
- In Curitiba, bi-articulated buses have high floors, and have to be boarded at specific stations with fare gates
- The Cambridgeshire Guided Busway has buses operating on dedicated "tracks" of pavement



- Buses can also be optically guided, following a line on the floor with a camera

# 3.7 Light Rail

- Vehicle design
  - High/low floor
  - Articulated or not
- Right of way
  - All options available
- Operation
  - Automated or manual
- Power
  - Overhead catenaries
  - Third rail
    - \* On street rails, the third rail is electronically controlled and is only powered when the train is coming

# 3.8 Heavy Rail

- Length
  - Limited by station length
  - In some cases (like in London) they allow the last door of the last car to stay in the runnel
- Turning radius

- Right of way
  - At-grade
  - Elevated
  - Tunnel
- Station spacing
- Control
- Power

#### 3.9 Commuter Rail

- Vehicles operating in trains with long station spacing
- Fare collection strategies
- Line length
- Through routing in CBD [central business district] (cross through city or go there and back)
  - Where to put trains when you're done
- Station spacing
- Parking capacity

### 3.10 Traditional and new service concepts

- Traditional
  - Bus on shared right of way
  - Streetcar on shared right of way
  - Heavy rail on exclusive ROW
  - Commuter/regional rail on semi-exclusive ROW
- New
  - Bus rapid transit
  - Light rail on exclusive ROW

### 3.11 Increasing diversity

- Driver arrangements
  - Part timers (cover peaks), 10 hour day (to cover peaks that are 8 hours apart), payment by vehicle type
- Routing and scheduling
- Vehicle types
- control options
- Priority options
- Dual mode operation

# 3.12 Bus vs rail comparison

- Rail advantages
  - Higher capacity
  - Lower unit operating cost
  - Better service quality
  - Stronger land use influence
  - Fewer negative externalities
- Bus advantages
  - Low capital costs
  - Wide network coverage
  - Single vehicle trips
  - Flexibility
  - Dual mode nature