Formula Sheet - ES96T Advanced Wireless Networks

$$G_{dB} = 10 \cdot \log_{10} G_{linear}$$

$$G_{linear} = 10^{(G_{dB}/10)}$$

Week 1

Bit rate example

Given 12 Mbps bit rate

QPSK 2 bits/symbol \rightarrow 6 M symbols/s \rightarrow 6 MHz Bandwidth

8-PSK 3 bits/symbol \rightarrow 4 M symbols/s \rightarrow 4 MHz Bandwidth

| Name | Bits per symbol |
|--------|-----------------|
| BPSK | 1 bits/symbol |
| QPSK | 2 bits/symbol |
| 8-PSK | 3 bits/symbol |
| 64-QAM | 6 bits/symbol |

Shannon Rate

$$R = B \cdot \log_2 \left(1 + \text{SNR}_{linear}\right)$$

$$R = B \cdot \log_2 \left(1 + \frac{P}{N_0 B}\right)$$

Maybe add Shannon for FDMA and TDMA

Week 2

Processing Gain

$$G_{linear} ext{ (processing gain)} = rac{R_c ext{ (chip rate)}}{R_s ext{ (user data rate)}} = rac{1/T_c}{1/T} = rac{T}{T_c}$$
 $SIR_f = SIR_b + G$

 $SIR_f =$ after de-spreading, $SIR_b =$ before de-spreading

$$SIR_{(b)} = rac{P_S ext{ (useful signal)}}{P_I ext{ (interference signal)}}$$

Example N users in a cell

$$SIR = \frac{P}{(N-1)P} = \frac{1}{N-1}$$

Free space communication

$$P_r ext{ (linear)} = P_T G_T G_r \left(rac{\lambda}{4\pi r}
ight)^2$$

 $P_T = \text{transmit power}, G_T = \text{transmit gain}, G_R = \text{receive gain},$

$$\lambda \text{ (wavelength)} = \frac{c}{f} = \frac{3 \cdot 10^8}{f}, r = \text{distance}$$

Another version

$$P_r(dBm) = P_t(dBm) - 21.98 + 20 \log_{10}(\lambda) - 20 \log_{10}(d)$$

Noise power

$$P_N$$
 (linear) = kTB

$$k \text{ (Boltzmann Constant)} = 1.38 \cdot 10^{-23}$$

$$T = \text{Temperature (Kelvin)}, B = \text{Bandwidth (Hz)}$$

Week 3

Average SIR approximation

$$S/I = SIR ext{ (linear)} = rac{(\sqrt{3N})^n}{i_0}$$

N =cluster size, n =path loss component

 $i_0 = \text{number of adjacent cells (6 for hexagonal)}$

Week 4

Power allocation strategies

| Feature | Waterfilling | Mercury Filling | Channel Inversion |
|--------------------------------|---|---|---|
| Objective | Maximize capacity by allocating power to better channels. | Maximize capacity while considering hardware constraints. | Ensure consistent signal strength at the receiver. |
| Channel Power Allocation | More power to better channels, less to weaker ones. | Modified based on constraints, penalizing certain channels. | More power to weaker channels, less to better ones. |
| Efficiency | Highly power-efficient, maximizing channel capacity. | Less efficient due to constraints but still optimized. | Power-inefficient, especially for poor channels. |
| Focus on Poor Channels | Low/no power for very poor channels. | Reduced power to penalized channels. | Allocates high power to poor channels. |
| Complexity | Simple to implement. | Moderately complex (accounts for imperfections). | Simple to implement. |
| Use Cases | OFDM, MIMO, and systems maximizing capacity. | Systems with hardware limitations (e.g., nonlinearities). | Systems needing uniform signal quality (e.g., fairness in service). |
| Impact on Capacity | Maximizes system capacity. | Slightly reduced capacity due to constraints. | Suboptimal capacity due to power wastage. |

$$Data\ Rate\ (throughput) = \frac{number\ of\ bits}{symbol\ duration}$$

$$\text{Data Rate (N Channels)} = \frac{\text{bits per symbol} \cdot \text{Number of channels}}{\text{total duration}}$$

Inter-Symbol interference exists when:

$$T_D < T_S$$

08/05/2025, 23:16 formulae

To avoid this we add

 T_U

such that

$$T_S + T_U \geq T_D$$
.

Where $T_D = \text{Delay spread}, T_S = \text{Symbol duartion}, T_U = \text{Cyclic prefix duration}$

Week 5

Water filling power allocation

$$\left(rac{1}{x}-rac{N_0}{\left|h_i
ight|^2}
ight)^+$$

Where $N_0= ext{Noise}$ power, $\dfrac{1}{x}= ext{Water level}, \left|h_i\right|^2= ext{Subchannel gain.}$ (All in W)

Week 7

$$P_{ ext{total}} = rac{P_{RH}}{ ext{efficiency}} imes rac{T}{C} + P_{OH}$$

$$L ext{(load)} = \frac{T}{C}$$

Where

 $P_{\text{total}} = \text{Total power}, P_{RH} = \text{Radiohead power}, P_{OH} = \text{Overhead power}$

$$T =$$
traffic demand, $C =$ Capacity