

Table of Contents

INTRODUCTION	
HOW DOES IT WORK?	5
Reserved Pins & GPIOs	5
Fusion of Software with Hardware	8
• Schematic	10
DATA STRUCT	11
Struct Walkthrough	11
TRANSMITTER	12
Data Encapsulation	12
RECEIVER	13
WORK-IN-PROGRESS WALK THROUGH	14
Finished Work	14
• Chassis	15
Wiring	16
Motor Wires Harness	17

ByteRider documentation



INTRODUCTION

HOW DOES IT WORK?

The BitByteRider RC car is powered by ESP32-C3 Breadboard & Power adapter development board.

Reserved Pins & GPIOs

The following table summarizes GPIOs and pins reserved for operations purposes.

The GPIO numbers correspond to those on the ESP32-C3 WROOM microcontroller. The Pin number corresponds to the pin on the Breadboard and Power adapter development board.

x- and y- axis

The **GPIOO** and **GPIO1** assigned to measuring the voltage of x- and y- axis of the Joystick. Lastly, there is a group of GPIO pairs responsible for PWM for DC motors.

Direction and Speed

The pairs of DC motors on the left side are wired to the dedicated PWM channels. This means that *ESP32-C3 Breadboard DevBoard* can control rotation speed and direction of DC motors in pairs only (i.e. left and right side). Consequently, only four PWM channels are sufficient for controlling the direction of the RC car. Based on this constraint, the RC car can only move front, back, and turn/rotate left and right. Any other movements are not possible (i.e. diagonal or sideways).

A pair of PWM channels are required for defining rotation speed and direction of the DC motors on each side. In particular, **GPIO6** and **GPIO5** provide PWM to the left- and right- side DC motors to rotate in a **clockwise** direction. Similarly, **GPIO4** and **GPIO7** provide PWM to the left- and right- side DC motors to rotate in a **counter-clockwise** direction. Changing PWM on each channel determines the speed and direction of the RC car.

The following images illustrate various PWM duty cycles registered by oscilloscope (duty cycles 0%, 48% and 91%, resp.).



DC Motor PWM duty cycle 0%



DC Motor PWM duty cycle 47.6%



DC Motor PWM duty cycle 90.8%

GPIO	Pin	Function	Notes
0	16	Joystick x-axis	ADC1_CH0
1	15	Joystick y-axis	ADC1_CH1
8	5	Joystick push button	
6	4	PWM for clockwise rotation of left-side motors	LEDC_CHANNEL_1
5	3	PWM for clockwise rotation of right-side motors	LEDC_CHANNEL_0
4	2	PWM for counter-clockwise rotation of right-side motors	LEDC_CHANNEL_2
7	6	PWM for counter-clockwise rotation of left-side motors	LEDC_CHANNEL_3

Fusion of Software with Hardware

The struct for storing motors PWM values.

```
struct motors_rpm {
    int motor1_rpm_pwm;
    int motor2_rpm_pwm;
    int motor3_rpm_pwm;
    int motor4_rpm_pwm;
};
```

The function for updating motors' PWM values.

```
// Function to send data to the receiver
void sendData (void) {
                                      // Declare data struct
    sensors_data_t buffer;
    buffer.crc = 0;
    buffer.x_axis = 0;
    buffer.y_axis = 0;
    buffer.nav_bttn = 0;
    buffer.motor1 rpm pwm = 0;
    buffer.motor2_rpm_pwm = 0;
    buffer.motor3 rpm pwm = 0;
    buffer.motor4 rpm pwm = 0;
    // Display brief summary of data being sent.
    ESP LOGI(TAG, "Joystick (x,y) position ( 0x%04X, 0x%04X )",
(uint8_t)buffer.x_axis, (uint8_t)buffer.y_axis);
    ESP_LOGI(TAG, "pwm 1, pwm 2 [ 0x%04X, 0x%04X ]",
(uint8_t)buffer.pwm, (uint8_t)buffer.pwm);
    ESP_LOGI(TAG, "pwm 3, pwm 4 [ 0x%04X, 0x%04X ]",
(uint8_t)buffer.pwm, (uint8_t)buffer.pwm);
    // Call ESP-NOW function to send data (MAC address of receiver,
pointer to the memory holding data & data length)
    uint8 t result = esp now send(receiver mac, &buffer,
sizeof(buffer));
    // If status is NOT OK, display error message and error code (in
hexadecimal).
    if (result != 0) {
       ESP_LOGE("ESP-NOW", "Error sending data! Error code:
0x%04X", result);
       deletePeer();
    else
```

```
ESP_LOGW("ESP-NOW", "Data was sent.");
}
```

The onDataReceived() and onDataSent() are two call-bacl functions that get evoked on each corresponding event.

The rc send data task() function runs every 0.1 second to transmit the data to the receiver.

```
// Continous, periodic task that sends data.
static void rc_send_data_task (void *arg) {
    while (true) {
        if (esp_now_is_peer_exist(receiver_mac))
            sendData();
        vTaskDelay (100 / portTICK_PERIOD_MS);
    }
}
```

Schematic



DATA STRUCT

DATA STRUCT

The struct is used as a payload for sending control signals from transmitting device to the receiver. In addition, it may contain telemetry data, battery status, etc.

The *sensors_data_t* struct is designed as a data payload that encapsulates all control commands and sensor states relevant to the vehicle's operation. It's intended to be sent from a transmitting device (like a remote control or master controller) to a receiver (such as a microcontroller onboard the vehicle).

```
typedef struct {
                                    // Joystick x-position
   int
                x_axis;
    int
                y_axis;
                                    // Joystick y-position
                nav_bttn;
                                    // Joystick push button
   bool
                                    // LED ON/OFF state
   bool
                led;
   uint8_t
                motor1_rpm_pwm;
                                    // PWMs for 4 DC motors
   uint8_t
                motor2_rpm_pwm;
   uint8 t
                motor3_rpm_pwm;
   uint8_t
                motor4_rpm_pwm;
} __attribute__((packed)) sensors_data_t;
```

Struct Walkthrough

x_axis and y_axis fields capture analog input from a joystick, determining direction and speed. nav_bttn represents a joystick push-button.

led allows the transmitter to toggle an onboard LED and is used for status indication (e.g. pairing, battery warning, etc).

TRANSMITTER

Data Encapsulation

RECEIVER

RECEIVER

WORK-IN-PROGRESS WALK THROUGH

Finished Work



Chassis



Completed chassis with only DC motor controllers installed.

Wiring



Completed wiring.

Motor Wires Harness



DC Motors wires secured inside harnes.

