For our 8-bit datapath, we have an instruction set architecture with the following description:

- All instructions have fixed-length of 16-bits.
- We have three types of instructions: R-type, I-type, & J-type

R-type (Register instructions): add, inv, and, or, clr

opcode	rs	rt	rd	padding
4-bits	2-bits	2-bits	2-bits	6-bits zero

opcode: unique operation idrs and rt: source registersrd: destination register

Examples: and \$rd, \$rs, \$rt and \$1, \$2, \$3

- For inv instruction, the rs field would be left unused. While only the \$rt field is as source register and \$rd register as destination register (set the value of rs field to 0).
- For clr instruction, the rs field would be left unused. Only the rt field is used as the source register and rd field as the destination register address (set the value of rs field to 0, rt and rd fields should have the same value in this case).

Examples: inv \$rd, \$rst clr \$rt

I-type (Immediate Instructions): addi, andi, ori, sra, sll, lw, sw

Opcode	rs	rd(rt)	immediate
4-bits	2-bits	2-bits	8-bits constant

opcode: unique operation id

rs: source registers rd: destination register

- For sra (Shift Right Arithmetic) and sll (Shift Left Logical) instructions, the rd register will be equal to rs register shifted to right or left by amount of immediate value (for our case it is always 1, shift by 1). For sra the sign of the number is also preserved (arithmetic shift to right).
- For **load (lw)** instruction, the **rs register** includes the **memory base address**, **rt register** is the **target register** and the **immediate** filed contains the **address offset**.
- For store (sw) instruction, the rs register includes the memory base address and rt register is the source register and the immediate filed contains the address offset.

J-type (Jump Instructions): beq, bne

opcode	rs	rt	immediate
4-bits	2-bits	2-bits	8-bits constant

opcode: unique operation id

rs: source registers rd: destination register

Examples: beq \$rs, \$rt, BranchLabel beq \$1, \$3, BranchLabel

• For beq instruction, the rs and rt registers are the source registers or the sides of comparison and the immediate field contains the instruction offset which you denote as a textual label in your assembly instruction.

Instruction Opcode to ALUOp bits translation table:

Instruction	Instruction OpCode [3:0]	ALUOp [2:0]	Description
lw	0000	000	Load Word Instruction (Iw), ALU add operation is selected to add the offset address to the base address
sw	0001	000	Store Word Instruction (sw), ALU add peration is selected to add the offset address to the base address
add	0010	000	add instruction, ALU add operation is selected
addi	0011	000	add immediate instruction, ALU add operation is selected
inv	0100	001	inv instruction, ALU inv operation is selected
and	0101	010	and instruction, ALU and operation is selected
andi	0110	010	and immediate instruction, ALU and operation is selected
or	0111	011	or instruction, ALU or operation is selected
ori	1000	011	or immediate instruction, ALU and operation is selected
sra	1001	100	sra instruction, ALU arithmetic shift to right operation is selected
sll	1010	101	sll instruction, ALU logical shift to left operation is selected
beq	1011	110	beq instruction, ALU branch if equal operation is selected
bne	1100	111	bne instruction, ALU branch if not equal operation is selected
clr	1101	010	and instruction, ALU and operation is selected, first operand will be zero
-	1110	-	
-	1111	-	-