SMA51 (35+) 8K WIN10 Adjustments

- Right click onto the desktop and choose → Screen Resolution.
- Click onto the first (1) (large) monitor and check the following parameters:

- Night light → Off

- Scale and layout → 100%


- Resolution → 7680 x 4320

- Orientation → Landscape

- Multiple displays → Extend these displays

- Make this my main display → Not checked


Display



Colour
Night light
Off
Night light settings
Scale and layout
Change the size of text, apps and other items
100%
Advanced scaling settings
Resolution
7680 × 4320 V
Orientation
Landscape
Multiple displays
Multiple displays
Extend these displays
Make this my main display

- Click onto the second (2) (small) monitor and check the following parameters:
 - Night light → Off
 - Scale and layout → 100%
 - Resolution \rightarrow 1920 x 1080
 - Orientation → Landscape
 - Multiple displays → Extend these displays
 - Make this my main display → Checked

Display



Colour


Night light



Night light settings


Scale and layout

Change the size of text, apps and other items



Multiple displays

Multiple displays



Important information if you create a new user under WIN 10

After creating a new user the following steps are necessary:

- Give full rights for the user to the folder C:\file-converter
- All backgrounds must be totally black
- All screensavers must be off
- All screens and hard drive may not go to stand by
- The exposure monitor has to show the images in the right size.

Disable the taskbar of the exposure monitor

- right click onto the taskbar
- choose → Taskbar settings
- look for → Multiple displays
- look for \rightarrow Show taskbar on all displays \rightarrow Off