Motor Abstraction Reference

Author

April 2022





1	Abstract Motor Class	1
2	Motor Configuration Load	5
Bi	bliography	9
Python Module Index		10
In	dex	11

CHAPTER

ONE

ABSTRACT MOTOR CLASS

class AbstractMotor(motor_id, **kwargs)

Bases: abc.ABC

Abstract Motor Class

Required attributes:

• motor_id Motor ID (hexadecimal or otherwise). This is used both for low level communication and to refer to individual motors in communication with the user.

Recommended attributes:

• motor Motor object containing methods for low-level motor control. It may be provided by the user or by a library. For further reference consider the T-Motor AK80-6 and AK80-9 interfaces provided by mini-cheetah-tmotor-python-can (pip).

```
__getattribute__(name)
```

Override attribute retrieval.

Conduct motor configuration validation at attribute retrieval time, and apply boilerplate to communicate the motor's state after all commands and provide the user with logs.

1. Motor configuration validation

- Ensure motor instance has all required attributes
- Ensure motor instance has a declared rest_state before calling any function other than __init__ or rest_state

2. Function boilerplate

- Push motor state via provided communication protocol after all motor commands
- Log motor disabling

```
__getattr__ (name)
Retrieve unknown attributes from motor controller.
_command (fn_command, *args, **kwargs)
_disable (fn_disable, *args, **kwargs)
```

```
rest_state (x_r)
    Set rest state
abstract __init__ (motor_id, **kwargs)
    Abstract Motor Class
```

Required attributes:

• motor_id Motor ID (hexadecimal or otherwise). This is used both for low level communication and to refer to individual motors in communication with the user.

Recommended attributes:

• motor Motor object containing methods for low-level motor control. It may be provided by the user or by a library. For further reference consider the T-Motor AK80-6 and AK80-9 interfaces provided by mini-cheetah-tmotor-python-can (pip).

```
abstract enable()
    Enable motor
abstract zero()
    Zero at current motor position
abstract rest()
    Rest position command
abstract command(u)
    Motor command
abstract disable()
    Disable motor
 _abstractmethods__ = frozenset({'__init__', 'command', 'disable',
'enable', 'rest', 'zero'})
 _dict__ = mappingproxy({'__module__':
'motor_abstraction.abstract_motor', '__getattribute__': <function
AbstractMotor.__getattribute__>, '__getattr__': <function
AbstractMotor.__getattr__>, '_command': <function
AbstractMotor._command>, '_disable': <function
AbstractMotor._disable>, 'rest_state': <function
AbstractMotor.rest_state>, '__init__': <function
AbstractMotor.__init__>, 'enable': <function AbstractMotor.enable>,
'zero': <function AbstractMotor.zero>, 'rest': <function</pre>
AbstractMotor.rest>, 'command': <function AbstractMotor.command>,
'disable': <function AbstractMotor.disable>, '__dict__': <attribute
  _dict__' of 'AbstractMotor' objects>, '__weakref__': <attribute
'__weakref__' of 'AbstractMotor' objects>, '__doc__': None,
'__abstractmethods__': frozenset({'rest', '__init__', 'enable',
'command', 'disable', 'zero'}), '_abc_impl': <_abc_data object>,
'__annotations__': {}})
```

```
__module__ = 'motor_abstraction.abstract_motor'
     __slots__ = ()
    __weakref__
        list of weak references to the object (if defined)
    _abc_impl = <_abc_data object>
class Protocol(*args, **kwargs)
    Bases: abc.ABC
    Initialize communication protocol for individual device
    ___init___(*args, **kwargs)
        Initialize communication protocol for individual device
    abstract generate_bindings(*args, **kwargs)
        Generate bindings
    abstract push(*args, **kwargs)
    abstract pull(*args, **kwargs)
      _abstractmethods__ = frozenset({'generate_bindings', 'pull',
    'push'})
     _dict__ = mappingproxy({'__module__':
    'motor_abstraction.communicator', '__init__': <function</pre>
    Protocol.__init__>, 'generate_bindings': <function</pre>
    Protocol.generate_bindings>, 'push': <function Protocol.push>,
    'pull': <function Protocol.pull>, '__dict__': <attribute '__dict__'
    of 'Protocol' objects>, '__weakref__': <attribute '__weakref__' of
    'Protocol' objects>, '__doc__': None, '__abstractmethods__':
    frozenset({'push', 'pull', 'generate_bindings'}), '_abc_impl':
    <_abc_data object>, '__annotations__': {}})
    __module__ = 'motor_abstraction.communicator'
    __slots__ = ()
    __weakref__
        list of weak references to the object (if defined)
    _abc_impl = <_abc_data object>
class lcm (topic, freq, generate bindings=False)
    Bases: motor_abstraction.communicator.Protocol
```

Motor Abstraction 0.0.0.a0

Initialize LCM protocol for individual device

```
___init__ (topic, freq, generate_bindings=False)
    Initialize LCM protocol for individual device
generate_bindings(*args, **kwargs)
    Generate bindings
push (content)
pull (content)
__abstractmethods__ = frozenset({})
__annotations__ = {}
__dict__ = mappingproxy({'__module__':
'motor_abstraction.communicator', '__init__': <function</pre>
lcm.__init__>, 'generate_bindings': <function lcm.generate_bindings>,
'push': <function lcm.push>, 'pull': <function lcm.pull>, '__doc__':
None, '__abstractmethods__': frozenset(), '_abc_impl': <_abc_data
object>, '__annotations__': {}})
__module__ = 'motor_abstraction.communicator'
__slots__ = ()
__weakref__
    list of weak references to the object (if defined)
_abc_impl = <_abc_data object>
```

CHAPTER

TWO

MOTOR CONFIGURATION LOAD

```
load (robot)
mjbots (robot)
    mjbots motor configuration
      1. Create transport with all
exception _AddendumException (msg, add=", lst=[], ind='')
    Bases: Exception
    Exception with addendum for user guidance.
    __init__ (msg, add=", lst=[], ind=' ')
     cause
         exception cause
     __context__
         exception context
     __delattr__(name,/)
         Implement delattr(self, name).
     __dict__ = mappingproxy({'__module__':
     'motor_abstraction.utils.exceptions', '__doc__': '\n Exception with
    addendum for user guidance.\n ', '__init__': <function
    _AddendumException.__init__>, '__weakref__': <attribute '__weakref__'
    of '_AddendumException' objects>, '__annotations__': {}})
     __getattribute__(name,/)
         Return getattr(self, name).
     __module__ = 'motor_abstraction.utils.exceptions'
     __new__ (**kwargs)
     __reduce__()
         Helper for pickle.
```

```
__repr__()
         Return repr(self).
     __setattr__(name, value, /)
         Implement setattr(self, name, value).
     __setstate__()
     __str__()
         Return str(self).
     __suppress_context__
     traceback
     __weakref__
         list of weak references to the object (if defined)
     args
     with_traceback()
         Exception.with_traceback(tb) - set self.__traceback__ to tb and return self.
exception ConfigurationError (msg, add=", lst=[], ind='')
     Bases: motor_abstraction.utils.exceptions._AddendumException
     Raised when configuration errors are detected.
     __annotations__ = {}
     __cause__
         exception cause
     __context__
         exception context
     __delattr__(name,/)
         Implement delattr(self, name).
      __dict__ = mappingproxy({'__module__':
     \verb|'motor_abstraction.utils.exceptions', '\__doc\__': \ \verb|'\n Raised when| \\
     configuration errors are detected.\n ', '__annotations__': {}})
     __getattribute__ (name, /)
         Return getattr(self, name).
     __init__ (msg, add=", lst=[], ind=' ')
     __module__ = 'motor_abstraction.utils.exceptions'
     __new__ (**kwargs)
```

```
__reduce__()
        Helper for pickle.
    __repr__()
        Return repr(self).
    __setattr__ (name, value, /)
        Implement setattr(self, name, value).
     __setstate__()
    __str__()
        Return str(self).
    __suppress_context__
    __traceback__
    __weakref__
        list of weak references to the object (if defined)
    args
    with_traceback()
        Exception.with_traceback(tb) - set self.__traceback__ to tb and return self.
exception SafetyException (msg, add=", lst=[], ind=' ')
    Bases: motor_abstraction.utils.exceptions._AddendumException
    Raised when operational safety is compromised.
     \_annotations\_ = {}
    __cause__
        exception cause
    __context__
        exception context
    __delattr__(name,/)
        Implement delattr(self, name).
      _dict__ = mappingproxy({'__module__':
    operational safety is compromised.\n', '__annotations__': {}})
    __getattribute__ (name, /)
        Return getattr(self, name).
    __init__ (msg, add=", lst=[], ind=' ')
    __module__ = 'motor_abstraction.utils.exceptions'
```

```
__new__ ( **kwargs)
     __reduce__()
          Helper for pickle.
     __repr__()
          Return repr(self).
     __setattr__ (name, value, /)
          Implement setattr(self, name, value).
     __setstate__()
     __str__()
          Return str(self).
     __suppress_context__
     __traceback__
     __weakref__
          list of weak references to the object (if defined)
     args
     with_traceback()
          Exception.with_traceback(tb) - set self.__traceback__ to tb and return self.
{\tt fallback\_disable}\,(goal)
shout_error(error)
{\tt shout\_disabled}(motor)
```

BIBLIOGRAPHY

[1] Russ Tedrake. Underactuated Robotics: Algorithms for Walking, Running, Swimming, Flying, and Manipulation (Course Notes for MIT 6.832). 2021. Downloaded on 28.07.2021 from http://underactuated.mit.edu/.



PYTHON MODULE INDEX

```
a
motor_abstraction.abstract_motor,1

C
motor_abstraction.communicator,3
motor_abstraction.config,4
motor_abstraction.config.load,5
motor_abstraction.config.postprocessing,5

m
motor_abstraction,1

U
motor_abstraction.utils,5
motor_abstraction.utils.exceptions,5
motor_abstraction.utils.fallback,8
motor_abstraction.utils.shout,8
```

INDEX

Non-alphabetical	module(_ <i>AddendumException attribute</i>), 5
abstractmethods (AbstractMotor attribute),	module(AbstractMotor attribute), 2
2	module(ConfigurationError attribute), 6
abstractmethods (lcm attribute), 4	module(<i>lcm attribute</i>), 4
abstractmethods (Protocol attribute), 3	module(Protocol attribute), 3
annotations(ConfigurationError attribute), 6	module(SafetyException attribute), 7
annotations(<i>lcm attribute</i>), 4	new() (_AddendumException method), 5
annotations(SafetyException attribute), 7	new() (ConfigurationError method), 6
cause (_AddendumException attribute), 5	new() (SafetyException method), 7
cause(ConfigurationError attribute), 6	reduce() (_AddendumException method), 5
cause(SafetyException attribute), 7	reduce() (ConfigurationError method), 6
context(_AddendumException attribute), 5	reduce() (SafetyException method), 8
context(ConfigurationError attribute), 6	repr() (_AddendumException method), 5
context(SafetyException attribute), 7	repr() (ConfigurationError method), 7
delattr() (_AddendumException method), 5	repr() (SafetyException method), 8
delattr() (ConfigurationError method), 6	setattr() (_AddendumException method), 6
delattr() (SafetyException method), 7	setattr() (ConfigurationError method), 7
dict(_AddendumException attribute), 5	setattr() (SafetyException method), 8
dict(AbstractMotor attribute), 2	setstate() (_AddendumException method),
dict(ConfigurationError attribute), 6	6
dict(lcm attribute), 4	setstate() (ConfigurationError method), 7
dict (Protocol attribute), 3	setstate() (SafetyException method), 8
dict (SafetyException attribute), 7	slots(AbstractMotor attribute), 3
getattr() (AbstractMotor method), 1	slots (<i>lcm attribute</i>), 4
getattribute() (_AddendumException	slots (<i>Protocol attribute</i>), 3
method), 5	str() (_AddendumException method), 6
getattribute() (AbstractMotor method), 1	str() (ConfigurationError method), 7
getattribute() (ConfigurationError	str() (SafetyException method), 8
method), 6	suppress_context (_AddendumException
getattribute() (SafetyException method),	attribute), 6
7	suppress_context (ConfigurationError at-
init() (_AddendumException method), 5	tribute), 7
init() (AbstractMotor method), 2	suppress_context (SafetyException at-
init() (ConfigurationError method), 6	tribute), 8
init() (lcm method), 3	traceback (_AddendumException attribute), 6
init() (Protocol method), 3	traceback(ConfigurationError attribute), 7
init() (SafetyException method), 7	traceback(SafetyException attribute), 8

weakref(_AddendumException attribute), 6	<pre>motor_abstraction.abstract_motor,</pre>
weakref(AbstractMotor attribute), 3	1
weakref(ConfigurationError attribute), 7	motor_abstraction.communicator,3
weakref(lcm attribute), 4	<pre>motor_abstraction.config,4</pre>
weakref(Protocol attribute), 3	${\tt motor_abstraction.config.load,5}$
weakref(SafetyException attribute), 8	<pre>motor_abstraction.config.postpro-</pre>
_abc_impl (AbstractMotor attribute), 3	cessing,5
_abc_impl (<i>lcm attribute</i>), 4	${ t motor_abstraction.utils,5}$
_abc_impl (<i>Protocol attribute</i>), 3	<pre>motor_abstraction.utils.excep-</pre>
_AddendumException,5	tions, 5
_command() (AbstractMotor method), 1	motor_abstraction.utils.fallback,
_disable() (AbstractMotor method), 1	8
Α	${ t motor_abstraction.utils.shout, 8}$
	motor_abstraction
AbstractMotor (class in motor_abstraction.ab-	module, 1
stract_motor), 1	motor_abstraction.abstract_motor
args (_AddendumException attribute), 6	module, 1
args (ConfigurationError attribute), 7	motor_abstraction.communicator
args (SafetyException attribute), 8	module, 3
C	motor_abstraction.config
	module, 4
command() (AbstractMotor method), 2	motor_abstraction.config.load
ConfigurationError, 6	module,5
D	motor_abstraction.config.postpro-
disable()(AbstractMotor method), 2	cessing
CISADIE () (Abstractivotor method), 2	module,5
E	motor_abstraction.utils
enable() (AbstractMotor method), 2	module, 5
Charle () (Residential inclines), 2	motor_abstraction.utils.exceptions
F	module, 5
<pre>fallback_disable() (in module motor_abstrac-</pre>	motor_abstraction.utils.fallback
tion.utils.fallback), 8	module, 8
	motor_abstraction.utils.shout
G	module, 8
<pre>generate_bindings() (lcm method), 4</pre>	P
<pre>generate_bindings() (Protocol method), 3</pre>	Protocol (class in motor_abstraction.communica-
	tor), 3
L	pull() (lcm method), 4
lcm (class in motor_abstraction.communicator), 3	pull() (Protocol method), 3
<pre>load() (in module motor_abstraction.config.load), 5</pre>	push() (lcm method), 4
N.A.	push () (Protocol method), 3
M	
$\verb mjbots \textit{ (in module motor_abstraction.config.post-} $	R
processing), 5	rest() (AbstractMotor method), 2
module	rest_state() (AbstractMotor method), 1
motor_abstraction, 1	, (



S

```
SafetyException, 7
shout_disabled() (in module motor_abstraction.utils.shout), 8
shout_error() (in module motor_abstraction.utils.shout), 8

W
with_traceback() (_AddendumException method), 6
with_traceback() (ConfigurationError method), 7
with_traceback() (SafetyException method), 8

Z
zero() (AbstractMotor method), 2
```