# 8086 Interrupts

#### Course Teacher:

#### Md. Obaidur Rahman, Ph.D.

Professor

Department of Computer Science and Engineering (CSE) Dhaka University of Engineering & Technology (DUET), Gazipur.

**Course ID:** CSE - 4503

**Course Title:** Microprocessors and Assembly Language Department of Computer Science and Engineering (CSE), Islamic University of Technology (IUT), Gazipur.

#### Lecture References:

- Book:
  - Microprocessors and Interfacing: Programming and Hardware, Chapter # 08, Author: Douglas V. Hall
  - Microprocessor and Microcomputer Based System Design,
    Author: Mohamed Rafiquzzaman
- Lecture Materials:
  - M.A. Sattar, BUET, Dhaka, Bangladesh.

#### Interrupt and Its Classifications

- Interrupt is a process where a normal program execution to be interrupted by some external signal or by a special instruction in the program.
- Microprocessor pay attention to the interrupt stopping the the current execution.
- Classification of Interrupts
  - Interrupts can be classified into two types:
    - Maskable Interrupts (Can be delayed or Rejected)
      - □ User-defined interrupts
    - Non-Maskable Interrupts (Can not be delayed or Rejected)
      - □ System Interrupts


### Interrupt & Its Consequences over MP

- An interrupt is considered to be an emergency signal that may be serviced.
  - The Microprocessor may respond to it as soon as possible.


#### What happens when MP is interrupted?

- When the Microprocessor receives an interrupt signal, it suspends the currently executing program and jumps to an Interrupt Service Routine (ISR) to respond to the incoming interrupt.
- Each interrupt will have its own ISR.
- After finishing the second program/interrupt, automatically return to the first program and start execution from where it was left


To understand this we will have to review how μP/μC communicate with the outside world.



▶ First Type: DEDICATED communication between MP and I/O devices.




▶ **Second Type:** POLLED I/O or PROGRAMMED I/O communication between MP and I/O devices.



#### **Disadvantages of Second Type Communication:**

- not fast enough
- waste too much microprocessor time

▶ Third Type: INTERRUPTED I/O communication between MP and I/O devices.



Interrupts are particularly useful when I/O devices are slow

### Polling and Interrupt

Both are methods to notify processor that I/O device needs attention

#### Polling

- simple, but slow
- processor check status of I/O device regularly to see if it needs attention
- similar to checking a telephone without bells!

#### Interrupt

- fast, but more complicated
- processor is notified by I/O device (interrupted) when device needs attention
- similar to a telephone with bells

### Interrupt Concept

- Intel processors include two hardware pins (INTR and NMI) that request interrupts.
- And one hardware pin (INTA) to acknowledge the interrupt requested through INTR.
- The processor also has software interrupts INT, INTO and INT 3.
- ▶ Flag bits IF (interrupt flag) and TF (trap flag), are also used with the interrupt structure.


# Classifications of 8086 Interrupts

- An 8086 interrupt can come from any of the **three** sources:
  - An external signal applied to NMI or INTR pin.
    - known as hardware interruption
    - It is a user-defined interrupt
    - Example: Connecting I/O Device
  - Execution of interrupt instruction *INT*.
    - referred as software interruption
    - It is also a user-defined interrupt
    - Example: INT 21h, INTO, INT 3
  - Some error condition produced by execution of an instruction, e.g., trying to divide some number by zero.
    - lt is known as **pre-defined interrupt**

### Function of 8086 during Interrupts

- At the end of each instruction cycle, 8086 checks to see if any interrupts have been requested.
- If yes, then 8086 responds to the interrupt by stepping through the following series of major actions:
  - It decremented SP by 2 and pushes *Flag register* on the stack.
  - It disables 8086 **INTR** input by clearing **IF** (Interrupt) flag in Flag register, IF=1.
  - It resets the **TF (Trap) flag** in Flag register
  - It decremented SP again by 2 and pushes current **CS** (**Code Segment**) contents on the stack.
  - It decremented SP again by 2 and pushes current IP (Instruction Pointer) contents on the stack.
  - It does an indirect far **Jump** to the start of the procedure (**ISR**) written to respond to the interrupt.

# Function of 8086 during Interrupts



#### Interrupt Vectors and Vector Table

- An interrupt vector is a pointer to where the ISR is stored in memory.
- All interrupts (vectored or otherwise) are mapped onto a memory area called the **Interrupt Vector Table (IVT)**.
  - The IVT is usually located in the first 1 Kbyte of memory segment (from 00000 H 003FF H).
  - The purpose of the IVT is to hold the vectors that redirect the microprocessor to the right place when an interrupt arrives.
- The starting address of an ISR is often called
  - the interrupt vector or the interrupt pointer.
- So the Table is referred to as
  - interrupt-vector table or interrupt-pointer table.

- Note that
  - The **IP** value is put in as the **low word** of the vector
  - ▶ **CS** as **high word** of the vector
- ▶ 4 bytes are required to store the CS and IP values for each interrupt service procedure, the *interrupt-vector* table can hold starting addresses for up to 256 interrupt procedures.
- ▶ Each **Double Word** interrupt vector is identified by a number from 0 to 255
- ▶ INTEL calls this number the TYPE of the interrupt

AVAILABLE		3FFH	TYPE 255
FOR USER	$\prec$		•••
(224)		080H	TYPE 32
			TYPE 31
RESERVED (27)	$\prec$		
		014H	TYPE 5
			TYPE 4
		010H	INTO OVERFLOW
			TYPE 3
Predefined/		00CH	INT
Dedicated/Internal			TYPE 2
Interrupts Pointers		H800	NON-MASKABLE
(5)			TYPE 1
		004H	SINGLE STEP
CS Base Address			TYPE 0
IP Offset		000H	DIVIDE ERROR

- The first five interrupt vectors are identical in all Intel processors
- Intel reserves the first 32 interrupt vectors
- ▶ The last 224 interrupt vectors are user-available
- Each is four bytes long in real mode and contains the starting address of the interrupt service procedure.
  - ▶ The first two bytes contain the offset address
  - ▶ The last two contain the segment address

#### Type 0

The **divide error** whenever the result from a division overflows or an attempt is made to divide by zero.

#### Type I

- Single-step or trap occurs after execution of each instruction if the trap (TF) flag bit is set.
- Upon accepting this interrupt, TF bit is cleared so the interrupt service procedure executes at full speed.

#### Type 2

- The **non-maskable interrupt** occurs when a logic 1 is placed on the NMI input pin to the microprocessor.
- Non-maskable—it cannot be disabled

#### Type 3

- A special one-byte instruction (INT 3) that uses this vector to access its interrupt-service procedure.
- Often used to store a breakpoint in a program for debugging

#### Type 4

- Overflow is a special vector used with the INTO instruction. The INTO instruction interrupts the program if an overflow condition exists.
- As reflected by the overflow flag (OF)

- ▶ How does 8086 get to Interrupt Service Routine (ISR)?
  - Simple. It loads its CS and IP registers with the address of ISR.
  - So, the next instruction to be executed is the first instruction of ISR.
- How does 8086 get the address of Interrupt Service Routine (ISR)?
  - It goes to specified memory location to fetch four consecutive bytes
    - higher two bytes to be used as CS (Code Segment)
    - lower two bytes to be used as IP (Instruction Pointer)

- How does 8086 get the address of that specified memory location?
  - In an 8086 system, the first IKbytes of memory, from 00000 to 003FF, is set aside as a **Table** for storing the starting addresses of **Interrupt Service Routines** (ISR).
  - Since 4 bytes are required to store **CS and IP** values for each ISR, the **Table** can hold the starting addresses for up to 256 ISRs.

- How does 8086 get the address of a particular ISR?
  - In an 8086 system, each "interrupter" has an id #
  - ▶ 8086 treat this id # as interruption type #
  - After receiving INTR signal, 8086 sends an INTA signal
  - After receiving INTA signal, interrupter releases it's id #, i.e., type # of the interruption.
  - ▶ 8086 multiplies this id# or type# by 4 to produced the desired address in the **vector table**
  - ▶ 8086 reads 4 bytes of memory starting from this address to get the starting address of ISR
    - ▶ lower 2 byte is loaded in to IP
    - higher 2 bytes to CS

- What happens if two or more interrupts occur at the same time?
  - Higher priority interrupts will be served first

Interrupt Type	Priority
DIVIDE ERROR, INT n, INTO	HIGHEST
NMI	
INTR	
SINGLE STEP	LOWEST

#### Thank You!!

