

## 4.24. setSpeakerA

For setting Speaker A status

### Request Parameters

name	type	required	description
enable	boolean	yes	Specifies Speaker A status

URI	<BaseURL>/v1/system/setSpeakerA?enable=<enable>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/system/setSpeakerA?enable=true

### Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " <a href="#">Response Code List</a> " for details

Example Response	{ "response_code":0 }
------------------	-----------------------------

## 4.25. setSpeakerB

For setting Speaker B status

### Request Parameters

name	type	required	description
enable	boolean	yes	Specifies Speaker B status

URI	<BaseURL>/v1/system/setSpeakerB?enable=<enable>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/system/setSpeakerB?enable=true

### Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " <a href="#">Response Code List</a> " for details

Example Response	{ "response_code":0 }
------------------	-----------------------------