

URI	<BaseURL>/v1/<zone>/set3dSurround?enable=<enable>		
Method	GET		
Example Request	http://{host}/YamahaExtendedControl/v1/main/set3dSurround?enable=true		

**Response Parameters**

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " <a href="#">Response Code List</a> " for details

Example Response	{ "response_code":0 }
------------------	-----------------------------

**5.10. setDirect**

For setting Direct status

**Request Parameters**

name	type	required	description
zone	string	yes	Specifies target zone. Available for zones with this function Values: "main" / "zone2" / "zone3" / "zone4"
enable	boolean	yes	Specifies Direct status

URI	<BaseURL>/v1/<zone>/setDirect?enable=<enable>		
Method	GET		
Example Request	http://{host}/YamahaExtendedControl/v1/main/setDirect?enable=true		

**Response Parameters**

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " <a href="#">Response Code List</a> " for details

Example Response	{ "response_code":0 }
------------------	-----------------------------

**5.11. setPureDirect**

For setting Pure Direct status

**Request Parameters**

name	type	required	description
zone	string	yes	Specifies target zone. Available for zones with this function Values: "main" / "zone2" / "zone3" / "zone4"
enable	boolean	yes	Specifies Pure Direct status