

**Response Parameters**

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " <a href="#">Response Code List</a> " for details

Example Response	{ "response_code":0 }
------------------	-----------------------------

**5.6. setMute**

For setting mute status in each Zone

**Request Parameters**

name	type	required	description
zone	string	yes	Specifies target zone. Available for zones with this function Values: "main" / "zone2" / "zone3" / "zone4"
enable	boolean	yes	Specifying mute status

URI	<BaseURL>/v1/<zone>/setMute?enable=<enable>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/main/setMute?enable=false

**Response Parameters**

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " <a href="#">Response Code List</a> " for details

Example Response	{ "response_code":0 }
------------------	-----------------------------

**5.7. setInput**

For selecting each Zone input

**Request Parameters**

name	type	required	description
zone	string	yes	Specifies target zone Values: "main" / "zone2" / "zone3" / "zone4"
input	string	yes	Specifies Input ID Values: Input IDs gotten via /system/getFeatures
mode	string	no	Specifies select mode. If no parameter is specified, actions of input change depend on a Device's specification Value: "autoplay_disabled" (Restricts Auto Play of Net/USB related Inputs). Available on and after API Version 1.12