

URI	<BaseURL>/v1/<zone>/setPureDirect?enable=<enable>		
Method	GET		
Example Request	http://{host}/YamahaExtendedControl/v1/main/setPureDirect?enable=true		

**Response Parameters**

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " <a href="#">Response Code List</a> " for details

Example Response	{ "response_code":0 }
------------------	-----------------------------

**5.12. setEnhancer**

For setting Enhancer status

**Request Parameters**

name	type	required	description
zone	string	yes	Specifies target zone. Available for zones with this function Values: "main" / "zone2" / "zone3" / "zone4"
enable	boolean	yes	Specifies Enhancer status

URI	<BaseURL>/v1/<zone>/setEnhancer?enable=<enable>		
Method	GET		
Example Request	http://{host}/YamahaExtendedControl/v1/main/setEnhancer?enable=true		

**Response Parameters**

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " <a href="#">Response Code List</a> " for details

Example Response	{ "response_code":0 }
------------------	-----------------------------

**5.13. setToneControl**

For setting Tone Control in each Zone. Values of specifying range and steps are different.

**Request Parameters**

name	type	required	description
zone	string	yes	Specifies target zone. Available for zones with this function Values: "main" / "zone2" / "zone3" / "zone4"
mode	string	no	Specifies Mode setting. If no parameter is specified, current Mode setting is not changed.