

8.5.7.6 SUBSCRIBE_SAMPLE

Address offset: 0x088

Subscribe configuration for task SAMPLE

8.5.7.7 EVENTS_READY

Address offset: 0x100

COMP is ready and output is valid

8.5.7.8 EVENTS DOWN

Address offset: 0x104

Downward crossing

Bit number	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ID	A																															
Reset 0x00000000	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
ID	R/W	Field	Value ID	Value	Description																											
A	RW	EVENTS_DOWN			Downward crossing																											
		NotGenerated	0		Event not generated																											
		Generated	1		Event generated																											

8.5.7.9 EVENTS UP

Address offset: 0x108