

Counts the number of clock cycles executed by the processor core on which the hart is running. This register is a read-only copy of MCYCLE

Bit number	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
ID	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A
Reset 0x00000000	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
ID	R/W	Field	Value ID	Value																									Description					
A	R	VAL																											User Cycle Counter value					

8.26.3.26 UINSTRET

Address offset: 0xC02

User Instruction Counter

Counts the number of instructions the hart has retired. This register is a read-only copy of MINSTRET

In this context retired means a successfully executed instruction

Bit number	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
ID	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A
Reset 0x00000000	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
ID	R/W	Field	Value ID	Value																									Description					
A	R	VAL																												User Instruction Counter value				

8.26.3.27 UCYCLEH

Address offset: 0xC80

User Cycle Counter (Upper part)

Counts the number of clock cycles executed by the processor core on which the hart is running. This register is a read-only copy of MCYCLEH

Bit number	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
ID	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A
Reset 0x00000000	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
ID	R/W	Field	Value ID	Value																									Description					
A	R	VAL																												User Cycle Counter value				

8.26.3.28 UINSTRETH

Address offset: 0xC82

User Instruction Counter (Upper part)

Counts the number of instructions the hart has retired. This register is a read-only copy of MINSTRETH

In this context retired means a successfully executed instruction

Bit number	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
ID	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A
Reset 0x00000000	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
ID	R/W	Field	Value ID	Value																									Description					
A	R	VAL																												User Instruction Counter (Upper part) value				