



TXL 221: Yarn Manufacture I

3 Credits

Course Coordinator: Prof. Sohel Rana
B.Tech. M.Tech. Ph.D. (IIT Delhi) FHEA CMgr (UK)



Marks Distribution

Minor: **40**

Quiz : **20**

Major: **40**

Attendance Policy



- **Minimum Attendance** : 75%
- **Attendance less than 75%** : One grade down
- **Attendance more than 95%** : **5 bonus marks will be added to the final marks.**
- **Late attendance** : Will be marked as absent after attendance has been already registered.



Course Outline (Lecture)

Opening/Blowroom:

- ✓ Principle of fibre opening in blow room
- ✓ Principle of fibre cleaning in blow room
- ✓ Opening and cleaning machines
- ✓ Principle of fibre blending
- ✓ Recent developments



Course Outline (Lecture)

Carding:

- Objective and principle of carding
- Machine elements and operations
- Sliver formation and fibre configurations in sliver
- Automation and recent developments



Course Outline (Lecture)

Drafting/Drawframe:

- ✓ Objectives, principles and methods of roller drafting.
- ✓ Purpose and principle of condensation of fibres.
- ✓ Causes of mass variation of sliver and control.
- ✓ Automation and recent developments in draw frames



Reference Books

- ✓ **A Practical Guide to Opening and Carding, Short-staple Spinning Series (Volume 2), By W. Klein**
- ✓ **A Practical Guide to Combing and Drawing, Short-staple Spinning Series (Volume 3), By W. Klein**
- ✓ **Fundamentals of Spun Yarn Technology By Carl A Lawrence**
- ✓ **Handbook of Yarn Production-Technology, Science and Economics By Peter R. Lord**
- ✓ **Spun Yarn Technology By Eric Oxtoby**
- ✓ **NPTEL lecture series, IIT Delhi**

Introduction

What is a yarn?

“A yarn may be defined as a product of substantial length and relatively small cross-section of fibres and/or filament(s) with or without twist, used for interlacing in processes such as knitting, weaving, or sewing”

Different Types of Yarn


- Continuous filament yarns




- Staple spun yarns



- Composite yarns



- Folded/plied/doubled yarns



Production of Staple Yarn: Cotton and Blends



Seed fibre, cellulosic, hydrophilic

Removal of cotton
fibre from seeds

Ginning process



Cotton Bale

How to make cotton yarn from bale?

- ✓ Opening
- ✓ Cleaning why?

Impurities in Cotton Fibre

- **Vegetable matter (50-80%)**
Seed fragments, stem fragments, leaf fragments, etc.
- **Mineral matter (10-20%)**
Dust, sand, soil, etc.
- **Fibre fragments**
- **Others**
Metal particles, cloth fragments, packaging materials, etc.




Trash size > 500 micron
Dust < 50 micron
Micro dust < 15 micron


Problems?

Yarn fault, damage to machines, health hazard to the workers


How staple yarns are produced?



Spinning Process Flowchart



Blowroom




Blowroom




Introduction to Blowroom

Fibres come to spinning mill in bale form.



Blowroom Operating Zones



Why Blowroom has different zones and machines?

Opening of Bale

How to open bale?

✓ Removing individual fibres from bale ?

✓ Dividing and subdividing bales?

Question: In a spinning mill, cotton fiber is supplied in compacted bales of about 226.8 kg each. The bale dimensions is typically $1.4 \times 0.53 \times 0.64$ m, and the bale density is 478 kg/m^3 . If the individual fibers are 30 mm in length and 1.7 dtex fineness and the production rate of the plant is 500 kg/h, then how many fibres need to be separated per second from the bale?

Ans:

No. of fibres in each bale = 45 billion (approx.)

No. fibres to be separated per hour = 98 billion, 27 million fibers per second



Opening of Bale

How to open bale?

Removing large clumps of fibres from a bale



Progressively dividing the large clumps into many smaller pieces.




Opening of Tufts

Different Possibilities


- ✓ A large tuft is divided into several smaller tufts



- ✓ Volume of tuft increases without disintegration




- ✓ Shape of the tuft changes



How to measure fibre openness?


- By measuring specific volume
- By measuring tuft weight



M1, M2,...blowroom machines


Opening of tufts: different principles

- ✓ Plucking
- ✓ Tearing between oppositely moving spikes
- ✓ Teasing in nipped state by needles or saw tooth
- ✓ Using impact force at nipped state or free flight





Opening of tufts: different principles

Plucking out




- Two spring systems facing each other.
- Material is grasped like finger
- Very gentle action
- Produces large tufts of uneven size

Forks or Plucker



Rotating discs

- ✓ Two rotating disc picks up fibre tufts from bale surface
- ✓ Tuft size: 30-80 mg




How blending is possible?
- Bale layout

Opening of tufts: different principles

Teasing out by Tooth disc



- ✓ Tooth discs have triangular plucking elements
- ✓ The discs are secured to a shaft
- ✓ Asymmetrically formed
- ✓ Operate only in one direction
- ✓ If the disc needs to operate in both direction ?



Opening of tufts: different principles

Tearing

- ✓ Tufts are acted by oppositely moving spikes and torn apart into pieces
- ✓ Thorough mixing How?
- ✓ Formation of neps
- ✓ The intensity of opening action depends on
 - Distance between the spiked devices
 - Speed relationships
 - Total working surface
 - No. of points





Mild action

Opening of tufts: different principles

Impact by Bladed Beaters

- ✓ Consists of 2-3 beater bars
- ✓ In one rotation, the feed sheet receives 2-3 blows across the full width





Opening and cleaning effect?
Low

Beating lines on tuft sheet

Opening of tufts: different principles

Impact by Strikers

- ✓ Flat, oval or round bars are riveted or screwed to a cylinder
- ✓ Various spacing of the strikers elements may be used. **Why?**
- ✓ Speed: 600 – 1000 rpm



Opening intensity depends on


- ✓ Distance between feeding and opening elements
- ✓ Speed ratio
- ✓ Number of striking elements

Why are the striking elements staggered?

Opening of tufts: different principles

Teasing out by Saw teeth

- ✓ A cylinder surface filled with saw tooth
- ✓ Fine setting between the elements
- ✓ Suitable for smaller flocks
- ✓ Generate new surfaces
- ✓ Spacing between teeth : **6 - 8.5 mm**
Tooth height: **4.5 - 5.5 mm**




Suitable for finest opening and best cleaning.

Opening of tufts: different principles

Teasing out by Needles

- ✓ Pinned bars are secured to the cast iron arms
- ✓ The inclined pins penetrate and combs through the fibres
- ✓ Generates new tuft surface and liberates trash particles
- ✓ Operates at 800-900 rpm



Kirschner Beater

Cleaning efficiency is very high

Opening Intensity

✓ Fibre Mass/Striker

$$\text{Intensity of opening } (I) = \frac{P \times 10^6}{60 \times n_b \times N}$$

✓ Blows/Kg

$$N_k = \frac{\text{Blows per hour}}{\text{Production per hour (Kg)}} = \frac{1}{P} (60 \times n_b \times N)$$

P = production rate (Kg/h), n_b = beater speed (rpm), N= number of strikers


✓ Beats/inch

$$\text{Intensity} = \frac{\text{Speed of beater} \times \text{number of blades on beater}}{\text{Delivery of feed roller}}$$

$$= \frac{\text{Speed of beater} \times \text{number of blades on beater}}{\text{Circumference of feed roller} \times \text{speed of feed roller}}$$


Typical beats per inch: 30-50

Cleaning Principle




Mechanism of Trash Liberation

- ✓ Loss of kinetic energy (scrubbing)
- ✓ Impulse (Beating)
- ✓ Centrifugal force
- ✓ Pneumatic force



- ✓ Fibre tufts are guided over stationary grid bars
- ✓ The kinetic energy of trash particles after impact becomes almost zero and liberated from fibre tufts




What is separation mechanism?

The liberated particles fall down due to **gravity** and separated

Mechanism of Trash Liberation


Grid Bars



- ✓ Slotted sheets (a): Poor cleaning
- ✓ Perforated sheets (b): Poor cleaning
- ✓ Triangular section bars (c): Mostly used
- ✓ Angle bars (d): Moderate cleaning
- ✓ Blades (e): Strong and effective

Cleaning action depends on:

- ✓ Distance of grid bars from beater
- ✓ Gaps between the bars
- ✓ Setting angle related to the beater



Mechanism of Trash Liberation


Impulse (Beating)

- Flocks are fed by feed rollers and are subjected to strong blows by the blades of a beater.
- Velocity of tufts changes instantly (in microseconds)

Impulse: change in momentum

$$= m(v_i - v_f)$$

m is the mass of tuft, v_i is the initial velocity, v_f is the final velocity, i.e., feed roller surface speed, final velocity (surface speed of bater at the top of strikers)




How the trash will be separated?

Mechanism of Trash Liberation



Centrifugal force

- ✓ Trash particles resting on the saw tooth, strikers or blades are subjected to a high centrifugal force.
- ✓ Trash particles have low attachment with the striking elements.



What is the trash separating mechanism?


$$CF = mr\omega^2$$



Mechanism of Trash Separation


Pneumatic force

- ✓ Trash with liberated trash particles are directed towards a moving perforated screen.
- ✓ Trash particles are sucked through the perforations



Separation by buoyancy difference

- ✓ Mixture of tufts and trash particles are directed downwards
- ✓ A stream of air flow cross the path horizontally.




Dust and Metal Removal

Dust Removal


Difficulties:

- ✓ Dust is lighter than fibres
- ✓ Strong adherence with fibres



Liberation mechanism:

- High metal to fibre friction
- Fibre to fibre friction



Metal Extractor


Separation Mechanism:

- ✓ Through suction

Cleaning Efficiency

$$\text{Cleaning efficiency (CE \%)} = \frac{\text{Trash in feed (\%)} - \text{trash in delivery (\%)}}{\text{Trash in feed (\%)}} \times 100$$

- ❖ The CE % of individual cleaner varies according to their type and position
- ❖ The beater or cleaner in the beginning of the blowroom line shows
 - higher cleaning efficiency
- ❖ More cleaning means more waste and loss of good fibres (lint)
- ❖ Lint in the waste should be in the range of 20-30%.
- ❖ After opening and cleaning nep level in blowroom increases significantly
 - due to blunt opening elements and grid bars
 - due to repeated action of beaters or strikers





Opening and Cleaning Principle

What we have learnt so far.....

Importance of Yarn manufacturing in India

- India is the world's second largest cotton producing country
- India has the world's second largest spinning capacity after China
- Ample opportunities in Technical Textiles (NTTM), entrepreneurship, machine manufacturing, etc.


Different Steps in Yarn Manufacturing

Objectives and Principles of Opening and Cleaning

- What is opening?
- Why and how opening is done?
- Why and how cleaning is done?
- Why does a blowroom line need a specific opener and cleaner at a specific place?
- How opening and cleaning intensity are measured?
- What are the parameters which affect opening and cleaning intensity?


New Opening and Cleaning Principles.....

Blowroom Machines





Blowroom Machines





Blowroom Machines

Automatic Bale Opener: Unifloc (Rieter)




- ✓ Rotating tooth discs pluck out fibre flocks (**micro tufts**)
- ✓ **Bale height is automatically detected**
- ✓ Depth of penetration: 2-4 mm
- ✓ Can turn by 180° to process bales on the other side
- ✓ Production: up to 2000 kg/hr



Bale lay down

Blowroom Machines

Coarse Cleaner



Step Cleaner

- ✓ Consists of series of drums with four rows of striking elements
- ✓ Grid bars cover 25% of individual drum chamber
- ✓ Inclination angle 45 to 60°
- ✓ Beater speed: 500 to 600 rpm




Blowroom Machines

Coarse Cleaner

- ✓ The drum surface is covered with 6-8 rows of striking elements
- ✓ The fibre tufts enters at right angle to the beater axis and receives strikes
- ✓ The guide plates ensure than the fibre tufts follow a spiral path. Why?


RIETER



Monocylinder Cleaner

Blowroom Machines


Coarse Cleaner




UNIclean B12

Blowroom Machines

Fine Cleaner




RN Cleaner (Trützschler)




Cleaner CL-C3 (Trützschler)

Blowroom Machines

Intensive Cleaner



ERM Cleaner (Rieter)






Uniflex (Rieter)

Blowroom Machines

Different types of clamping device




Feed Roller



- ✓ Higher clamping distance
- ✓ Not powerful grip
- ✓ Uneven clamping

Feed Plate

- ✓ Small clamping distance
- ✓ More powerful grip
- ✓ Uneven clamping



Pedal rollers

- ✓ 16 pedal rollers
- ✓ Small clamping distance
- ✓ Even clamping

Piano Feed

Blowroom Machines




Mixer/Blender


Purpose of blending/mixing

- ✓ To average out the variation in fibre characteristics
- ✓ To engineer a textile yarn with specific properties
- ✓ To produce a certain shade by mixing fibres of different colours
- ✓ To reduce the cost

Form	Stage	Machine
Bale	Blow room	Automatic bale opening machine
Flock/ tuft	Within blow room	1. Hand stack blending 2. Automatic blending equipment 3. Multi mixers
Lap	Within blow room	Scutcher
Sliver	Drawing , pre-combing stage, combing	Draw frame, sliver lap machine , comber draw box
Web	Pre combing stage, blending drawing	Ribbon lap machine , blending draw frame
Roving	Spinning	Ring spinning machine



Fibre blending using drawframe




Fibre blending using blowroom

Blowroom Machines



Mixer

Mixing through bale lay down




Blowroom Machines




Mixer

Automatic bale opener does not give homogeneous mixing. Why?



Blowroom Machines

Multimixer




- ✓ Consists of 6-10 vertical compartments
- ✓ Cotton tufts are filled up to a certain filling height

Blowroom Machines

Multimixer

Discontinuous Operation




$$BDT = 93 - 3 = 90 \text{ min}$$

The largest difference in the filling time of tufts in different boxes is known as **Blending delay time (BDT)**

BDT is constant in case of discontinuous operation


Continuous Operation



The compartments are filled up in a staggered configuration from 1st to last compartment


Blowroom Machines

Multimixer




Blending delay time (BDT): **45 min**

4th cycle:
Blending delay time (BDT): **72 min**



Blending delay time (BDT): **57 min**

5th Cycle:
Blending delay time (BDT): **75 min**



Blending delay time (BDT): **66 min**

6th cycle:
Blending delay time (BDT): **75 min**


How BDT changes with feed cycle and number of compartments?

Blowroom Machines

Unimix (Rieter)




RIETER



90° bend in the material flow produces a shift in the timing resulting in long term blending

Blowroom Machines

Blender





Metered amount of tufts are mixed together to maintain the blend ratio

Blowroom Machines

Blender


- 1, 2, 3 – Feed
- 4 – Dust extraction
- 5 – Sensor
- 6 – Evener roller
- 7 – Spike lattice
- 8 – Doffer roller
- 9 – Closing flaps
- 10 – Weigh pan
- 11 – Trap doors
- 12 – Drop area on conveyor



- ✓ A metering system is used to drop a measured quantity of material to the conveyor belt
- ✓ Materials from 3-4 blenders are dumped together in sandwich form to form the blend

Blowroom Machines

Blender



Blowroom Machines


Blender



UNIblend A 81


Parameters influencing waste level

- ✓ The amount of trash (%) in feed
- ✓ Speed of the opening device
- ✓ Setting between feed roller and line of action of beater
- ✓ Grid bar inclination and opening




Parameters influencing waste level

Effect of trash%



Waste % increases linearly with the trash%


Effect of feed pedal distance




Waste % decreases with the increase in feed pedal distance

Parameters influencing waste level

Effect of grid bar opening




Effect of grid bar angle




Parameters influencing waste level

Effect of trash% on cleaning



Why non-linear after 4% trash?

Effect of fibre type on cleaning



Cleaning resistance of cotton




Parameters influencing waste level


Problem: In a blowroom line, a fine cleaner gives cleaning efficiency of 24% for trash content in the feed of 4.3%. The amount of waste collected under the cleaner is 2.8%. Calculate the trash and lint% in the waste.

Ans: Trash collected in waste: 40%
Lint collected in waster: 60%

Cleaning of different fibre types




Cleaning of different fibre types




Cleaning of different fibre types

VARIOline cleaning concept – **high trash content**




Lap Formation




No Scutcher in modern blowroom line:
Flock Feed system

- $Production(m) = \text{delivery speed}(m/\text{min}) \times \text{duration}(\text{min})$
- $Production(Kg) = \text{Delivery speed}(m/\text{min}) \times \text{duration}(\text{min}) \times \frac{1}{1000} \times \text{lap weight } (g/m)$


Carding Process



Carding Machine Zones



Carding Machine Zones





RIETER

C 70 High-performance card

The card with the maximum active carding area





Purpose of Carding Process

Individualization of fibre tufts


Cleaning of fibres

Removal of fibre clusters/neps

Mixing of fibres

Production of assembly of random array of fibres


Carding Action



Conditions for carding action:

- ✓ Wire points of interacting surfaces should be inclined with inclination direction opposite to each other: **point against point configuration.**
- ✓ **The surfaces can move in the same or opposite directions**
- ✓ **If they move in same direction, the material carrying surface should move at a faster speed**

Carding Action



R: Tension in the fibre
 μ : Frictional co-efficient

$$P_1 = R \sin \alpha_1$$

$$P_2 = R \cos \alpha_1$$

For carding action,

Fibre should move towards the base of the wire point by overcoming fibre-metal frictional force

So, $P_2 > \mu P_1$

$$RCos\alpha_1 > \mu RSin\alpha_1$$

Similarly,


$$Cota_2 > \mu \dots \dots \dots (2)$$

Carding Action

Values of α		
Fibre	Values of μ between steel & fibre	Value of α_1
Cotton	0.27	$\leq 75^\circ$
Wool	0.23	$\leq 77^\circ$
Polyester	0.40	≤ 68

Wire point inclination angle depends on the frictional co-efficient between fibre and wire point.


Stripping Action



Conditions for stripping action:

- ✓ Wire points of interacting surfaces should be inclined in the same direction: **point against back configuration.**
- ✓ The surfaces can move in the same or opposite directions
- ✓ If they move in same direction, the material receiving the material surface should move at a faster speed

Stripping Action



R: Tension in the fibre

μ : Frictional co-efficient

$$S_1 = R \sin \beta$$

$$S_2 = RCoc\beta$$

For stripping action,


Fibre should move away from the wire point by overcoming fibre-metal frictional force

So,

$$S_2 > \mu S_1$$

Main Parts of Carding Machine

Licker in/Taker in



Diameter: 10 inch
Speed: 800-1600 rpm


Function of Licker in

- ✓ Tear apart the lap/flocks into tufts
- ✓ Remove trash particles
- ✓ Transfer the fibre to cylinder

What is the action between like in and cylinder wire points?

Main Parts of Carding Machine

Cylinder zone



Diameter: $50 \frac{3}{4}$ inch
Speed: 200 to 600 rpm

Carding zone: 158 cm
Rieter C81 card: 3.16 m

Function of Cylinder


- ✓ Carding action (between wire points of cylinder and flats)
- ✓ Removal of trash particles: which mechanism?
- ✓ Removal of short fibres
- ✓ Removal/opening of neps
- ✓ Fibre blending

How fibre blending occurs on cylinder ?

Main Parts of Carding Machine


Flats

- ✓ Flats are cast iron bars which have T-shaped cross-section
- ✓ Lower surface is covered with wire points
- ✓ 80-110 flats are linked together to form a chain
- ✓ Flat rests on metallic strips on both sides known as flexible bends




Function of Flats

- ✓ Carding action (between wire points of cylinder and flats)
- ✓ Removal of trash particles
- ✓ Removal of short fibres
- ✓ Removal/opening of neps




Main Parts of Carding Machine

Flats



Why a flat has a T-shaped cross-section?

- ✓ A flat can be considered as a beam supported at its both end
- ✓ The gap between a flat and cylinder wire points is constant across the width of the cylinder
- ✓ The gap between a flat and cylinder wire points gradually decrease in the direction of cylinder movement **Why?**



Heel and toe arrangement


Main Parts of Carding Machine

Movement of Flats:


Continuous operation:

- ✓ No need to stop for cleaning
- ✓ No need to stop for wire points grinding


Which Direction?



Clean flats are introduced from doffer side



Large trash particles are removed immediately




Main Parts of Carding Machine

Flats

How long opening continues in the carding zone?


- ✓ Effective opening of tufts occurs until 15th flat location
- ✓ Carding force represents the force to open the fibre tufts.
- ✓ After 16th flat location, carding force remains constant, but cleaning process continues.



Main Parts of Carding Machine


Cylinder -Doffer Region

- ✓ Suction hood removes the dust laden air from the card generated due to carding action.
- ✓ Post carding segments open the fibre clusters which escape the opening action in the carding region.




Main Parts of Carding Machine

Doffer



Fibres are transferred from cylinder to doffer.

- Carding or stripping mode?



- ✓ Cast iron cylinder
- ✓ Diameter: 27 inch
- ✓ Speed: 10-60 rpm

Main Parts of Carding Machine

Fibre Transfer to Doffer

Is fibre transfer in stripping mode possible?

- ✓ Fibre layer will be too thin
- ✓ Fibre layer can be thrown due to high centrifugal force
- ✓ Very difficult to form a coherent sliver

Problem with carding mode of transfer:

- ✓ Fibre disorientation
- ✓ Too thick cylinder load deteriorates the quality of carding

