CENG 311 Computer Architecture Lecture Notes

Ege Özkan

February 1, 2021

Introduction - October 16, 2020

1.1 Four Key Current Directions

- 1. Fundementally secure/reliable/safe architectuers
- 2. Fundementally energy-efficient and memory centric architectures
- 3. Fundementally low latency and predictable archiectures
- 4. Architectures for AI/ML, Genomics, Medicine, etc.

1.2 Transformation Hierarchy

The order travels through different hierarchical levels until it reaches the electrons. From problems to algorithms, thrugh program/language to system software to SW/HW Interface to lower hardware components.

Computer architecture was traditionally limited to SW/HW Interface and to Microarchitecture, but in the present day, computer architecture expands from algorithms to devices. This is because, to achieve the highest energy efficiency and performance, one must take the expanded view therefore co-designing across the hierarchy.

This way, once can specialize most of the components for a specific domain.

1.3 Computer Architecture

Computer architecture is the science and art of designin computing platforms to achibe a set of design goals. Designing a supercomputer is different from designing a smartphone, but many fundemental principles are similiar.

The computer architecture allows better systems to be built by making computer faster, cheaper, smaller and more reliable, it enables new applications and enables better solutions to be found.

Studying computer architecutre allows one to understand why computers work the way they do.

1.3.1 Computer Architecture Today

The present day industry has entered a paradigm shift to novel architectures, as many difficult problems motivate and cause a demand for novel architectures.

Computer Abstractions - October 23, 2020

Computer architecture is the science and art of selecting and interconnecting hardware components to create a computer that meets functional, performance and cost goals. Computer systems come in many forms, from general purpose personal computers to supercomputers.

A system must be Functional (correct), Reliable (continue to perform correctly.), High performance, low cost, low power/energy consumption and it must be secure. Keep in mind that the word correct may mean different things in different accuracy levels.

2.1 Abstractions

The computer system structure consists of the Application software at the top, the system software in the middle and the hardware in the bottom. Hardware-software interface handles the translation.

The compiler takes a high level compiled language (such as C), converts it into an Assembly language, and the assembler takes the Assembler code and converts it into the machine code.

A Microarchitecture is an implementation of an ISA, there may be multiple implementations from the same ISA.

Levels of transmformation create abstractions. High-level language programmer does not really need to know what the ISA is and how a computer executes instructions. Abstractions also improve productivity, decisions made in the underlaying level does not need to be considered.

Knowledge of the lower level may improve higher level design choices of a person. [For instance, consider the fact that modulo operator is *slower* in the hardware level, when writing C code, modulo operations can be transformed into bit-shift operations, which are *faster*, improving speed.]

2.2 the Von Neumann Architecture

the Von Neumann Architecture consists of a main memory, a CPU and the interconnection between them. Within the CPU, there is a control unit, and an arithmatic/logic unit. the Von Neumann Architecture is the *traditional*

structure of computers.

2.3 Main Memory

Collection of locations, each of which is capable of storing both instructions and data. Every location consists of an adress, which is used to access the location, and the contents of the location. It is similar in structure to a programming array. [Intresting to note, many emulators actually use arrays to emulate the memory of simpler machines.]

2.4 Central Processing Unit

CPU consists of multiple parts, **control unit**, **arithmatic logic unit** and **registers**. Memory is *fetched/read* to the CPU, as CPU sizes tend to be significantly smaller then Memory sizes, that is why despite CPU being much faster, memory is used to read/fetch from and *write/store* to.

2.4.1 Program Compilation as Execution

C is a compiled language, which means C code such as float value = x[i]; would get translated to assembly instructions such as ld r0 addr[1]. [Many C compilers also optimize your code, so there are changes made to it. (Some even causing bugs.)]

The resulting assembly code is stored in the memory as binary machine code. These instructions are fetched from the memory to the CPU (ALU). A specialised register called **program counter** (PC), *points* to the instruction to be executed. When ALU executes an instruction, program counter is incremented.

2.4.2 Metrics

Performance is generally valued in the CPU architecture, this is not as straightforward as one assumes, however. Consider an airplane, airplane performance can be defined as passsanger capacity, cruising speed, crusining range or passangers per mph. As such, there are different *metrics* to optimize for.

For computers, **Latency** is the elapsed time to do a task, how long it takes to do a task while **Throughput** is total work done per unit time. Although they may *look* similar, they are not the same.

In this course, while discussing processor performance, the focus will primarilly be on the execution time for a single job (latency). It can be measured in different ways, **Execution time** includes all aspects, the total response time while **CPU time** is the direct time spent on processing a given job, this discounts IO time and other jobs' shares.

Performance =
$$\frac{1}{\text{Execution Time}}$$
 (2.1)

Relative performance is the performance comperasion between two computers. Saying X is n time faster than Y is the same as dividing their performances or the inverse of their execution times.

If Computer A runs a program in 10 seconds, and B in 15 seconds, A is told to be 1.5 times faster than B.

2.4.3 CPU Clock

CPU clock determines when events take place in the hardware. [a clock cycle is similar to a Minecraft Tick.] a clock period is the duration of a clock cycle. Clock period has the unit of time and Clock frequency, which is the cycles per second, has the unit of Hz.

This has the effect that the CPU Time is the:

CPU Time = Cycle Count
$$\times$$
 Cycle Time (2.2)

Where Cycle Count count of cycles needed for program to run, CPU Time is the CPU time of the program, Cycle Time is the time it takes for a single CPU cycle.

CPU Time =
$$\frac{\text{Cycle Count}}{\text{Clock Rate}}$$
 (2.3)

Where Clock Rate is the clock rate. Therefore, increasing the clock rate, or decreasing the cycle time will improve performance.

For isntance, if a program runs in 10 seconds on a computer A, which has a 2GHz clock rate, whihe means the clock cycles needed for this program in computer A is $2 \times 10^9 \text{Hz} \times 10 \text{s}$ Clock cycles.

If computer B runs this program in 6 seconds, but 1.2x more clock cycles, to calculate its clock rate, one just has to multiply the Clock rate above with $\frac{1.2}{6s}$, which results in the calculation Clock Rate = 4GHz

Different instructions take different amounts of time on different machines, division generally takes more time than addtion, floating point operations take longer than itneger ones, accessing memory takes more time than accessing registers. So one can assume that the number of cycles will equal the number of instructions for simplicity, but it would be incorrect.

Instruction count for a program is determined by a program, ISA and compiler, but the avarage cycles per instruction is determined by CPU hardware, if different instructions have different CPI, avarage CPI is affected by instruction mix.

Clock Cycles equal Instruction count \times Cycles per instruction, whereas the CPU time depends on the product of Instruction count, CPI and Clock Cycle time, keep in mind Clock Cycle Time can be changed with $\frac{1}{\text{Clock Rate}}$.

Imagine an example where:

Computer	Cycle Time	CPI
A	250 ps	2.0
В	500 ps	1.2

Here, $t_a = \text{CC} \times \text{CCT} = I \times 2 \times 250$ and $t_b = I \times 1.2 \times 500$ where I is the instruction count, comparing them, $\frac{t_a}{t_b} = \frac{500I}{600I}$, shows that computer a is $\frac{6}{5}$ times faster for a program.

Another example, this time with compilers:

	A	В	\mathbf{C}
CPI for class	1	2	3
IC in sequence 1	2	1	2
IC in sequence 2	4	1	1

Here the compiler writer can chose between different code generation sequences for three classes A, B and C. But which code sequence is faster, and what is the CPI for each sequence?

For the first sequence, there is a total of $1 \times 2 + 2 \times 1 + 3 \times 2 = 10$ Clock Cycles spent, for the second sequence, there is a total of $1 \times 4 + 2 \times 1 + 3 \times 1 = 9$. Since the compiler will execute them in the same computer, the clock rate is equal, and hence, the time being spent is directly related to the number of clock cycles, therefore, the second sequence is much more beneficial.

One could also calulcate the avarage CPI, this is calculated using:

$$\begin{aligned} \text{CPI}_A &= \frac{\text{Clock Cycles}}{\text{Instruction Count}} & \text{(2.4)} \\ &= \sum_{i=1}^n \left(\text{CPI}_i \times \frac{\text{Instruction Count}_i}{\text{Instruction Count}} \right) & \text{Improving an aspect of a compute and expections a proportional improvement in overall performance. Where n is the improvement factor: } \end{aligned}$$

Clock Cycles =
$$\sum_{i=1}^{n} (\text{CPI}_i \times \text{Instruction Count}_i)$$
 $T_{\text{improved}} = \frac{T_{affected}}{n} + T_{\text{unaffected}}$

(2.6)

Where CPI_A is the weighted avarage CPI. Overall:

CPU Time =
$$\frac{\text{Instructions}}{\text{Program}} \times \frac{\text{Clock cycles}}{\text{Instruction}} \times \frac{\text{Seconds}}{\text{Clock Cycle}} \times \frac{\text{Seconds}}{\text{Clock Cycle}} = \frac{80}{n} + 20$$
 (2.9)

Determining the Values

CPU Execution Time can be determined by running the program.

Clock cycle time is usually published with documentation.

Instruction Count via the software tools that profile execution or by simulators.

CPI however, depends on a wide variety of design details including the memory system and the processor structure, therefore it is much harder to determine.

Computer Benchmarks are programs or set of programs used to evaluate computer performance, benchmarks allow us to make performance comparisions based on eexecution times, they can vary greatly in terms of their complexity and their usefulness, benchmarks should:

• Be representitive of the type of applications that run on the computer.

• Not be overly dependent on one or two features of a computer.

$$T_{\text{improved}} = \frac{T_{affected}}{n} + T_{\text{unaffected}}$$
 (2.8)

For instance if multiply accounts for 80 seconds of 100, how much improvement in multiply perfromance to get 2 times overall improvement. [ie to make 100 seconds to fall to 50 seconds

Must improve by 2.6 times.

However if multiply accounts for 80 seconds of 100 seconds and we want five times overall improvement. This is impossible, since the unaffected part also takes 20 seconds.

Summary of Performance Evaluation

Good benchmarks, such as SPEC can provide an accurate method for evaluating and comparing computer performance. Ahmdal's law provides an efficent method for determining speedup due to an enhancment, and one must make the common case fast.

Instructions: Language of the Computer - October 30, 2020

It was allready established that the Compilers and Assemblers bring high-level languages to binary machine language program. The Instruction Set Architecture (ISA) consists of Instructions and Memory.

ISA's instructions are controlled by Opcodes, Addressing Modes, Data Types, Instruction Types and Fromats, Registers and Condition codes. An ISA interracts with the memory's address space, it has to deal with its addressability, alignment and virtual memory managment.

A microarchitecture is a specific implementation of an ISA under specific design constraints and goals. It is the things done in hardware without exposure to the software. These range from pipelining to voltage/frequency scaling.

3.1 MIPS Instruction Set

MIPS is a simple ISA.

3.1.1 Assembler Instructions

Add and Substract

Takes two sources and has one destination.

add a, b, c

Where a gets b + c, arithmatic operations occur only on registers in MIPS. sub, mult and div take the same form.

This is an important lesson on design, as a design principle, *simplicity favours regularity*. Consider the code

$$f = (g + h) - (i + j)$$

Compiles to the following MIPS Assembly

add t0, g, h add t1, i, j sub f, t0, t1

Register Operands

Observe that the arithmetic instructions use register operands. MIPS has a 32x32-bit register file, that is, 32 register with 32-bit register size. Used for frequently accessed data, numbered 0 to 31. In Assembly, they are named \$t0 to \$t9 for temporary values and \$s0 to \$s7 for saved variables.

Smaller is faster.

In the same C code, consider that all variables are stored in \$s0 to \$s4.

(keep in mind that above MISP codes were not assemble-able).

add \$t0, \$s1, \$s2 add \$t1, \$s3, \$s4 sub \$s0, \$t0, \$t1

Memory Operands

Main memory is used for composite data (arrays, structures, dynamic data) to apply arithmatic operations (loading and storing values), it is byte-addressed. Words are alligned in memory (its address must be a multiple of 4.) [This design decision is shared with x86, this is why sometimes stuff is padded in C in weird ways.]

A word is a 4-byte construct, (32-bits) that correspond to an integer. Do consider that big-endianness or little-endianness of an architecture will impact in which order a word, or an integer, will be stored in the memory in which order.

MIPS is a big-endian architecture.[Meanwhile x86 is a little-endian architecture]

d is the destination register, b is the base register off is offset value, b + off forms the memory address to be accessed. lw is the load word instruction, while sw is the store word instruction.

Consider the C code g = h + A[8];, g is in \$s1, h in \$s2 and the base address of the A array is in \$s3.

lw
$$$t0$$
, $32($s3)$
add $$s1$, $$s2$, $$t0$

Observe that the $8 \times 4 = 32$ since 4i is the offset value for a specific index value in C. This

is due to the fact words occupy 4 bytes, and they align by four too.

Consider the similar C code A[12] = h + A[8]; which also stores the result, this assembles into:

lw
$$$t0$$
, $32($s3)$
add $$s1$, $$s2$, $$t0$
sw $$t0$, $48($s3)$

!*!*!*

Since registers are significantly faster to access than memory, compiler should try to use registers for variables as much as possible. This would be correct even if register access time and memory access time was the same, [Which they aren't], since memory access requires more instructions.

Immediate Operands

Immediate instructions negate the need for using load instructions by using scalars. Consider, addi which is the immediate addition instruction, compared to add, it does not need the usage of a load. For instance, this snippet:

Can easily be rewritten as

Without using 1i. Which itself is an immediate operand that immediatelly loads a value to a register. This corresponds to the third design principle of MIPS, making the common case fast. Here, small constants are common, immediate operand avoids a load instruction.

Related to this, **\$zero** read-only register (it cannot be overwritten) holds the value zero, adding with the zero register can be used to move values between registers for instance.

Logical Operations

Logical operations are bitwise operations used to perform boolean logic on values. These are and, or, nor, and their immediate equivalents andi and ori.

And is useful for masking bits. For instance, anding bits in a word with a word whose certain parts are zero would mask out these parts. Likewise, or is useful for swapping certain bits to 1 in a word.

MIPS does not have a not instruction, instead, one can **nor** (not or) with the special \$zero register. Since $\neg p = \neg (p \lor 0)$

Shift Operations

Another bitwise manipulation operations. sll and srl is used for left logical and right logical shifts respectivelly. Both of them fill the shifted parts with zero.

Shifting a number left i times is same as multiplying it by 2^i , and shifting a number i times right would mean dividing it by 2^i .

3.1.2 Instruction Representation

Instructions are kept as a series of high and low electronic signals. MIPS instructions are 32 bits long.

MIPS Instructions are classified into different types of instructions.

R-Type Instructions

Most well-known of these R-Types are aritmathic instructions. Shift amount refeers to the amount of shift that will be applied to the number (For sll and srl.) Function code is used to further distinguish between

Part	Length	Explanation
op	6 Bits	OP-Code
rs	5 Bits	Source register
rt	5 Bits	Source register
rd	5 Bits	Destination register
shamt	5 Bits	Shift Amount
funct	6 Bits	Function Code

Table 3.1: The structure of R-Type Instructions

instructions as an extension of the OP Code.

Register numbers in the machine codes differ from their assembler counterparts a bit. Registers between \$t0 and \$t7 are translated to numbers 8 to 15, Registers \$t8 and \$t9 gets translated to 24 and 25 and registers between \$s0 and \$s7 are translated to 16 to 23.

[I should probably point out the instructor at this point said we should now the general instruction structure but not the register translations.]

Function field may look redundant, it exists due to the fact that all arithmatic operations are encoded with OP-Code 0, hence they are differentiated via their Function codes. [This whole deal occurs to keep the OP-Code length the same between R, I and J type operations. There are many more R type operations, instead of giving OP-Code more space OP-Code field is used to group them to certain categories, and Function field specifies the exact instruction. This also greatly simplifies the processor design, all instructions with OP-Code 0 gets sent to ALU, for instance.]

[You may point out, but Amber, doesn't all of the R type instructions go to ALU anyway? What is the point? Well, padawan, MIPS is designed to be extended, Sony PSP

for instance has an VFPU in it as well, and R Type instructions on VFPU use a different OP-Code

Assembler instructions like add, sub, div, srl and sll are translated to R-Type instructions.

I-Type Instructions

Part	Length	Explanation
op	6 Bits	OP-Code
rs	5 Bits	Register 1
rt	5 Bits	Register 2
constant/address	16 Bits	16 Bit Number.

Table 3.2: The structure of I-Type Instructions

Instructions in the I-Type are imediate arithmatic instructions, load/store instructions and branch instructions.

Meaning of registers change from instruction to instruction. The address is used to offset one of the registers.

Assembler Instructions like addi, lw, sw are translated to I-Type instructions.

J-Type Instructions

Part	Length	Explanation
ор	6 Bits	OP-Code
pseudo-address	26 Bits	Shortened address

Table 3.3: The structure of J-Type Instructions

[These were not mentioned, but I am still putting this here for the sake of completeness, although I believe we will return to these in the future.]

J-Type instructions are reserved for Jump instructions, hence they have a large amount of space left for an address. This value, stored at the pseudo-address field is the shortened address of the destibation, its two least significant and four most significant bits are removed and are assumed to be the same as the current instruction's address. (Wikibooks - MIPS Assembly)

Instructions: Language of the Computer (Cont'd) - November 13, 2020

This chapter directly continues the previous 4.1.1 chapter.

4.1 Instructions for Making Decisions

These instructions *jump* to the label, labelled as L1. beq does this when two register values are equal, bne jumps when they are **not** equal, and **j unconditionally jumps** to the label L1.

bne is preffered over beq, this is because not branching is preffered over branching for performance reasons.

j instruction is represented via J-Type instructions, while other branches are represented via I-Type.

4.1.1 Basic Branching

Branching instructions can be used to represent conditionals and loops easily.

Representing If-Else Conditionals Using Branching

Consider the C code below:

$$if (i=j) f = g+h;$$

 $else f = g - h;$

Assuming f, g, h, i, j is stored in \$s0, \$s1, \$s2, \$s3 and \$s4 respectively, this can be translated to:

```
bne $s3, $s4, Else
add $s0, $s1, $s2
j Exit
Else: sub $s0, $s1, $s2
Exit: ...
```

Where under the label Exit will exit the program properly. This same program can also be written as:

```
beq $s3, $s4, If
sub $s0, $s1, $s2
j Exit
If: add $s0, $s1, $s2
Exit: ...
```

Representing Loops Using Branching

A while loop of the form

while
$$(save[i] == k)$$

 $i += 1;$

If i, k and the base address of save is stored in \$s3, \$s5 and \$s6 respectively, this is compiled to the following series of MIPS instructions:

```
Loop: sll $t1, $s3, 2
add $t1, $t1, $s6
lw $t0, 0($t1)
bne $t0, $s5, Exit
addi $s3, $s3, 1
j Loop
```

Where shift left by two is used to multiply the index by four, the idea behind this decision is of course the elements are words, so we need to multiply the index by four to find the offset.

Conditional Set

```
slt rd, rs, rt
slti rt, rs, constant
sltu rd, rs, rt
sltui rt, rs, constant
```

The slt instructions sets rd to 1 if the value in rs is less than rt, while slti does the same if the value in rs is less than the constant.

The sltu and sltui work the same, however they assume the numbers being hold at the registers are *unsigned*. This could [or rather, will] be problematic, given that signed integers work with two's complement.

4.1.2 Procedure Calls

Procedure calling works thusly:

1. Place parameters in registers.

- 2. Transfer control to procedure.
- 3. Acquire storage for procedure.
- 4. Perform procedure's operations.
- 5. Place result in register for caller.
- 6. Return to place of call. [Return control]

Register Structure

Registers	Explanation
\$a0 - \$a3	To pass arguments
\$v0, \$v1	To store return values
\$ra	Return address
\$sp	Call stack pointer

Table 4.1: Registers used in procedure calls

Procedure Call Instructions

jal ProcedureLabel jr \$ra

To call a procedure, we use the jump and link instruction, jal, the jump and link instruction stores the address of the next instruction (the adress the program will return to this address) [the return address] to the \$raand jumps to the target address.

To return from a procedure, we use jump register instruction, jr, which copies the \$rato the program counter, which means the next instruction to be executed will be the return address, that is, we jump back to where came. (Address of the last jal call +1)

Procedure Call

The caller puts the parameter values in \$a0 - \$a3, then uses jal X to cump to the procedure X, jal stores PC+4 (Instructions are

four bytes apart) in \$ra.

The calee performs the calculations (executes any instructions it has) places the results in \$v0 and \$v1, it then returns the control to the caller using jr \$ra.

The PC (Program counter) is the specialised register containing the address of the instruction in the program being executed.

Call Stack

Any registers needed by the caller must be restored to the values that they contained before the procedure was invoked, for this reason, a stack is used, the special stack pointer \$spdenotes the most recently allocated address in a stack that shows where registers should be spilled or where old register values can be found.

Consider the C code

```
int leaf_example (int g, int h,
  int i, int j) {
    int f;
    f = (g + h) - (i + j);
    return f;
}
```

Assume that arguments are stored in \$a0 - \$a3 and consider f in \$s0 (hence, \$s0 must be saved on stack). The C code f = (g + h) - (i + j); is translated to MIPS assembly:

```
add $t0, $a0, $a1
add $t1, $a2, $a3
sub $s0, $t0, $t1
```

Since the callee will modify \$t0, \$t1 and \$s0. Their previous values (if they had any) must be stored in the call stack using \$spThis is done by starting to add values to \$spby subtracting four times three from it, ie, allocating space for three registers.

leaf_example:

```
addi $sp, $sp, -12 # Allocate space.

sw $t1, 8($sp) # Save stack.

sw $t0, 4($sp)

sw $s0, 0($sp)

add $t0, $a0, $a1

add $t1, $a2, $a3

sub $s0, $t0, $t1

add $v0, $s0, $zero # Store result.

lw $t1, 8($sp) # Restore values

lw $t0, 4($sp)

lw $s0, 0($sp)

addi $sp, $sp, 12

jr $ra # Return
```

The above examples shows the complete MIPS translation of the leaf_example function in C as a MIPS procedure.

[Stack pointer does not run out of space, because it is located in the top of the memory. It grows and shrinks usable memory more calls you made to a function like this.]

Convention

This is not actually how most of the time MIPS programmers do things, instead, we assume that, across a procedure call, the following registers are preserved:

- 1. Saved registers, \$s0-\$s7
- 2. The stack pointer register \$sp
- 3. The return address \$ra
- 4. Stack above the stack pointer, [ie, previous call].

And the following isn't preserved:

- 1. Temporary, \$t0-\$t7
- 2. The argument registers \$a0-\$a3
- 3. The return registers \$v0, \$v2

4. Stack below the stack pointer, [ie, next calls, procedure calls made inside the procedure call].

beq \$t0, \$zero, L1
addi \$v0, \$zero, 1
jr \$ra # and return

sw ra, 4(sp)

Using the convention, above code simplifies to:

L1: **addi \$sp**, **\$sp**, -8

```
leaf_example:
```

```
mple:

addi $sp, $sp, -4 # Allocate space.

sw $s0, 0($sp) # Store saved.

add $t0, $a0, $a1

add $t1, $a2, $a3

sub $s0, $t0, $t1

add $v0, $s0, $zero # Store result.

lw $s0, 0($sp)

addi $sp, $sp, 8

mul $v0, $a0, $v0

jr $ra
```

If we haven't used the saved register \$s0, then we didn't needed to save and restore it at all.

addi \$sp, \$sp, 2

jr \$ra # Return

(From November 20, 2020)

Nested Procedures

Procedures that call other procedures, for nested call, caller needs to save its return address, and any arguements and temporaries needed after the call to the stack, and restore them from the stack after the call.

Consider the C code:

```
int fact (int n) {
    if (n < 1) return 1;
    else return n * fact(n -
}</pre>
```

This is a very simple (and well-know, recursive) factorial algorithm, with the argument n being stored in \$a0 and result in \$v0, this can be compiled to the following MIPS assembly code:

fact:

```
slti $t0, $a0, 1
```

Here, in the recursive part, we need to store the return address and the \$a0 in the stack to recover them later. We recover these values after the recursive call jal fact.

This is because, of course, if the values of \$a0 gets lost, then we will have significant problems, the code will not work correctly, and we do need to overwrite \$a0, since the function we are calling, the function we are already in, expects its input value in \$a0.

Original \$a0 may not be always have to stored however, since in certain recursive function we may not need to use the previous inputs, it is fine to overwrite them then.

Keep in mind there is a certain point that may arise if one uses the stack too much, if the stack size exceeds that of the memory, a stack 1) overflow will occur.

[A similar problem occured in eraly Sinclair ZX80 computers, the screen memory was shared with the RAM, and if your program consumed too much memory, the display would literally shrink. It was reportedly not amusing to use Sinclair ZX 80 due to this reason, well, one of the reasons.]

Instructions: Language of the Computer (Cont'd) - November 20, 2020

5.1 Representing Instructions 5.2

Kept as a series of high and low electronic signals (binary) and represented as numbers. MIPS instructions are 32 bits long.

We had already gone over the I-Type and R-Type instructions extensivly. It should be noted that I-Type instructions also include the branching instructions, which does make sense, since they require two registers to compare and an address to jump to.

J-Type Instructions

Part	Length	Explanation
ор	6 Bits	OP-Code
pseudo-address	26 Bits	Shortened address

Table 5.1: The structure of J-Type Instructions

J-Type instructions are reserved for j and jal unconditional jump instructions. Observe that the Address can be any unsigned number up to 2^{28} , compare to I-Type's 2^{16}

5.2 Addressing Modes

There are different sorts of addressing modes used in MIPS.

5.2.1 Immediate Addressing

The operand is a constant withing the instruction itself. This is used in I-Type instructions with a constant, such as in addi. This value is a 16-bit value.

32-Bit Immediate Operands

But, let us say we want to load a very big 32-bit number such as 4000000, this is done via the lui rt, constant instruction, which sets the first 16 bits (upper part) of the register rt to the constant and sets the remaining part to the zero.

lui **\$s0**, 61 ori **\$s0**, **\$s0**, 2304

We **load** the upper 16 bits of the value to the first 16 bits of the \$s0 register using the Load Upper Immediate instruction, and then, we use the Logical Or Immediate operation to simply mask the remaining lower 16 bits (but signed, so can be negative) of the value to the register.

5.2.2 Register Addressing

Register addressing simply refeers to putting the number of the register to the register fields of the I-Type and R-Type instructions.

5.2.3 Base Addressing

The operand is at the memory location whose address is the sum of a register and a constant in the instruction, such as in, do realise that the offset might be negative as well:

$$lw \$t0, 1200(\$t1)$$

Which loads an integer from the 1200 bytes after the address at \$t1. (1200 + [\$t1]).

5.2.4 PC-Relative Addressing

The branch address is the sum of the PC and a constant in the instruction. $PC + offset \times 4$

This is a relative addressing mode, this way, the amount of memory usable by the program increases substentially.

The multiplication by four part refeers to the fact that an instruction occupies four bytes (32-bits) in the memory.

5.2.5 Pseudo-direct Addressing

The jump address is the 26 bits of the instruction concatenated (after being multiplied by four) with the upper bits of the PC.

j L1

Here the 26 bits represent the 28 lower bits of the address (it will be multiplied by the four, or shifted by two) and are concanated with the upper four bits of the program counter.

For instance, the following MIPS assembler instructions,

Exit: ...

Compiles to these machine instructions:

80000	0	0	19	9	2	0
80004	0	9	22	9	0	32
80008	35	9	8		0	
80012	5	8	21		2	
80016	8	19	19		1	
80020	2	20000				

5.2.6 Branching Far Away

If the branching target is too far to encode with 16-bit offset, assembler rewrites the code:

Becomes:

. .

Instructions: Language of the Computer (Cont'd) - November 27, 2020

6.1 Byte & Halfword Operations

```
lb rt, offset(rs)
lh rt, offset(rs)
}
```

For loading and storing bytes and halfwords, 1b, 1h, 1bu, 1hu; sb and sh can be used to get a single byte/halfword from the memory.

1b and 1h sign extends the value to 32 bits in rt, their unsigned counterparts 1bu, 1hu on the other hand, zero-extends the value to 32 bits.

For instance, if we have F0 in the memory, 1b would load FFFFFFF0, but 1bu would load 000000F0.

```
void strcpy (char x[], char y[]) {
    int i;
    i = 0;
    while ((x[i]=y[i])!='\0') L2
        i += 1;
}
```

Assuming the addresses in x, y is in a0 and a1. i in s0.

```
void strcpy (char x[], char y[]) {
```

```
strcpy:
    addi $sp, $sp, -4
    sw $s0, 0($sp)
    add $s0, $zero, $zero

L1:

    add $t1, $s0, $a1
    lbu $t2, 0($t1)
    add $t3, $s0, $a0
    sb $t2, 0($t3)
    beq $t2, $zero, L2
    addi $s0, $s0, 1
    j L1

L2:
    lw $s0, 0($sp)
    addi $sp, $sp, 4
    jr $ra
```

6.2**Program**

6.2.1 Compiler

Compiler transforms higher level programming languages into assembly language program, a symbolic form of what the machine understands. [Some Compilers translate directly to machine code too.]

6.2.2Assembler

Assembler converts Assembly instructions to machine code. Most of the time, machine instructions have a one-to-one relationship with machine instructions. Pseudoinstructions are instructions that do not have implementations, but simplify translation and programming (in Assembly) For instance blt pseudoinstruction assembles into a slt and bne instruction.

The \$at register is used as the assembler temporary to write this pseudoinstructions.

Assembler turns the program into an Object file that includes machine language instructions, data, and information needed to place instructions properly in memory.

6.2.3 Object File

The object file includes:

Object File Header The size and position of the other pieces of the object file.

Text Segment The machine language code.

Static Data Segment Data allocated for the life of the program.

Relocation information Instructions and data words that depend on absolute addresses.

Translation and Starting a Symbol Table Global definitions and external references (labels)

> Debug Information Associates machine instructions with C source files. [In gcc, you can enable this via the -g3 switch.]

6.2.4 Linker

Places code and data modules symbolically in memory. Determines the addresses of data and instruction labels (by using relocation info) patches the internal and external references and produces executable file.

6.2.5Memory Layout

In MIPS architecture, on top of the reserved segment sits the text segment, pointed to by the program counter, on top of which sits the static data, pointed by the \$gp, on top of which sits the **dynamic data**, the heap. and on top sits the stack, pointed by the \$sp.

Text segment and data segment sits in the object file, stack and dynamic data provided by the system itself. [In MS-DOS MASM x86, you actually had to tell the system the size of the stack you wished.] Keep in mind that the stack grows downwards, towards the dynamic data segment.

6.2.6 Loader

This is the part of the computer that actually copies the instructions and date from the executable file into memory. Copies the parameters to the main program, initializes the machine registers and sets the stack pointer to the first free locations, jumps to the start up routine that copies the parameters into the argument registers and calls the main routine.

6.2.7 Dynamic Linking

With Static linking, the library routines become part of the executable, loads all routines in the library even if not used, dynamically linked libraries (DLLs) are linked during execution.

6.3 Compiler Optimization

Many compilers do not just generate assembler code, in the background, certain optimizations are done to speed up code.

gcc Optimization Levels

gcc, the de facto standard GNU/Linux compiler provides six different optimization levels.

Register Allocation

Given a block of code, the compiler wants to choose assignments of variables to register to minimize the total number of required registers.

$$w = a + b;$$

 $x = c + w;$
 $y = c + d;$

Here the naive register allocation would result in assigning seven registers for the seven variables, but this is not actually necessary, there is a better way.

Dead Code Elimination

Code that will never be executed can be safely removed from the program.

Loop Transformations

Switch	Optimization Level	For the processors, loops come with overhead,
-00	Optimize for compile time (default)	therefore, the compilers try to limit them.
-01, -0	first level of optimization size and e	xecution time.
-02	Second level of optimization size an	d extenstion to tipmetransformation is loop un-
-03	Third level of optimization for code	sizdling.execution time.
-0s	Optimize for code size	\mathbf{for} $(\mathbf{i} - 0, \mathbf{i} < \mathbf{N}, \mathbf{i} + 1)$
-Ofast	Optimizes even more than -03 but	for $(i = 0; i < N; i++)$ { math is not IEEE compliant.

Table 6.1: Different optimization levels of GNU C Compiler.

As can be seen in Table 6.1, there are different levels of optimization in gcc, these may increase the compilation time and memory usage, but in general will decrease the execution time. -Ofast allows for fast mathematical operations, but it is not completely IEEE compliant.

6.3.1 Compiler Optimizations

Here are certain optimizations performed by the compiler. If the N = 4, then it can be unrolled four times

```
a[0] = b[0] * c[0];

a[1] = b[1] * c[1];

a[2] = b[2] * c[2];

a[3] = b[3] * c[3];
```

Or it may be unrolled "twice", reducing the times we check the condition.:

```
for (i = 0; i < 2; i++) {  a[i*2] = b[i*2] * c[i*2]; \\ a[i*2 + 1] = b[i*2 + 1] * c[i*2 + 1];  }
```

which combines two or more loops into a single ing code modularity and generality. loop.

Another transformation is loop fusion, how to improve performance without destroy-

```
for (i = 0; i < 300; i++)
        a[i] = a[i] + 3;
}
for (i = 0; i < 300; i++)
        b[i] = b[i] + 3;
 is transferred to:
for (i = 0; i < 300; i++)
        a[i] = a[i] + 3;
        b[i] = b[i] + 3;
}
```

Another transformation is **loop tiling**, which breaks up a loop into a set of nested procedures that operate on a subset of data.

Procedure Inlining

The body of the procedure is substituted in place for the procedure call to eliminate the call overhead.

This however, increases the code size. [CPython does not do this, it is one of the reasons it has abysmal performance compared to PyPy.]

Performance Optimization 6.3.2

While optimizing, it is pivotal to optimize at multiple levels, taking into account the data representation, algorithm, procedures and loops.

One must also understand the system to optimize performance, how programs are compiled and executed, how modern processors and memory systems operate, how to measure program performance and identify bottlenecks,

Arithmetic Operations - December 4, 2020

7.1 Representing Numbers

Using 32 bits, it is possible to represents unsigned numbers between zero and $2^{32} - 1$, for signed numbers, this number is $2^{31} - 1$

7.1.1 Unsigned Integers

While representing unsigned numbers of n-1 numbers, the value of a number x can easily be calculated via:

$$x = \sum_{k=0}^{n-1} x_k 2^k \tag{7.1}$$

Where x_k represents the digits of the number, and is either one or zero.

And n bit unsigned integer can represent values between zero and $2^n - 1$

7.1.2 Signed Integers

The two's complement system is used in the signed integers, where the least significant bit is the sign bit, one for negative and zero for positive numbers. The value of a number x of n bits length can be calculated using:

$$x = -x_{m-1}2^{n-1} + \sum_{k=0}^{n-2} x_k 2^k$$
 (7.2)

In practice, one can convert a two complement to a normal number by inverting its bits and adding one and multiplying via -1.

A number signed number x of n bits long can represent any number between 2^{n-1} to $2^{n-1}-1$.

7.2 Arithmetic Operations

Processors can perform many arithmetic operations.

7.2.1 Integer Addition

Integer additions use a carry, and when adding two numbers of the same sign, an overflow may occur. If two negative numbers are being added, if the first bit ends up zero, (or one if both are positive) the overflow is said to have occurred.

7.2.2 Integer Subtraction

This is the same as adding the negation of the second number to the first number, subtracting a positive number from a negative operand is

Operation	Left	Right	Result
Addition	+	+	-
Addition	_	_	+
Subtraction	_	+	+
Subtraction	+	_	_

Table 7.1: Overflow conditions for subtraction and addition

said to have resulted in an overflow if the result sign is zero. (Or reverse in the reverse case).

7.2.3 Dealign with Overflows

The addu, addiu and subu ignores overflows and do not cause exceptions, on the other hand add, addi and sub cause an exception, when an overflow occurs, the PC is saved in the EPC register, predefined handler address is jumped and mfc0 instruction can retrieve EPC value to return after corrective action.

7.2.4 Multiplication

One can just place a copy of the multiplicand in the proper place if the multiplier digit is 1, or zero if the multiplier digit is zero.

The proper place can be calculated using the shift operations. The multiplication operation uses shift and sum operations to achieve its goal in the hardware level.

As one can see, there is redundancy in the multiplication, half of the bits are spent for zeros, three steps per bit is used. And also the least significant bit is updated only once.

An improved version of the multiplication hardware performs steps in parallel, executing two steps per bit.

Signed Multiplication

Signed multiplication acts as if the numbers are positive, and remembers the original signs, converting to the appropriate sign in the end.

Multiplication in MIPS

MIPS provides two 32-bit registers for product, HI and LO.

mult rs, rt
multu rs, rt
mfhi rd
mflo rd

mult and multu multiply rs and rd and stored the 64-bit product in LO and HI, the special move instructions mfhi (move from LO) and mflo, (move from HI) can be used to get the values in these special registers.

The simpler mul rd, rs, rt places the least significant 32 bits of product to rd register.

7.2.5 Divison

n bit operands yield n bit quotient and remainder. It checks for divisor to be smaller than the divident bits, one bit in quotient, subtract otherwise 0 bit in quotient bring down next dividend bit. This is called the **long divison** approach.

Signed division divide using absolute values and then adjust signs as needed.

Similar to multiplication, MIPS divison is done with a div instruction that uses HI and LO.

Keep in mind that shift operations are significantly better.

Field	64-Bit	32-Bit
Sign	1 Bit	1 Bit
Exponent	11 Bits	8 Bits
Fraction	52 Bits	23 Bits

Table 7.2: Fields of single and double-precision floating point numerals.

7.3 Floating Point

Floating point is [used to represent] numbers with fractions, reals. It can be written in scientific notation, or normalized notation. Normalized notation is number in scientific notation that has no leading 0s.

The floating point takes the following form: Where the whole number x is:

$$x = (-1)^s \cdot (1+F) \cdot 2^{E-B} \tag{7.3}$$

Where B is the bias. Significant is normalized, that is, it always has a leading pre-binary-point 1 bit, so no need to represent it explicitly, exponent (E) is the actual representation plus a bias (B).

The bias of a single precision floating point number is 127.

[Other than double precision (64 bits) and single precision (32 bits), there is also extended precision (40 bits) and also extended double precision (80 bits)]

[Early computers and chipsets actually had dedicated Floating Point coprocessors. Intel x86 even had something called an x87, a subset of x86 working with the Intel 8087 Floating Point Coprocessors. Nowadays, x87 is a proper part of x86.]

Processor Design - December 18, 2020

The implementation of a subset of the MIPS-1 instruction set that includes lw and sw memory reference instructions, add, sub, and, or and slt arithmatic-logical instructions, as well as the beq and j control-transfer instructions.

The instruction execution follows a basic format:

- 1. **Fetching** the instruction from the instruction memory, pointed by the PC.
- 2. Data held in the memory is imported to the Register file.
- 3. ALU may be used to calculate arithmetic results, memory addresses and comparison.
- 4. Access the data memory for load/store.
- 5. Write the data from ALU to register if ALU is used.
- Change the PC based on comparison for branch if a comparison instruction is used. Otherwise Program counter is incremented by four.

In conclusion a basic processor implementation for a subset of MIPS includes a PC, Register file, ALU and memory. A control unit is also responsible for deciding where

instructions go and what do they do using multiplexers.

This CPU design uses Multiplexer and Adder combinational elements.

8.1 Data Path

8.1.1 Instruction Fetch

Fetch the instruction from the instruction memory. Increment the PC so that it points at the next instruction, four bytes later.

Instruction Memory

Instruction Memory is a read-only memory takes one input and gives one output, both 32-bit. Takes the address of the instruction to read and returns the instruction at that address.

Program Counter

A special register that gets updated at the end of every clock cycle.

Adder

A simple ALU wired to always adds four to the input.



8.1.2 R-Format Instruction

These instructions need a register file and an ALU, it reads from two registers, performs an arithmetic logical operation on the contents of the register, writes the result to a register.

in our simplified MIPS implementation, these add, sub, or, sll

Register File



The above diagram summerizes how the Register File works. This file contains two outputs for data as well as one input for incoming data. The three register inputs in the left hand side tells it which registers to read or write and they take 5 bits of input. The bottom Reg-Write flags is set high when there will be a write.

\mathbf{ALU}

The operation to be performed by the ALU is set by the control unit through the control lines.

ALU Control Lines	Function
0000	AND
0001	OR
0010	ADD
0110	SUBTRACT
0111	SLT
1100	NOR

8.1.3 Load/Store Instructions

An instruction such as lw \$t1, offset(\$t2) reads register operands, computes the memory address by adding the base register to the signed offset and load/store the value from/to memory into/from register.

Components needed for this operation is:

- Register File.
- ALU (for addition operation).
- Data Memory Unit
- Sign Extension Unit

Sign Extension Unit

Sign extension replicates the most significant bit loaded into the upper sixteen bits.

Data Memory Unit

Data memory unit is the unit that holds the data as memory.

8.1.4 Branch Instructions

To execute an instruction such as beq \$t1, \$t2, loop you would have to:

- 1. Read the register values.
- 2. Compare the values by subtracting and checking for zero. The ALU Has a special Zero output for this reason that is logical high when the result is zero.

3. Calculate the target address by sign extending the displacement

8.2 A Single Datapath

Execute all instructions in one clock-cycle, to share a datapath element between two different instruction classes, allow multiple connections to the input of an element (multiplexer and control signal to select among multiple inputs).

8.2.1 Control

the Control unit takes the OP-Code as its input, and proceeds to set certain control paths to their appropriate values depending on the OP-code.

Processor Design (Cont'd) - December 25, 2020

9.1 Control Unit

In order for Processor to work correctly, the Control Unit must be able to set the Control Lines appropriately.

In R and I type instructions, first six bits determine the op-code. Next five bits rs, is always sent to the read section of the register file. the rt (next six bits) is always read also, except when the instruction is a load instruction. rd (the next six bits) and rt for load is he write register. Finally, the next sixteen bytes for I-Type is sign-extend and add. For arithmetic instructions, the last five bits is the function code that determines the ALU operation.

9.1.1 ALU

The ALU Control unit is the dedicated control unit for the ALU. The main control Unit sends an ALUOp signal to the ALU Control Unit, and the ALU Control unit generates the ALU Control input, which is equivalent to function code.

The source lines of the ALU is determined via a multiplexer governed by the Main Control Unit.

The ALUOp signal determines the type of

the operation ALU will perform and is the output of the control unit. the ALU Control is further uses this signal to determine the value of the ALU control lines.

00 is used for add in load and store, 01 is subtract for beq and 10 is used to delegate the decision to the function field.

9.1.2 J-Type Jump Instruction

Jump uses pseudo addressing, a 26 bit address whose last two bits are omitted and whose top four bits come directly from the Program Counter.

The Control Unit sets the Jump Control Signal to logical high in order to make sure PC is set to the pseudo-address.

Pipelining - January 6, 2021

Pipelining is a commonplace optimisation that is found in most contemporary processors. The clock cycle is normally determined by the longest delay, pipelining divides a clock cycle to multiple *stages*, and tries to execute one instruction each stage thus increasing throughput.

The general idea is to divide each instruction to different stages and then multiple instructions can be parallelised in the same cycle but in different stages

Despite its robust nature, stalls may occur in pipelining, these issues can be solved in the hardware level, such as by *forwarding*, or in software level such as by *code scheduling*, which reorders code.

Memory System - January 8, 2021

From the programmer's point of view memory is a monolithic bloc accessed via store and load commands.

For most programs, memory access is a more significant bottleneck.

Memory comes in many different forms, chiefly, Dynamic RAM and Static Ram, former is slower but cheaper compared to the latter.

A memory is a sort of array with an address selection logic and readout circuitry. Its performance is generally captured by two parameters, latency and bandwidth.

Latency the time from the issue of a memory request to the time data is available at the processor.

Bandwidth the rate at which data can be pumped to the processor by the memory system.

Some memory systems are organised in banks rather than one big array.

The selection of memory structure is a balancing act between the capacity, latency and bandwidth; as a result, contemporary technologies use a a hierarchy to ensure most of the data processor needs is residing in the it is not, it is called a miss.

faster levels.

Top of the hierarchy is the Cache, generally an SRAM structure. Both of these components reside in the CPU itself, below the Cache sits the Main memory which is generally DRAM, and below that sits the Hard Disk. The caches themselves may also have levels, there may be multiple caches each faster than other.

Locality Principle

Locality Principle says that programs access a small proportion of their address space at any time.

Temporal Locality Items accessed recently are likely to be accessed again soon. [Loops]

Spatial Locality Items near those accessed recently are likely to be accessed soon. [Arrays]

Data Locating

The data is first looked for in the upper level of the hierarchy, and travels downwards until it is reached, when it is found, the data is brought up to the CPU travelling through the hierarchy.

When data is found it is called a **hit**, when

Modern Memory Hierarchy

In modern systems, main caches and main memory is handled automatically in hardware. The disk might have a swap portion, handled automatically, and the register file cache interaction is handled on a compiler level.

Manual memory managment is no longer used in general computing, however, development on embedded processors sometimes uses manual management by the program.

11.0.1 Cache Block

A cache block is a multiple word wide block that holds data, the memory accesses operate on these blocks rather than individual data items.

Cache Mappings

Caches maybe direct mapped, N-way set associative or fully associative.

Cache Operations - January 15, 2021

When CPU needs to read data, it checks the Level 1 cache then the level 2 Cache, and so on. If the data is available, it is a *cache hit*, otherwise a *cache miss*.

When CPU needs to write data, the line is written to main memory when it is written to the cache, this is called a *write-through*, if the data isn't written, marked as dirty, when the cache line is replaced by a new cache line from memory, the dirty line is written to memory, this is called *write-back*.

Write through is simpler and keeps all levels consistent, but it uses more bandwith compared to write-back, which can combine multiple writes to the same block before eviction, but it needs an extra bit in the tag store indicating the block is dirty modified.

Question of whether or not allocating a cache block on a write miss is not straightforward, not allocating it conserves cache space, but allocating it will combine writes and is simpler despite requiring the transfer of the whole cache block.

12.1 Associative Caches

Associative caches are an alternative to directly mapped caches, rather than having one-to-map mapping, n-way associative

caches, there are n possible locations for the data in the cache.

On a cache miss, there are multiple strategies, Eviction/Replacement Policy replaces any invalid block first otherwise a random, FIFO or least recently used, etc.

Cache Performance - January 22, 2021

Cache size is a consideration on cache performance, larger sized caches provide better temporal locality, but it increases latency, on the other hand a smaller cache will not be able to exploit temporal locality well.

Likewise block size has a similar effect, except on the spatial locality when small and less temporal locality exploitation when too large, too small blocks also cause a larger tag overhead, and too large blocks cause a waste of cache space and bandwidth/energy if the spatial locality is not high.