

## RESPOND TO RESTRICTION DEVIATION ALERT



QUICK REFERENCE GUIDE (QRG)

## **Helpful Hints**


- **Restrictions Deviations** are created on an hourly basis and are used to record a reason as to what conditions are limiting the site from achieving a particular production target.
- Operators can only respond to a Deviation Alert from their current shift, while Shift Supervisors can respond to any alert. If you don't have access to respond contact your site administrator.
- Possible Deviation Alerts include:
  - Negative Deviation YELLOW ♠ (current shift) or RED ♠ (late with no response) status.
  - Responded Deviation GREEN
  - Positive Deviation GREEN

## **Procedure**



- 1. On the navigation pane, click on the Restrictions icon Restrictions to navigate to the Restrictions screen.
- 2. Click on the **Deviation Alerts** tab Deviation Alerts (located on the top of your screen) to select it.
- 3. Select a **Deviation Alert** from the grid and click on the **Respond** toolbar Response window.

4. Click on Add... button to record a reason and assign an amount. Once the **Reason Code Assignment** window is displayed complete the fields as required.



- a) Select an item from the location list that you wish to assign a reason code to.
- b) Select the current Plant State at the time the condition occurred.
- c) Select one of the available Reason Code for the item you've selected in the tree.
- d) Enter the Amount to Assign to this reason code.
- 5. Click on **OK** to save your work and go back to the **Deviation Response** window.