OpenVera® Checker Library Reference Manual

Version C-2009.06 June 2009

Comments?
E-mail your comments about this manual to: vcs_support@synopsys.com.



Copyright Notice and Proprietary Information

Copyright © 2008 Synopsys, Inc. All rights reserved. This software and documentation contain confidential and proprietary information that is the property of Synopsys, Inc. The software and documentation are furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. No part of the software and documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Synopsys, Inc., or as expressly provided by the license agreement.

Right to Copy Documentation

The license agreement with Synopsys permits licensee to make copies of the documentation for its internal use only. Each copy shall include all copyrights, trademarks, service marks, and proprietary rights notices, if any. Licensee must assign sequential numbers to all copies. These copies shall contain the following legend on the cover page:

This document is duplicated with the permiss	sion of Synopsys,	Inc., for th	ne exclusive	use of
and	l its employees. Ti	his is copy	number	"

Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

Disclaimer

SYNOPSYS, INC., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Registered Trademarks (®)

Synopsys, AMPS, Cadabra, CATS, CRITIC, CSim, Design Compiler, DesignPower, DesignWare, EPIC, Formality, HSIM, HSPICE, iN-Phase, in-Sync, Leda, MAST, ModelTools, NanoSim, OpenVera, PathMill, Photolynx, Physical Compiler, PrimeTime, SiVL, SNUG, SolvNet, System Compiler, TetraMAX, VCS, Vera, and YIELDirector are registered trademarks of Synopsys, Inc.

Trademarks (TM)

AFGen, Apollo, Astro, Astro-Rail, Astro-Xtalk, Aurora, AvanWaves, Columbia, Columbia-CE, Cosmos, CosmosEnterprise, CosmosLe, CosmosScope, CosmosSE, DC Expert, DC Professional, DC Ultra, Design Analyzer, Design Vision, DesignerHDL, Direct Silicon Access, Discovery, Encore, Galaxy, HANEX, HDL Compiler, Hercules, Hierarchical Optimization Technology, HSIMplus, HSPICE-Link, iN-Tandem, i-Virtual Stepper, Jupiter, Jupiter-DP, JupiterXT-ASIC, Liberty, Libra-Passport, Library Compiler, Magellan, Mars, Mars-Xtalk, Milkyway, ModelSource, Module Compiler, Planet-PL, Polaris, Power Compiler, Raphael, Raphael-NES, Saturn, Scirocco, Scirocco-i, Star-RCXT, Star-SimXT, Taurus, TSUPREM-4, VCS Express, VCSi, VHDL Compiler, VirSim, and VMC are trademarks of Synopsys, Inc.

Service Marks (SM)

MAP-in, SVP Café, and TAP-in are service marks of Synopsys, Inc.

SystemC is a trademark of the Open SystemC Initiative and is used under license. ARM and AMBA are registered trademarks of ARM Limited. Saber is a registered trademark of SabreMark Limited Partnership and is used under license.

All other product or company names may be trademarks of their respective owners.

Contents

1.	Checker Library
	Conventions
	Coverage Properties
	Shared Syntax
	Functional Groups1-8Value Integrity1-8Temporal Sequence1-10
	Checker Descriptions
2.	OVL-Equivalent Checkers
	Converting from a Verilog OVL Library to OVA

Restrictions	2-4
Macro symbol ASSERT_OFF	2-5
Inlining OVA Units in a Verilog Wrapper Module	2-5
Using OVL-Equivalent Checkers with VHDL Designs	2-6
Descriptions of OVL-Equivalent OVA Checkers	2-6
assert_always	2-8
assert_always_on_edge	2-11
assert_change	2-15
assert_cycle_sequence	2-19
assert_decrement	2-21
assert_delta	2-22
assert_even_parity	2-24
assert_fifo_index	2-27
assert_frame	2-29
assert_handshake	2-31
assert_implication	2-33
assert_increment	2-34
assert_never	2-36
assert_next	2-37
assert_no_overflow	2-39
assert_no_transition	2-41
assert_no_underflow	2-43
assert_odd_parity	2-45
assert_one_cold	2-49
assert_one_hot	2-52
assert_quiescent_state	2-55

assert_range
assert_time 2-58
assert_transition 2-60
assert_unchange 2-62
assert_width 2-60
assert_win_change
assert_win_unchange
assert_window 2-70
assert_zero_one_hot

Index

1

Checker Library

The OpenVera Assertions Checker Library is a collection of temporal expressions and assertions intended for a variety of commonly needed tests. These checkers will enable you to significantly increase the speed of coding your own temporal assertions.

This chapter covers the following topics:

- Conventions Explains the basic syntax components of the checkers covered in this manual.
- Coverage Properties
- Shared Syntax Describes syntax elements shared among most of the checkers
- Functional Groups Lists and organizes all OVA checkers within functional groups.
- Checker Descriptions Provides syntax, descriptions, and examples for all standard OVA checkers.

Conventions

All OVA checkers described in this chapter are available in both unit and template form. The two forms have identical functions, however, their usage differs as follows:

- Use the unit form to bind checkers to a design
- Use the template form to build more complex checkers inside your own units

The unit form of a checker is distinguished from the template form by an "ova_" prefix. For example, "ova_bit" is the unit form and "bit" is the template form of the same checker. To simplify the descriptions, the checkers are referred to by their unit names unless only the template form is meant.

Units are the preferred way to inline assertions in your Verilog.

The following is an example of a one-hot check of signal a inlined within Verilog:

```
module m(a, b, clk)
input a, b, clk;
//ova bind ova_one_hot(1'b1, top.clk, a);
```

Coverage Properties

The checkers contain OVA assertions used in verification of the intended behavior (the original purpose of the checkers), and a large number of them also contain coverage properties that can be used to detect the occurrence of events related to the behavior, in particular such as triggering conditions and corner cases.

The coverage can be controlled globally by a macro symbol OVA_COVER_ON and locally on a per-instance basis using a parameter coverage level (See "Shared Syntax" on page 1-4.).

Note that you can also use \$ova tasks such as \$ova_stop, \$ova_start, \$ova_assertion_start, and \$ova_assertion_stop also to control cover properties locally by inserting them in your code.

The following checkers contain coverage statements:

Standard OVA Checkers

```
ova arbiter
                        ova asserted
ova bits
                        ova code distance
ova deasserted
                        ova driven
ova dual clk fifo
                        ova even parity
ova fifo
                        ova follows
ova hold
                        ova hold value
ova memory
                        ova mutex
ova next state
                        ova no contention
```

```
ova_one_hotova_overflowova_rangeova_req_ack_uniqueova_req_requiresova_stackova_timeoutova_valueova window
```

OVL-Equivalent Checkers

```
assert_always assert_always_on_edge
assert_change assert_even_parity
assert_odd_parity assert_one_cold
assert_one_hot assert_unchange
assert zero one hot
```

Shared Syntax

Many checkers share the same syntax elements. These elements are described in this section in order to avoid repeating their descriptions throughout this document.

Macro Symbols

The way checkers are used, whether for checking by assertions or coverage gathering or both, can be selected using two global 'define symbols:

OVA ASSERT OFF

When the symbol is **defined**, all assertions are **removed** from the checker. That is, when left undefined the behavior is backward compatible with earlier versions of the library.

OVA COVER ON

When the symbol is **defined**, the cover statements in the checkers are **included**.

Parameters and Ports

The following are shared ports and parameters of all the checkers.

en

Used as a scaler guard expression (port). This expression enables the start of a check. Default = 1 b1 (if en is not specified, it defaults to true).

Once the check starts, *en* can change without affecting the checker. The *en* scaler expression can be used to specify a not-a-reset situation or some other guard expression (potentially in combination with the reset expression in a complex boolean expression).

edge expr

Specifies the active edge for the clock signal (clk) in unit syntax. Use the following parameter values to specify the edge type:

- posedge: 0 (the default)
- negedge: 1
- edge: 2

If edge_expr is not specified, it defaults to posedge.

clk

Specifies the clock signal (port) on which inputs are sampled and the checks are performed. In unit syntax, give just the clock signal. The active edge is specified with <code>edge_expr</code>. In template syntax, use the full edge expression, as in <code>posedge m clk</code>.

msq

Specifies a quoted text string (parameter) that is printed to output when the checker's assertion fails. The default message is "assertion triggered". If the default message is used in a checker instantiation, the empty actual parameter can be omitted.

severity

Specifies the severity level (parameter) of the assertion, default is 0. This parameter can be used to group assertions used for a similar purpose, and provide a selection/filtering mechanism to enable/disable individual or groups of assertions.

category

Specifies the category of the assertion, default is 0. This parameter can be used to group assertions used for a similar purpose, and provide a selection/filtering mechanism to enable/ disable individual or groups of assertions.

Note also the following:

- The descriptions also give the names of the assertions used in the checkers. Use these names to identify the results of the checkers in the OVA reports. If a checker has more than one assertion, this information also identifies more exactly what succeeded or failed.
- In the unit form, all parameters are integers except for *msg*, which is a string. All ports are the logic type. Port widths are 1 bit unless otherwise indicated.

 All standard OVA checkers described in this chapter have severity, category, and coverage_level (if present at all) parameters as the the last items on the unit parameter list and the template argument list. Note that coverage properties are not available in the template form of the checkers.

coverage_level

Specifies which coverage levels should be enabled (provided that the symbol COVER_ON is defined.) The following levels are supported (default is 2):

Level 1: Basic coverage, implemented using cover statements. Used by simulation and Magellan.

Level 1 is enabled by setting bit 0 of coverage_level to 1.

Example: The number of Enqueues and Dequeues in a FIFO.

Level 2: This level is intended mainly for data coverage using cover groups in System Verilog. Since OVA does not support such constructs this level is absent in all but a few checkers where it is implemented using cover (property) statements.

Level 2 is enabled setting bit 1 of coverage_level to 1. This is the default level selected by this parameter (for compatibility with SVA checkers.)

Example: Inidividual bits in a vector asserted at-least once.

Level 3: Mostly cover statements for specific corner points as specified by parameters of the checker. Used primarily by formal tools as goals, but can be enabled in simulation too. These coverage items ensure that the corner case condition of the RTL/design block are verified during testing.

Level 3 is enabled setting bit 2 of coverage_level to 1.

Examples: The number of times FIFO reached HIGH water mark. The number of times ACK was received at the next clock after REQ was issued. The number of times the specified Min latency value was reached.

Functional Groups

This section lists all checkers according to functional groups. The following groups are included:

- Value Integrity
- State Integrity
- Temporal Sequence
- Protocol

Value Integrity

Value Integrity checkers check and verify that the values of objects (signals, etc.) are within the constraints and limitations specified. The checks are performed specifically to a single object and not with respect to other objects. The following checkers are included in this category:

```
ova_arith_overflowova_assertedova_bitsova_check_boolova_constova_deassertedova_decova_delta
```

ova_even_parityova_forbid_boolova_incova_mutexova_no_contentionova_odd_parityova_overflowova_rangeova_underflowova_value

State Integrity

State Integrity checkers ensure correct state transitions and correct value encodings of state variables. The following checkers are included in this category:

```
ova_code_distanceova_drivenova_multiport_fifoova_next_stateova_one_coldova_one_hotova_quiescent_stateova_tri_state
```

Temporal Sequence

Temporal Sequence checkers ensure the correct timing of events. The following checkers are included in this category:

```
ova_holdova_hold_valueova_reg_loadedova_sequenceova_timeoutova_window
```

Protocol

Protocol checkers ensure the correct ordering of events and values over time. These events and values normally involve two or more signals from the design. The following checkers are included in this category:

```
ova_arbiterova_data_usedova_dual_clk_fifoova_fifoova_followsova_memoryova_memory_asyncova_multiport_fifoova_no_contentionova_req_ack_uniqueova_req_requiresova_req_respova_stackova_valid_id
```

Checker Descriptions

This section provides syntax, descriptions, and examples for all standard OVA checkers.

Note: The severity and category parameters for these checkers can take defalt values as specified by the set_severity and set_category OVA commands.

ova_arbiter

Ensures that a resource arbiter provides grants to corresponding requests between the specified minimum and maximum number of clock cycles between a request and a grant.

Unit syntax:

```
ova_arbiter
#(no_chnl, bw_prio, grant_one_chk, fairness_chk,
   priority_chk, fifo_chk, min_lat, max_lat, edge_expr,
   msg, severity, category, coverage_level)
instance_name (en, clk, requests, priority, grants);
```

Template syntax:

```
arbiter(en, clk, requests, priority, bw_prio, grants,
no_chnl, grant_one_chk, fairness_chk, priority_chk,
fifo_chk, min_lat, max_lat, msg, severity, category);
```

Arguments

no chnl

The number of channels (bits) in requests and grants. Default = 2.

bw prio

The number of bits that are used to encode req_priority. Default = 1.

grant one chk

If true, then the unit will check to ensure that only one grant is issued per clock cycle. Default = 1.

fairness_chk, req_priority_chk, and fifo_chk Indicate which arbitration scheme is to be verified. These must be compile-time constants. If no arbitration scheme is asserted, no checks will be performed to verify the arbitration scheme.

fairness chk

If true, then this unit will ensure that no channel will be issued more than one grant while other channels have requests pending except if this is the only request at the highest $req_priority$ when $req_priority_chk$ is asserted. Default = 0.

req priority chk

If true, then this checker will ensure that grants are issued according to the priority indicated in the req_priority vector.

If 0 (disabled), then req_priority is not taken into account in any of the other checks. However, the argument priority must still have the correct dimension even though the actual values do not matter (e.g., pass vector of 0's). The $req_priority$ vector may be a design vector (i.e., not a constant array). However, while a request is being processed the $req_priority$ should not change, otherwise certain checks may produce incorrect results (success or failure). Default = 0.

fifo chk

If true, then this unit will ensure that grants are issued according to the order that their requests were received unless $req_priority_chk$ is asserted which means that the fifo check is performed only on requests of the current highest req_priority. Default = 0.

min lat

The minimum global grant latency. Default = 1.

If 0, then the grant is expected starting the same cycle as the request (i.e., combinational arbiter is possible with $max_lat = 0$). If priority arbitration check is enabled, then min_lat should be 0 or 1 only.

max lat

If $max_{lat} > 0$, it specifies the maximum global grant latency regardless of the selection criterion. That is, a persistent request must be granted within max_{lat} clock cycles. The check is useful in systems where a request must be granted within a certain latency even in the presence of other requests.

If $max_{lat} = 0$, the global latency check is disabled. Default = 0.

requests

Requests signals as vectors.

Vector of size [no_chnl-1:0] where the bits correspond to the corresponding channels in reqs . req is assumed to be 1 when active.

priority

A [bw_prio*no_chnl-1 : 0] bitvector of bw_prio*no_chnl bits formed by concatenating non-negative integer req_priority values corresponding to the request lines. The right-most bw_prio bits in req_priority corresponds to channel 0, etc. The req_priority value 0 is the lowest req_priority.

For the assertions in the checker to operate correctly, the *priority* assignments to the requests should remain constant over time. Otherwise, the assertions may report unwanted failures.

grants

Grants signals as vectors. Vector of size $[no_chnl-1:0]$ where the bits correspond to the corresponding channels in reqs. Assumed to be 1 when active.

Note the following:

- If min_lat is 0 then the grant is expected starting the same cycle as the request (that is, a combinational arbiter is possible with min_lat = 0).
- If min_lat > 0 and max_lat = 0 then the grant can arrive any time at or after the next clock cycle, that is, in [min_lat ..].

 Usually this is only possible when a priority arbiter is employed.
- The <code>fairness_chk</code>, <code>priority_chk</code>, and <code>fifo_chk</code> arguments indicate which arbitration scheme is to be verified. These must be compile-time constants. If no arbitration scheme is asserted, no checks are performed to verify the arbitration scheme.

Assumptions:

- FIFO and fairness checks should not normally be enabled at the same time because they may contradict each other.
- When $req_priority_chk = 0$ it is assumed that the req_priority vector is set to all 0 values.
- A grant is expected to be one clock cycle wide, unless the grant is for more than one consecutive request.

It is assumed that a request holds asserted until granted. It is assumed that a request is removed on the clock tick the grant is sampled, unless another request is immediately asserted. Its removal before a grant causes the grant to be cancelled, and this does cancel the check for a grant.

Report Message

This checker uses several assertions to cover different aspects and modes:

- Assertion ova_c_one_cycle_gnt[i] checks that, in position [i], the grant signal is deasserted on the next cycle.
- Assertion ova_c_req_granted[i] checks that, in position
 [i], the grant signal arrives within the specified latency.
- Assertion ova_c_granted_only_if_req[i] checks that, in position [i], there is no grant signal when there is no req signal.
- Assertion ova_c_highest_grant[i] checks that, for line [i], the granted request is that of the highest priority. This assertion is active only if priority chk is 1.
- Assertion ova_c_fifo_chk[i][j] checks if, on line [j], the
 grant is not asserted before the grant on line [i], while the
 requests came in the opposite order. This assertion is active only
 if fifo chk is 1.
- Assertion ova_f_two_active[i][j] checks that, although there are continuous requests on lines [i] and [j], the grant on line [i] does not arrive twice without a grant on line [j]. This assertion is active only if fairness_chk is 1.
- Assertion ova_c_single_grant checks that there is no more than one grant at the same time. This assertion is active only if grant_one_chk is 1.

Coverage modes

Level_1 (bit 0 set in coverage_level)

Cover cover_arbiter_req_granted counts the number of granted requests, for each channel

Cover cover_abandoned_req counts the number of abandoned request, for each channel

Level_3 (bit 2 set in coverage_level)

Cover cover_req_granted_exactly_after_min_lat indicates how many times the req-to-grant latency was exactly equal to the specified min_lat value.

Cover cover_req_granted_exactly_after_max_lat indicates how many times the req-to-grant latency was exactly equal to the specified max_lat value.

Examples

- Assume that there are two request and grant lines enabled all the time.
- Priority 0 and 1 encoded over one bit, for channel 0 and 1, respectively.
- Implement grant one chk, fairness chk, and priority chk.
- Require that a grant be issued within 2 to 5 clock cycles after the request.
- Coverage Level 1 enabled by default in the unit instance.

Unit:

```
bind module dut : ova_arbiter
  #(2, , , 1, 1, , 2, 5, 0, "Arbiter failed.")
arbiter inst(1'b1, clk, 2'b1 0, requests, grants);
```

Template:

```
arbiter ( , posedge clk, requests, , grants, , , 1,
      1, , 2, 5, "Arbiter failed.");
```

ova_arith_overflow

Checks that the value of a signal does not overflow the range of a specified target signal. An overflow occurs when the bits of exp that do not fit in the target signal have a non-zero value.

Note: You can use a four-state version of this checker. See Appendix A, Four-State OVA Checkers.

Syntax

Unit syntax:

```
ova_arith_overflow
#(target_bw, exp_bw, edge_expr, msg, severity, category)
instance_name (en, clk, target, exp);
```

Template syntax:

```
arith_overflow(en, clk, target, target_bw, exp, exp_bw, msg,
severity, category);
```

Arguments

```
target bw
```

Number of bits in the specifed target signal (target). Default = 1.

exp bw

Number of bits in the specified signal of interest (exp). Default = 1.

target

Signal that receives the signal of interest (exp).

The target port is optional. It is not currently used but might be in a future version. You can include target for readability, so that it is clear what the target signal is. exp

Signal of interest whose value is compared against the target signal (target).

Assumptions:

- Unsigned values only.
- The target and exp ports are vectors of descending range where the msb is the left-most bit.
- For the checker to have meaning, <code>target_bw</code> must have a value less than exp_bw and both must be greater than zero.
- The exp is assumed to have a size of [exp_bw 1 : 0] and target a size of [target_bw 1 : 0].

Report Message

In report messages, the assertion name is ova c arith oflow.

Examples

Note that the following examples:

- Ensure that the value on sigA, a 16-bit vector, fits on sigB, which has only eight bits.
- A message is returned when an overflow occurs.

Unit:

```
bind module dut : ova_arith_overflow sigAtoB
  #(8, 16, , "sigA overflowed sigB.")
oflo_inst (rst_n, clk, sigB, sigA);
```

Template:

ova_asserted

Once the specified start expression (start) evaluates as true, this checker makes sure that the signal under test (exp) is asserted (1 or true) until the stop expression (stop) evaluates true. Once the stop expression is true, the signal under test (exp) can be de-asserted. The check is performed on the active clock (clk) specification. The delay specification is the number of cycles after the start expression evaluates true before the signal under test (exp) will be asserted. The default value for delay is zero, meaning that the evaluation starts on the same clock tick that the start expression becomes true. The delay must be a non-negative integer.

Unit syntax:

```
ova_asserted
#(delay, edge_expr, msg, severity, category, coverage_level)
instance name (en, clk, exp, start, stop);
```

Template syntax:

```
asserted(en, clk, exp, start, stop, delay, msg, severity,
category);
```

Arguments

delay

The number of clock cycles after the start signal (start) is true and before the signal under test (exp) is asserted. Default = 0.

exp

Signal being tested.

start

Signal that marks the start of the window.

stop

Signal that marks the end of the window.

Report Message

In report messages, the assertion name is ova c asserted.

Coverage modes

```
Level_1 (bit 0 set in coverage_level)

Cover cover_num_of_start_events indicates how many
times start occurred.
```

Cover cover_num_of_matches indicates how many times exp remained true within the required interval from start plus delay to stop.

Example

If in burst mode, ensure that the burst control signal remains asserted starting 1 clock after burst mode is entered and ending after leaving burst mode. The default message is output on a failure. Coverage Level 1 is enabled in the unit instance.

Unit:

```
bind module dut : ova_asserted
  #(1, , , , , 1)
asserted_inst (rst_n, clk, burst, start, stop);
```

Template:

ova_bits

Checks that the value of the signal being tested (exp) falls between the specified minimum (min) and maximum (max) number of bits (inclusive) that are asserted or deasserted as indicated by the deasserted flag. To specify a single number and not a range, ensure that min == max. Make sure that min and max are non-negative integers and $min \leq max$.

Syntax

Unit syntax:

```
ova_bits
#(min, max, deasserted, exp_bw, edge_expr, msg, severity,
    category, coverage_level)
instance_name (en, clk, exp);
```

Template syntax:

```
bits(en, clk, exp, min, max, deasserted, msg, severity,
category);
```

Arguments

min

Minimum number of bits asserted or deasserted. Default = 1.

max

Maximum number of bits asserted or deasserted. Default = 1.

deasserted

If 1, checks for deasserted (0) bits. If 0, checks for asserted (1) bits. Default = 0.

exp_bw

The number of bits in $\langle \exp \rangle$. Default = 2.

exp

Signal being tested (it must be more than one bit wide.)

Report Message

In report messages, the assertion name is ova_c_bits.

Coverage modes

```
Level_1 (bit 0 set in coverage_level)

Cover cover_bits_exp_change indicates how many times
exp changed value.
```

Cover cover_bits indicates how many times the required behavior was matched on a change of exp value.

```
Level_3 (bit 2 set in coverage_level)

Cover cover_max_bits_asserted indicates how many times
the max number of bits was (de)asserted on a change of exp
```

Cover cover_min_bits_asserted indicates how many times the min number of bits was (de)asserted on a change of exp value.

Covers cover_bits_asserted[i] indicate how many times bit exp[i] was (de)asserted on a change of exp value.

Example

value.

The following examples ensure that state is one cold by counting the bits that are deasserted. Coverage Levels 1 and 3 are enabled in the unit instance.

Unit:

```
bind module dut : ova_bits one_cold
#(1, 1, 1, 8, 1, "Too many cold bits.", , ,5)
```

```
cold_inst_name (rst_n, clk, state);
```

Template:

ova_check_bool

Verifies that the specified expression is always true.

Syntax

Unit syntax:

```
ova_check_bool
#(edge_expr, msg, severity, category)
instance name (expr, clk);
```

Template syntax:

```
check bool(expr, msg, clk, severity, category);
```

Arguments

expr

Signal being tested.

Report Message

In report messages, the assertion name is cb.

Example

The following examples ensure that signal is always true.

Unit:

```
bind module dut : ova_check_bool
  #( , "sig is false.")
bool inst (sig, sysclk);
```

Template:

```
check bool (sig, "sig is false.", posedge sysclk);
```

ova_code_distance

Checks that when the specified signal (exp) changes, the number of bits that are different compared to exp2 fall within the specified minimum (min) and maximum (max) number of bits.

Syntax

Unit syntax:

```
ova_code_distance
#(min, max, bw, edge_expr, msg, severity, category,
   coverage_level)
instance name (en, clk, exp, exp2);
```

Template syntax:

```
code_distance(en, clk, exp, exp2, min, max, msg, severity,
category);
```

Arguments

min

The minimum number of bits that are different. Default = 1.

max

The maximum number of bits that are different. Default = 1.

bw

The number of bits in exp and exp2. Default = 2.

exp

Signal being tested.

exp2

Signal that that signal under test (exp) is compared to.

Report Message

In report messages, the assertion name is ova c code distance.

Coverage modes

```
Level_1 (bit 0 set in coverage_level)

Cover cover_exp_change indicates how many times exp value changed.
```

Cover cover_code_distance_match indicates how many time the code distance matched the requirements.

```
Level_3 (bit 2 set in coverage_level)

Cover cover_code_distance_eq_to_min indicates how
many times the code distance was exactly min bits.
```

Cover cover_code_distance_eq_to_max indicates how many times the code distance was exactly max bits.

Examples

Raw data response is checked against the selected likely response chosen via Hamming code correction to ensure that it is within the difference of 0 to 3 bits permitted by the code. The default message is output on a failure. Coverage Level 3 is enabled in the unit instance.

Unit:

```
bind module dut : ova_code_distance
  #(0, 3, 16, , , , , 4)
  check_hamming (rst_n, clk, raw_data, selected_match);
```

Template:

ova_const

Checks that the value of the signal being tested (exp) is always constant.

The check is performed only on the active clock (clk) edge (the signal being tested can glitch in between the specified clock edges without causing this check to fail).

Note: You can use a four-state version of this checker. See Appendix A, Four-State OVA Checkers.

Syntax

Unit syntax:

```
ova_const
#(bw, edge_expr, msg, severity, category)
instance name (en, clk, exp);
```

Template syntax:

```
const(en, clk, exp, msg, severity, category);
```

Arguments

bw

exp

The number of bits in the signal being tested (exp). Default = 1.

Signal being tested.

Report Message

In report messages, the assertion name is ova_c_const.

Examples

The following examples ensure that the local sync reset is not active when there is no global asynchronous reset. The default message is sent on a failure.

Unit:

```
bind module dut : ova_const no_running_rst
  (rst n, clk, sync rst n);
```

Template:

```
const no_running_rst (rst_n, posedge clk,
    sync_rst_n, );
```

ova_cover_bool

Collects information about when the mandatory argument expr is high, low, posedge or negedge as selected by the parameter cover kind and sampled by the clock.

Syntax

Unit syntax:

```
ova_cover_bool
#(edge_expr, msg, cover_kind, severity, category)
instance name (expr, clk);
```

Template syntax:

```
cover bool(expr, msg, clk, cover kind, severity, category);
```

Arguments

expr

Signal being tested.

```
cover kind
```

Specifies value at which to test *expr*.

$cover_kind$	Expression covered
0	expr == 1'b0
1	<pre>expr == 1'b1 (default)</pre>
2	posedge expr
3	negedge expr

ova_data_used

Checks that data from the source signal (src[sleft:sright]) appears in the desitination signal (dest[dleft:dright]) within the specified window. The window is specified as the number (start) of cycles from the specified time the trigger signal (trigger) is asserted until the specified number of cycles (finish) after the trigger signal is asserted.

Note: You can use a four-state version of this checker. See Appendix A, Four-State OVA Checkers.

Syntax

Unit syntax:

```
ova_data_used
#(sleft, sright, dleft, dright, start, finish, edge_expr,
msg, severity, category)
instance_name (en, clk, trigger, src, dest);
```

Template syntax:

```
data_used(en, clk, trigger, src, sleft, sright, dest, dleft,
dright, start, finish, msg, severity, category);
```

Arguments

```
sleft
```

The most significant bit of the source signal's (sxc) bit slice. Default = 1.

sright

The least significant bit of the source signal's (src) bit slice. Default = 0.

dleft

The most significant bit of the destination signal's (dest) bit slice. Default = 1.

dright

The least significant bit of the destination signal's (dest) bit slice. Default = 0.

start

The number of cycles after the trigger signal (trigger) asserts to start the window. Default = 1. Note that the specified number must be greater than zero.

finish

The number of cycles after the trigger signal (trigger) asserts to stop the window. Default = 1.

For an open-ended interval [start ..], set finish equal to zero.

trigger

Signal that is part of starting the window.

src

Source signal.

dest

Destination signal.

Report Message

In report messages, the assertion name is ova_c_data_used. When the assertion fails, the "offending" expression in the message might include "ova_v_src_value". This is an OVA variable that stores the original source signal (src) value.

Examples

The following examples ensure that the lower 18 bits of busAddr is the address value communicated to the memory chip, and that the memAddr transitions two cycles after adrStrb signals a good address value on busAddr and remains valid 5 cycles after adrStrb.

Unit:

```
bind module dut : ova_data_used addr_decode
  #(17, 0, 17, 0, 2, 5)
  (rst_n, clk, adrStrb, busAddr, memAddr);
```

ova_deasserted

Once the start expression (start) evaluates true, this checker makes sure that the signal being tested (exp) is deasserted (0 or false) until the stop expression (stop) evaluates true (excluding the clock tick when stop is true). The specified delay (delay) is the number of cycles after the start expression (start) evaluates true before the signal being test (exp) is deasserted. The specified delay must be a non-negative integer (it defaults to zero, meaning that the check starts on the same clock tick as when start expression (start) becomes true.

Syntax

Unit syntax:

```
ova_deasserted
#(delay, edge_expr, msg, severity,
   category, coverage_level)
instance name (en, clk, exp, start, stop);
```

Template syntax:

```
deasserted(en, clk, exp, start, stop, delay, msg, severity,
category);
```

Arguments

delay

The number of clock cycles after the start signal (start) goes true before the signal being tested (exp) is deasserted. Default = 0.

exp

Signal being tested.

start

Signal that marks the start of the window.

stop

Signal that marks the end of the window.

Report Message

In report messages, the assertion name is ova_c_deasserted.

Coverage modes

```
Level_1 (bit 0 set in coverage_level)

Cover cover_num_of_start_events indicates how many times start occurred.
```

Cover cover_num_of_matches indicates how many times exp remained deasserted within the required interval from start plus delay to stop.

Examples

The following example check that the wen line remains deasserted during a read. Coverage Level 1 is enabled in the unit instance.

Unit:

```
bind module dut : ova_deasserted
  #(0, , , , ,1)
no_wen_during_read (rst_n, clk, wen, start, stop);
```

ova dec

Checks that when the signal being tested (exp) changes value, the new value is always between the specifed minimum (min) and maximum (max) less than the previous value.

Note: You can use a four-state version of this checker. See Appendix A, Four-State OVA Checkers.

Syntax

Unit syntax:

```
ova_dec
#(min, max, bw, edge_expr, msg, severity, category)
instance_name (en, clk, exp);
```

Template syntax:

```
dec(en, clk, exp, min, max, msg, severity, category);
```

Arguments

min

The minimum change in value. Default = 1.

max

The maximum change in value. Default = 1.

bw

The number of bits in the signal being tested (exp). Default = 2.

exp

Signal being tested.

Report Message

In report messages, the assertion name is ova_c_dec.

Examples

The following examples ensure that the countdown timer is always decremented by 1.

Unit:

```
bind module dut : ova_dec countdown_check
  #(1, 1, 16, , "Countdown timer error.")
dec_inst(rst_n, clk, count);
```

ova_delta

Checks that when the signal being tested (exp) changes value, the new value is \pm the specified minimum (min) to maximum (max) change of the previous value. Both the specified minimum and maximum values must be positive integers.

Note: You can use a four-state version of this checker. See Appendix A, Four-State OVA Checkers.

Syntax

Unit syntax:

```
ova_delta
#(min, max, bw, edge_expr, msg, severity, category)
instance_name (en, clk, exp);
```

Template syntax:

```
delta(en, clk, exp, min, max, msg, severity, category);
```

Arguments

min

The minimum change in value. Default = 1.

max

The maximum change in value. Default = 1.

bw

The number of bits in the signal being tested (exp). Default = 2.

exp

Signal being tested.

Report Message

In report messages, the assertion name is ova c delta.

Examples

The following examples ensure that number of elements in the FIFO changes by only 1 from one clock to the next.

Unit:

```
bind module dut : ova_delta check_state_transition
  #(1, 1, 16, , "FIFO size changed wrong.")
  (rst_n, clk, fifo.elems);
```

ova_driven

Checks that all bits are driven (none are floating Z or X).

Syntax

Unit syntax:

```
ova_driven
#(bw, edge_expr, msg, severity, category, coverage_level)
instance name (en, clk, exp);
```

Template syntax:

```
driven(en, clk, exp, msg, severity, category);
```

Arguments

bw

The number of bits in the signal being tested (exp). Default = 2.

exp

Signal being tested.

Report Message

In report messages, the assertion name is ova c driven.

Coverage modes

```
Level_1 (bit 0 set in coverage_level)

Cover cover_exp_not_x_or_z indicates the number of times

exp was neither x nor z. Not usable with Magellan.
```

Examples

The following examples check that the on-chip bus is always driven. Coverage Level 1 is enabled.

Unit:

```
bind module dut : ova_driven
  #(8, 2, "On-chip bus has X or Z bits.", , ,1)
driven inst (rst n, clk, cbus);
```

ova_dual_clk_fifo

Implements a checker for a dual-clock, single in- and single out-port queue.

Syntax

Unit syntax:

```
ova_dual_clk_fifo
#(depth, elem_sz, hi_water_mark, enq_lat, deq_lat,
  oflow_chk, uflow_chk, value_chk, enq_edge_expr,
  deq_edge_expr, msg, severity, category, coverage_level)
instance_name
  (reset, enq_clk, enq, enq_data, deq_clk, deq, deq_data);
```

Template syntax:

```
dual_clk_fifo(reset, depth, hi_water_mark, elem_sz,
enq_clk, enq, enq_lat, enq_data, deq_clk, deq, deq_lat,
deq_data, oflow_chk, uflow_chk, value_chk, msg, severity,
category);
```

Arguments

depth

The maximum number of elements in the queue. Default = 2. The specified depth can be at most 2^{16} .

elem sz

The size of queue elements in bits. Default = 1.

```
hi water mark
```

If positive, then the depth of the queue after enqueue will be checked to see if hi water mark is reached. Default = 0.

eng lat

The number of specified cycles (enq_clk) between enq being asserted 1 and enq data being valid. Default = 0.

deq lat

The number of deq_{c1k} cycles between deq being asserted 1 and deq data being valid. Default = 0.

oflow chk

If 1, checks that queue does not overflow the maximum size given by the depth specification. Default = 1.

uflow chk

If 1, checks that queue is not empty before dequeuing data. Default = 1.

value_chk

If 1, checks that deq_{data} matches the data at the head of the queue. Default = 1.

eng edge expr

The active clock edge of $eng\ clk$. Default = 0.

deq edge expr

The active clock edge of $deg\ clk$. Default = 0.

reset

Initializes the queue to empty when set to 1. It is assumed that the specified value (reset) is synchronous and spans at least one clock period of both clocks.

enq clk

Clock signal for enqueue side.

enq

Set to 1 when data is being enqueued.

eng data

Data being enqueued.

 deq_clk

Clock signal for dequeue side.

deq

Set to 1 when data is being dequeued.

deq data

Data being dequeued.

When enq is asserted 1: If oflow_chk evaluates true, ensures that queue does not overflow the maximum size given in depth. The specified depth can be at most 2**16.

The enq_lat value is a compile-time non-negative integer constant that indicates the number of enq_clk cycles between enq being asserted 1 and enq_data being valid. At that point all enqueue data is dropped and further checking is disabled until dequeue occurs. If an enqueue and dequeue happen simultaneously then no overflow is reported.

If the specified <code>hi_water_mark</code> is a positive value, then the depth of the queue after enqueue will be checked to see if the <code>hi_water_mark</code> is reached. Once high water has been exceeded once, this check is disabled until the FIFO size falls below the mark again.

When the specified deq is asserted 1: If $uflow_chk$ evaluates true, ensures that queue was not empty (underflow). If a dequeue on empty is detected then the check is disabled until the next enqueue operation.

If $value_chk$ evaluates true, ensures that deq_data is the same as that at the head of the queue. The deq_lat specification is a compiletime non-negative integer constant that indicates the number of deq_clk cycles between deq being asserted and deq_data being valid.

If an enqueue and dequeue operations happen simultaneously on an empty queue, it is assumed that enqueue happens after dequeue. This means that if a queue is empty at the time of a simultaneous enqueue and dequeue, it will flag it as error if uflow chk is enabled.

If an enqueue and dequeue operations happen simultaneously on a full queue then the enqueue detects a full queue and reports an error if oflow chk is enabled.

Report Message

This checker uses several assertions to cover different aspects and modes:

- Assertion ova_f_fifo_dcq_overflow checks that enq is not issued while the FIFO is full.
- Assertion ova_f_fifo_dcq_underflow checks that the deq command is not issued while the FIFO is empty.
- Assertion ova_c_fifo_dcq_value_chk checks the integrity of values coming off the queue. This assertion is active only if value_chk is 1.
- Assertion ova_f_fifo_dcq_hi_water_chk checks that the FIFO is not filled above the high-water mark.

Coverage modes

Level_1 (bit 0 set in coverage_level)

Cover cover_number_of_enqs indicates the number an enqueues.

Cover cover_number_of_deqs indicates the number of dequeues.

Cover cover_enq_followed_eventually_by_deq indicates the number of times an enqueue was followed later by a dequeue.

```
Level_3 (bit 2 set in coverage_level)

Cover cover_fifo_hi_water_chk indicates how many times
the high water mark was reached on an enqueue.
```

Cover cover_number_of_empty indicates how many times empty was reached on dequeue.

Cover cover_number_of_full indicates how many times full was reached on enqueue.

Examples

The examples below specify the following:

- Will reset the queue when reset is 1 (must cover at least one posedge eclk and one negedge dclk)
- The number of elements in the FIFO is 10
- High-water mark is disabled by default, the data size is 16 bits
- All checks (overflow, underflow, and value) are enabled
- There is only the default message
- Coverage Levels 1 and 3 are enabled in the unit instance (coverage level = 5).

Unit:

```
bind module dut : ova_dual_clk_fifo
  #(10, 16, , , , , , 0, 1, , , ,5)
fifo_inst
  (reset, eclk, enqueue, data_in, dclk, dequeue, data_out);
```

```
dual_clk_fifo(reset, 10, , 16, posedge eclk, enqueue,
   , data_in, negedge dclk, dequeue, , data_out);
```

ova_even_parity

Checks that the value of the signal being tested (exp) always has an even number of bits set to 1. Usually the specified signal (exp) is formed by concatenating the data and parity bits.

Syntax

Unit syntax:

```
ova_even_parity
#(bw, edge_expr, msg, severity, category)
instance_name (en, clk, exp);
```

Template syntax:

```
even parity(en, clk, exp, msg, severity, category);
```

Arguments

bw

The number of bits in the signal being tested (exp). Default = 2.

exp

Signal being tested.

Report Message

In report messages, the assertion name is ova_c_even_parity.

Coverage modes

```
Level_1 (bit 0 set in coverage_level)

Cover cover_exp_change indicates how many times exp
changed value.
```

Examples

The following examples ensure data read from memory has even parity. Note that mdata includes both the data and the parity bits.

Unit:

```
bind module dut : ova_even_parity
  #(9, , "Parity error on mdata.")
parity_inst (rst_n, clk, mdata);
```

```
even_parity memory_data(rst_n, posedge clk, mdata,
   "Parity error on mdata.");
```

ova_fifo

Implements a checker for a single-clock, single in- and single outport queue. The width of the fifo elements is set using the parameter $elem_sz$, and the width of the head and tail pointers is set using ptr width.

Syntax

Unit syntax:

```
ova_fifo
#(depth, elem_sz, hi_water_mark, enq_lat, deq_lat,
    oflow_chk, uflow_chk, value_chk, pass_thru, edge_expr,
    msg, severity, category, coverage_level. ptr_width)
instance_name (reset, clk, enq, enq_data, deq, deq_data);
```

Template syntax:

```
fifo(reset, clk, depth, hi_water_mark, elem_sz, enq, enq_lat,
enq_data, deq, deq_lat, deq_data, oflow_chk, uflow_chk,
value_chk, pass_thru, msg, severity, category, ptr_width);
```

Arguments

depth

The maximum size of the queue. Default = 2. The specified depth can be at most 2^{16} .

```
elem sz
```

The size of queue elements in bits. Default = 1.

```
hi water mark
```

If positive, then the depth of the queue after enqueue will be checked to see if hi water mark is reached. Default = 0.

```
eng lat
```

The number of enq_clk cycles between enq being asserted 1 and enq_data being valid. Default = 0.

deq lat

The number of deq_{Clk} cycles between deq being asserted 1 and deq data being valid. Default = 0.

oflow chk

If 1, checks that queue does not overflow the maximum size given in depth. Default = 1.

uflow chk

If 1, checks that queue is not empty before dequeuing data. Default = 1.

value_chk

If 1, checks that deq_{data} matches the data at the head of the queue. Default = 1.

pass thru

Specifies behavior when enqueue and dequeue operations happen at the same time with an empty queue. If 0, dequeue happens first, triggering an underflow. If 1, enqueue happens first and the data is passed through. Default = 0.

reset

Initializes the queue to empty when set to 1. It is assumed that reset is synchronous and spans at least one clock period of both clocks.

enq

Set to 1 when data is being enqueued.

eng data

Data being enqueued.

dea

Set to 1 when data is being dequeued.

deq data

Data being dequeued.

ptr width

Width of the pointer. Default = 16.

reset asserted 1 initializes the queue to empty. All operations are synchronous to the clock (clk) ticks, including reset.

When enq is asserted 1: If oflow_chk evaluates true, ensures that queue does not overflow the max size given in depth. The specified depth can be at most 2**16.

The enq_{lat} is a compile-time non-negative integer constant that indicates the number of cycles between enq being asserted 1 and enq_{data} being valid. At that point all enqueue data is dropped and further checking is disabled until dequeue occurs. If an enqueue and dequeue happen simultaneously then no overflow is reported.

If hi_water_mark is a positive value, then the depth of the queue after enqueue will be checked to see if hi_water_mark is reached. Once high water has been exceeded once, this check is disabled until the FIFO size falls below the mark again. If $hi_water_mark = 0$ then the high-water mark check is disabled and only overflow is checked when the depth of the queue is exceeded (provided that $oflow_chk = 1$).

When deq is asserted 1: If $uflow_chk$ evaluates true, ensures that queue was not empty (underflow). If a dequeue on empty is detected then the check is disabled until the next enqueue operation.

If $value_chk$ evaluates true, ensures deq_data is the same as that at the head of the queue. The specified deq_lat is a compile-time non-negative integer constant that indicates the number of cycles between deq being asserted and deq_data being valid.

If an enqueue and dequeue operation happens simultaneously on an empty queue, then the behavior depends on the <code>pass_thru</code> argument to the checker instance (it must be a compile-time constant):

If $pass_thru = 0$ then the dequeue happens before enqueue, hence the empty condition is detected and reported and an underflow (provided that $uflow_chk = 1$). If $value_chk = 1$ then the value check fails.

If $pass_thru = 1$ then it is assumed that enqueue happens first and the data is immediately dequeued and compared with deq_data if $value_chk$ i s enabled. Also, there is no underflow error reported.

If the enqueue and dequeue operations happen simultaneously on a full queue then no overflow is reported and the new element is enqueued while the element at the head of the queue is dequeued without changing the size of the queue.

Report Message

This checker uses several assertions to cover different aspects and modes:

- Assertion ova_f_fifo_overflow checks that enq is not issued while the FIFO is full.
- Assertion ova_f_fifo_underflow checks that the deq command is not issued while the FIFO is empty (and no simultaneous enq with pass_thru enabled).
- Assertion ova_c_fifo_value_chk checks the integrity of values coming off the queue. This assertion is active only if value_chk is 1.
- Assertion ova_f_fifo_hi_water_chk checks that the FIFO is not filled above the high-water mark.

Coverage modes

Level 1 (bit 0 set in coverage level)

Cover cover_number_of_enqs indicates the number of enqueue operations.

Cover cover_number_of_deqs indicates the number of dequeue operations.

Cover cover_simultaneous_enq_deq indicates the number of simultaneous enqueue and dequeue operations.

Cover cover_enq_followed_eventually_by_deq matches whenever there is an enqueue followed eventually by a dequeue.

Level 3 (bit 2 set in coverage level)

Cover cover_fifo_hi_water_chk indicates how many time the high water mark was reached on an enqueue.

Cover cover_simultaneous_enq_deq_when_empty indicates how many times there were simultaneous enqueue and dequeue operations on an empty queue.

Cover cover_simultaneous_enq_deq_when_full indicates how many times there were simultaneous enqueue and dequeue operations on a full queue.

Cover cover_number_of_empty indicates how many times empty is reached on dequeue.

Cover cover_number_of_full indicates how many times empty is reached on enqueue.

Examples

The following examples specify the following:

 The FIFO is initialized anytime reset is 1 (synchronously with posedge clk)

- There are up to 10 elements in the fifo
- The high_water_mark is by default 0 (disabled)
- The size of the data is 16 bits, data_in is enqueued when enqueue is 1 with no latency
- The data_out specification must be equal to that at the head of the fifo when dequeue is 1 with latency
- The overflow, underflow and value checks are enabled with pass through when empty allowed
- Coverage Levels 1 and 3 are enabled (coverage level = 5).
- The default pointer width of 16 is selected.

Unit:

```
bind module dut : ova_fifo
  #(10, 16, , , , , , 1, , , , 5)
fifo_inst(reset, clk, enqueue, data_in, dequeue, data_out);
```

ova_follows

Checks that the follower expression (follower) evaluates true within the specified minimum min_lat and maximum max_lat latency period once the leader expression (leader) evaluates true. That is, the check for follower begins in the same clock as leader is true. Both the leader and follower trigger on their positive edges. If min_lat and $max_lat == 0$ (the defaults), then leader and follower are expected to be true in the same cycle.

Syntax

Unit syntax:

```
ova_follows
#(min_lat, max_lat, edge_expr, msg, severity,
   category, coverage_level)
instance name (en, clk, leader, follower);
```

Template syntax:

```
follows(en, clk, leader, follower, min_lat, max_lat, msg,
severity, category);
```

Arguments

min lat

Number of clock cycles between the leader signal (leader) going true and the beginning of the latency period. Default = 0.

max lat

Number of clock cycles between leader signal (leader) going true and the end of the latency period. Default = 0.

leader

Signal that precedes the follower signal (follower).

follower

Signal that follows the leader signal (leader).

Report Message

In report messages, the assertion name is ova_c_follows.

Coverage modes

```
Level_1 (bit 0 set in coverage_level)

Cover cover_num_of_leader_triggers indicates the number of times the leader triggered the evaluation.
```

Cover cover_num_of_matches indicates the number of matches of follower after the leader.

```
Level_3 (bit 2 set in coverage_level)

Cover cover_num_of_matches_exactly_on_min_lat indicates the number of times follower occurred exactly at min_lat clock cycles after leader.
```

Cover cover_num_of_matches_exactly_on_max_lat indicates the number of times follower occurred exactly at max lat clock cycles after leader.

Examples

The following examples ensure a req is always followed by a response from an arbiter arbitrating 2 users. Response must follow req within 1 to 6 clock ticks. Coverage Level 1 is enabled (coverage level = 1).

Unit:

```
bind module dut : ova_follows
  #(1, 6, , "Arbiter response 0 is late.", , ,1)
req0_resp0 (rst_n, clk, req[0], resp[0]);
bind module dut : ova follows
```

```
#(1, 6, , "Arbiter response 1 is late.", , ,1)
req1_resp1 (rst_n, clk, req[1], resp[1]);
```

```
follows req0_resp0(rst_n, posedge clk,
    posedge req[0], posedge resp[0], 1, 6,
    "Arbiter response 0 is late.");
follows req1_resp1(rst_n, posedge clk,
    posedge req[1], posedge resp[1], 1, 6,
    "Arbiter response 1 is late.");
```

ova_forbid_bool

Checks that the expression is never true.

Syntax

Unit syntax:

```
ova_forbid_bool
#(edge_expr, msg, severity, category)
(expr, clk);
```

Template syntax:

```
forbid bool(expr, msg, clk, severity, category);
```

Arguments

expr

Signal being tested.

Report Message

In report messages, the assertion name is cb.

Examples

The following examples ensure that sig is never true.

Unit:

```
bind module dut : ova_forbid_bool
  #( , "sig is true.")
  (sig, sysclk);
```

Template:

forbid_bool(sig, "sig is true.", posedge sysclk);

ova_hold

Checks that the value of the signal being tested (exp) remains constant for the minimum (min +1) to maximum (max) number of cycles. Both the minimum and maximum specifications default to zero, meaning that the signal being tested (exp) is to change on every clock cycle. A new check begins every time the signal being tested (exp) changes. If the maximum number of cycles (max) is specified, then the signal being tested (exp) must change within min +1 to max +1 cycles.

Note: You can use a four-state version of this checker. See Appendix A, Four-State OVA Checkers.

Syntax

Unit syntax:

```
ova_hold
#(min, max, bw, edge_expr, msg, severity,
  category, coverage_level)
instance name (en, clk, exp);
```

Template syntax:

```
hold(en, clk, exp, min, max, msg, severity, category);
```

Arguments

min

The minimum number of clock cycles (minus one) to hold the value. Default = 0.

max

The maximum number of clock cycles (minus one) to hold the value. Default = 0. For an open-ended interval [min ..], set max equal to zero and min greater than zero.

bw

The number of bits in the signal being tested (exp). Default = 1.

clk

The clock signal on which inputs are sampled and the checks are performed. In unit syntax, give just the clock signal. The active edge is specified with <code>edge_expr</code>. In template syntax, use the full edge expression, as in <code>posedge m clk</code>.

exp

Signal being tested.

Report Message

In report messages, the assertion name is ova c hold.

Coverage modes

Level 1 (bit 0 set in coverage level)

Cover cover_num_of_exp_changes indicates the number of times exp changed value.

Cover cover_num_of_matches indicates the number of matches of exp changing value within the specified interval.

```
Level 3 (bit 2 set in coverage level)
```

Cover cover_num_of_matches_exactly_on_min indicates the number of times exp changed exactly min clock cycles.

Cover cover_num_of_matches_exactly_on_max indicates the number of times exp changed exactly max clock cycles.

Examples

In the examples below, wen must be held for at least 3 cycles and is dropped after 7. Coverage Levels 1 and 3 are enabled (coverage level = 5).

Unit:

```
bind module dut : ova_hold
  #(3, 7, , , "wen hold time error.", , ,5)
hold_wen (en, clk, wen);
```

ova_hold_value

Checks that the signal being tested (exp) remains the value to hold (value) from the specified minimum (min) to maximum (max) number of cycles. That is, it must stay at value for min cycles, then it may change. After max cycles it must change to some other value.

Note: You can use a four-state version of this checker. See Appendix A, Four-State OVA Checkers.

Syntax

Unit syntax:

```
ova_hold_value
#(min, max, bw, edge_expr, msg, severity,
   category, coverage_level)
instance name (en, clk, exp, value);
```

Template syntax:

```
hold_value(en, clk, exp, value, min, max, msg, severity,
category);
```

Arguments

min

Minimum number of clock cycles to hold the value. Default = 0.

max

Maximum number of clock cycles to hold the value. Default = 0.

For an open-ended interval [min ..], set max equal to zero and min to greater than zero.

bw

The number of bits in the signal being tested (exp). Default = 2.

exp

Signal being tested.

value

Value to hold.

The check is triggered by a value change of the signal being tested (exp) to value. Both the minimum (min) and maximum (max) default to zero, meaning that exp is to equal value for one clock cycle.

Report Message

In report messages, the assertion name is ova_c_hold_value.

Coverage modes

Level 1 (bit 0 set in coverage level)

Cover cover_exp_change indicates the number of times exp changed to value.

Cover cover_num_of_matches indicates the number of matches of exp holding value within the specified interval.

Level 3 (bit 2 set in coverage level)

Cover cover_hold_value_exactly_for_min indicates the number of times exp held value exactly for min clock cycles.

Cover cover_hold_value_exactly_for_min indicates the number of times exp held value exactly for max clock cycles.

Examples

The following examples specify that the address must be held for at least 3 cycles, but not more than 5 cycles after it has the value 4'hff00. Coverage Level 1 is enabled (coverage level = 1).

Unit:

```
bind module dut : ova_hold_value
    #(3, 5, 16, , , , 1)
hold_address (en, clk, bus_addr[15:0], 4'hff00);
```

ova_inc

Checks that when the signal being tested (exp) changes value, the new value is always between the specified minimum (min) and maximum (max) more than the previous value.

Note: You can use a four-state version of this checker. See Appendix A, Four-State OVA Checkers.

Syntax

Unit syntax:

```
ova_inc
#(min, max, bw, edge_expr, msg, severity, category)
(en, clk, exp);
```

Template syntax:

```
inc(en, clk, exp, min, max, msg, severity, category);
```

Arguments

min

The minimum change in value. Default = 1.

max

The maximum change in value. Default = 1.

bw

The number of bits in the signal being tested (exp). Default = 2.

exp

Signal being tested.

Report Message

In report messages, the assertion name is ova c inc.

Examples

The following examples ensure counter is always incremented by 1 or 2.

Unit:

```
bind module dut : ova_inc check_counter
  #(1, 2, 8, , "Counter incremented wrong.")
  (en, clk, count);
```

ova_memory

Checks the integrity of synchronous memory contents and accesses.

Syntax

Unit syntax:

Template syntax:

```
memory(data_bits, addr_bits, start_addr, end_addr, mem_sz,
ren, raddr, rclk, rdata, wen, waddr, wclk, wdata, addr_chk,
init_chk, conflict_chk, pass_thru, read1_chk, write1_chk,
value_chk, msg, severity, category);
```

Arguments

```
Number of bits in the data. Default = 1.
```

addr_bits
Number of bits in the addresses. Default = 1.

mem sz

The number of words in the memory. Default = 2. The <code>end_addr</code> - <code>start addr</code> + 1 must be less than or equal to <code>mem sz</code>.

```
addr chk
```

If 1, checks that address is valid. Default = 1.

init chk

If 1, checks that addresses read have been previously written. Default = 1.

conflict chk

If 1, checks that simultaneous reading and writing of the same address does not occur. Default = 0.

This check should only be enabled when rclk == wclk. When the two clocks are different the conflict check does not make much sense.

pass thru

Specifies behavior when read and write happen at the same time on the same address. If 0, read gets the old data before the write. If 1, read gets the new data after the write. Default = 0.

read1 chk

If $\overline{1}$, checks that an address has at most one read between writes. Default = 0.

write1 chk

If 1, checks that an address is read at least once before it is overwritten. Default = 0.

value chk

If $\overline{1}$, checks that the value read from an address is the value that was written to that address. Default = 0.

w edge expr

The active clock edge of wc1k. Default = 0.

r_edge_expr

The active clock edge of rclk. Default = 0.

start_addr

Starting address of the memory.

end addr

Ending address of the memory.

ren

Read enable.

raddr

Read address.

rclk

Read clock.

rdata

Read data.

wen

Write enable.

waddr

Write address.

wclk

Write clock.

wdata

Write data.

When $addr_chk$ evaluates true, ensures that $start_addr \le raddr \le end_addr$ when ren is true, and that $start_addr \le waddr \le end_addr$ when wen is true. All other checks apply only if the address is valid. Therefore, we recommend that $addr_chk$ be enabled.

When *init_chk* evaluates true, ensures that addresses read have been previously written.

When *value_chk* evaluates true, ensures that the value read from an address is the value that was written to that address.

A read/write conflict occurs when a read operation occurs simultaneous with a write operation on the same address. When a conflict occurs, a read is assumed to happen before a write in the same cycle.

When $conflict_chk$ evaluates true, ensures that simultaneous reading and writing of the same address does not occur. This check should only be enabled when rclk == wclk. When the two clocks are different the conflict check does not make much sense.

The $pass_thru$ specification defines the behavior of the memory when a read and write occur simultaneously on the same address. When $pass_thru = 0$ then the read operation obtains the old data (before the write takes place). If $pass_thru = 1$, then the read operation gets the new value written in memory. Note that this option has effect only when $value_chk$ or $init_chk$ are enabled. Furthermore, $pass_thru$ should only be enabled when rclk = wclk and $conflict_chk = 0$.

When <read1_chk> evaluates true, ensures that an address has at most one read in between writes.

When write1_chk evaluates true, ensures that an address is read at least once before it is over-written by different data.

Separate read and write port RAMs are naturally supported. For single-port R/W RAMs, simply associate the same actuals with the appropriate parameters. For single clock synchronous RAMs, provide the same clock edge parameter for both rclk and wclk.

The parameters $data_bits = number of bits in the data, addr_bits = number of bits in the addresses, <math>start_addr = first address$, $end_addr = last address$, and $mem_sz = number of words$, are compile-time constant values which describe the layout of the memory. Note that $end_addr - start_addr + 1$ must be less than or equal to mem_sz .

Report Message

This checker uses several assertions to cover different aspects and modes:

- Assertion ova_c_mem_init checks that the memory address is initialized before reading or that there is a simultaneous read and write with pass-through allowed. When the assertion fails, the "offending" expression in the message might include "ova_v_mem_addr_init [temp_raddr]". This is an OVA variable holding a record of which addresses have been written.
- Assertion ova_c_mem_waddr_chk checks that the write address is within the limits when wen is asserted.
- Assertion ova_c_mem_raddr_chk checks that the read address is within the limits when ren is asserted.
- Assertion ova_c_mem_conflict_chk checks that, when conflict_check is asserted and there is a simultaneous read and write, the addresses are not the same.
- Assertion ova_c_mem_read1_chk checks that when read1_chk
 is asserted, the address is read only once before being
 overwritten. When the assertion fails, the "offending" expression
 in the message might include
 - "ova_v_mem_read1_flags[temp_raddr]" and
 "ova_v_mem_write1_flags[temp_raddr]". These are OVA
 variables holding a record of which addresses have been read
 and written.

Assertion ova_c_mem_write1_chk checks that, when write1_chk is asserted, the address is read at least once before being overwritten. When the assertion fails, the "offending" expression in the message might include

```
"Ova_v_mem_addr_init[temp_waddr]",
"ova_v_mem_read1_flags[temp_waddr]", and
"ova_v_mem_write1_flags[temp_waddr]". These are OVA
variables holding a record of which addresses have been read
and written.
```

Assertion ova_c_mem_val_chk checks the behavior of the memory when a read and write occur simultaneously on the same address. The check is according to the value of pass_thru. When the assertion fails and pass_thru is 0, the "offending" expression in the message might include

"ova_v_mem_mirror[temp_raddr]". This is an OVA variable holding a mirror of what is written in the memory (the old data).

Coverage modes

Level 1 (bit 0 set in coverage level)

Cover cover_number_of_reads indicates the number of read operations to any address.

Cover cover_number_of_writes indicates the number of write operations to any address.

Cover write_followed_by_read indicates how many times a write was followed by a read to the same address.

```
Level_3 (bit 2 set in coverage_level)

Cover
```

cover_two_or_more_writes_without_intervening_re ad indicates how many times two writes occurred to the same (any) address without an intervening read operation to that address.

Cover

cover_two_or_more_reads_without_intervening_write indicates how many times two reads occurred to the same (any) address without an intervening write operation to that address.

Cover simultaneous_read_and_write_to_same_addr indicates how many times (quasi)simultaneous read and write operations occurred to the same (any) address as seen by the read clock rclk.

Cover

simultaneous_read_and_write_to_different_addr how many times (quasi)simultaneous read and write operations occurred to the different addresses as seen by the read clock rclk.

Cover read_to_start_addr indicates how many read operations occurred to the address start addr.

Cover write_to_start_addr indicates how many write operations occurred to the address start addr.

Cover read_to_end_addr indicates how many read operations occurred to the address end addr.

Cover write_to_end_addr indicates how many write operations occurred to the address end_addr.

Cover write_followed_by_read_to_start_addr indicates how many write operations were followed by a read to the address start addr.

Cover write_followed_by_read_to_end_addr indicates how many write operations were followed by a read to the address end addr.

Examples

The following examples do the following:

- Memory accesses are checked with data and address width of 16 bits
- The low address bound is 0
- The high address bound is 16'h0fff
- The memory size is 2**12 = 16'h1000
- The same clock is used for read and write,
- The addr_chk and init_chk specifications are enabled by default
- The conflict_chk and pass_thru specifications are enabled
- The read1_chk and write1_chk specifications are disabled by default
- The value chk is enabled.
- Coverage Levels 1 and 3 are enabled in the unit instance (coverage level = 5).

Unit:

```
memory(16, 16, 16'h0000, 16'h0fff, 16'h1000, ren,
   addr, posedge clk, rdata, wen, addr, posedge clk,
   wdata, , , 1, 1, , , 1);
```

ova_memory_async

Checks the integrity of asynchronous memory contents and accesses.

Syntax

Unit syntax:

```
ova_memory_async
#(data_bits, addr_bits, mem_sz, addr_chk, init_chk,
read1_chk, write1_chk, value_chk, msg, severity, category)
(start_addr, end_addr, ren, raddr, rdata, wen, waddr, wdata);
```

Template syntax:

```
memory_async(data_bits, addr_bits, start_addr, end_addr,
mem_sz, ren, raddr, rdata, wen, waddr, wdata, addr_chk,
init_chk, read1_chk, write1_chk, value_chk, msg, severity,
category);
```

Arguments

```
data bits
```

Number of bits in the data. Default = 1.

```
addr bits
```

Number of bits in the addresses. Default = 1.

```
mem sz
```

The number of words in the memory. Default = 2. Note that $end \ addr - start \ addr + 1$ must be less than or equal to $mem \ sz$.

addr chk

If 1, checks that address is valid. Default = 1.

init chk

If 1, checks that addresses read have been previously written. Default = 1.

read1 chk

If 1, checks that an address has at most one read between writes. Default = 0.

write1 chk

If 1, checks that an address is read at least once before it is overwritten. Default = 0.

value chk

If $\overline{1}$, checks that the value read from an address is the value that was written to that address. Default = 0.

start addr

Starting address of the memory.

end addr

Ending address of the memory.

ren

Read enable.

raddr

Read address.

rdata

Read data.

wen

Write enable.

waddr

Write address.

wdata

Write data.

When $addr_chk$ evaluates true, ensures that $start_addr \le raddr \le end_addr$ as sampled by the negedge of ren, and that $start_addr \le waddr \le end_addr$ as sampled by the negedge of wen. There is thus no clock other than the ren and wen signals that indicate when each

operation is to take place by their falling edges. If negative ren and wen assert is desired, just pass a complement of the design signals as the actual arguments.

Note:

All sampling is done "before" the ren and wen falling edges at t-1.

All other checks apply only if the address is valid. Therefore, we recommend that addr_chk be enabled.

When *init_chk* evaluates true, ensures that addresses read have been previously written.

When *value_chk* evaluates true, ensures that the value read from an address is the value that was written to that address.

A read/write conflict occurs when a read operation occurs simultaneously with a write operation on the same address. When a conflict occurs, a read is assumed to happen before a write in the same cycle. There is however no conflict check, because in asynchronous read and write this condition is bound to happen and the check is meaningless. If the exclusion is actually required because ren and wen are derived from some synchronous signals, the mutual exclusion over these signals can be verified separately using the ova_mutex checker, for instance.

When read1_chk evaluates true, ensures that an address has at most one read in between writes.

When write1_chk evaluates true, ensures that an address is read at least once before it is over-written by different data. A write is considered to have occurred even when the value did not change.

Separate read and write port RAMs are naturally supported. For single port R/W RAMs, simply associated the same actuals with the appropriate parameters.

The parameters $data_bits = number of bits in the data, addr_bits = number of bits in the addresses, <math>start_addr = first address$, $end_addr = last address$, and $mem_sz = number of words$, are compile-time constant values which describe the layout of the memory. Note that $end_addr - start_addr + 1$ must be less or equal to mem_sz .

Report Message

This checker uses several assertions to cover different aspects and modes:

- Assertion ova_c_mem_async_init checks that the memory address is initialized before reading. When the assertion fails, the "offending" expression in the message might include "ova_v_mem_async_addr_init[temp_raddr]". This is an OVA variable holding a record of which addresses have been written. This assertion is active only if init chk is 1.
- Assertion ova_c_mem_async_waddr_chk checks that the write address is within the limits just before negedge of wen. This assertion is active only if addr_chk is 1.
- Assertion ova_c_mem_async_raddr_chk checks that the read address is within the limits just before negedge of ren. This assertion is active only if addr_chk is 1.

- Assertion ova_c_mem_read1_chk checks that the address is read no more than once before being overwritten. When the assertion fails, the "offending" expression in the message might include "ova_v_mem_async_read1_flags[temp_raddr]" and "ova_v_mem_async_write1_flags[temp_raddr]". These are OVA variables holding a record of which addresses have been read and written. This assertion is active only if read1_chk is 1.
- Assertion ova_c_mem_async_write1_chk checks that the address is read at least once before being overwritten. When the assertion fails, the "offending" expression in the message might include "ova_mem_async_addr_init[temp_waddr]", "ova_v_mem_async_read1_flags[temp_waddr]", and "ova_v_mem_async_write1_flags[temp_waddr]". These are OVA variables holding a record of which addresses have been read and written. This assertion is active only if write1_chk is 1.
- Assertion ova_c_mem_async_val_chk checks that the value read from an address is the value that was written to that address. When the assertion fails, the "offending" expression in the message might include "ova_v_mem_async_mirror[temp_raddr]". This is an OVA variable holding a mirror of what is written in the memory. This assertion is active only if value_chk is 1.

Examples

The examples below specify the following:

- Memory accesses are to be checked with data and address width of 16 bits
- The low address bound is 0
- The high address bound is 16'h0fff

- The memory size is 2**12 = 16'h1000
- addr_chk and init_chk are enabled by default
- read1_chk and write1_chk are enabled
- value chk is enabled.

Unit:

```
bind module dut : ova_memory_async
  #(16, 16, , , 1, 1, 1)
  (16'h0000, 16'h0fff, 16'h1000, ren, addr, rdata,
    wen, addr, wdata);
```

```
memory_async(16, 16, 16'h0000, 16'h0fff, 16'h1000, ren, addr, rdata, wen, addr, wdata, , , 1, 1, 1);
```

ova_multiport_fifo

Implements a checker for a single-clock, multi-port in- and multi-port out queue.

Unit Syntax:

```
ova_multiport_fifo
#(depth, elem_sz, no_ports, hi_water_mark, enq_lat, deq_lat,
oflow_chk, uflow_chk, value_chk, pass_thru, edge_expr, msg,
severity, category)
(reset, clk, enq, enq data, deq, deq data);
```

Template Syntax:

```
multiport_fifo(reset, clk, depth, hi_water_mark, elem_sz,
no_ports, enq, enq_lat, enq_data, deq, deq_lat, deq_data,
oflow_chk, uflow_chk, value_chk, pass_thru, msg, severity,
category);
```

reset

Asserted 1 initializes the queue to empty. All operations are synchronous to c1k ticks, including reset.

```
enq and deq
```

Bit vectors of equal size no_ports . Each pair of corresponding bits in these vectors defines the enqueue and dequeue signals for a port. Their priority is such that bit 0 is the lowest priority and the highest order bit, no_ports -1, is the highest priority. That is, the enqueue port and the dequeue port of the highest priority are processed at every clk tick.

eng data

A 2-D array of data. It is assumed that it is dimensioned as $[elem_size-1:0]$ enq_data $[0:no_ports-1]$. Any time a bit in enq is asserted 1, the corresponding data element in enq_dat must be valid after enq_lat clock cycles. Only the highest priority data is actually enqueued.

eng lat

A compile-time, non-negative integer constant that indicates the number of cycles between *enq* being asserted 1 and *enq_data* being valid in the corresponding position.

oflow chk

When a enq is asserted 1: If oflow_chk evaluates true, ensures that queue does not overflow the maximum size given in depth. The depth can be at most 2**16.

hi water mark

If hi_water_mark is a positive value, then the depth of the queue after enqueue will be checked to see if hi_water_mark is reached. Once high water has been exceeded once, this check is disabled until the FIFO size falls below the mark again. If $hi_water_mark = 0$ then the high-water mark check is disabled and only overflow is checked when the depth of the queue is exceeded (provided that $oflow_chk = 1$).

deq data

A 2-D array of data. It is assumed that it is dimensioned as [elem_size-1:0] deq_data [0:no_ports-1]. Whenever a bit in deq is asserted 1, the corresponding data value must be available on deq_data in the corresponding position delayed deq_lat clock cycles. The number of elements in deq_data and enq_data must be the same as the number of bits in eng and deq.

deq lat

A compile-time non-negative integer constant that indicates the number of cycles between when deq is asserted and deq_data is valid.

uflow chk

If this evaluates true, it ensures that the queue is not empty (underflow) when a deq bit is asserted. If a dequeue on empty is detected then the check is disabled until the next enqueue operation.

value chk

If this evaluates true, it ensures deq_data as selected by the same position as the highest priority The deq bit is the same as that at the head of the queue.

pass thru

If an enqueue and dequeue operation happens simultaneously on an empty queue, then the behavior depends on the pass_thru argument to the checker instance (it must be a compile-time constant).

If $pass_thru = 0$ then the dequeue happens before enqueue, hence the empty condition is detected and reported, and an underflow (provided that $uflow_chk = 1$). If $value_chk = 1$ then the value check fails.

If $pass_thru = 1$ then it is assumed that enqueue happens first and the data is immediately dequeued and compared with deq_data if $value_chk$ is enabled. Also, there is no underflow error reported.

If an enqueue and dequeue operation happens simultaneously on a full queue then no overflow is reported and the new element is enqueued while the element at the head of the queue is dequeued without changing the size of the queue.

Defaults

```
depth = 2
   Maximum number of elements in the queue is 2.
elem_sz = 1, no_ports = 2
   Number of channels or ports.
hi_water_mark = 0
   High-water mark check disabled.

oflow_chk = 1
   Overflow check enabled.
```

```
uflow chk = 1
```

Underflow check enabled.

```
value\_chk = 1
```

Checking of dequeued data enabled.

```
pass thru = 0
```

Simultaneous enqueue and dequeue on empty reports underflow.

```
enq lat = 0
```

Enqueue data at the same time as <enq> asserted.

```
deq lat = 0
```

Dequeue data checked at the same time as deg asserted.

Report Message

This checker uses several assertions to cover different aspects and modes:

- Assertion ova_f_fifo_overflow checks that enq is not issued while the FIFO is full.
- Assertion ova_f_fifo_underflow checks that when the deq command is issued, the FIFO is not empty.
- Assertion ova_c_fifo_value_chk checks that the integrity of values coming off the queue. This assertion is active only if value_chk is 1.
- Assertion ova_f_fifo_hi_water_chk checks that the FIFO is not filled above the high-water mark.

Example

The following examples check that the FIFO is initialized anytime reset is 1 (synchronously with posedge clk), there are up to 10 elements in the FIFO, $high_water_mark$ is by default 0 (disabled), the size of the data is 16 bits, there are two channels (enqueue and dequeue are 2 bits wide, data in and data out

are arrays of two 16-bit words), data_in[i] is enqueued when enqueue[i] is 1 with no latency, data_out[i] must be equal to that at the head of the fifo when dequeue[i] is 1 with no latency, and overflow, underflow and value checks are enabled with pass through when empty allowed.

Unit:

```
bind module dut : ova_multiport_fifo
  #(10, 16, , , , , , , 1)
  (reset, clk, enqueue, data_in, dequeue, data out);
```

```
multiport_fifo(reset, posedge clk, 10, ,16 , ,
    enqueue, , data in, dequeue, , data out, , , , 1 );
```

ova_mutex

Checks that the specified signals (a) and (b) never evaluate true at the same time.

Syntax

Unit syntax:

```
ova_mutex
#(edge_expr, msg, severity, category, coverage_level)
instance name(en, clk, a, b);
```

Template syntax:

```
mutex(en, clk, a, b, msg, severity, category);
```

Arguments

Arguments

First signal being tested.

b

Second signal being tested.

Report Message

In report messages, the assertion name is ova_c_mutex.

Coverage modes

```
Level_1 (bit 0 set in coverage_level)

Cover cover_changes_on_a indicates how many times a changed value.
```

Cover cover_changes_on_b indicates how many times b changed value.

Examples

The following examples ensure that reading and writing are not enabled at the same time. The check is always enabled by default. Coverage Level 1 is enabled in the unit instance (coverage_level = 1).

Unit:

```
bind module dut : ova_mutex read_write
  #(, "Read and write enables asserted at same time.", , , 1)
  mutex inst (1'b1, clk, ren, wen);
```

ova next state

Checks that when the signal being tested (exp) is in the specified current state (cs) it will transition to one of the specified legal next states.

Syntax

Unit syntax:

```
ova_next_state
#(no_ns, width, min_hold, max_hold, disallow, edge_expr,
  msg, severity, category, coverage_level)
  instance name (en, clk, exp, cs, ns);
```

Template syntax:

```
next_state(en, clk, exp, cs, no_ns, ns, min_hold, max_hold,
disallow, msq, severity, category);
```

Arguments

no ns

The number of legal next states possible from the specified current state ($_{CS}$). Default = 1.

width

The number of bits in the signal being tested (exp), the current state (cs), and each element of a bitvector of the concatenated legal state values (ns). The vector is $ns[width * no_ns- 1:0]$. Default = 1.

min hold

The minimum number of clock ticks the signal being tested (exp) must hold at the current state (cs) value. Default = 1.

max hold

The maximum number of clock ticks the signal being tested (exp) can hold at the the current state (cs) value. Default = 0.

disallow

If 1, checks that the signal being tested (exp) does *not* transition to any of the values in a specified array of legal states (ns). Default = 0. If 0, the checker makes sure that a transition to one of the states occurs.

exp

Signal being tested.

CS

The current state. The check starts when exp = cs (and en = 1).

ns

A bitvecor of concatenated legal states that exp can transition to from cs.

Note the following:

- max_hold indicates the maximum number of clock ticks the signal being tested (exp) may hold at the current state (cs) value.
- $min_hold = max_hold = 1$ indicates that the signal being tested (exp) changes to the next value on the next clock tick.
- min_hold = m, max_hold = 0 indicates that the signal being tested
 (exp) must hold the current state value (cs) for at least m clock
 ticks, no upper bound on when it must change.
- min_hold = m, max_hold = n indicates that the signal being tested
 (exp) must hold the current state value (cs) for at least m clock
 ticks and must advance to the next value within n ticks.

Report Message

This checker uses two assertions to cover different modes:

- Assertion ova_c_next_state checks for a transition to an allowed state during the hold time. This assertion is active only if disallow is 0.
- Assertion ova_f_next_state checks for no transition to a disallowed state during the hold time. This assertion is active only if disallow is 1.

Coverage modes

```
Level_1 (bit 0 set in coverage_level)
When disallow == 0:
```

Cover cover_exp_state_transitions indicates how many times a valid transition to a state in ns occurred.

```
When disallow == 1:
```

Cover cover_exp_state_transitions indicates how many times a transition to a state other than those in ns occurred.

```
Level_3 (bit 2 set in coverage_level)

Exists only when disallow == 0
```

Cover cover_exp_changes_to_ns[i] indicates how many times there was a transition from state cs to state ns[i].

Examples

The following examples verify that when $state_var$ takes on value 0, then on the next posedge clk, $state_var$ takes on one of the values 0, 2, or 4. Coverage levels 1 and 3 are enabled in the unit $(coverage_level = 5)$.

Unit:

ova_no_contention

Checks that bus signal being tested (bus) always has a single active driver and that there is no X or Z on the bus when driven. That is, that en_vector is not zero. The total number of en_vector bits that are asserted can be at most 1. Specify 0 for no minimum bus quiet time between bus transactions.

Syntax

Unit syntax:

```
ova_no_contention
#(min_quiet, max_quiet, bw_en, bw_bus, edge_expr, msg,
   severity, category, coverage_level)
  instance name (en, clk, en vector, bus);
```

Template syntax:

```
no_contention(en, en_vector, clk, bus, min_quiet, max_quiet,
msg, severity, category);
```

Arguments

```
min quiet
```

The minimum number of clock cycles between bus transactions. Default = 0.

max quiet

The maximum number of clock cycles between bus transactions. Default = 0.

bw en

The number of bits in en vector. Default = 2.

bw bus

The number of bits in the bus signal being tested (bus). Default = 2.

en vector

Enable signals for bus drivers as a vector.

bus

Bus signal being tested.

Report Message

This checker uses three assertions to cover different aspects:

- Assertion ova_c_no_xs checks that the bus does not have an x or z on any of its bits while at least one driver is enabled.
- Assertion ova_c_1_driver checks that there is no more than one driver enabled.
- Assertion ova_c_quiet_time checks that all drivers are disabled for the specified quiet time followed by only one driver being enabled.

Coverage modes

```
Level_1 (bit 0 set in coverage_level)

Cover cover_driver_enable indicates how many times bit
en vector[i] was set to 1 (enabled).
```

```
Level_3 (bit 2 set in coverage_level)
```

Cover

cover_no_contention_quiet_time_equal_to_min_quiet indicates how many times the observed quiet time is exactly equal to the specified min value.

Cover

cover_no_contention_quiet_time_equal_to_max_quiet indicates how many times the observed quiet time is exactly equal to the specified max value.

Examples

The following examples ensure that the bus is not multiply driven; it must have 2 cycles of quiet time in between transactions, but no more than 100 cycles of uninterrupted quiet time. Coverage Level 1 is enabled in the unit instance (coverage level = 1).

Unit:

```
bind module dut : ova_no_contention
  #(2, 100, 8, 8, , , , , 1)
  chip_bus_check
    (1'b1, clk, {chp0_oe, chp1_oe, chp2_oe, chp3_oe},
    data_bus);
```

```
no_contention chip_bus_check(
         {chp0_oe, chp1_oe, chp2_oe, chp3_oe},
         posedge clk, data bus, 2, 100);
```

ova_odd_parity

Checks that the value of the signal being tested (exp) always has an odd number of bits set to 1. Usually the signal (exp) is formed by concatenating the data and parity bits.

Syntax

Unit syntax:

```
ova_odd_parity
#(bw, edge_expr, msg, severity, category)
(en, clk, exp);
```

Template syntax:

```
odd parity(en, clk, exp, msg, severity, category);
```

Arguments

bw

The number of bits in the signal being tested (exp). Default = 2.

exp

Signal being tested.

Report Message

In report messages, the assertion name is ova c odd parity.

Examples

The following examples ensure data read from memory has odd parity. mdata contains the data bits and the parity bit.

Unit:

```
bind module dut : ova_odd_parity memory_data
#(9, , "Parity error on mdata.")
  (rst_n, clk, mdata);
```

ova_one_cold

Checks that only one bit is set to zero or, optionally, that all bits are set to 1 in the state value.

Syntax

Unit syntax:

```
ova_one_cold
#(strict, bw, edge_expr, msg, severity, category)
(en, clk, state);
```

Template syntax:

```
one_cold(en, clk, state, strict, msg, severity, category);
```

Arguments

strict

If 1, checks for a strict one-cold state encoding. Default = 0.

The check fails if all bits are set to one.

bw

The number of bits in the signal being tested (state). Default = 2.

Signal being tested. The signal must be more than one bit wide.

Report Message

In report messages, the assertion name is ova c one cold.

Examples

The following examples ensure state is a strict one cold (always 1 bit that is set to zero).

Unit:

```
bind module dut : ova_one_cold assert_one_cold
  #(1, 8, , "state does not have a one-cold value.")
  (rst n, clk, state);
```

ova_one_hot

Checks that only one bit is set to one or, optionally, that all bits are set to zero in the state value.

Syntax

Unit syntax:

```
ova_one_hot
#(strict, bw, edge_expr, msg, severity,
  category, coverage_level)
  instance name (en, clk, state);
```

Template syntax:

```
one hot (en, clk, state, strict, msg, severity, category);
```

Arguments

strict

If 1, checks for a strict one-hot state encoding. Default = 0.

The check fails if all bits are set to zero.

bw

The number of bits in the signal being tested (state). Default = 2.

Signal being tested. The signal must be more than one bit wide.

Report Message

In report messages, the assertion name is ova c one hot.

Coverage modes

```
Level_1 (bit 0 set in coverage_level)

Cover cover_state_change indicates how many times

test_expr changed value.

Level_3 (bit 2 set in coverage_level)

Cover cover_state_bit_is_1[i] indicates how many times

bit i was 1 after a change of value of state[i].
```

Examples

The following examples ensure state is one hot (can have a state with no bits asserted). Coverage Levels 1 and 3 are enabled in the unit instance ($coverage_level = 1$).

Unit:

```
bind module dut : ova_one_hot
  #(0, 8, , "state is not a one-hot or all-0 value.", , , 5)
hot_inst (rst_n, clk, state);
```

ova overflow

Checks that the signal being tested (exp) does not transition from $\geq max$ to $\leq min$. Works only with unsigned vector values.

Syntax

Unit syntax:

```
ova_overflow
#(min, max, bw, edge_expr, msg, severity,
   category, coverage_level)
instance_name (en, clk, exp);
```

Template syntax:

```
overflow(en, clk, exp, min, max, msg, severity, category);
```

Arguments

min

The minimum value allowed. Default = 0.

max

The maximum value allowed. Default = 1.

bw

The number of bits in the signal being tested (exp). Default = 2.

exp

Signal being tested.

Report Message

In report messages, the assertion name is ova_c_overflow.

Coverage modes

```
Level_1 (bit 0 set in coverage_level)

Cover cover_exp_change indicates how many times exp
changed value.
```

```
Level_3 (bit 2 set in coverage_level)
```

Cover cover_exp_reached_min indicates how many times exp reached the min value.

Cover cover_exp_reached_max indicates how many times exp reached the max value.

Examples

The following examples check that the value of an 8-bit counter does not go from FF to 0 unless there is a reset. Coverage Levels 1 and 3 are enabled in the unit instance (coverage level = 1).

Unit:

```
bind module dut : ova_overflow
  #(0, 8'hff, 8, , , , 5)
counter_oflo_inst (rst_n, clk, counter);
```

```
overflow assert_cntr_no_overflow(rst_n, posedge clk,
  counter, 0, 8'hff);
```

ova_quiescent_state

Checks that when eos_exp evaluates true, exp has value of fstate.

Note: You can use a four-state version of this checker. See Appendix A, Four-State OVA Checkers.

Syntax

Unit syntax:

```
ova_quiescent_state
#(bw, edge_expr, msg, severity, category)
(en, clk, exp, fstate, eos exp);
```

Template syntax:

```
quiescent state(en, clk, exp, fstate, eos exp, msg);
```

Arguments

bw

The number of bits in the signal being tested (exp) and the state to match (fstate). Default = 2.

exp

Signal being tested.

fstate

State to match.

eos exp

When true, signals that the state to match (exp) is in the state.

Report Message

In report messages, the assertion name is ova c quiescent.

Examples

The following examples specify that at the end of a long computation, an <code>output_ready</code> flag is asserted. At this time, we want to ensure that the chip's input ready flag is asserted.

Unit:

```
bind module dut : ova_quiescent_state computation_done
  #(1, , "Output ready but ready flag not set.")
  (rst_n, clk, ready, 1'b1, output_ready);
```

ova_range

Checks that the signal being tested greater than or equal to the specified minimum value (min), and less than or equal to the specified maximum value (max). Works with signed or unsigned vector values, depending on the Verilog data type.

Syntax

Unit syntax:

```
ova_range
#(bw, edge_expr, msg, severity, category, coverage_level)
instance_name (en, clk, exp, min, max);
```

Template syntax:

```
range(en, clk, exp, min, max, msg, severity, category);
```

Arguments

hи

The number of bits in the signal being tested (exp), the minimum value allowed (min), and the maximum value allowed (max). Default = 1.

exp

Signal being tested.

min

The minimum value allowed.

max

The maximum value allowed.

Report Message

In report messages, the assertion name is ova c range.

Coverage modes

```
Level_1 (bit 0 set in coverage_level)

Cover cover_exp_change indicates how many times exp
changed value.
```

```
Level 3 (bit 2 set in coverage level)
```

Cover cover_exp_reached_min indicates how many times exp reached the min value.

Cover cover_exp_reached_max indicates how many times exp reached the max value.

Examples

The following example ensure that coeff is between 2 and 6. Coverage Levels 1 and 3 are enabled in the unit instance (coverage level = 1).

Unit:

```
bind module dut : ova_range
  #(4, , "coeff out of range.", , , 5)
  filter_coeff_check (rst_n, clk, coeff, 4'd2, 4'd6);
```

ova_reg_loaded

Checks that the register being tested (reg) is loaded with source data (src). The value of the register (reg) is checked against a stored source value of (src) starting with a specified number of delay (delay) cycles (minimum of one, which is the default) after the trigger condition evaluates true and within the specified end_cycle cycles (defaults to one) after the trigger evaluates true or when the stop signal (stop) evaluates true (whichever occurs first). The default of the stop signal (stop) is zero. If used to control the end time, stop should become true at least one clock cycle after the register being tested (reg) is loaded, which means a minimum of two cycles after the trigger condition. The source data value (src) is "captured" when the trigger evaluates true. The check is made by comparing this saved source value (src) against the register contents (reg) during the load window. Once the register has loaded the value during the window, the check terminates with success.

If the window is terminated only by the stop signal (stop) (that is, there is no timeout and end_cycle does not apply), then set end_cycle to 0.

Note: You can use a four-state version of this checker. See Appendix A, Four-State OVA Checkers.

Syntax

Unit syntax:

```
ova_reg_loaded
#(delay, end_cycle, bw, edge_expr, msg, severity, category)
(en, clk, trigger, src, dst_reg, stop);
```

Template syntax:

```
reg_loaded(en, clk, trigger, src, reg, delay, end_cycle,
stop, bw, msg, severity, category);
```

Arguments

delay

The number of cycles after the trigger signal (trigger) goes true to start the window. Default = 1.

end cycle

The number cycles after the trigger signal (trigger) goes true to end the window. Default = 1.

bw

The number of bits in the source date (src) and the register under test (reg). Default = 2.

The width (bw) of src and reg should match their actual widths. If bw is less than the actual width, the check might fail if the bits above bw are not zero. If bw is more than the actual width, the additional bits are taken to be zero. A bw of zero is illegal.

trigger

Signal that is part of starting the window.

src

Data loaded into the register.

req

Register being tested.

stop

Signal that stops the check.

Report Message

In report messages, the assertion name is $ova_c_reg_loaded$. When the assertion fails, the "offending" expression in the message might include " $ova_v_reg_src$ ". This is an OVA variable that stores the value of the source data (src) when the triger signal (trigger) is true.

Examples

The examples below specity that the adder output must be loaded into the multiplier register within 2 cycles of the adder's output being ready.

Unit:

```
bind module dut : ova_reg_loaded sum_to_multiplier
  #(1, 2, 16)
  (rst n, clk, adder oe, sum, multiplier, 1'b0);
```

```
reg_loaded sum_becomes_multiplier(rst_n, posedge clk,
  adder oe, sum, multiplier, 0, 2, 1'b0, 16);
```

ova_req_ack_unique

Verifies that each req receives an ack within the specified interval min_time and max_time clock clk ticks. Note that acks are attributed to reqs in a fifo manner.

Syntax

(Unit syntax only)

```
ova_req_ack_unique
#(min_time, max_time, max_time_log_2, edge_expr, msg,
   version, severity, category, coverage_level)
  instance name (reset, clk, req, ack)
```

Arguments

min time

Defines the minimum time separation between a req and an ack (default is 1).

```
max_time
```

Defines the maximum time separation between a req and an ack (default is 15).

```
max\_time\_log\_2
```

Specifies the superior integer of log2 of max_time , used to dimension the data structures. The default is 4 (= sup(log2(15))).

version

This parameter specifies two versions of the checker:

==0 — Selects a version that is suitable for max_time <= 15.
 It uses IDs to identify requests and then generates as many assertions as the max_time clock ticks.

• ==1 — Selects a version that is suitable for $max_time > 15$. It uses a time stamp computed mod $2 max_time$ to mark the requests, the time stamp is enqueued. When an ack arrives it verifies that the time stamp at the head of the queue satisfies the timing requirements.

reset

Synchronous reset, active high (1), initializes all request history to nill.

req and ack

The signals of interest.

Coverage modes

Level 1 (bit 0 set in coverage level)

Cover cover_number_of_req indicates how many times req was asserted.

Cover cover_number_of_ack indicates how many times ack was asserted.

NOTE: Coverage at Level 3 is only available with version = 1.

```
Level 3 (bit 2 set in coverage level)
```

Cover cover_ack_with_exact_min_lat indicates how many time the observed latency was exactly equal to the specified min value.

Cover cover_ack_with_exact_max_lat indicates how many time the observed latency was exactly equal to the specified max value.

Example

```
bind module mod_name: ova_req_ack_unique
          #( 20, 100, 7, 0, "req_ack failed", 1, , , 5)
```

req_grant_1_1 (!reset_n, clk, request, grant);

In the example, the instance req_grant_1_1 of ova_req_ack_unique verifies that for each request there is a grant received within 20 and 100 posedge edges of clk. The checker is reset on reset_n low. Version 1 is used, i.e., using time stamps. Coverage Levels 1 and 3 are enabled in the unit instance (coverage level = 1).

ova_req_requires

Checks that if the first expression in a sequence $(trig_req)$ evaluates true, then the second $(follow_req)$ and third $(follow_resp)$ expressions in the sequence evaluate true before the last expression $(trig_resp)$ evaluates true. The delay between the first expression in a sequence $(trig_req)$ and the last expression $(trig_resp)$ in the sequence is specified as a latency window via the $min\ lat\ and\ max\ lat\ parameters$.

Syntax

Unit syntax:

```
ova_req_requires
  #(min_lat, max_lat, edge_expr, msg, severity,
     category, coverage_level)
instance_name
  (en, clk, trig_req, follow_req, follow_resp, trig_resp);
```

Template syntax:

```
req_requires(en, clk, trig_req, follow_req, follow_resp,
trig resp, min lat, max lat, msg, severity, category);
```

Arguments

min lat

Minimum number of clock cycles between the first expression in a sequence $(trig_req)$ going true and the last expression in the same sequence $(trig_resp)$ going true. Default = 1.

```
max lat
```

Maximum number of clock cycles between the first expression in a sequence $(trig_req)$ going true and the last expression in the same sequence $(trig_resp)$ going true. Default = 0. For an openended interval $[min\ lat\ ..]$, set the $max\ lat$ equal to zero.

trig req

First signal in the sequence.

follow req

Second signal in the sequence.

follow resp

Third signal in the sequence.

trig resp

Last signal in the sequence.

Note:

The defaults are $min_lat = 1$ and $max_lat = 0$, meaning that $trig \ resp$ must come at least one clock tick after $trig \ req$.

Report Message

In report messages, the assertion name is ova_c_req_requires.

Coverage modes

Level 1 (bit 0 set in coverage level)

Cover cover_no_of_trig_reqs indicates the number of times trig_req was asserted.

Cover cover_req_requires indicates how many times the specified sequence occurred.

Level_2 (bit 1 set in coverage_level)

Cover cover_trig_req_follow_req indicates how many times there was a a follow req after a trig req.

Cover cover_trig_req_follow_req_follow_resp indicates how many times there was a follow_req after a trig req and then followed by follow resp.

```
Level 3 (bit 2 set in coverage level)
```

Cover cover_trig_resp_exactly_on_min_lat indicates how many times the observed latency between trig_req and trig_resp was exactly equal to the min value.

Cover cover_trig_resp_exactly_on_max_lat indicates how many times the observed latency between trig_req and trig_resp was exactly equal to the max value.

Note: Coverage is collected correctly only when the transactions delimited by trig_req and trig_resp asserted do not overlap, i.e., there is no new assertion of trig_req while such a transaction is in progress.

Examples

The following examples specify a request to transmit a packet can only be satisfied if the transmitter can be granted access to the bus. The packet must be sent within 10 cycles. Levels 1, 2 and 3 are enabled in the unit instance (coverage level = 7).

Unit:

```
req_requires xmit_packet(rst_n, posedge clk,
   send_pkt[0], bus_req[1], bus_grant[1], pkt_ack[0],
   1, 10);
```

ova_req_resp

Checks that the rising edge of a bit in the vector of a request signal (req) is followed by a single rising edge of the corresponding bit of the vector of a response signal (resp) within the latency response window specified by the minimum (min_lat) and maximum number of clock cycles (max_lat) . It is assumed that no new request is issued until after a response is received for the current request.

Syntax

Unit syntax:

```
ova_req_resp
#(no_chnl, min_lat, max_lat, resp_cycles, no_req4resp,
req_till_resp, req_drop_after_resp, edge_expr, msg,
severity, category)
(en, clk, req, resp);
```

Template syntax:

```
req_resp(en, clk, req, resp, no_chnl, min_lat, max_lat,
resp_cycles, no_req4resp, req_till_resp,
req_drop_after_resp, msg, severity, category);
```

Arguments

no chnl

The number of bits in the vector of the request signal (req) and the vector of the response signal (resp.) Default = 1.

min lat

Minimum number of clock cycles between a bit in the specified vector of a request signal (reg) going true and a bit in the vector of a response signal (resp) going true. Default = 1.

max lat

Maximum number of clock cycles between a bit in the specified vector of a request signal (req) going true and a bit in the vector of a response signal (resp) going true. Default = 1.

For an open-ended interval [min_lat ..], set the max_lat equal to zero.

resp cycles

Number of clock cycles that the vector of a response signal (resp) must stay asserted. Default = 0. If zero or less, the duration is not checked.

no req4resp

If 1, checks that each response has a corresponding request. Default = 0.

reg till resp

If 1, checks that the request remains asserted until the response is received. Default = 0.

req drop after resp

Number of cycles after the response is deasserted that the request must be deasserted. Default = 0.

req

Vector of 1-bit request signals.

resp

Vector of 1-bit response signals.

The specified req and resp are vectors where the bit position indicates the corresponding req and resp. The no_chn1 specification is the number of req and resp bits. That is, the size of the req and resp vectors is $[no_chn1 - 1 : 0]$ or $[0 : no_chn1 - 1]$.

Report Message

This checker uses several assertions to cover different aspects and modes:

- Assertion ova_c_req_gets_resp[i] checks that the response on channel [i] arrives within the expected latency interval.
- Assertion ova_c_req_until_resp[i] checks that req[i] remains asserted until a rising edge on resp[i].
- Assertion ova_c_resp_cycles[i] checks that resp[i] stays asserted for resp_cycles clock ticks.
- Assertion ova_c_drop_after_resp[i] checks that req[i] stays asserted for exactly $req_drop_after_resp$ clock cycles after the falling edge of resp[i].
- Assertion ova_f_no_req4resp[i] checks that resp[i] is not asserted while there is no new req[i] asserted. This assertion is active only if no req4resp is 1.

Examples

The following examples check that the response comes 1 to 3 cycles after a rising edge on request.

Unit:

```
bind module dut : ova_req_resp
#(2, 1, 3, 0, 1, 1, 0, 1)
(1'b1, clk, request, response);
```

```
req_resp( , negedge clk, request, response, 2, 1,
      3, 0, 1, 1, 0);
```

ova_sequence

Ensure that exp takes on values in the order implied by their sequence in the vals bitvector. bw is the number of bits in exp and in each of the required values.

Syntax

Unit syntax:

```
ova_sequence
# (no_vals, min_hold, max_hold, bw, disallow, edge, exp,
msg, severity, category);
(en, clk, exp, vals);
```

Template syntax:

```
sequence(en, clk, exp, no_vals, vals, min_hold, max_hold,
disallow, bw, msg, severity, category)
```

Arguments

no vals

An integer value indicating the number of values in the sequence. For example, if bw = 3, $no_vals = 2$, and the values are 3'b000 and 3'b110 (to be reached in that order) then the value bound to the vals port is 6'b110_000. Default = 2.

min hold

The minimum number of clock ticks ticks exp must hold at a specific value. Default = 1.

max hold

The maximum number of clock ticks exp must hold at a specific value. Default = 1.

bw

Number of bits in exp and in each of the required values.

disallow

If 1, then the sequence is forbidden. Default = 0, sequence is required.

If 0, ensures that the sequence progression occurs.

exp

The assertion will check the sequence whenever exp takes on the first value in the sequence and en evaluates true.

vals

The constant bitvector is formed by concatenating the bitvectors of each of the required values in the sequence, such as., vals has bw * no vals bits.

Note the following:

- $min_hold = max_hold = 1$ indicates that exp progresses to the next value on the next clock tick (i.e., held for one cycle).
- $min_{hold} = max_{hold} = 0$ indicates that exp must hold the current value for at least m clock ticks, no upper bound.
- $min_hold = m$, $max_hold = 0$ indicates that exp must hold the current value for at least m clock ticks, no upper bound.
- min_hold = m, max_hold = n indicates that exp must hold the current value for at least m clock ticks and must advance to the next value within n ticks.

Report Message

This checker uses two assertions to cover different modes:

• Assertion ova_c_sequence checks that the sequence happens correctly. When disallow = 0, the assertion ova_c_sequence will report as the failing expression

```
(past(exp) == exp)
```

when exp is not stable for min_hold clock ticks after entering one of the first $no\ vals$ -1 values in vals, and

```
(exp == val i)
```

When exp did not take on the expected value val_i in the constant array vals within the expected hold time interval.

 Assertion ova_f_sequence checks that the sequence does not happen. When disallow = 1, the failure of the assertion ova_f_sequence means that the whole sequence and the hold intervals were satisfied which was disallowed to happen.

Examples

```
ova_sequence #(5, 1, 1, 4, 0, 1)
(1, clk, counter, 20'h0 2 3 1 0);
```

It is required that the 4-bit variable counter, once it takes on the value 0, it must forever follow the Grey-code cycle 0-1-3-2-0-..., advancing to the next value on every tick of negedge clk. (disallow = 0, meaning that the sequence is required). Note that the sequence in vals is read from right to left.

ova stack

Checks operations on a stack.

Syntax

Unit syntax:

```
ova_stack
  #(depth, elem_sz, hi_water_mark, push_lat, pop_lat,
    value_chk, push_pop_chk, edge_expr, msg,
    severity, category, coverage_level)
instance_name (reset, clk, push, push_data, pop, pop_data);
```

Template syntax:

```
stack(reset, clk, depth, elem_sz, hi_water_mark, push,
push_lat, push_data, pop, pop_lat, pop_data, value_chk,
push_pop_chk, msg, severity, category);
```

Arguments

depth

The maximum size of the stack. Default = 2. The specified depth can be at most 2^{16} .

```
elem sz
```

The size of data elements in bits. Default = 1.

```
hi water mark
```

If positive, checks that the depth of the queue is not greater than specified hi water mark. Default = 0.

```
push lat
```

The number of enq_clk cycles between push being asserted 1 and $push_data$ being valid. Default = 0.

pop lat

The number of deq_{Clk} cycles between pop being asserted 1 and pop data being valid. Default = 1.

value chk

If 1, checks that pop_data matches the data at the top of the stack. Default = 1.

push_pop_chk

If 1, checks that push and pop operations do not occur simultaneously. Default = 1.

reset

Initializes the stack to empty when set to 1.

push

Set to 1 when data is being pushed.

push_data

Data being pushed.

pop

Set to 1 when data is being popped.

pop data

Data being popped.

Note the following:

- All operations including reset are synchronous to a tick of clk.
- When push is asserted 1: Ensures no stack overflow. push_lat specifies the number of ticks of clk between the asserting of push and when push_data is valid. It must be a compile-time nonnegative integer constant (not an interval).
- If hi_water_mark is a positive value, then the depth of the stack after the push will be checked to see if hi_water_mark is exceeded (>=). Once high water has been exceeded once, this check is disabled until the stack falls below the mark again (<).

 hi water mark can be a constant or a design variable.

- If the stack depth is exceeded, a failure is reported and all further checks are disabled until the stack is reset.
- When pop is enabled: Ensures the stack is not empty when popped. If a pop is performed on an empty stack, all checking of pop operations is disabled until reset is applied or a push occurs.
- If value_chk evaluates to 1, it ensures pop_data is what was on the top of the stack. pop_lat specifies the number of cycles of clk between the asserting of pop and when pop_data is valid. It must be a compile-time non-negative integer constant (not an interval).
- If push_pop_chk evaluates 1, ensures that push and pop operations do not occur simultaneously. If push and pop do occur simultaneously, the effect is the same as if push were done first followed by a pop (that is, the stack is not changed). If value_chk = 1 then pop_data is compared with push_data in that case.

Report Message

This checker uses several assertions to cover different aspects and modes:

- Assertion ova_c_stack_overflow checks that when push is issued, the stack is not full. When the assertion fails, the reported time of failure is on the clock tick following the failed deferred push operation.
- Assertion ova_c_stack_underflow checks that when pop is issued, the stack is not empty (and no simultaneous push). When the assertion fails, the reported time of failure is on the clock tick following the failed deferred push operation.

- Assertion ova_c_stack_value_chk checks that the pop_data value matches the expected top-of-stack value. If the stack is empty and there is a simultaneous push, the assertion checks that the value pushed on the stack matches the value popped off the stack. This assertion is active only if value_chk is 1.
- Assertion ova_c_stack_hi_water_chk checks that the stack is not filled above the high-water mark.
- Assertion ova_c_push_pop_fail checks that push and pop are not enabled simultaneously (and push_pop_chk is 1).

Coverage modes

Level_1 (bit 0 set in coverage_level)

Cover cover_number_of_pushes indicates how many times there was a push operation.

Cover cover_number_of_pops indicates how many times there was a pop operation.

Cover cover_push_followed_eventually_by_pop indicates how many times a push was followed eventually by a pop without an intervening push.

Level_3 (bit 2 set in coverage_level)

Cover cover_simultaneous_push_pop indicates how many times there were simultaneous push and pop operations.

Cover cover_simultaneous_push_pop_when_empty indicates how many times there were simultaneous push and pop operations while the stack was empty.

Cover cover_simultaneous_push_pop_when_full indicates how many times there were simultaneous push and pop operations while the stack was full.

Cover cover_stack_hi_water_chk indicates how many times the high water mark was reached.

Cover cover_number_of_full indicates how many times the stack became full after a push.

Cover cover_number_of_empty indicates how many times the stack became empty after a pop.

Examples

The examples below specify the following:

- Checks that the stack is initialized when sys reset is asserted.
- The stack is 10 elements deep and 16 bits wide.
- The water mark is set at 8, which is point at which the water-mark check is enabled.
- The push and pop latencies are both 0, which means that data_in must be present at the same time that push is asserted and data_out must be present at the same time that pop is asserted.
- The value check is enabled meaning that data_out will be checked against the data expected on the top of the stack.
- Levels 1 and 3 are enabled in the unit instance (coverage level = 6).

Unit:

```
bind module dut : ova_stack
    #(10, 16, 8, 0, 0, 1, 0, , , , 6)
    stack_inst (sys_reset, clk, push, data_in, pop, data_out);
```

```
stack(sys_reset, posedge clk, 10, 16, 8, push, 0,
  data_in, pop, 0, data_out, 1, 0);
```

ova_timeout

Checks that the value of the signal being tested (exp), a bit vector, changes within the specified number of cycles (period). That is, the value of the signal (exp) cannot remain constant longer than the specified maximum number of clock cycles (period). A new check begins every time the signal (exp) changes.

Note: You can use a four-state version of this checker. See Appendix A, Four-State OVA Checkers.

Syntax

Unit syntax:

```
ova_timeout
  #(period, bw, edge_expr, msg, severity, category,
     coverage_level)
instance name (en, clk, exp);
```

Template syntax:

```
timeout(en, clk, exp, period, msg, severity, category);
```

Arguments

period

The maximum number of clock cycles before the specified signal (exp) changes. Default = 1. The specified period must be greater than zero. The default is one, meaning that the specified signal (exp) must change every clock cycle.

bw

The number of bits in the specified signal (exp). Default = 1.

exp

Signal being tested.

Report Message

In report messages, the assertion name is ova c timeout.

Coverage modes

```
Level_1 (bit 0 set in coverage_level)

Cover property exp_change indicates how many times exp
changed value.
```

Cover property cover_exp_changes_within_period indicates how many times the change occurred within the required period.

```
Level_3 (bit 2 set in coverage_level)

Cover property

cover_exp_changes_exactly_at_period_clks indicates
how many times exp changed exactly at period clock cycles.
```

Examples

The following examples ensure that a PLL output changes at least once every 10 clocks. Coverage Levels 1 and 3 are enabled in the unit instance ($coverage\ level = 5$).

Unit:

```
bind module dut : ova_timeout
  #(10, 1, , "PLL output lasted too long.", , , 5)
  pll pulse (rst n, clk, pll out0);
```

ova_tri_state

Checks that the tri-states of the specified input and output signals are equal (inp == outp) at the start of the assertion (en is 1).

Note: You can use a four-state version of this checker. See Appendix A, Four-State OVA Checkers.

Syntax

Unit syntax:

```
ova_tri_state
#(bw, edge_expr, msg, severity, category)
(en, clk, inp, outp);
```

Template syntax:

```
tri state(en, clk, inp, outp, msg, severity, category);
```

Arguments

bw

The number of bits in input (inp) and output (outp) signals. Default = 1.

inp

Input signal.

outp

Output signal.

Report Message

In report messages, the assertion name is ova_c_tri_state.

Examples

Unit:

```
bind module dut : ova_tri_state assert_tri_state
  #(,, "Asserted oen, data does not match data_read.")
  (oen, clk, data_read, data);
```

ova_underflow

Checks that the signal being tested (exp) does not transition between the specified minimum (min) and maximum (max) values. Works only with unsigned vector values.

Syntax

Unit syntax:

```
ova_underflow
#(min, max, bw, edge_expr, msg, severity, category)
(en, clk, exp);
```

Template syntax:

```
underflow(en, clk, exp, min, max, msg, severity, category);
```

Arguments

min

The minimum value allowed. Default = 0.

max

The maximum value allowed. Default = 1.

bw

The number of bits in the signal being tested (exp). Default = 2.

exp

Signal being tested.

Report Message

In report messages, the assertion name is ova_c_underflow.

Examples

The following examples check that the countdown timer does not flip from 0 to FF unless it is reset.

Unit:

```
bind module dut : ova_underflow counter_underflow
  #(0, 8'hff, 8, , "Countdown timer underflowed.")
  (rst n, clk, counter);
```

```
underflow assert_cntr_no_underflow(rst_n, posedge clk,
   counter, 0, 8'hff, "Countdown timer underflowed.");
```

ova_valid_id

Checks that IDS are issued and returned.

Syntax

Unit syntax:

```
ova_valid_id
#(id_bw, max_ids, max_out_ids, max_out_per_id, min_lat,
max_lat, edge_expr, msg, severity, category)
(en, clk, issued_sig, issued_id, ret_sig, ret_id, reset_sig,
reset id);
```

Template syntax:

```
valid_id(en, clk, id_bw, max_ids, max_out_ids,
max_out_per_id, issued_sig, issued_id, ret_sig, ret_id,
reset_sig, reset_id, min_lat, max_lat, msg, severity,
category);
```

Arguments

id bw

The number of bits in <code>issued_id</code>, <code>ret_id</code>, and <code>reset_id</code>. Default = 2. That is, <code>id_bw</code> is the maximum number of bits used to encode an ID.

max ids

The maximum number of IDs. Default = 4.

The maximum value is 2¹⁶.

```
max out ids
```

The maximum number of IDs that can be outstanding. Default = 1.

```
max out per id
```

The maximum number of issues outstanding per ID. Default = 1.

min lat

Minimum number of clock cycles between an ID being issued and returned. Default = 1.

max lat

Maximum number of clock cycles between an ID being issued and returned. Default = 0.

eissued_sig

If 1, issued id has a valid value.

issued id

The ID being issued.

ret_sig

If 1, ret id has a valid value.

ret id

The ID being returned.

reset_sig

If 1, reset id has a valid value.

reset id

The ID whose outstanding count is being reset.

Note the following:

- The signal <code>issued_sig</code> asserted 1 validates a request identified by the value in <code>issued_id</code>. This request is expected to be acknowledged by <code>ret_id</code> and validated by <code>ret_sig</code> asserted 1 within [<code>min_lat</code> .. <code>max_lat</code>] delay.
- When <code>issued_sig</code> is asserted 1, it ensures that <code>max_out_ids</code> is not exceeded and that <code>issued_id</code> is at most <code>max_out_per_id</code> outstanding (that is, not returned). When <code>max_out_per_id > 1</code> then the returns for an ID cannot be distinguished. But for any issue, there must be a return of the ID within the latency interval.
- The assumption is that <code>issued_id</code> and <code>ret_id</code> will always be values in the range of 0:(<code>max ids -1</code>).

- When $reset_sig$ is asserted 1 then the outstanding count of $reset_id$ ID is reset to 0. The specified $issued_sig$ must not be asserted at the same time as $reset_sig$. The specified ret_id must not be asserted at the same time as $reset_id$.
- If an <code>issued_id</code> exceeds the number of outstanding IDs,

 <code>max_out_ids</code>, an error is reported. Necessarily <code>max_ids</code> >=

 <code>max_out_ids</code> must hold. Only those IDs are counted that have <code>en</code> asserted at issuance.
- When ret_sig is asserted 1, ret_id must match an outstanding ID. A returned ret_id is counted only against issued IDs in the previous clock cycles. It also ensures that issued_id is outstanding for at least min_lat cycles but no longer than max lat cycles after issuance.
- The issued_sig and ret_sig control signals are active for only one clock or they are edge expressions (posedge ret_sig or negedge ret_sig, for example).
- To trigger a check for an issued ID, en must be asserted 1 at the time issued_sig is asserted and also at the time ret_sig is asserted. If an ID is returned and en is asserted while at issuance of this ID, en is deasserted, this return is flagged as an error.
- $min_lat = 1$ and $max_lat = 1$ means that the ID must be returned on the next clock cycle after issuance.
- $min_lat = m$ and $max_lat = 0$ means that the ID must be returned any time after m clock ticks.
- min_lat = m and max_lat = n means that the ID must be returned within the interval m..n clock ticks after issuance.

Report Message

This checker uses several assertions to cover different aspects and modes:

- Assertion ova_c_valid_id[i] checks that when an ID of value i is issued, that ID is returned within the required latency interval [min_lat .. max_lat] clock cycles.
- Assertion ova_c_issued_id_ok checks that when an ID is issued, it is not in circulation with a count exceeding max_out_per_id.
- Assertion ova_c_ret_id_ok checks that when an ID is returned, there is such an ID value in circulation (that is, this ID has been issued).
- Assertion ova_c_max_issued_ids_ok checks that the total of different IDs in circulation does not exceed the max_out_ids value.

Examples

The following examples specify:

- The checker is enabled when out of reset. All signals are sampled on posedge clk.
- There are at most 8 IDs (0 to 7) of which at most 6 can be in circulation at any time and only one copy of each.
- The count of the copies of an ID is reset when clear is asserted with the corresponding ID value on clear id.
- An issued ID is valid when issued valid is asserted.
- A returned ID is valid when ret valid is asserted.
- An issued ID must be returned in 1 to 10 clock cycles.

Unit:

```
bind module dut : ova_valid_id
  #(8, 8, 6, 6, 1, 1, 10, ,
    "latency 1 to 10, 6 out of 8 IDs, 1 copy each")
  (!reset, clk, issued_valid, issued_id, ret_valid,
    ret id, clear, clear id);
```

```
valid_id(!reset, posedge clk, 8, 8, 6, 1,
  issued_valid, issued_id, ret_valid, ret_id,
  clear, clear_id, 1, 10,
  "latency 1 to 10, 6 out of 8 IDs, 1 copy each");
```

ova value

Checks that the signal being tested (exp) is only one of the specified values.

Syntax

Unit syntax:

```
ova_value
  #(no_vals, disallow, bw, edge_expr, msg, severity,
     category, coverage_level)
  instance name(en, clk, exp, vals);
```

Template syntax:

```
value(en, clk, exp, no_vals, vals, disallow, bw, msg,
severity, category);
```

Arguments

```
no vals
```

The number of entries in the vals specification. Default = 1.

disallow

If 1, checks that the signal being tested (exp) does not match any of the values in the specified array of values (val). Default = 0.

If 0, checks that the signal being tested (exp) does match one of the values in the specified array of values (val).

bw

Number of bits in the signal being tested (exp) and each element of the specified array of values (val). Default = 2.

exp

Signal being tested.

vals

A bitvector of concatenated values that the signal being tested (exp) must evaluate to (logic [bw*no vals-1:0] vals).

Report Message

This checker uses two assertions to cover different modes:

- Assertion ova_c_value checks that exp is one of the specified values. This assertion is active only if disallow is 0.
- Assertion ova_f_value checks that exp is not one of the specified values. This assertion is active only if disallow is 1.

Coverage modes

```
Level_1 (bit 0 set in coverage_level)

Cover cover_exp_change indicates how many times exp
changed value.
```

```
When disallow == 0:
```

Cover cover_value indicates how many times a valid value from vals occurred.

```
When disallow == 1:
```

Cover cover_exp_state_transitions indicates how many times a value other than those in vals occurred.

```
Level_3 (bit 2 set in coverage_level)
Exists only when disallow == 0
```

Cover cover_exp_changes_to_value[i] indicates how many times exp was equal to the value vals[i].

Examples

The following examples check that when load is 1 and reset is 0, control_reg has one of the four values 0, 1, 3, or 5. Coverage Levels 1 and 3 are enabled in the unit instance (coverage_level = 5).

Unit:

Template:

ova_window

Checks that individual bits in the bitvector signal (<code>assert_vector</code>) are asserted or deasserted either within or outside the window. The window is defined at the beginning by <code>start_sig</code> evaluating true plus <code>delay</code> cycles and ending with <code>stop_sig</code> evaluating true or <code>win_time</code> number of cycles after posedge <code>start_sig</code> plus <code>delay</code> cycles evaluates true.

Syntax

Unit syntax:

```
ova_window
   #(check_type, delay, win_time, bw, edge_expr, msg,
        severity, category, coverage_level)
instance_name (en, clk, start_sig, stop_sig, assert_vector);
```

Template syntax:

```
window(en, clk, start_sig, delay, stop_sig, win_time,
assert vector, bw, check type, msg, severity, category);
```

Arguments

```
check type
```

The type of check. Default = 0.

- 0: Each bit must be asserted at some time during the window, but not necessarily at the same time.
- 1: Each bit must be asserted at least once outside the window.
- 2: Each bit must be de-asserted during the entire length of the window.
- 3: Each bit must be de-asserted on every c1k outside the window.

delay

The number of cycles after the start signal ($start_sig$) evaluates true to the beginning of the window. Default = 0.

win time

The maximum length of the window in clock cycles. Default = 1.

The cycle that the window opens on is outside the window. The cycle that closes the window is inside the window. If there is no window timeout, then win time should be 0.

bw

The number of bits in the assert_vector specification. Default = 1.

A signal value is checked in or out of the window only if en is asserted at that clock tick. Whenever there is no window active, it is considered as outside the window and en can be used to control when checking outside the window is performed (types 1 and 3).

start sig

Signal that is part of starting the window.

stop sig

Signal that marks the end of the window. If there is no <code>stop_sig</code> (only a specific number of cycles is to be considered), then <code>stop_sig</code> should be 0 (the default value).

assert vector

Signal being tested.

Report Message

This checker uses several assertions to cover different modes:

- Assertion ova_c_asserted_in checks that all bits of asserted_in are set during the window. When the assertion fails, the "offending" expression in the message might include "var_asserted_in". This is an OVA variable that accumulates the bits asserted during the window. This assertion is active only if check type is 0.
- Assertion ova_c_asserted_out checks that all bits of asserted_out are set outside the window. When the assertion fails, the "offending" expression in the message might include "var_asserted_out". This is an OVA variable that accumulates the bits asserted outside the window. This assertion is active only if check type is 1.
- Assertion ova_c_deasserted_in checks that all bits of deasserted_in remain 0 during the window. When the assertion fails, the "offending" expression in the message might include "var_deasserted_in". This is an OVA variable that accumulates the bits asserted during the window. This assertion is active only if check type is 2.
- Assertion ova_c_deasserted_out checks that all bits of
 deasserted_out remain 0 outside the window. When the
 assertion fails, the "offending" expression in the message might
 include "var_deasserted_out". This is an OVA variable that
 accumulates the bits asserted outside the window. This assertion
 is active only if check_type is 3.

Coverage modes

```
Check_type = 0 (asserted inside)
Level 1 (bit 0 set in coverage level)
```

Cover cover_asserted_in indicates how many times there was a match within the window.

Level_3 (bit 2 set in coverage_level)

Cover

cover_num_of_times_bit_asserted_just_after_star t_sig_plus_delay[i] indicates how many times bit assert_vector[i] was set to 1 exactly delay cycles after start_sig was asserted.

Cover

cover_num_of_times_bit_asserted_just_at_stop_sig[i] indicates how many times bit assert_vector[i] as set to 1 exactly when stop_sig occurred.

Cover

cover_num_of_times_bit_asserted_just_at_win_tim e_expires[i] indicates how many times bit assert_vector[i] as set to 1 exactly when win_time expired.

Cover

cover_num_of_times_all_bits_asserted_just_after _start_sig_plus_delay indicates how many times all bits were asserted at the same time delay cycles after start_sig was asserted.

Cover

cover_num_of_times_all_bits_asserted_just_at_st op_sig indicates how many times all bits were asserted at the same time when stop sig was asserted.

Cover

cover_num_of_times_all_bits_asserted_just_at_win_time_expires indicates how many times all bits were asserted at the same time when win time expired.

```
Check_type = 1 (asserted outside)
Level 1 (bit 0 set in coverage level)
```

Cover cover_asserted_out indicates how many times there was a match outside the window.

```
Level_3 (bit 2 set in coverage_level)

Cover
```

cover_num_of_times_bit_asserted_just_at_start_s ig_plus_delay[i] indicates how many times bit assert_vector[i] was set to 1 exactly delay cycles after start sig was asserted.

Cover

cover_num_of_times_bit_asserted_just_after_stop _sig[i] indicates how many times bit assert_vector[i] as set to 1 just after stop sig occurred.

Cover

cover_num_of_times_bit_asserted_just_after_win_ time_expires[i] indicates how many times bit assert_vector[i] as set to 1 just after win_time expired.

Cover

cover_num_of_times_all_bits_asserted_just_at_st art_sig_plus_delay indicates how many times all bits were asserted at the same time at delay cycles after start_sig was asserted.

Cover

cover_num_of_times_all_bits_asserted_just_after _stop_sig indicates how many times all bits were asserted at the same time just after stop_sig was asserted.

Cover

cover_num_of_times_all_bits_asserted_just_after _win_time_expires indicates how many times all bits were asserted at the same time just after win_time expired.

```
Check_type = 2 (deasserted inside)
Level 1 (bit 0 set in coverage level)
```

Cover cover_deasserted_in indicates how many times there was a match within the window.

```
Level_3 (bit 2 set in coverage_level)

Cover
```

cover_num_of_times_bit_deasserted_just_after_st art_sig_plus_delay[i] indicates how many times bit assert_vector[i] as set to 1 exactly delay cycles after start sig was asserted.

Cover

cover_num_of_times_bit_reasserted_just_after_st op_sig[i] indicates how many times bit assert_vector[i] rose right after stop sig occurred.

Cover

cover_num_of_times_bit_reasserted_just_after_win_time_expires[i] indicates how many times bit assert_vector[i] rose right after win_time expired.

Cover

cover_num_of_times_all_bits_deasserted_just_aft er_start_sig_plus_delay indicates how many times all bits were deasserted at the same time just after delay cycles after start_sig was asserted.

Cover

cover_num_of_times_all_bits_reasserted_just_aft er_stop_sig indicates how many times all bits were reasserted at the same time just after stop_sig_was asserted.

Cover

cover_num_of_times_all_bits_reasserted_just_aft er_win_time_expires indicates how many times all bits were reasserted at the same time just after win time expired.

```
Check_type = 3 (deasserted outside)
Level_1 (bit 0 set in coverage_level)
```

Cover cover_deasserted_out indicates how many times there was a match outside the window.

```
Level_3 (bit 2 set in coverage_level)

Cover
```

cover_num_of_times_bit_reasserted_just_after_st art_sig_plus_delay[i] indicates how many times bit assert_vector[i] rose just after delay cycles after start_sig was asserted.

Cover

cover_num_of_times_bit_deasserted_just_after_st
op_sig[i] indicates how many times bit assert_vector[i]
fell just after stop_sig_occurred.

Cover

cover_num_of_times_bit_deasserted_just_after_win_time_expires[i] indicates how many times bit assert_vector[i] fell just after win_time expired.

Cover

cover_num_of_times_all_bits_reasserted_just_aft er_start_sig_plus_delay indicates how many times all bits were reasserted at the same time just after delay cycles after start_sig was asserted.

Cover

cover_num_of_times_all_bits_deasserted_just_aft er_stop_sig indicates how many times all bits were deasserted at the same time just after stop_sig_was asserted.

Cover

rvmLIMIT3cover_num_of_times_all_bits_deasserted _just_after_win_time_expires indicates how many times all bits were deasserted at the same time just after win_time expired.

Examples

The following examples specify that the window starts 1 clock tick after start transitions to 1 and lasts for two clock cycles. There are two bits in flags that should be asserted during the window.

Coverage Levels 1 and 3 are selected (coverage level = 5).

Unit:

```
bind module dut : ova_window
    #(0, 1, 2, 2, , , , 5)
win inst (reset n, clk, start, 1'b0, flags);
```

Template:

```
window (reset_n, posedge clk, start, 1, 0, 2, flags,
    2, 0);
```

2

OVL-Equivalent Checkers

This chapter describes OVA checkers that verify the same behavior as checkers available in Accellera's proposed "Open Verification Library", Version 02.09.24.

This chapter covers the following topics:

- Converting from a Verilog OVL Library to OVA
- Descriptions of OVL-Equivalent OVA Checkers

Converting from a Verilog OVL Library to OVA

There are several methods you can use to convert OVL Verilog checker instances in a Verilog model to equivalent inlined OVA checkers:

- Single Line Replacement
- Multiple Line Replacement
- Combining OVA and OVL Checkers in the Same Design

This section describes each of these methods.

Single Line Replacement

If the OVL module instance extends over only one line of code, you only need to place the prefix "//ova bind " in front of the original OVL instance.

For example, suppose you want to replace the following OVL module instance:

```
assert_always my_inst (clk, reset_n, expression);
The equivalent OVA is as follows:
//ova bind assert_always my_inst (clk, reset_n, expression);
```

Multiple Line Replacement

dlf the OVL module instance extends over multiple lines, you can use either of the following two multi-line specification techniques:

Technique #1:

- 1. Insert a line "/* ova bind" before the instance.
- 2. insert a line with "*/" after the instance.

Technique #2:

- 1. Insert a line with "//ova begin" before the instance.
- 2. Prefix the OVL instance with "bind".
- 3. Insert a line with "//ova end" after the instance.

For example, suppose you want to replace the following OVL instance with an equivalent OVA checker.

```
assert_always #(1, 0, "my_message")
    my_always_instance (clk, reset_n, expression);
```

The following example shows a valid forms of specifying OVA inlined checkers:

```
/* ova bind
assert_always #(1, 0, "my_message")
          my_always_instance (clk, reset_n, expression);
*/

or

ova_begin bind
assert_always #(1, 0, "my_message")
          my_always_instance (clk, reset_n, expression);
ova_end
```

Combining OVA and OVL Checkers in the Same Design

You can use original OVL checkers and new OVA-based checkers in the same design. Using the `define macro, you can select which checker to use in which situation (e.g., use OVA to get functional coverage information).

For example:

```
`ifdef OVA
//ova bind assert_always #(,,"message-OVA") my_AG_instance (clk, rst_n, expr);
`elsif
```

```
assert_always #(,,"message-OVL") my_AG_instance (clk, rst_n, expr);
`endif
```

Restrictions

Note the following restrictions when using OVL-equivalent checkers:

- The OVL checker assert_proposition is not available in OVA because it is an asynchronous checker that does not require variable sampling.
- Unit parameters that control the extent of synchronous delays (number of clock ticks) and assertion variants in a checker must be compile-time constants — they must not be specified using design parameters. This restriction concerns the following checkers and parameters:

Checker	Parameters
assert_always_on_edge	edge_type
assert_change	<pre>num_cks, flag</pre>
assert_cycle_sequence	<pre>necessary_condition, num_cks</pre>
assert_frame	<pre>min_cks, max_cks, flag</pre>
assert_handshake	<pre>min_ack_cycle, max_ack_cycle, req_drop, deassert_count, max_ack_length</pre>
assert_next	<pre>num_cks, check_overlapping, only_if</pre>
assert_one_cold	inactive

```
assert_time num_cks, flag
assert_unchange num_cks, flag
assert width min cks, max cks
```

Macro symbol ASSERT_OFF

The assert directives in the OVL-like checkers that include cover directives as listed in Chapter 1 can be globally disabled by defining the symbol ASSERT_OFF.

Inlining OVA Units in a Verilog Wrapper Module

Many of the OVA units described in this chapter can be inlined in a Verilog wrapper module, which then can be instantiated in the design (Note: Of the 30 available checkers, 20 can be used for inlining; exceptions are described in the "Restrictions" section below). The compile command must include the "-ova_inline" option to indicate that the OVA checkers should be processed.

To change from an original OVL checker to a OVA-based checker, you must do the following:

- 1. Remove any reference to the original OVL library.
- 2. Include a reference to the directory where the OVA Verilog wrapper modules are located.
- 3. Compile with the -ova_inline option.

Note: Coverage using cover statements in the select checkers listed in "Coverage Properties" on page 1-3 is not available through OVL Verilog wrappers at this time.

Using OVL-Equivalent Checkers with VHDL Designs

OVA assertions and checkers cannot yet be inlined in VHDL designs. Therefore, the only way to add the checkers to such designs is by creating an external OVA file that contains the appropriate OVA bind statements.

Descriptions of OVL-Equivalent OVA Checkers

This section provides descriptions of the following OVL-equivalent checkers:

```
assert always on edge
                        assert no transition
assert change
                        assert no underflow
assert cycle sequence
                       assert odd parity
assert decrement
                        assert one cold
assert delta
                        assert one hot
assert even parity
                        assert quiescent state
assert fifo index
                        assert range
assert frame
                        assert time
assert handshake
                        assert transition
assert implication
                        assert unchange
                        assert width
assert increment
assert never
                        assert win change
assert next
                        assert win unchange
assert no overflow
                        assert window
                        assert zero one hot
```

Note: The severity and category parameters for these checkers can take defalt values as specified by the set_severity and set_category OVA commands.

assert_always

This checker continuously monitors $test_expr$ at every positive edge of clock, c1k. It verifies that $test_expr$ will always evaluate TRUE. If $test\ expr$ evaluates to FALSE, the assertion will fire.

Syntax

Arguments

```
severity level
```

Severity of the failure (default is 0).

options

Currently, the only supported option is options=1, which defines the assertion as an assumption for formal tools. The default is 0 (no options specified).

msg

Error message printed when the checker fires.

```
category
```

Checker type (default is 0).

clk

Sampling clock of the checker.

reset n

Signal indicating completed initialization.

```
test expr
```

Expression being verified at the posedge of clk.

Coverage modes

Level_1 (bit 0 set in coverage_level)

Cover property cover_always indicates the number of times test_expr was asserted when enabled by reset n.

Example

```
'define ASSERT ON
'define COVER ON
module testbench;
reg reset n, clk;
child CH (reset n, clk);
initial begin
    clk = 0;
    reset n = 0;
    #40 reset n = 1;
    #980 $finish;
end
always #20 clk = ~clk;
endmodule
module child(reset n, clk);
input reset n, clk;
reg [3:0] count;
initial $monitor("count = %b \n", count);
always @(posedge clk) begin
    if (reset n == 0 \mid \mid count >= 9)
        count <= 1'b0;
    else
        count <= count + 1;</pre>
end
/*
ova bind assert always //coverage level = 4 (Level 3)
```

```
#(0, 0, "ERROR: count not within 0 and 9", 0, 4)
   valid_count
  (clk, reset_n, (count >= 4'b0000) && (count <= 4'b1001));
*/
endmodule</pre>
```

assert_always_on_edge

This checker continuously monitors the $test_expr$ at every specified edge of the $sampling_event$ that coincides with the positive edge of clock, clk. The $test_expr$ should always evaluate TRUE at the $sampling_event$. If $test_expr$ evaluates to FALSE, the assertion will fire.

Syntax

edge_type

Selects the transition for sampling event:

0 — no edge (default)

1 — positive edge

2 — negative edge

з — any edge

options

Currently, the only supported option is options=1, which defines that the assertion is an assumption for formal tools.

msg

The error message that will be printed if the assertion fires.

category

Checker type (default is 0).

clk

Triggering or clocking event that monitors the assertion.

reset n

Signal indicating completed initialization.

sampling event

Expression defines when to evaluate test_expr. Transition of sampling_event are selected by edge type.

test expr

Expression being verified at the positive edge of clk, AND if sampling_event matches transition selected by edge_type.

Coverage modes

Level_1 (bit 0 set in coverage_level)

Cover property cover_always_on_edge indicates the number of times test_expr was asserted on the specified edge of sampling event.

Example

```
'define ASSERT ON
'define COVER ON
module testbench;
reg reset_n, clk, sig;
child CH (reset n, clk, sig);
initial begin
    $vcdpluson;
    clk = 0;
    reset n = 0;
    siq = 0;
    #40 reset n = 1;
    #980 $finish;
end
always #20 clk = ~clk;
always #40 sig = ~sig;
endmodule
module child(reset n, clk, sig);
input reset n, clk, sig;
reg [3:0] count;
initial $monitor("count = %b \n", count);
always @(posedge clk) begin
    if (reset n == 0 \mid | count >= 9)
        count <= 1'b0;
    else
        count <= count + 1;</pre>
end
/* ova
bind assert always on edge // coverage level = 1
  \#(0, 1, 0, "ERROR: count not within 0 and 9", , 1)
    valid always on edge
 (clk, reset n, sig, (count >= 4'b0000) &&
```

```
(count <= 4'b1001));
*/
endmodule</pre>
```

assert_change

This checker continuously monitors the <code>start_event</code> at every positive edge of the clock. When <code>start_event</code> is TRUE, the checker ensures that the expression, <code>test_expr</code>, changes values on a clock edge at some point within the next <code>num_cks</code> number of clocks. This assertion will fire upon a violation.

Syntax

Arguments

severity level

Severity of the failure (default is 0).

Width

Width of the expression, test expr (default is 1.

Num cks

Number of clocks for $test_expr$ to change its value before an error is triggered after $start_event$ is asserted (default is 1).

flag

- 0 Ignore any start_event assertion after the first one has been detected.
- 1 Restart the monitoring test_expr, if start_event is asserted in any subsequent clock while monitoring test_expr.
- 2 Issue an error if an asserted start_event occurs in any clock cycle while monitoring test expr.

options

Currently, the only supported option is options=1, which defines the assertion is an assumption for formal tools. msq

Error message that will be printed when the assertion fires.

category

Checker type (default is 0).

clk

Sampling clock of the checker.

reset n

Signal that indicates a completed initialization.

start event

Starting event that triggers monitoring of the test expr.

test expr

Expression or variable being verified at the positive edge of clk.

Coverage modes

Level 1 (bit 0 set in coverage level)

Cover property cover_change indicates the number of times exp changed within num cks.

Cover property cover_start_event indicates the number of times start event occurred.

Level_3 (bit 2 set in coverage_level)

Cover property cover_overlapping_start_events indicates how many times start_event occured while there was another evaluation attempt in progress.

Cover property cover_change_after_1_clk indicates the number of times test_expr changed value at the next clock tick after start event.

Cover property cover_change_after_num_cks indicates the number of times test_expr changed value at num_clks clock ticks after start_event.

Example

```
'define ASSERT ON
'define COVER ON
module testbench;
reg reset_n, clk;
child CH (reset n, clk);
initial begin
    $vcdpluson;
    clk = 0;
    reset n = 0;
    #40 reset n = 1;
    #1000 $finish;
end
always #20 clk = ~clk;
endmodule
module child(reset n, clk);
input reset n, clk;
reg start;
reg [3:0] expr;
integer count;
initial $monitor ("count = %d start = %b expr = %b \n",
```

```
count, start, expr);
always @(posedge clk)
begin
     if (reset n == 0)
     begin
         start <= 0;
         expr <= 4'b0000;
         count <= 0;
     end
     else
         count <= count + 1;</pre>
    if (count == 3 | count == 4 | count == 5 | count ==
6 | count == 7 | count == 8 | count == 9)
         expr <= 4'b0110;
     else
         expr <= expr + 1;
     if (count == 4)
         start <= 1;
     else
         start <= 0;
end
/* ova bind
assert change #(0, 4, 4, 0, 0,
"ERROR: expr did not change in num clk cycles after start",
                       , 7) // all Coverage Levels
valid change (clk, reset n, start, expr);
*/
endmodule
```

assert_cycle_sequence

This checker verifies the following conditions:

- When necessary_condition = 0, if all num_cks-1 first events of a sequence (event_sequence [num_cks-1:1]) are TRUE, the last sequence (event_sequence [0]) should follow.
- When necessary_condition = 1, if the first event of a sequence (event_sequence[num_cks-1]) is TRUE, then all the remaining event_sequence[num_cks-2:0] events should follow.

Syntax

```
assert_cycle_sequence
  [#(severity_level, num_cks, necessary_condition, options,
msg, category)]
  instance_name (clk, reset_n, event_sequence);
```

Arguments

```
severity_level
```

Severity of the failure (default is 0).

```
num cks
```

The length of the <code>event_sequence</code> (number of clock cycles of the <code>event_sequence</code>) that must be valid. Otherwise, the checker will fire.

```
necessary_condition Either 1 or 0 (default 0).
```

options

Currently, the only supported option is options=1, which defines that the assertion is an assumption for formal tools.

msg

Error message that will be printed when the assertion fires.

category

Checker type (default is 0).

clk

Sampling clock of the checker.

reset n

Signal indicating completed initialization.

event sequence

A Verilog concatenation expression, where each bit represents an event.

assert_decrement

This checker continuously monitors the $test_expr$ at every positive edge of the clock signal, c1k. It checks that the $test_expr$ will never decrease by anything other than the value specified by value.

Syntax

```
assert decrement
  [#(severity level, width, value, options, msg, category)]
  instance name (clk, reset n, test expr);
Arguments
severity level
   Severity of the failure (default 0).
width
   Width of test expr (default is 1).
value
   Maximum decrement value allowed for test expr (default is 1).
options
   Currently, the only supported option is options=1, which defines
   that the assertion is an assumption for formal tools.
msq
   Error message that will be printed when the assertion fires.
category
   Checker type (default is 0).
clk
   Sampling clock of the checker.
reset n
   Signal indicating completed initialization.
test expr
   Expression being verified at the positive edge of c1k.
```

assert_delta

This checker continuously monitors the $test_expr$ at every positive edge of clock signal, c1k. It verifies that $test_expr$ will never change value by anything less than "min" and anything more than "max" value.

Syntax

```
assert_delta
  [#(severity_level, width, min, max, options, msg,
category)]
  instance_name (clk, reset_n, test_expr);
```

Arguments

```
severity_level
Severity of the failure (default is 0).
```

width

Width of $test_expr$ (default is 1).

min

Minimum changed value allowed for $test_expr$ in two consecutive clocks of clk (default is 1).

max

Maximum changed value allowed for $test_expr$ in two consecutive clocks of clk (default is 1).

options

Currently, the only supported option is options=1, which defines that the assertion is an assumption for formal tools.

msg

Error message that will be printed when the assertion fires.

category

Checker type (default is 0).

clk

Sampling clock of the checker.

reset_n

Signal indicating completed initialization.

test expr

 $\overline{\mathsf{Expression}}$ being verified at the positive edge of c1k.

assert_even_parity

This checker continuously monitors the $test_expr$ at every positive edge of the clock signal, c1k. It verifies that $test_expr$ will always have an even number of bits asserted.

Syntax

```
assert even parity
   [#(severity level, width, options, msg, category,
      coverage level)]
   instance name (clk, reset n, test expr);
Arguments
severity level
   Severity of the failure (default is 0).
width
   Width of test expr (default is 1).
options
   Currently, the only supported option is options=1, which defines
   that the assertion is an assumption for formal tools.
msq
   Error message that will be printed when the assertion fires.
category
   Checker type (default is 0).
clk
   Sampling clock of the checker.
reset n
   Signal indicating completed initialization.
test expr
```

Expression being verified at the positive edge of clk.

Coverage modes

Level_1 (bit 0 set in coverage_level)

Cover property cover_test_expr_change indicates how
many times test_expr changed value.

Example

```
'define ASSERT ON
'define COVER ON
module testbench;
reg reset_n, clk;
child CH (reset n, clk);
initial begin
    $vcdpluson;
    clk = 0;
    reset n = 0;
    #40 reset n = 1;
    #980 $finish;
end
always #20 clk = ~clk;
endmodule
module child(reset n, clk);
input reset n, clk;
reg [7:0] count;
initial $monitor("count = %b \n", count);
always @(posedge clk)
begin
    if (reset n == 0)
        count <= 8'b11111111;</pre>
    else
        count <= count << 2;</pre>
end
/* ova bind
assert_even_parity // Default coverage level
#(0, 8, 0, "ERROR: count has odd number of bits asserted")
valid count even (clk, reset n, (count));
*/
endmodule
```

assert_fifo_index

This checker ensures that the FIFO element:

- Never overflows and underflows
- Allows/disallows simultaneous push and pop.

Syntax

```
assert fifo index
  [#(severity level, depth, push width, pop width, options,
msg, category)]
  instance name (clk, reset n, push, pop);
Arguments
severity level
   Severity of the failure (default is 0).
depth
   Depth of the FIFO (default is 1). It should never be set to 0,
   otherwise an assertion will fire.
push width
   Width of the PUSH signal (default is 1).
pop width
   Width of the POP signal (default is 1).
options
   Currently, the only supported option is options=1, which defines
   the assertion is an assumption for formal tools.
msg
   Error message that will be printed when the assertion fires.
category
   Checker type (default is 0).
clk
   Sampling clock of the checker.
```

reset_n

Signal indicating completed initialization.

push

FIFO PUSH/enqueue signal.

pop

FIFO POP/dequeue signal.

assert_frame

This checker validates proper cycle timing relationships between two events in the design. When a <code>start_event</code> evaluates TRUE, then the <code>test_expr</code> must evaluate TRUE within a minimum and maximum number of clock cycles.

Syntax

```
assert_frame
  [#(severity_level, min_cks, max_cks, flag, options, msg,
category)]
  instance_name (clk, reset_n, start_event, test_expr);
```

Arguments

severity level

Severity of the failure (default is 0).

min cks

Minimum number of clock cycles, within which the $test_expr$ should not become TRUE. When min_cks is 0, then $test_expr$ can occur at the same time as $start_event$ or after, as controlled by max cks. Default is 0.

max cks

Maximum number of clock cycles, before which $test_expr$ must become TRUE. This check will be disabled when max_cks is not specified. If both min_cks and max_cks are 0 then $test_expr$ must occuer at the same time as there is a 0 to 1 transition on $start\ event$. The default is 0.

flaq

0—Ignores any asserted start_event after the first one has been detected (default).

1—Restart monitoring test_expr if start_event is asserted in any subsequent clock while monitoring test expr.

2 — Issue an error if an asserted start_event occurs in any clock cycle while monitoring test_expr.

options

Currently, the only supported option is options=1, which defines that the assertion is an assumption for formal tools.

msg

Error message that will be printed when the assertion fires.

category

Checker type (default is 0)

clk

Triggering or clocking sampling event for assertion.

reset n

Signal indicating completed initialization.

start_event

Starting event that triggers monitoring of the test_expr. The start event is a cycle transition from 0 to 1.

test expr

Expression being verified at the positive edge of clk.

assert_handshake

This checker continuously monitors the req and ack signals at every positive edge of the clock c1k. Note that both req and ack must go inactive prior to starting a new cycle.

To activate one or more checks in the checker, the following parameters should be specified with a non-zero value:

min ack cycle

When this parameter is greater than 0, the assertion will ensure that an *ack* does not occur before *min ack cycle* clock ticks.

max ack cycle

When this parameter is greater than 0, the assertion will ensure that an ack does not occur after max ack cycle clock ticks.

req drop

When this parameter is greater than 0, the assertion will ensure that req remains active until an ack occurs.

deassert count

When this parameter is greater than 0, the assertion will ensure that req becomes inactive (0) within deassert_count clock ticks after an ack.

max ack length

When this parameter is greater than 0, the assertion will ensure that ack is not asserted for greater than max_ack_length clock cycles and does not become inactive (0) within $deassert_count$ clocks after ack is asserted (that is, check for ack stuck active).

Note that if you do not specify a parameter with a non-zero value, the corresponding check will not be active.

Syntax

```
assert handshake
   [#(severity level, min ack cycle, max ack cycle,
      req_drop, deassert_count, max_ack_length, options,
      msq, category)]
   instance name (clk, reset n, req, ack);
Arguments
severity level
   Severity of the failure (default is 0).
min ack cycle
   Activate min ack cycle check if greater than 0.
max ack cycle
   Activate max ack cycle check if greater than 0.
req drop
   Activate req drop check if greater than 0.
deassert count
   Activate deassert count if greater than 0.
max ack length
   Activate max_ack_length check if greater than 0.
options
   Currently, the only supported option is options=1, which defines
   the assertion is an assumption for formal tools.
msg
   Error message that will be printed when the assertion fires.
category
   Checker type (default is 0)
clk
   Sampling clock of the checker.
reset n
```

Signal indicating completed initialization.

assert_implication

This checker continuously monitors <code>antecedent_expr</code>. If it evaluates to TRUE, then this checker will verify that <code>consequent_expr</code> is TRUE.

When antecedent_expr is evaluated to FALSE, then consequent_expr expression will not be checked at all and the implication is satisfied.

Syntax

```
assert_implication [#(severity_level, options, msg,
category)]
  instance_name (clk, reset_n, antecedent_expr,
consequent expr);
```

Arguments

```
severity level
```

Severity of the failure, default 0.

msg

Error message that will be printed when the assertion fires.

```
category
```

Checker type, default 0.

clk

Sampling clock of the checker.

```
reset n
```

Signal indicating completed initialization.

```
antecedent expr
```

Expression verified at the positive edge of the clock, clk.

```
consequent expr
```

Expression verified at the positive edge of the clock, clk.

assert_increment

This checker continuously monitors $test_expr$ at every positive edge of the clock, clk. It verifies that $test_expr$ will never increase by anything other than the value specified by value. The $test_expr$ can be any valid Verilog expression. The check will not start until the first clock after the reset n is asserted.

Syntax

```
assert increment
  [#(severity level, width, value, options, msg, category)]
  instance name (clk, reset n, test expr);
Arguments
severity level
   Severity of the failure (default is 0).
width
   Width of test expr (default is 1).
value
   Maximum increment value allowed for test\ expr (default is 1).
options
   Currently, the only supported option is options=1, which defines
   that the assertion is an assumption for formal tools.
   Error message that will be printed when the assertion fires.
category
   Checker type (default is 0).
clk
   Sampling clock of the checker.
reset n
   Signal indicating completed initialization.
```

test_expr

Expression being verified at the positive edge of c1k.

assert never

This checker continuously monitors $test_expr$ at every positive edge of clock, c1k. It verifies that $test_expr$ will never evaluate TRUE. The $test_expr$ can be any valid Verilog expression. When $test\ expr$ evaluates TRUE, this checker will fail.

Syntax

```
assert_never
  [#(severity_level, options, msg, category)]
  instance name (clk, reset n, test expr);
```

Arguments

```
severity_level
Severity of the failure (default is 0).
```

options

Currently, the only supported option is options=1, which defines that the assertion is an assumption for formal tools.

msg

Error message that will be printed when the assertion fires.

```
category
```

Checker type, default 0.

clk

Sampling clock of the checker.

reset n

Signal indicating completed initialization.

test expr

Expression being verified at the positive edge of clk.

assert_next

This checker verifies the proper cycle timing relationship between two events in the design at every posedge of the clock, clk. When a start_event evaluates TRUE, then test_expr must evaluate TRUE exactly num cks number of clock cycles later.

This checker supports overlapping sequences. For example, if you assert that $test_expr$ will evaluate TRUE exactly four cycles after $start_event$, it is not necessary to wait until the sequence finishes before another sequence can begin.

Syntax

```
assert_next [#(severity_level, num_cks, check_overlapping,
only_if, options, msg, category)]
   instance_name (clk, reset_n, start_event, test_expr);
```

Arguments

severity_level

Severity of the failure (default is 0).

num cks

Number of clocks for the test_expr to become TRUE after start_event is asserted (default is 0).

check overlapping

If set to 1, permits overlapping sequences. In other words, a new start_event can occur (starting a new sequence in parallel) while the previous sequence continues. (Default is 1.)

only if

If set to 1, a $test_expr$ can only evaluate TRUE if preceded num_cks earlier by a $start_event$. If $test_expr$ occurs without a $start_event$, then an error is reported. Default 0.

options

Currently, the only supported option is options=1, which defines that the assertion is an assumption for formal tools.

msg

Error message that will be printed when the assertion fires.

category

Checker type (default is 0).

clk

Sampling clock of the assertion on posedge clk.

reset n

Signal indicating completed initialization.

start_event

Starting event that triggers monitoring of the test expr.

test expr

Expression or variable being verified at the positive edge of clk.

assert_no_overflow

This checker ensures that the expx, from 'max' value, never goes to a value that is less than or equal to 'min' and greater than 'max', at every posedge of the clock, clk.

Syntax

```
assert_no_overflow
  [#(severity_level, width, min, max, options, msg,
category)]
  instance name (clk, reset n, expr);
```

Arguments

severity level

Severity of the failure (default is 0).

width

Width of the monitored expression, expr (default is 1).

min

Minimum value limit for the expr at clock tick t+1 when expr == max at clock tick 't' (This value is excluded from the acceptable range). Default is 0.

max

Maximum value limit for the expr at clock tick t+1 when expr == max at clock tick 't' (This value is included in the acceptable range). Default is 1.

options

Currently, the only supported option is options=1, which defines the assertion is an assumption for formal tools.

msg

Error message that will be printed when the assertion fires.

category

Checker type, default 0.

clk

Sampling clock of the checker.

reset_n

Signal indicating completed initialization.

expr

Expression being verified at the positive edge of c1k.

assert_no_transition

This checker ensures that, when the state variable $test_expr$ reaches a value specified by $start_state$, it does not transit to a state/value specified by $next_state$. All variables are sampled at posedge of the clock, clk.

Syntax

```
assert_no_transition
  [#(severity_level, width, options, msg, category)]
  instance_name (clk, reset_n, test_expr, start_state,
next_state);
```

Arguments

```
severity_level
Severity of the failure (default is 0.)
```

width

Width of test_expr, start_state, and next_state signals (default is 1).

options

Currently, the only supported option is options=1, which defines the assertion is an assumption for formal tools.

msq

Error message that will be printed when the assertion fires.

category

Checker type (default is 0).

clk

Sampling clock of the checker.

reset n

Signal indicating completed initialization.

test expr

Expression being verified at the positive edge of c1k.

start_state

State value at the start. When $test_expr$ equals this value, the evaluation starts.

next state

Next state value. Once test_expr matches with $start_state$, $test_expr$ should not transit to this value at the next clock tick.

assert_no_underflow

This checker ensures that $test_expr$ never canges from 'min' value to a value that is less than 'min' and greater than or equal to 'max'.

Syntax

```
assert_no_underflow
  [#(severity_level, width, min, max, options, msg,
category)]
  instance_name (clk, reset_n, test_expr);
```

Arguments

severity level

Severity of the failure (default is 0).

width

Width of the monitored expression, $test_expr$. Currently, this value is limited to 32 bits due to a Verilog limitation on the number of bits in a parameter. Default 1.

min

Minimum value limit for the test_expr at clock tick t+1 when test_expr == max at clock tick 't' (this value is included in the acceptable range).

max

Maximum value limit for the test_expr at clock tick t+1 when test_expr == max at clock tick 't' (This value is excluded from the acceptable range).

options

Currently, the only supported option is options=1, which defines the assertion is an assumption for formal tools.

msq

Error message that will be printed when the assertion fires.

category

Checker type (default is 0).

clk

Sampling clock of the checker.

reset n

Signal indicating completed initialization.

test expr

 $\overline{\mathsf{Expression}}$ being verified at the positive edge of c1k.

assert_odd_parity

This checker monitors for odd number of '1's in $test_expr$ at every positive edge of the clock, c1k.

Syntax

Arguments

```
severity level
```

Severity of the failure (default is 0).

width

Width of test expr (default is 1).

options

Currently, the only supported option is options=1, which defines the assertion is an assumption for formal tools.

msg

Error message that will be printed when the assertion fires.

category

Checker type (default is 0).

clk

The sampling clock of the checker.

reset n

Signal indicating completed initialization.

test expr

Expression being verified at every positive edge of c1k.

Coverage modes

Level_1 (bit 0 set in coverage_level)

Cover property cover_test_expr_change indicates how many times test_expr changed.

Example

```
module testbench;
reg reset_n, clk;
child CH (reset_n, clk);
initial begin
    $vcdpluson;
    clk = 0;
    reset n = 0;
    #40 reset_n = 1;
    #980 $finish;
end
always #20 clk = ~clk;
endmodule
module child(reset n, clk);
input reset n, clk;
reg [6:0] count;
initial $monitor("count = %b \n", count);
always @(posedge clk)
begin
    if (reset n == 0)
    begin
        count <= 7'b1111111;</pre>
    end
    else
        count <= count << 1;</pre>
end
/*ova bind
assert_odd_parity #(0, 7, 0, //
```

```
"ERROR: count does not have an odd number of bits asserted",
   0, 1)
valid_count_odd (clk, reset_n, count);// Coverage Level 1
*/
endmodule
```

assert_one_cold

This checker ensures that the variable, $test_{expr}$, has only one bit low at any positive clock edge when the checker is configured for no inactive states.

The checker can also be configured to accept all bits equal to either 0 or 1 as the inactive level.

Syntax

Arguments

```
severity_level
```

Severity of the failure (default is 0).

width

Width of $test\ expr\ (default\ is\ 32)$.

inactive

Specifies the inactive state of test expr:

inactive = 0 allows the inactive state of $test_expr$ to be all zeros.

inactive = 1 allows the inactive state of $test_{expr}$ to be all ones.

inactive = 2 (default) specifies that no inactive state is allowed.

options

Currently, the only supported option is options=1, which defines that the assertion is an assumption for formal tools.

msg

Error message that will be printed when the assertion fires.

category

Checker type (default is 0).

clk

The sampling clock of the checker.

reset n

Signal indicating completed initialization.

test expr

Expression to be verified for "one cold" at the positive edge of Clk.

Coverage modes

Level 1 (bit 0 set in coverage level)

Cover property cover_test_expr_change indicates how many times test expr changed value.

Level 2 (bit 1 set in coverage level)

Cover property cover_test_expr_with_all_1 indicates how many times test_expr was all 1s. Enabled when inactive == 1.

Cover property cover_test_expr_with_all_0 indicates how many times test_expr was all 0s. Enabled when inactive == 0.

Level_3 (bit 2 set in coverage_level)

Cover property cover_test_expr_bit_is_0[i] indicates how many times bit i of test_expr was 0 when test_expr changed value.

Example

```
'define ASSERT ON
'define COVER ON
module testbench;
reg reset_n, clk;
child CH (reset n, clk);
initial begin
    $vcdpluson;
    clk = 0;
    reset n = 0;
    #40 reset n = 1;
    #980 $finish;
end
always #20 clk = ~clk;
endmodule
module child(reset n, clk);
input reset n, clk;
reg [7:0] count;
initial $monitor("count = %b \n", count);
always @(posedge clk)
begin
    if (reset n == 0)
        count <= 8'b11111110;</pre>
    else
        count <= ((count << 1) | {7'b0000000, count[7]});</pre>
end
/* ova bind
assert one cold #(0, 8, 0, 0, "ERROR: count is not one-cold",
                   0 ,2) // Level 2 coverage
valid one cold (clk, reset n, count);
*/
endmodule
```

assert_one_hot

This checker ensures that the variable, $test_{expr}$, has only one bit high at any positive clock edge.

Syntax

Arguments

```
severity level
```

Severity of the failure (default is 0).

width

Width of test expr (default is 32).

options

Currently, the only supported option is options=1, which defines that the assertion is an assumption for formal tools.

msq

Error message that will be printed when the assertion fires.

category

Checker type (default is 0).

clk

The sampling clock of the checker.

reset n

Signal indicating completed initialization.

test expr

Expression to be verified for "one hot" at the positive edge of Clk.

Coverage modes

Level_1 (bit 0 set in coverage_level)

Cover property cover_test_expr_change indicates how
many times test expr changed value.

Level_3 (bit 2 set in coverage_level)

Cover property cover_test_expr_bit_is_1[i] inidcates how many times bit i of test_expr was 1 when test_expr changes value.

Example

```
'define ASSERT ON
'define COVER ON
module testbench;
reg reset n, clk;
child CH (reset n, clk);
initial begin
    $vcdpluson;
    clk = 0;
    reset n = 0;
    #40 reset n = 1;
    #980 $finish;
end
always #20 clk = ~clk;
endmodule
module child(reset n, clk);
input reset n, clk;
reg [7:0] count;
initial $monitor("count = %b \n", count);
always @(posedge clk)
begin
    if (reset n == 0)
        count <= 8'b00000001;
    else
        count <= ((count << 1) | {7'b0000000, count[7]});</pre>
end
/*ova bind
assert one hot #(0, 8, 0, "ERROR: count is not one-hot",
           0, 5) // coverage level = 5: Level 1 and 3 coverage
invalid one hot (clk, reset n, count);
* /
endmodule
```

assert_quiescent_state

This checker verifies that the value in the variable <code>state_expr</code>, is equal to the value specified by <code>check_value</code> when a sampled positive edge is detected on <code>sample event</code>.

Syntax

```
assert_quiescent_state
  [#(severity_level, width, options, msg, category)]
  instance_name (clk, reset_n, state_expr, check_value,
    sample event);
```

Arguments

```
severity level
```

Severity of the failure (default is 0).

width

Width of state expr and check value signals (default is 1).

options

Currently, the only supported option is options=1, which defines the assertion is an assumption for formal tools.

msq

Error message that will be printed when the assertion fires.

```
category
```

Checker type (default is 0).

clk

Sampling clock of the checker.

```
reset n
```

Signal indicating completed initialization.

```
state expr
```

Variable to be checked at every posedge of clk.

check_value

Signal that holds the value to be compared with $state_expr$ when $sample_event$ is asserted.

sample_event

Sampling trigger signal.

assert_range

This checker ensures that the value of $test_expr$ will always be within the 'min' and 'max' value range.

Syntax

```
assert range
   [#(severity level, width, min, max, options, msg,
category)]
   instance name (clk, reset n, test expr);
Arguments
severity level
   Severity of the failure (default is 0).
width
   Width of test expr (default is 1).
min
   Minimum value allowed for range check (default is 0).
max
   Maximum value allowed for range check. (default is 1).
options
   Currently, the only supported option is options=1, which defines
   that the assertion is an assumption for formal tools.
msg
   Error message that will be printed when the assertion fires.
category
   Checker type (default is 0).
clk
   Sampling clock of the checker.
reset n
   Signal indicating completed initialization.
test expr
   Expression being verified at the positive edge of clk.
```

assert time

This checker continuously monitors the <code>start_event</code> at every positive edge of the clock, <code>clk</code>. When <code>start_event</code> is TRUE, the checker ensures that the expression, <code>test_expr</code>, is TRUE up to <code>num cks</code> number of clock ticks.

Syntax

```
assert_time
[#(severity_level, num_cks, flag, options, msg, category)]
instance name (clk, reset n, start event, test expr);
```

Arguments

```
severity_level
Severity of the failure (default is 0).
```

num cks

Number of clock ticks for $test_expr$ to remain TRUE after $start\ event$ is asserted.

Flag

- 0 Ignores any asserted start_event after the first one has been detected.
- 1 Restart monitoring test_expr, if start_event is asserted in any subsequent clock cycle while monitoring test expr.
- 2 Issue an error if an asserted start_event occurs in any clock cycle while monitoring test_expr.

options

Currently, the only supported option is options=1, which defines the assertion is an assumption for formal tools.

msg

Error message that will be printed when the assertion fires.

category

Checker type (default is 0).

clk

Sampling clock of the assertion.

reset n

Signal indicating completed initialization.

start event

Starting event that triggers monitoring of test_expr.

test_expr

One-bit variable verified at the positive edge of c1k.

assert_transition

This checker ensures that, when the state variable $test_expr$ reaches the value specified by $start_state$, it does transit to a state/value specified by $next_state$.

Syntax

```
assert_transition
  [#(severity_level, width, options, msg, category)]
  instance_name (clk, reset_n, test_expr, start_state,
next state);
```

Arguments

```
severity level
```

Severity of the failure (default is 0).

width

Width of test_expr, start_state, and next_state signals (default is 1).

options

Currently, the only supported option is options=1, which defines the assertion is an assumption for formal tools.

msg

Error message that will be printed when the assertion fires.

category

Checker type (default is 0).

clk

Sampling clock of the checker.

reset n

Signal indicating completed initialization.

test expr

Expression verified at the positive edge of c1k.

start_state

Start value of $test_expr$. When $test_expr$ equals this value, the veriication begins.

next state

Next value. Once $test_expr$ matches with $start_state$, $test_expr$ should transit to this next value (or hold at $start_state$).

assert_unchange

This checker monitors the <code>start_event</code> at every positive edge of the clock, <code>clk</code>. When <code>start_event</code> is TRUE, the checker ensures that the expression, <code>test_expr</code> does not change its value within <code>num cks</code> clocks.

Syntax

Arguments

severity_level
Severity of the failure (default is 0).

Width

Width of test expr (default is 1).

Num cks

Number of clock ticks for $test_expr$ to remain unchanged after $start_event$ is asserted.

Flag

- 0 Ignores any asserted start_event after the first one has been detected.
- 1 Re-start monitoring $test_expr$ if start_event is asserted in any subsequent clock while monitoring $test_expr$.
- 2 Issue an error if an asserted <code>start_event</code> occurs in any clock cycles while monitoring test_expr.

options

Currently, the only supported option is options=1, which defines the assertion is an assumption for formal tools.

msg

Error message that will be printed when the assertion fires.

category

Checker type (default is 0).

clk

Sampling clock of the checker.

reset_n

Signal indicating completed initialization.

start event

Starting event that triggers monitoring of test expr.

test expr

Expression verified at the positive edge of clk.

Coverage modes

Level 1 (bit 0 set in coverage level)

Cover property cover_start_event indicates how many times start_event was asserted.

Cover property cover_unchange indicates how many times test expr remained stable the required time interval.

Level 3 (bit 2 set in coverage level)

Cover property cover_overlapping_start_events indicates how many times a start_event occurred while a previously triggered evaluation attempt was still in progress.

Example

```
'define ASSERT ON
'define COVER ON
module testbench;
reg reset_n, clk;
child CH (reset n, clk);
initial begin
    $vcdpluson;
    clk = 0;
    reset n = 0;
    #40 reset n = 1;
    #1000 $finish;
end
always #20 clk = ~clk;
endmodule
module child(reset n, clk);
input reset n, clk;
reg start;
reg [3:0] expr;
integer count;
initial $monitor ("count = %d start = %b expr = %b \n",
```

```
count, start, expr);
always @(posedge clk)
begin
    if (reset n == 0)
    begin
        start <= 0;
        expr <= 4'b0000;
        count <= 0;
    end
    else
        count <= count + 1;</pre>
    if (count == 3)
        start <= 1;
    else
        start <= 0;
   if (count == 3 | count == 4 | count == 5 | count ==
6 | count == 7 | count == 8 | count == 9)
        expr <= 4'b0110;
    else
        expr <= expr + 1;
end
/*ova bind
assert unchange #(0, 4, 4, 1, 0,
"ERROR: expr not stable in the num clk cycles after start",
   0, 3) // coverage level = 3: Levels 1 and 2
valid unchange (clk, reset n, start, expr);
*/
endmodule
```

assert_width

This checker ensures that, when test expr becomes TRUE it should remain TRUE at least for 'min' number of clock cycles and at most 'max' number of clock cycles. It should never remain TRUE beyond that limit.

Syntax

```
assert width
   [#(severity level, min cks, max cks, options, msg,
category)]
   instance name (clk, reset n, test expr);
Arguments
```

```
severity level
   Severity of the failure (default is 0).
```

```
min cks
   test expr should be held TRUE at least for min cks n umber
   of clocks (default is 1).
```

```
max cks
   test expr should not be held TRUE for more than max cks
   number of clocks (default is 1).
```

options

Currently, the only supported option is options=1, which defines that the assertion is an assumption for formal tools.

msg

Error message that will be printed when the assertion fires.

```
category
```

Checker type (default is 0).

clk

Sampling clock of the checker.

reset_n

Signal indicating completed initialization.

test_expr

Expression verified at every positive edge of clk.

assert_win_change

This checker ensures that $test_expr$ changes its value at least once between the assertions of start event and end event.

Syntax

```
assert win change
   [#(severity level, width, options, msg, category)]
   instance name (clk, reset n, start event, test expr,
end event);
Arguments
severity level
   Severity of the failure (default is 0).
width
   Width of the monitored expression, test expr. (default is 1).
options
   Currently, the only supported option is options=1, which defines
   the assertion is an assumption for formal tools.
msg
   Error message that will be printed when the assertion fires.
category
   Checker type, (default is 0).
clk
   Sampling clock of the checker.
reset n
   Signal indicating completed initialization.
start event
   Start of the window.
test expr
   Expression verified at the positive edge of clk.
end event
   End of the window.
```

assert_win_unchange

This checker ensures that the test_expr never changes its value between the assertions of start event and end event.

Syntax

```
assert win unchange
   [#(severity level, width, options, msg, category)]
   instance name (clk, reset n, start event, test expr,
end event);
Arguments
severity level
   Severity of the failure (default is 0).
width
   Width of the monitored expression, test_expr (default is 1).
options
   Currently, the only supported option is options=1, which defines
   that the assertion is an assumption for formal tools.
msq
   Error message that will be printed when the assertion fires.
category
   Checker type (default is 0).
clk
   Sampling clock of the checker.
reset n
   Signal indicating completed initialization.
start event
   Start of the window.
test expr
   Expression being verified at the positive edge of c1k.
end event
   End of the window.
```

assert_window

This checker ensures that $test_expr$ is asserted 1 as long as the window is open. Window open and close events are signaled by $start_event$ and end_event expressions. The verification starts on the next clock tick following $start_event$.

Syntax

```
assert window
   [#(severity_level, options, msg, category)]
   instance name (clk, reset n, start event, test expr,
end event);
Arguments
severity level
   Severity of the failure (default is 0).
options
   Currently, the only supported option is options=1, which defines
   the assertion is an assumption for formal tools.
msg
   Error message that will be printed when the assertion fires.
category
   Checker type (default is 0).
clk
   Sampling clock of the checker.
reset n
   Signal indicating completed initialization.
start event
   Start of the window.
test expr
   Signal being verified at the positive edge of clk.
end event
   End of the window.
```

assert zero one hot

This checker ensures that the variable, test expr, has only one bit 1 or all bits 0 at any positive edge of the clock, clk.

Syntax

```
assert zero one hot
    [#(severity level, width, options, msg,
       category, coverage level)]
    instance name (clk, reset n, test expr);
```

Arguments

```
severity level
```

Severity of the failure (default is 0).

width

Width of test expr (default is 32).

options

Currently, the only supported option is options=1, which defines the assertion is an assumption for formal tools.

msq

Error message that will be printed when the assertion fires.

category

Checker type (default is 0).

clk

Sampling clock of the checker.

reset n

Signal indicating completed initialization.

test expr

Expression to be verified for "one hot or all bits 0" at the positive edge of c1k.

Coverage modes

- Level_1 (bit 0 set in coverage_level)

 Cover property cover_test_expr_change indicates how
 many times test expr changed value.
- Level_2 (bit 1 set in coverage_level)

 Cover property cover_test_expr_with_all_0 indicates
 how many times the all 0 value occurred when test_expr
 changed value.
- Level_3 (bit 2 set in coverage_level)

 Cover property cover_test_expr_bit_is_1[i] indicates
 how many times bit test expr[i] was 1 after a change of value.

Example

```
'define ASSERT ON
'define COVER ON
module testbench;
reg reset_n, clk;
child CH (reset n, clk);
initial begin
    $vcdpluson;
    clk = 0;
    reset n = 0;
    #40 reset n = 1;
    #980 $finish;
end
always #20 clk = ~clk;
endmodule
module child(reset n, clk);
input reset n, clk;
reg [7:0] count;
initial begin
    monitor("count = %b \n", count);
end
always @(posedge clk)
begin
    if (reset n == 0 || count == 8'b00000000)
        count <= 8'b00000001;
    else
        count <= ((count << 1) | {7'b0, count[7]});</pre>
    if (count == 8'b10000000)
        count <= 8'b00000000;
end
/*ova bind
```



Four-State OVA Checkers

Checkers in the OVA Checker Library, except ova_driven, ova_forbid_bool, and ova_no_contention, use boolean equality (==, !=) in their underlying assertions. While the checkers may be used in four-state simulation, they do not detect equality or inequality on x and z (a check of x == y will be false if any operand has an x or z, even if it is in the same bit position).

The following come in two versions. The default one uses boolean equality while another version, also available in the library under a different name, supports case equality (===). The latter checkers in both unit and template forms are located in files having the postfix .4state in the OVA Checker Library. Note that most formal tools, supports only synthesizable assertions and should use only the default checkers should be used (case equality (===) as in all .4state checkers is not synthesizable, whereas boolean equality is). See your documentation for information.

ova_arith_overflow ova_hold_value

ova_const ova_inc

ova_data_used ova_quiescent_state

ova_dec ova_reg_loaded

ova_delta ova_tri-state ova_hold ova_timeout

To use the 4-state checkers, you define a macro of the same name as the checker in the OVA file, and then `include the checker file.

For example, to use four-state version of the std unit ova_inc, add the following two lines at the beginning of the OVA file:

```
`define inc
`include "$VCS_HOME/etc/ova/inc_u.ova.4state"
```

If you need to only the inc template, the two lines becomes:

[`]define inc

[`]include "\$VCS HOME/etc/ova/inc.ova.4state"

Index

A a 1-82 always evaluates to true 2-8 arbiter 1-12 arith_overflow 1-18 assert_always 2-8 assert_always_on_edge 2-11 assert_change 2-15 assert_cycle_sequence 2-19 assert_decrement 2-21 assert_delta 2-22	assert_quiescent_state 2-55 assert_range 2-57 assert_time 2-58 assert_transition 2-60 assert_unchange 2-62 assert_width 2-66 assert_win_change 2-68 assert_win_unchange 2-69 assert_window 2-70 assert_zero_one_hot 2-71 asserted 1-20
assert_even_parity 2-24 assert_fifo_index 2-27 assert_frame 2-29 assert_handshake 2-31 assert_implication 2-33 assert_increment 2-34 assert_never 2-36 assert_next 2-37 assert_no_overflow 2-39 assert_no_transition 2-41 assert_no_underflow 2-43 assert_odd_parity 2-45 assert_one_cold 2-49 assert_one_hot 2-52 assert_proposition 2-4	B bits 1-22 C change values 2-15 check_bool 1-25 Checker Library 1-1, 2-1, A-1 conventions 1-2 functional groups 1-8 ova_arbiter 1-12 ova_arith_overflow 1-18 ova_asserted 1-20 ova_bits 1-22 ova_check_bool 1-25

	ova_code_distance 1-26	conventions, Checker Library 1-2
	ova_const 1-28	converting from a Verilog OVL library 2-1
	ova_cover_bool 1-30	cover bool 1-30
	ova_data_used 1-31	COVEL_DOOL 1-30
	ova_deasserted 1-34	
	ova_dec 1-36	D
	ova_delta 1-38	D
	ova_driven 1-40	data_used 1-31
	ova_dual_clk_fifo 1-42	deasserted 1-34
	ova_even_parity 1-47	
	ova_fifo 1-49	dec 1-36
	ova_follows 1-55	delta 1-38
	ova_forbid_bool 1-58	dickery 1-2, 2-2
	ova_hold 1-60	
	ova_hold_value 1-63	driven 1-40
	ova_inc 1-66	dual_clk_fifo 1-42
	ova_memory 1-68	
	ova_memory_async 1-76	_
	ova_multiport_fifo 1-82	E
	ova_mutex 1-82	oven parity 1-47
	ova_next_state 1-89	even_parity 1-47
	ova_no_contention 1-93	
	ova_odd_parity 1-96	F
	ova_one_cold 1-98	Γ
	ova_one_hot 1-100	fifo 1-49
	ova_overflow 1-102	follows 1-55
	ova_quiescent_state 1-104	
	ova_range 1-106	forbid_bool 1-58
	ova_reg_loaded 1-108	Four-state checkers A-1
	ova_req_requires 1-114	functional groups, Checker Library 1-8
	ova_req_resp 1-117	
	ova_sequence 1-120	_
	ova_stack 1-123	G
	ova_timeout 1-128	and the clear Library 4.0
	ova_tri_state 1-130	groups, Checker Library 1-8
	ova_underflow 1-132	
	ova_valid_id 1-134	1.1
	ova_value 1-139	Н
	ova_window 1-142	hickory 1-1, 2-2
	protocol group 1-11	hold 1-60
	state integrity group 1-10	
	temporal sequence group 1-10	hold_value 1-63
	value integrity group 1-8	
cl	neckers, four-state A-1	1
C	ode_distance 1-26	I
	ombining OVA and OVL checkers 2-3	inc 1-66
	•	
C	onst 1-28	integrity, state group 1-10

integrity, value group 1-8	ova_dual_clk_fifo 1-42
	ova_even_parity 1-47
L	ova_fifo 1-49
	ova_follows 1-55
library 1-1, 2-1, A-1	ova_forbid_bool 1-58
	ova_hold 1-60
M	ova_hold_value 1-63
	ova_inc 1-66
memory 1-68	ova_memory 1-68
memory_async 1-76	ova_memory_async 1-76
multiport_fifo 1-82	ova_multiport_fifo 1-82
mutex 1-82	ova_mutex 1-82
	ova_next_state 1-89
N	ova_no_contention 1-93
next_state 1-89	ova_odd_parity 1-96
no_contention 1-93	ova_one_cold 1-98
no_contention 1 33	ova_one_hot 1-100
	ova_overflow 1-102
O	ova_quiescent_state 1-104
odd_parity 1-96	ova_range 1-106
one_cold 1-98	ova_reg_loaded 1-108
one_hot 1-100	ova_req_requires 1-114
Open Verification Library (OVL) checkers	ova_req_resp 1-117
2-1	ova_sequence 1-120
OVA checkers	ova_stack 1-123
assert_next 2-37	ova_timeout 1-128
ova_arbiter 1-12	ova_tri_state 1-130
ova_arith_overflow 1-18	ova_underflow 1-132
ova_asserted 1-20	ova_valid_id 1-134
ova_bits 1-22	ova_value 1-139
ova_check_bool 1-25	ova_window 1-142
ova_code_distance 1-26	overflow 1-102
ova_const 1-28	OVL checkers
ova_cover_bool 1-30	assert_always 2-8, 2-11, 2-15, 2-19, 2-
ova_data_used 1-31	21
ova_deasserted 1-34	assert_delta 2-22, 2-24 assert_fifo_index 2-27
ova_dec 1-36	assert frame 2-29
ova_delta 1-38	assert_handshake 2-31
ova driven 1-40	assert implication 2-33

restrictions, OVL 2-4 assert_increment 2-34 assert_never 2-36 assert_no_overflow 2-39 S assert_no_transition 2-41 assert_no_underflow 2-43 sequence 1-120 assert_one_cold 2-49 sequence, temporal group 1-10 assert_one_hot 2-52 assert_quiescent_state 2-55 stack 1-123 assert_range 2-57 state integrity group 1-10 assert_time 2-58 assert_transition 2-60 assert_unchange 2-62 Т assert_width 2-66 assert_win_change 2-68 templates 1-1, 2-1, A-1 assert_win_unchange 2-69 temporal sequence group 1-10 assert_window 2-70 timeout 1-128 assert_zero_one_hot 2-71 tri_state 1-130 OVL checkersassert_odd_parity 2-45 U Р underflow 1-132 protocol group 1-11 units 1-1, 2-1, A-1 V quiescent_state 1-104 valid_id 1-134 value 1-139 R value integrity group 1-8 range 1-106 reg_loaded 1-108 W req_requires 1-114 window 1-142 req_resp 1-117