# Image Plugin

#### The SOFA team

2011

#### Abstract

This document describes the SOFA image plugin.

### 1 Overview

## 2 Image Type

The Image data type is instantiated on the pixel types. The resulting Image types are:

- ImageC (char),
- ImageUC (unsigned char),
- ImageI (int),
- ImageUI (unsigned int),
- ImageS (short),
- ImageUS (unsigned short),
- ImageL (long),
- ImageUL (unsigned long),
- ImageF (float),
- ImageD (double),
- ImageB (bool).

All components of the plugin are instantiated on the image types (ImageUC by default).

Images have a total of five dimensions: the spatial dimensions [x, y, z], the channels (for instance the three rgb color channels, the three values of a vectorial image, the six values of a tensor image, etc.) and the time.

Internally, SOFA uses the open-source CImg library (http://cimg.sourceforge.net/) to store and process images.

## 3 Image Transformations

Image transformation types have been implemented to describe the relation between 5d image integer coordinates and the real 3d spatial and temporal coordinate. They are instantiated on Reals (double or float precisions).

Currently, linear (scale+rotation+translation) and perspective transforms are implemented using a single structure. Therefore, components do not need to be instantiated on the transformation types (yet). A transformation vector is a concatenation of 12 parameters: spatial translation + rotation (3 Euler angles in degrees) + spatial scale (=pixel spacing) + temporal offset + temporal scale + a boolean to switch between linear and perspective transforms. For instance the translation [1, 2, 3] and orientation [10, 20, 30] of a 3D image of voxel size [4, 5, 6] can be described in a scene as : transform = "1 2 3 10 20 30 4 5 6 0 1 0".

Perspective transforms (only for 2D and 2D+t images) model pinhole cameras. Cameras are located in space at the position  $[scale_x(dim_x - 1)/2, scale_y(dim_y - 1)/2, -scale_z/2]$ .

Transformations are encapsulated into SOFA Data, and can therefore be easily transmitted from one component to another.

## 4 Input / Output

The following formats are supported by the ImageContainer (reader) and ImageExporter (writer) components:

```
• 2D:
```

- ".bmp", ".jfif", ".jif", ".ppm", ".pgm", ".pnm", ".pfm", ".exr", ".cr2", ".crw", ".dcr", ".mrw", ".nef", ".orf", ".pix", ".ptx", ".raf", ".srf"
- compressed (requires imagemagick http://www.imagemagick.org/Magick++): ".png",
  ".jpg", ".jpeg", ".jpe", ".tiff"
- 2D + time:
  - videos (requires ffmpeg http://www.ffmpeg.org): ".avi", ".mov", ".asf", ".divx",
    ".flv", ".mpg", ".m1v", ".m2v", ".m4v", ".mjp", ".mkv", ".mpe", ".movie", ".ogm",
    ".ogg", ".qt", ".rm", ".vob", ".wmv", ".xvid", ".mpeg"

#### • 3D:

- raw + header file : ".raw" + ".nfo"
- dicom (requires xmedcon (http://xmedcon.sourceforge.net/): ".dcm", ".dicom"
- parrec: ".par", ".rec"
- analyze: ".hdr", ".nii"
- inria: ".inr"
- 3D + time :
  - cimg: ".cimg"

Some formats (".par", ".rec" and ".inr") implement the pixel size. The spatial scale transformation parameters are retrieved automatically by the reader. For the "raw" format, a separate header file containing the transformation and the image dimensions is read/written. For the other formats, the transformation needs to be defined in the xml scene.

# 5 Engines

By default, images are shared memory images. So, there is no memory overhead if they are referenced into different components using Data. Engines can be implemented to process images. The classic image filters are implemented through the ImageFilter component (CImg binding).

### 6 GUI

# 7 Implementation