Lab work no. 9

Programs with multiple segments

Object of laboratory

Procedure definition, procedure call from the same segment and from different segments; working with programs written in more, separately assembled modules.

Theoretical considerations

Procedures may be defined as FAR or NEAR type. The procedure's type determines the way in which the call is made and the information that is saved on the stack at calling.

When calling a NEAR type procedure, IP register and the state is saved on the stack. CS register remains unmodified and is not saved on the stack. This implies the belonging of the two procedures, the called one and the one that makes the call, to the same code segment. If the two procedures are defined in different program modules or files, the fact that they belong to the same segment is defined in concordance with the names of code segments in which the procedures were defined. The code segment needs to have the <u>same name</u>. The link-editor knows to concatenate in a single segment code segments with the same name from different modules.

The declaration of a procedure that is defined in another program module than the one that makes the call (uses the procedure) is made through the EXTRN directive. The called procedure has to be declared with the PUBLIC directive in the module in which it is defined. EXTRN and PUBLIC declarations must be written **inside** the segment and not outside for near procedure

When calling a FAR type procedure CS, IP are saved on the stack. In this case the two procedures must belong to <u>different</u> segments. EXTRN declaration is made <u>outside</u> the segment and the PUBLIC inside the segment. FAR type calling is used only when the NEAR type calling is not possible, because this type of call is slower due to the more references made to the stack both at calling time and return time. A FAR type call is necessary when the length of the two procedures might exceed 64K, this being the maximum admitted dimension for a segment.

Procedure definition example: NEAR type procedures with procedures in different modules/files:

The calling, main, procedure:

```
DATE SEGMENT PARA PUBLIC 'DATA'; data segment definition
```

;...

DATE ENDS

STAC SEGMENT PARA STACK 'stack' ;stack segment definition

db 64 dup ('MY_STACK')

STAC ENDS

COD1 SEGMENT PARA PUBLIC 'CODE'; cod segment definition

EXTRN PROCED: NEAR

PRPRINC PROC FAR ; main procedure definition

ASSUME CS: COD1, DS: DATE, SS: STAC, ES: NOTHING

PUSH ds ;prepare stack SUB ax, ax ;to return PUSH ax ;to DOS

MOV AX, DATE ; load register MOV DS, AX ; DS with data segment

; The instructions of the main procedure

CALL PROCED ; call procedure

; Other instructions

RET ; coming back to DOS
PRPRINC ENDP ; end procedure
COD1 ENDS ; segment's end
END PRPRINC ; end of the first module

-----end of first file

The called procedure defined in another program module:

COD1 SEGMENT PARA 'CODE' ; segment code

definition

PUBLIC PROCED ; declare proced as

PUBLIC

ASSUME CS: COD1

PROCED PROC NEAR ; procedure definition

;The instructions of the called procedure

RET ; coming back to the procedure,

which made the call

```
PROCED ENDP
                          ; end procedure
COD1 ENDS
                           ; end segment
   END
                                  ; end of second module
              ----- end of second file
    FAR type procedure call example, procedure in different segments with the
procedures in two different modules/files:
EXTRN PROCED2: FAR
STAC SEGMENT PARA STACK 'stack' ;stack segment
definition
    db 64
                 dup ('MY_STACK')
STAC ENDS
DATE SEGMENT PARA PUBLIC 'DATA' ; data segment
definition
                                       data definition
    ; ...
DATE ENDS
COD2 SEGMENT PARA PUBLIC 'CODE'; code segment
definition
ASSUME CS: COD2, DS: DATE, SS:STAC, ES:NOTHING
PRPRINC2 PROC FAR
                                      ; main procedure
definition
    PUSH DS
SUB AX, AX
                       ; prepare stack
                           ; to return
    PUSH AX
                          ; to DOS
    MOV AX, DATE ; load register
MOV DS, AX ; DS with data segment
; The main procedure's instructions
    CALL PROCED2
                            ; procedure call
; Other instructions
                          ; coming back to DOS
    RET
PRPRINC2 ENDP
COD2 ENDS
                           ; end procedure
                           ; end segment
    END PRPRINC
                           ; end of the first module
----- end of first file
    The called procedure defined in another program module:
COD3 SEGMENT PARA 'CODE'; code
                                                 segment
definition
PUBLIC PROCED2
                               ; procedure declaration
as public
```

```
ASSUME
        CS: COD3
        PROC FAR ; procedure definition
PROCED2
; The instructions of the called procedure
         RETF
                                                 ; back
    to the procedure which made the call
PROCED2 ENDP
                          ; end procedure
COD3
        ENDS
                           ; end segment
                           ; end of second module
         END
              ----- end of second file
```

Passing parameters to procedures

There are three known types of parameter transfers to procedures in assembly language: through registers, through pointers and data structure and through the stack.

Transfer through registers

The advantage of this solution is that that in the procedure, the actual parameters are immediately available. For register conservation, these are saved on the stack before calling the procedure and are restored after returning from the procedure. There are 2 disadvantages of this:

- the limited number of available registers
- non-uniformity of the method there is no ordered modality of transferring, each procedure having it's own rules for transfer

Another advantage is speed, many operations with the memory (stack) not needed.

Transfer through memory

In this transfer type a data zone is prepared previously and the address of this data zone is transmitted to the procedure.

To ease access to the parameters it is recommended to define a structure, which describes the structure of the parameters:

```
_ZONA STRUC

VAL1 DD ?

VAL2 DD ?

RETURN DD ?

_ZONA ENDS

DAT SEGMENT PARA PUBLIC 'data'

ZONE _ZONA <10, 20, ?>
dat ends

COD SEGMENT PARA PUBLIC 'code'
Assume cs:cod, ds:dat
```

```
extrn proce:near

LEA BX, ZONE

CALL PROCe

cod ends

end
```

Parameter transfer through stack

Transferring parameters through the stack is the most uniform transfer modality. The transfer through stack is compulsory if the applications contain both ASM modules and modules in high level languages. The standard access technique to the parameters procedure is based on based addressing using BP register, which uses by default SS register as segment register to access the data. The access is achieved through the following operations, executed when entering the procedure:

- BP register is saved on the stack
- SP is copied to BP
- the registers used by the procedure are saved on the stack
- the parameters are accessed through indirect addressing using BP

When ending the procedure, the following operations are executed:

- the saved registers are restored
- BP is restored
- Return to the program which made the call through RET

Lab tasks

- 1. Study the given examples, noticing the differences between the two procedure call types: FAR and NEAR.
- 2. Write a program which calculates the sum of a string of numbers using a NEAR and then a FAR type procedure, written in another code segment, first both segments being written in the same file and then in different files. The procedure will be called *sum* and it will get as input parameters: the address and length of the string from DS: BX and CX registers. The procedure will return the sum in AX register.

Observations:

- The procedures which are to be included in a library will be defined of the same type, FAR or NEAR, in segments with the same name (if possible), in order not to complicate any more the call and the link edition.
- It is also recommended to group procedures of the same type (mathematical, display, etc) in different libraries having suggestive names.

Solved problem: Write a recursive procedure to display a number stored in AX

Solution:

```
TIP
                     ; pattern for parameters
     STRUC
  _BP DW ?
  _CS DW ?
  IP DW ?
      DW ?
  N
      ENDS
TIP
MYSTACK SEGMENT STACK 'stack'
      DB 4096 DUP (?) ; stack segment declaration
MYSTACK ENDS
COD SEGMENT PARA PUBLIC 'CODE'
  ASSUME CS:COD, SS:MYSTACK
  DISPL PROC FAR
                ; standard access
      PUSH BP
      MOV BP, SP
                  ; sequence
      PUSH DX
      PUSH AX
                ; we will work with these
registers in the
                  ; procedure, so we save them
      PUSH BX
      MOV AX,[BP].N
      CMP AX, 10
                         ; if n<10, dl=n
      MOV DL, AL
      only one number)
                 ; general case; calculates n/10 and n mod
      MOV BX, 10
                           ; general case
      MOV DX, 0
10
      DIV BX
                       ; AX=n/10;
                       ; dl=n mod 10
      PUSH AX
                      ; recursive call with n/10
parameter
      CALL FAR PTR DISPL
DISPLAY_1:
      ADD DL, '0'
                           ; +'0'
      MOV AH, 02H ; Dos function for display
```

INT 21H ; display

; restore POP BX POP AX

; registers

POP DX

POP BP

RETF 2 ; FAR type return

DISPL ENDP

START:

MOV AX, 65535; prepare register with number to

display

PUSH AX ; we put it on the stack as

parameter

CALL FAR PTR DISPL ; procedure call

MOV AX, 4C00H; return to

INT 21H ; DOS

COD ENDS

END START