

Mighty™

User Manual

Version 1.2 | 06.09.2017



Table of Contents

0. READ THIS FIRST

[About the User Manual](#)

[Updating to the latest releases](#)

1. USING THE MIGHTY MOBILE APP

[1.1 Downloading the mobile app](#)

[1.2 Navigating the mobile app](#)

[Navigating the mobile app](#)

[Using the mobile app for the first time](#)

[Re-opening the mobile app after setup is complete](#)

[1.3 Bluetooth connections](#)

[Connecting your Mighty to the mobile app for the first time](#)

[Reconnecting your Mighty to the mobile app](#)

[Disconnecting your Mighty from the mobile app](#)

[Connecting Bluetooth accessories to your Mighty](#)

[1.4 WiFi connections](#)

[Connecting your Mighty to a WiFi network for the first time](#)

[Reconnecting your Mighty to a WiFi network](#)

[Disconnecting your Mighty from a WiFi network](#)

[1.5 Mighty account connection](#)

[Setting up your Mighty account for the first time](#)

[Logging into your Mighty account](#)

[Changing your Mighty account settings](#)

[Logging out of your Mighty account](#)

[1.6 Spotify account connection](#)

[Connecting your Spotify account to Mighty for the first time](#)

[Reconnecting to your Spotify account](#)

[Changing your Spotify account settings](#)

[Disconnecting your Spotify account from Mighty](#)

[Switching the Spotify account that is connected to Mighty](#)

[1.7 Managing your music](#)

[Syncing playlists to your Mighty](#)

[Refreshing the playlists on your Mighty](#)

[Removing playlists from your Mighty](#)

[1.8 Managing your Mighty's settings](#)

[Naming your Mighty](#)

[Mighty Help](#)

[Mighty Setup](#)

[About your Mighty](#)

[1.9 Software Updates](#)

[Updating your Mighty](#)

[Updating the mobile app](#)

2. USING YOUR MIGHTY

[2.1 Power settings](#)

[Powering your Mighty on and off](#)

[Charging your Mighty](#)

[Your Mighty in sleep mode](#)

[Your Mighty's battery life](#)

[2.2 Playing music with wired headphones](#)

[2.3 Playing music with a Bluetooth accessory](#)

[What is a Bluetooth accessory?](#)

[Accessing the Bluetooth accessory control panel](#)

[Scanning for Bluetooth accessories](#)

[Pairing and connecting a Bluetooth accessory for the first time](#)

[Reconnecting a Bluetooth accessory](#)

[Switching the connection a different Bluetooth accessory](#)

[Disconnecting from a connected Bluetooth accessory](#)

[Unpairing a previously paired Bluetooth accessory](#)

[List of supported Bluetooth accessories](#)

[2.4 The buttons and headphone jack](#)

[2.5 The LED indicator](#)

[2.6 The audio cues](#)

3. MIGHTY'S TECHNICAL SPECS

4. REGULATORY INFORMATION

[FCC](#)

[IC](#)

5. NEED MORE HELP?

[Check out our online resources](#)

[Still need help?](#)

0. READ THIS FIRST

Welcome!

- Thank you for becoming part of the Mighty family. We designed Mighty to be easy to setup and use, but because Mighty is a new technology, there is a learning curve for most users. Below is a diagram that helps explain how Mighty uses Bluetooth to communicate with your phone and WiFi to communicate with Spotify. The rest of this User Manual explains how Mighty works in great detail.



About the User Manual

- The User Manual reflects the Mighty experience for users who are running the latest mobile app and software releases. As of June 20, 2017, the latest releases are:

- Mighty iOS mobile app: version 1.0
- Mighty Android mobile app: version 1.0
- Mighty software: version 0.9

See Section 1.8 for instructions on checking which version of the mobile app and software that you're running.

Updating to the latest releases

- If you're not running the latest mobile app and software releases, please follow these instructions:
 - Mighty mobile app: Complete the update process through the Apple App Store or Google Play Store.

Play

- Mighty software: You will be prompted to update your Mighty after connecting to WiFi through the mobile app. See Section 1.9 for more information on updating your Mighty's software.

1. USING THE MIGHTY MOBILE APP

1.1 Downloading the mobile app

- The Mighty mobile app is available on the Apple App Store and Google Play Store. Search for "Mighty Audio" and download the mobile app to your phone. The mobile app is currently compatible with iOS 9.3.5 or higher and Android Lollipop (5.0), Marshmallow (6.0), and Nougat (7.0).




Good to Know:

- The mobile app is not currently compatible with iPads or Android tablets, Microsoft phones, Android Wear and other smartwatch platforms, or computer operating systems such as Mac OS and Windows. Additional operating systems will be supported in the near future.

1.2 Navigating the mobile app

Navigating the mobile app




SCREENS (TOP)

1. Mighty - Playlists that have been synced to Mighty
2. Your Music - All of your Spotify playlists

TABS (BOTTOM)

1. Connections - Bluetooth, Wifi, Spotify Account
2. Music - Your music and playlists
3. User- Your account and Mighty's settings



Using the mobile app for the first time


- We recommend that you follow the Mighty Setup Guide. Power on your Mighty, plug it into a charger, and launch the mobile app. Click the Setup button and follow the on-screen instructions. You will be guided through the full setup process.

Good to Know:


- As you complete the Mighty Setup Guide, you may be asked to update your Mighty to the latest software release. If you're asked to update your Mighty, please plug your Mighty into a charger and follow the on-screen instructions. See Section 1.9 for more information on updating your Mighty.

Re-opening the mobile app after setup is complete

- The mobile app will attempt to automatically reconnect to your Mighty, any previously stored WiFi network, and your Spotify account. The reconnection process can take 5-10 seconds and the Connections tab will display an X during this period to indicate that connections are being established. The Connections tab will display a checkmark once the reconnection process is complete.




- If the mobile app is unable to reconnect to your Mighty, a WiFi network, and/or your Spotify account, the Connections tab will display an X to indicate that the reconnection wasn't successful. You can manually reconnect by navigating to the Connections tab and clicking on the Bluetooth, WiFi, and/or Spotify icons at the top of the screen. See Sections 1.3-16 for more information on establishing Bluetooth, WiFi, and Spotify connections.



1.3 Bluetooth connections

Connecting your Mighty to the mobile app for the first time

- We recommend that you follow the Mighty Setup Guide. Power on your Mighty, plug it into a charger, and launch the mobile app. Click the Setup button and follow the on-screen instructions. You will be guided through the Bluetooth setup process.
- To manually connect your Mighty to the mobile app: On the Mighty Setup Guide page, click the No Thanks button. Navigate to the Connections tab and click on the Bluetooth icon to see all Mightys in your proximity. Click the plus button ("+") next to your Mighty to connect it to the mobile app. Wait for your Mighty's LED to start blinking blue, then click on your Mighty's play/pause button. In the app, a blue checkmark will appear to the left of your Mighty's name to indicate that the connection has been established.




Good to Know:

- If you experience issues connecting your Mighty to the mobile app via Bluetooth, we recommend that you reboot your Mighty and try again. See Section 2.1 for information on Mighty's power settings.
- Your Mighty will not be discoverable by the mobile app during music playback. You must pause playback, then connect your Mighty to the mobile app. It takes 15-30 seconds for your Mighty's name to appear in the mobile app after playback has been paused.


Reconnecting your Mighty to the mobile app

- The mobile app will attempt to automatically reconnect to your Mighty. A green checkmark will be displayed next to the Bluetooth icon in the Connections tab to indicate that the reconnection was successful.




- To manually reconnect your Mighty to the mobile app: Navigate to the Connections tab and click on the Bluetooth icon to see all Mightys in your proximity. Click the plus button (“+”) next to your Mighty to reconnect. **IMPORTANT:** If your Mighty’s LED blinks blue, press the play/pause button to establish the connection.

In the app, a blue checkmark will appear to the left of your Mighty’s name to indicate that the connection was successful.



Disconnecting your Mighty from the mobile app

- Navigate to the Connections tab and click on the Bluetooth icon at the top of the screen to see your Mighty. You’ll see a blue checkmark to the left of your Mighty’s name to indicate that it is connected to the mobile app. Swipe left on your Mighty’s name to display the disconnection icon, then tap the icon to disconnect your Mighty from the mobile app.




Connecting Bluetooth accessories to your Mighty

- See Section 2.3 for information on connecting Bluetooth accessories to your Mighty.

1.4 WiFi connections

Connecting your Mighty to a WiFi network for the first time


- We recommend that you follow the Mighty Setup Guide. Power on your Mighty, plug it into a charger, and launch the mobile app. Click the Setup button and follow the on-screen instructions. You will be guided through the WiFi setup process.



- To manually connect your Mighty to a WiFi network: On the Mighty Setup Guide page, click the No Thanks button. Navigate to the Connections tab and click on the WiFi icon to see all WiFi networks in your proximity. Click the plus button ("+") next to your WiFi network, then enter the WiFi network password on the next page to connect. In the app, a blue checkmark will appear to the left of the WiFi network's name to indicate that the connection was successful.


Good to Know:

- If you experience issues connecting your Mighty to WiFi, we recommend that you reboot your Mighty and try again. See Section 2.1 for information on Mighty's power settings.
- Mighty does not currently support portal-protected WiFi networks that require action to be taken on a webpage in order to connect. Support for portal-protected networks will be added in the near future.




Reconnecting your Mighty to a WiFi network

- The mobile app will automatically reconnect to your WiFi network. A green checkmark will be displayed next to the WiFi icon in the Connections tab to indicate that the connection was successful.
- To manually reconnect to your Mighty to a WiFi network: Navigate to the Connections tab and click on the WiFi icon to see all WiFi networks in your proximity. Click the plus button (“+”) next to your WiFi network, then enter the WiFi network password on the next page to reconnect. In the app, a blue checkmark will appear to the left of the WiFi network’s name to indicate that the connection was successful.



Disconnecting your Mighty from a WiFi network

- Navigate to the Connections tab and click on the WiFi icon at the top of the screen to see the WiFi network that your Mighty is connected to. A blue checkmark will appear to the left of the WiFi network’s name to indicate that your Mighty is connected. Swipe left on your WiFi network’s name to display the disconnection icon, then tap the icon to disconnect your Mighty from the WiFi network.




1.5 Mighty account connection

Setting up your Mighty account for the first time

- We recommend that you follow the [Mighty Setup Guide](#). Power on your Mighty, plug it into a charger, and launch the mobile app. Click the Setup button and follow the on-screen instructions. You will be guided through the Mighty account setup process.
- To manually create your Mighty account: On the Mighty Setup Guide page, click the No Thanks button. You will be redirected to the Mighty account login screen.


Good to Know:

- As a security measure, you must be logged into your Mighty account in order to use the mobile app.




Logging into your Mighty account

- After you've logged into your Mighty account once, the mobile app will automatically log you back in each time you open the app. Your username will be displayed in the User tab to indicate that you're logged in.
- To manually log into your Mighty account: Once you login, you will remain logged into your Mighty account indefinitely unless you receive an app update, reinstall the mobile app, or change certain settings on your phone. If you get logged out, you will be redirected to the Mighty account login screen when you open the app.




Changing your Mighty account settings

- If you forget your password: Navigate to the User tab and click the Forgot Password button. Follow the on-screen instructions to receive a new password via email.





- If you want to change your password: Navigate to the User tab and click the Change Password button. Follow the on-screen instructions to change your password.
- If you forgot your Mighty account username: You cannot currently retrieve or change your Mighty account username through the app. If you forget your username, navigate to the Forgot Password tool and enter the email address that's associated with your Mighty account to receive an email with your username and a new password. If you can't remember the email address that's associated with your Mighty account, email us at heyo@bemighty.com for assistance.



Logging out of your Mighty account


- Navigate to the User tab and click the Logout button. You will not be able to use the mobile app while logged out of your Mighty account and you will be redirected to the Mighty account login screen. As a security measure, if you login with a different Mighty account than the account that was used previously and connect your Mighty to the mobile app, all previously synced playlists will be deleted from that Mighty.



1.6 Spotify account connection

Connecting your Spotify account to Mighty for the first time


- We recommend that you follow the Mighty Setup Guide. Power on your Mighty, plug it into a charger, and launch the mobile app. Click the Setup button and follow the on-screen instructions. You will be guided through the Spotify account connection process.



- To manually connect to your Spotify account to Mighty: On the Mighty Setup Guide page, click the No Thanks button. Navigate to the Connections tab and click on the Spotify icon at the top of the screen, then click on the Connect button to connect your Spotify account to Mighty. You will be redirected to Spotify to establish the connection, then redirected back to the Mighty app. A green checkmark will be displayed next to the Spotify icon to indicate that the connection was successful.


Good to Know:

- You must have a Spotify Premium account in order to take your playlists offline with Mighty. If you don't have a Spotify Premium account, you can get one at www.spotify.com/premium.



Reconnecting to your Spotify account

- The mobile app will automatically reconnect to your Spotify account. A green checkmark will be displayed next to the Spotify icon in the Connections tab to indicate that the connection was successful.
- To manually reconnect to your Spotify account to Mighty: Navigate to the Connections tab and click on the Spotify icon at the top of the screen, then click on the Connect button to connect your Spotify account to Mighty. You will be redirected to Spotify to establish the connection, then redirected back to the Mighty app. A green checkmark will be displayed next to the Spotify icon to indicate that the connection was successful.




Changing your Spotify account settings

- To adjust download quality: Navigate to the Connections tab and click on the Spotify icon at the top of the screen, then click the Download Quality button. Select from Normal, High, and Extreme (the same download qualities that are available on Spotify) and click the Save button. The download quality that you select is specific to Mighty and will not be applied to any of your other Spotify-enabled devices.


Good to Know:

- All playlists currently synced to your Mighty will be removed if you change download quality. You will need to resync those playlists at the new download quality.



Disconnecting your Spotify account from Mighty


- Navigate to the Connections tab and click on the Spotify icon, then click the Logout button.



- To deauthorize Mighty from accessing your Spotify account: The deauthorization process is completed through Spotify. To deauthorize Mighty, open a web browser and go to [spotify.com](https://www.spotify.com), then sign into your Spotify account. Navigate to the Settings section and click on Apps, then find Mighty and click Revoke Access.


Good to Know:

- For security purposes, you must keep your Spotify account connected to the Mighty app in order to play music on your Mighty. Playback will be prohibited if you disconnect your Spotify account from the Mighty app while your Mighty is connected to the mobile app.



Switching the Spotify account that is connected to Mighty


- To switch Spotify accounts on your phone: Open the Spotify app on your phone and click on the Settings link in the upper right-hand corner of the app. Click the Logout button, then follow the on-screen instructions to login to the desired Spotify account. If you do not have the Spotify app installed on your phone, open and web browser and go to [spotify.com](https://www.spotify.com) to sign into the account that you would like to connect to Mighty.



- To reconnect with the new Spotify account: Navigate to the Connections tab and click on the Spotify icon, then click the Connect button. You will be redirected to Spotify to establish the connection, then redirected back to the Mighty app. A green checkmark will be displayed next to the Spotify icon to indicate that the connection was successful.

Good to Know:


- As a security measure, all playlists that have been synced to your Mighty will be removed if you connect the Mighty app to a different Spotify account than the one that was originally used to sync the playlists.




1.7 Managing your music

Syncing playlists to your Mighty


- To select playlists to sync: Connect your Mighty to the mobile app and click on Your Music at the top of the screen to see all the playlists in your Spotify library. Scroll through the list and click the plus button ("+") next to each playlist that you would like to sync.



- To sync the selected playlists: Once you have selected one or more playlists, the grey SYNC button will turn blue. Tap it. The Mighty image to the left of the SYNC button will display the percentage of the sync that has been completed. You can also navigate to the Mighty screen to view the sync progress. On the Mighty screen, a grey checkmark will be displayed to the left of any playlist that is in the process of being synced. A blue checkmark will be displayed to the left of any playlist that has been synced.




- To fill your Mighty with a random selection of your playlists: Mighty has a *Fill-er-up!* feature that allows you to fill up your Mighty with randomly selected playlists. To use this feature, scroll to the bottom of the Your Music screen and click the *Fill-er-up!* button. Mighty can hold more than 1,000 songs, so the *Fill-er-up!* sync process generally takes more than an hour to complete. We recommend running this sync at night.



- To stop the sync process before it has completed: You can stop a sync in progress by navigating to the Mighty screen, which displays all playlists currently synced to your Mighty. A grey checkmark will be displayed to the left of any playlist that is in the process of being synced. To stop syncing any of those playlists, swipe left on the playlist to display the trash icon, then tap the trash icon.

Good to Know:

- To ensure a speedy sync process, your Mighty must be connected to a WiFi network in order to sync. Your phone does not need a WiFi connection, but you must use the mobile app to give Mighty a WiFi connection (denoted by a green checkmark next to the WiFi icon in the Connections tab).
- If syncing a large number of songs (greater than 100), we recommend that you plug your Mighty into a charger. Syncing requires a lot of processing power and plugging into your Mighty into a charger will ensure that your battery remains full.
- Mighty currently only supports playlists. Mighty does not support albums, artists, podcasts, or other types



of Spotify content. As a workaround, you can use the Spotify app or desktop program to add most types of Spotify content to a playlist. To sync to Mighty, use Spotify to add the content to a playlist, close and reopen the Mighty app to refresh your Spotify library, then sync that playlist. Additional Spotify content types will be supported in the near future.


- Mighty does not support local files (MP3s) that have been uploaded to your Spotify library. Local files will show in the playlist song count on the Your Music screen, but they will not be transferred during the sync process. On the Mighty screen, the playlist song count will not include local files (it displays the number of songs that are actually synced).

Refreshing the playlists on your Mighty

- To refresh the playlists that are synced to your Mighty: Navigate to the Music tab and click on the Mighty icon at the top of the screen. Find the *Stay Fresh!* bar and click the icon next to that bar to initiate the refresh. This will automatically pull-in any changes that you've made to your synced playlists, including track additions/removals and changes to the order of tracks.
- To refresh your Spotify library in the Mighty app: Changes that you make to your Spotify library using the Spotify app or desktop program will automatically be reflected in the Mighty app each time you close and relaunch the Mighty app. If you want to refresh your Spotify library without closing the Mighty app, you can disconnect and reconnect your Spotify account via the Connections tab, then navigate back to the Your Music screen. See Section 1.6 for more information on connecting and disconnecting your Spotify account.

Good to Know:

- *Stay Fresh!* generally takes a few minutes to complete because all synced playlists must be analyzed to determine which songs have been added, removed, and modified. Similar to a standard sync, the Mighty image will tell you what




percentage of the *Stay Fresh!* sync has been completed.

- Your phone must have a WiFi or cell connection in order to perform a *Stay Fresh!* sync.

Removing playlists from your Mighty


- Navigate to the Music tab and click on the Mighty icon at the top of the screen to view all of your synced playlists. Swipe left on the playlist that you would like to remove to display the trash icon, then tap the icon to remove that playlist for your Mighty. The playlist will be removed automatically, no sync is required.



1.8 Managing your Mighty's settings

Naming your Mighty


- By default, your Mighty's name will be "Mighty-" followed by a unique string of numbers and letters. This unique identifier is used to distinguish your Mighty from any other Mightys in the area.



- To rename your Mighty:** Navigate to the Connections tab and click on the Bluetooth icon at the top of the screen to display all Mightys in your proximity. Find your Mighty and connect it to the mobile app, then click on your Mighty's current name to display an open text field. Enter a name of your choosing and click the Save button at the top of the screen. No spaces or special characters are allowed in your Mighty's name.

Good to Know:

- After you rename your Mighty, a reboot is required in order to see the updated name in the mobile app. See section 2.1 for information on powering your Mighty on/off.



Mighty Help


- Navigate to the User tab and click on the Mighty Help button. You will be redirected to a contact form at www.bemighty.com/contact. You can also email us directly at heyo@bemighty.com if you have a question or want to chat.

Good to Know:

- We recommend that you check out the [Setup page](#) and [FAQ](#) prior to contacting us. You'll probably find the answer to your question there.

Mighty Setup

- We recommend that you go through the Mighty Setup Guide the first time you launch the mobile app.
- To access the Mighty Setup Guide after setup is complete: Navigate to the User tab and click on the Mighty Setup button. You will be redirected to the same Mighty Setup Guide that you completed when you first setup your Mighty. Your Mighty will be disconnected from the mobile app and you'll be instructed to reconnect it as part of the setup process.




About your Mighty

- Navigate to the User tab and click the About button to view the version of your Mighty mobile app and software. A Mighty Community Manager may ask you for this information if you happen to have an issue with your Mighty.

1.9 Software Updates

Updating your Mighty


- Automatic updates: Your Mighty will automatically check for updates after establishing a connection to a WiFi network. You will be prompted to initiate an update if one is available. Plug your Mighty into a charger and follow the on-screen instructions. It typically takes five minutes to complete an update.



- To manually check for updates: Connect your Mighty to the mobile app and connect to a WiFi network. Navigate to the User tab and click on the Software Update button to check for any updates. You will be prompted to initiate an update if one is available. Plug your Mighty into a charger and follow the on-screen instructions. It typically takes five minutes to complete an update.

Good to Know:

- We recommend that you check for updates to your Mighty software regularly. We're constantly making improvements to the Mighty experience.
- Updates to Mighty software may be required and you will not be able to access parts of the mobile app until the updates are complete. You will be prompted to initiate an update if one is required.



Updating the mobile app

- To update the mobile app through Apple App Store:
Navigate to the App Store app and click on the Updates button on the bottom of the screen. Scroll down to the Mighty app, select it, and click the Update button to initiate the update process.
- To update the mobile app through Google Play:
Navigate to the Google Play app and click on the menu button on the top left of the screen. Scroll down and select My apps & games. Click on the Updates (if applicable) or the Installed tab and scroll down to the Mighty app. Click the Update button to initiate the update process.

Good to Know:

- We recommend that you check for updates to the Mighty mobile app regularly. We're constantly making improvements to the Mighty experience.

2. USING YOUR MIGHTY

2.1 Mighty's power settings

Powering your Mighty on and off

- To power on your Mighty: Tap the play/pause button and your Mighty's LED will turn solid green to indicate that your Mighty is powering on. Mighty takes 30 seconds to power on.
- When your Mighty is on: Your Mighty's LED will blink green every five seconds to indicate that your Mighty is on.
- To power off your Mighty: Hold the play/pause button for 4 seconds and your Mighty's LED will turn solid orange to indicate that your Mighty is powering off. After your Mighty powers off, please wait 20 seconds before attempting to power it back on. Mighty takes 20 seconds to fully power down and cannot power back on during this time.

Charging your Mighty

- Plug one end of the charging cable in your Mighty's headphone jack and the other end into any USB outlet. Your Mighty's LED will blink either white or pink (depends on your eyesight) while charging and will be solid white or pink once fully charged.

Your Mighty in sleep mode

- Entering sleep mode: Your Mighty will automatically enter sleep mode after five minutes of non-activity (no music playback, no button presses, no activity on mobile app). While sleeping, your Mighty will be in a low power mode and will not be able to play music or connect to the mobile app. The LED will not be illuminated when your Mighty is in sleep mode. To conserve battery life, your Mighty will automatically power off after 45 minutes in sleep mode.
- To wake your Mighty up from sleep mode: Tap the play/pause button once and your Mighty's LED will turn solid green for 3 seconds, then begin blinking green to indicate that it is powered on. You will be able to play music and connect to the mobile app as soon as your Mighty's LED begins blinking green.

Your Mighty's battery life

- While playing music, your Mighty has up to 5 hours of battery life.
- While in sleep mode, your Mighty has up to 48 hours of battery life.
- While powered off, your Mighty has up to 30+ days of battery life.
- While charging, your Mighty takes approximately 30 minutes to charge from 0% to 80% full and an additional 30 minutes to charge from 80% to 100% full.

Good to Know:

- Your Mighty automatically turns on when plugged into a charger and does not power off when unplugged. We recommend that you power off your Mighty when unplugging it from the charger if you're not using it right away.

2.2 Playing music on Mighty

Using Mighty with wired headphones

- Power on your Mighty, plug in your headphones, and press the play/pause button. If there's music on your Mighty, it will start playing.

Good to Know:

- Mighty does not currently support auxiliary out playback through wired cords. This includes some high-end headphones that use an auxiliary cable for playback. We plan to support this mode of playback in the near future.
- You cannot charge your Mighty while playing music through wired headphones.

Using Mighty with a Bluetooth accessories

- See Section 2.3 for more information on using Mighty with a Bluetooth accessory.

Spotify offline playback limits

- You must have a Spotify Premium account in order to take your playlists offline. If you don't have a Spotify Premium account, you can get one at www.spotify.com/upgrade.
- Spotify allows you to have up to 3 offline devices. Mighty counts as one offline device.
- Spotify allows you to store up to 3,333 songs on each offline device. Mighty will sync as many songs as possible and will stop syncing once the 3,333 song limit is reached. However, you are unlikely to hit this limit when using Mighty.
- Spotify allows you to play up to 8,000 songs in a single offline session. Mighty will provide a VoiceOver audio warning after 4,000 tracks played. Mighty will provide another VoiceOver notification after 8,000 songs played, then playback will be disabled. To re-enable playback, connect your Mighty to the mobile app, navigate to the Music tab, and click the *Stay Fresh!* button. This will start a new offline session.
- Spotify allows you to play your songs for up to 30 days in a single offline session. Playback will be disabled after 30 days. To re-enable playback, connect your Mighty to the mobile app, navigate to the Music tab, and click the *Stay Fresh!* button. This will start a new offline session.

2.3 Using Mighty with a Bluetooth accessory

What is a Bluetooth accessory?


- Any Bluetooth-enabled device that is used to play music from Mighty. This includes, but is not limited to, Bluetooth headphones, speakers, and car entertainment systems.

Accessing the Bluetooth accessory control panel

- Connect your Mighty to the mobile app via Bluetooth. Once the connection has been established, navigate to the Connections tab and click on the Bluetooth icon at the top of the screen.

Scanning for Bluetooth accessories

- Put your Bluetooth accessory in pairing mode, which is generally denoted by a blinking blue and/or red LED. Connect your Mighty to the mobile app, then navigate to the Bluetooth accessory control panel and pull down on the screen to initiate a scan. The mobile app will display a list of all Bluetooth accessories in your proximity.



Good to Know:

- You must disconnect the Bluetooth accessory from your phone in order to pair it with your Mighty. This is a Bluetooth limitation - an accessory can only be connected to one device at a time.
- In certain situations, Bluetooth accessories that have not been previously paired with your Mighty will be listed as "n/a" in the mobile app. This is due to a delay in passing the make/model information from the Bluetooth accessory to the mobile app. You can still connect to the Bluetooth accessory and the make/model information will automatically be displayed in the app once the information is available.
- Mighty works with most Bluetooth-enabled car entertainment systems. If you're unable to find your car entertainment system through the Bluetooth accessory control panel, you may need to make it "visible" to Mighty. Check your car's user manual for information on making the entertainment system


visible (also referred to as “discoverable”) over Bluetooth.

Pairing and connecting a Bluetooth accessory for the first time

- Navigate to Bluetooth accessory control panel. Press the plus (“+”) button next to the name of the Bluetooth accessory to pair and connect it with your Mighty. A blue checkmark will be displayed to the left of the Bluetooth accessory name and you will hear a two-tone beep through the Bluetooth accessory to indicate that the connection was successful. Press the play/pause button on your Mighty to initiate playback through the Bluetooth accessory.

Good to Know:

- Playback through wired headphones takes priority over playback through a Bluetooth accessory. As such, you must remove headphones from the jack/charger in order to play music through a Bluetooth accessory.
- You are able to charge your Mighty while playing music through a Bluetooth accessory.



Reconnecting a Bluetooth accessory


- Your Mighty will automatically reconnect to the last Bluetooth accessory that was used for playback. To initiate the reconnection, start with your Mighty and the Bluetooth accessory powered off. Power on your Mighty and wait for your Mighty's LED to blink green to denote that it's powered on, then power on the Bluetooth accessory. You will hear a two-tone beep through the Bluetooth accessory to indicate that the reconnection was successful.

Good to Know:

- If you want to visually confirm that the reconnection was successful, open the mobile app and navigate to the Bluetooth accessory control panel. A blue checkmark will be displayed to the left of the Bluetooth accessory that is connected to your Mighty.


Switching the connection a different Bluetooth accessory

- To connect to a Bluetooth accessory that you previously paired but is not currently connected: Navigate to Bluetooth accessory control panel. All previously paired Bluetooth accessories in your proximity will be displayed with a chain link icon to the left of the accessory name. Press the plus ("+") button next to the name of your Bluetooth accessory to connect it to your Mighty. A blue checkmark will be displayed to the left of the Bluetooth accessory name and you will hear a two-tone beep through the Bluetooth accessory to indicate that the reconnection was successful.
- To connect a Bluetooth accessory that you have not previously paired: Follow the process outlined in the "Pairing and connecting a Bluetooth accessory for the first time" section above.



Disconnecting from a connected Bluetooth accessory

- Navigate to Bluetooth accessory control panel. A bluecheck will be displayed to the left of the Bluetooth accessory that is currently connected to your Mighty. Swipe left on the Bluetooth accessory to display an unlinked chain icon, then tap the unlinked chain icon to disconnect it from your Mighty.




Unpairing a previously paired Bluetooth accessory

- Navigate to Bluetooth accessory control panel. All previously paired Bluetooth accessories will be displayed with a chain link icon to the left of the accessory name. Swipe left on the Bluetooth accessory to display a trash icon, then tap the trash icon to unpair it from your Mighty.

List of supported Bluetooth accessories

- Mighty supports most Bluetooth headsets, speakers, and car entertainment systems. The list below only shows accessories that have been tested and verified to work with Mighty, but we expect that 99% of accessories will work. You can contribute to the list of supported accessories by filling out [this form](#).
- Headsets
 - Anker SoundBuds
 - Beats Solo Wireless 2
 - Bose SoundSpot Wireless Headphones
 - JLab Epic Wireless Earbuds
 - Moshi Mythro Air Wireless
 - Moshi Mythro-Air
 - Phaiser BHS 5-30
 - PowerBeats Wireless
 - TaoTronics TT-BH07
 - TREBLAB XR100
- Speakers
 - Beats Pill+
 - Bose Soundlink Bluetooth Speaker II
 - Bose SoundLink Mini
 - JBL Micro Wireless
 - Spector T230
- Car entertainment systems
 - 2014 BMW 528i
 - 2015 Audi A7
 - Mazda 3

2.3 Mighty's buttons and headphone jack



- Playlist Selector: Tap to scroll through the playlists that are synced to your Mighty. Each time you tap the playlist selector, Mighty will speak the playlist title back to you. Press the song forward and back buttons to scroll through the songs in that playlist.
- Play/Pause/Power: Tap to power on your Mighty; press and hold for 4 seconds to power off your Mighty. See Section 2.1 for more information on your Mighty's power settings.
- Jack/Charger: If using for playback with wired headphones, plug in your headphones, and press the play/pause button. If there's music on your Mighty, it will start playing. If using for charging your Mighty, plug one end of the charging cable in your Mighty's headphone jack and the other end into any USB outlet. Your Mighty's LED will blink either white or pink (depending on your eyesight) while charging and will be solid white or pink once fully charged.

2.5 Mighty's LED indicator



● - ● - ●	Blinking pink	charging
●	Solid pink	charged
●	Solid green	powering on
● - ● - ●	Blinking green	on
● - ● - ●	Rapid blinking green	syncing music or updating software
● - ● - ●	Rapid blinking blue	the mobile app is trying to connect to Mighty (press the play/pause button on your Mighty to connect)
● - ● - ●	Blinking orange	low battery
●	Solid orange	powering off

White or pink (depends on your eyesight) means charging and charged

- Blinking white or pink (every five seconds) means that your Mighty is charging.
- Solid white or pink means that your Mighty is fully charged.

Green means power and syncing

- Solid green means that your Mighty is powering on.
- Blinking green (every five seconds) means that your Mighty is currently on.
- Rapid blinking green (every one second) means that your Mighty is currently syncing music.
- During the software update process, rapid blinking green means that your Mighty is updating.

Blue means Bluetooth

- Rapid blinking blue (every one second) means that the mobile app is attempting to connect with your Mighty. Tap the play/pause button on your Mighty to connect it to the mobile app.

Orange means low power and power off

- Blinking orange (every five seconds) means that your Mighty has 20% or less battery life remaining.
- Solid orange means your Mighty is powering down.

2.6 Mighty's audio cues

- Power on: You will hear a two-tone beep to indicate that your Mighty has fully powered on. Mighty takes 30 seconds to power on.
- Maximum volume: You will hear a one-tone beep to indicate that your Mighty has reached maximum volume.
- Low battery: You will hear a one-tone beep to indicate that your Mighty has 20% battery life remaining.

- Power off: You will hear a two-tone beep to indicate that your Mighty is powering off. It will take your Mighty an additional 20 seconds to fully power down, during which you will not be able to power your Mighty back on.
- Playlist VoiceOver: Each time you tap the playlist selector, Mighty will speak the playlist title back to you. See Section 2.4 for more information on the playlist selector button.
- Bluetooth accessory connection: You will hear a two-tone beep through the Bluetooth accessory to indicate that the Bluetooth accessory was successfully paired and connected to your Mighty.

Good to Know:

- Mighty does not currently support voice commands. We plan to support this feature in the near future.

3. MIGHTY'S TECHNICAL SPECS

- Dimensions: 1.5" x 1.5" x 0.7"
- Weight: 19.5 grams (0.7 ounces)
- Processor: TI
- RAM:
- WiFi/Bluetooth module: Murata
- Codec: TI
- Battery: 300 mAh lithium ion
- Flash memory: 8GB (5GB for music storage)
- Charging cable: 3.5mm headphone jack to USB
- Operating system: Linux
- Drop resistance: Passed 3.5 foot drop testing in a controlled environment
- Water resistance: IPX4 (a rating that means Mighty can handle getting splashed, running in light rain, and drops of sweat. Mighty is not rated for full submersion, so no baths)

4. REGULATORY INFORMATION

FCC

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.

IC

- This device complies with Industry Canada's license-exempt RSSs. Operation is subject to the following two conditions:
 - This device may not cause interference; and
 - This device must accept any interference, including interference that may cause undesired operation of the device.
- Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:
 - l'appareil ne doit pas produire de brouillage, et
 - l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement."
- CAN ICES-3(B)/NMB-3(B)

5. NEED MORE HELP?

Check out our online resources

- [Setup Guide](#)
- [FAQ](#)
- How To Videos

Still need help?

- Fill out the form at www.bemighty.com/contact and one of our Community Managers will be in touch with you in the next day or so.



MightyTM

Venice, California