Version: PRB\_9188\_v114\_revA\_17May2023 Last update: 17/05/2023

Flow Cell Number:	DNA Samples:	
Before start checklist		
Materials	Consumables	Equipment
50 ng high molecular weight plasmid DNA per sample	1.5 ml Eppendorf DNA LoBind tubes	MinION or GridION device
Rapid Barcoding Kit 24 V14 (SQK-RBK114.24) OR Rapid Barcoding Kit 96 V14 (SQK-RBK114.96)	2 ml Eppendorf DNA LoBind tubes	lce bucket with ice
	0.2 ml thin-walled PCR tubes or 0.2 ml 96- well PCR plate	Microplate centrifuge, e.g. Fisherbrand™ Mini Plate Spinner Centrifuge (Fisher Scientific, cat # 11766427)
	Nuclease-free water (e.g. ThermoFisher, AM9937)	Timer
	Freshly prepared 80% ethanol in nuclease-free water	☐ Thermal cycler or heat block at 30°C and 80°C
	Optional) Bovine Serum Albumin (BSA) (50 mg/ml) (e.g Invitrogen™ UltraPure™ BSA 50 mg/ml, AM2616)	☐ Magnetic rack
	Qubit™ Assay Tubes (Invitrogen, Q32856)	Hula mixer (gentle rotator mixer)
	Qubit dsDNA HS Assay Kit (Invitrogen, Q32851)	Qubit fluorometer (or equivalent for QC check)
		Pipettes and pipette tips P2, P20, P100, P200, P1000
INSTRUCTIONS		NOTES/OBSERVATIONS
Library preparation		
☐ Program the thermal cycler: 30°C for 2 minutes	, then 80°C for 2 minutes.	
Thaw kit components at RT, spin down briefly using below:	g a microfuge and mix by pipetting as indicated by the	e table
	Plate (RB01-96): not frozen, briefly spin down, mix w	ell by
Rapid Adapter (RA): not frozen, briefly spin do	own, mix well by pipetting	
AMPure XP Beads (AXP): thaw at RT, briefly suse	spin down, mix by pipetting or vortexing immediately l	pefore
Elution Buffer (EB): thaw at RT, briefly spin do	own, mix well by pipetting	

Page 1/5 nanoporetech.com

Adapter Buffer (ADB): thaw at RT, briefly spin down, mix by vortexing

Version: PRB\_9188\_v114\_revA\_17May2023 Last update: 17/05/2023



INSTRUCTIONS	NOTES/OBSERVATIONS
Prepare the DNA in Nuclease-free water, as follows. Approximately 50 ng of plasmid DNA is required in 9 µl of volume for each sample for barcoding.	
☐ 100 ng/µl 34 µl @ 2 µl (36 µl cycles)	
☐ 90 ng/µl 31 µl @ 2 µl (33 µl cycles)	
□ 80 ng/μl 27 μl @ 2 μl (29 μl cycles)	
☐ 70 ng/µl 35 µl @ 3 µl (38 µl cycles)	
☐ 60 ng/μl 20 μl @ 2 μl (22 μl cycles)	
☐ 40 ng/µl 31 µl @ 5 µl (36 µl cycles)	
☐ 30 ng/µl 22 µl @ 5 µl (27 µl cycles)	
20 ng/µl 13 µl @ 5 µl (18 µl cycles)	
П 10 ng/µl 8 µl @ 10 µl (18 µl cycles)	
$\square$ <5.56 ng/μl 0 μl @ 9 μl (9 μl cycles)	
Select a unique barcode for every sample to be run together on the same flow cell. Up to 96 samples can be barcoded and combined in one experiment.	
In 0.2 ml thin-walled PCR tubes or plate, mix the following reagents. The Rapid Barcodes can be transferred using a multichannel pipette:	
☐ 9 µl 50 ng template DNA	
1 μl Rapid Barcodes (RB01-96, one for each sample)	
☐ Ensure the components are thoroughly mixed by pipetting and spin down briefly.	
☐ Incubate the tubes or plate at 30°C for 2 minutes and then at 80°C for 2 minutes. Briefly put the tubes or plate on ice to cool.	
Spin down the tubes or plate to collect the liquid at the bottom.	
Pool all the barcoded samples into a clean 1.5 ml Eppendorf DNA LoBind tube, noting the total volume.	
Resuspend the AMPure XP beads (AXP) by vortexing.	
To the entire pooled barcoded sample, add an equal volume of resuspended AMPure XP Beads (AXP) and mix by flicking the tube.	
<ul> <li>Volume of AXP</li> <li>- For 12 samples: 10 μl</li> <li>- For 24 samples: 120 μl</li> <li>- For 48 samples: 240 μl</li> <li>- For 96 samples: 480 μl</li> <li>- : 960 μl</li> </ul>	
☐ Incubate on a Hula mixer (rotator mixer) for 5 minutes at RT.	
Prepare at least 3 ml of fresh 80% ethanol in Nuclease-free water.	
Spin down the sample and pellet on a magnet. Keep the tube on the magnet, and pipette off the supernatant.	
Keep the tube on the magnet and wash the beads with 1.5 ml of freshly prepared 80% ethanol without disturbing the pellet. Remove the ethanol using a pipette and discard	

Page 2/5 nanoporetech.com

Version: PRB\_9188\_v114\_revA\_17May2023 Last update: 17/05/2023



INSTRUCTIONS	NOTES/OBSERVATIONS
Repeat the previous step.	
☐ Briefly spin down and place the tube back on the magnet. Pipette off any residual ethanol. Allow to dry for 30 seconds, but do not dry the pellet to the point of cracking.	
Remove the tube from the magnetic rack and resuspend the pellet in 15 μl Elution Buffer (EB). Incubate for 10 minutes at RT.	
Pellet the beads on a magnet until the eluate is clear and colourless, for at least 1 minute.	
Remove and retain 15 µl of eluate into a clean 1.5 ml Eppendorf DNA LoBind tube.  Remove and retain the eluate which contains the DNA library in a clean 1.5 ml Eppendorf DNA LoBind tube  Dispose of the pelleted beads	
Quantify 1 µl of eluted sample using a Qubit fluorometer.	
☐ Transfer 11 µl of the sample into a clean 1.5 ml Eppendorf DNA LoBind tube.	
In a fresh 1.5 ml Eppendorf DNA LoBind tube, dilute the Rapid Adapter (RA) as follows and pipette mix:  1.5 µl Rapid Adapter (RA)  3.5 µl Adapter Buffer (ADB)	
$\hfill \square$ Add 1 $\mu I$ of the diluted Rapid Adapter (RA) to the barcoded DNA.	
☐ Mix gently by flicking the tube, and spin down.	
☐ Incubate the reaction for 5 minutes at RT.	
The prepared library is used for loading into the flow cell. Store the library on ice until ready to load.	
Priming and loading the SpotON flow cell	
IMPORTANT  Please note, this kit is only compatible with R10.4.1 flow cells (FLO-MIN114).	
☐ Thaw the Sequencing Buffer (SB), Library Beads (LIB) or Library Solution (LIS, if using), Flow Cell Tether (FCT) and one tube of Flow Cell Flush (FCF) at RT. Mix by vortexing and spin down.	
IMPORTANT	
For optimal sequencing performance and improved output on MinION R10.4.1 flow cells (FLO-MIN114), we recommend adding Bovine Serum Albumin (BSA) to the flow cell priming mix at a final concentration of 0.2 mg/ml.	
To prepare the flow cell priming mix with BSA, combine the following reagents and pipette mix at RT:  1,170 µl Flow Cell Flush (FCF)  5 µl Bovine Serum Albumin (BSA) at 50 mg/ml  30 µl Flow Cell Tether (FCT)	
Open the MinION or GridION device lid and slide the flow cell under the clip. Press down firmly on the flow cell to ensure correct thermal and electrical contact.	

Page 3/5 nanoporetech.com

Version: PRB\_9188\_v114\_revA\_17May2023 Last update: 17/05/2023



INSTRUCTIONS	NOTES/OBSERVATIONS
☐ Slide the flow cell priming port cover clockwise to open the priming port.	
IMPORTANT	
Take care when drawing back buffer from the flow cell. Do not remove more than 20-30 μl, and make sure that the array of pores are covered by buffer at all times. Introducing air bubbles into the array can irreversibly damage pores.	
After opening the priming port, check for a small air bubble under the cover. Draw back a small volume to remove any bubbles:	
Set a P1000 pipette to 200 μl	
☐ Insert the tip into the priming port	
Turn the wheel until the dial shows 220-230 ul, to draw back 20-30 ul, or until you can see a small volume of buffer entering the pipette tip	
Note: Visually check that there is continuous buffer from the priming port across the sensor array.	
Load 800 µl of the priming mix into the flow cell via the priming port, avoiding the introduction of air bubbles. Wait for 5 minutes. During this time, prepare the library for loading by following the steps below.	
☐ Thoroughly mix the contents of the Library Beads (LIB) by pipetting.	
IMPORTANT	
☐ The Library Beads (LIB) tube contains a suspension of beads. These beads settle very quickly. It is vital that they are mixed immediately before use.	
In a new tube, prepare the library for loading as follows:	
☐ 37.5 µl Sequencing Buffer (SB)	
25.5 μl Library Beads (LIB) mixed immediately before use, or Library Solution (LIS), if using	
☐ 12 µl DNA library	
Complete the flow cell priming:	
Gently lift the SpotON sample port cover to make the SpotON sample port accessible.	
Load 200 µl of the priming mix into the flow cell priming port (not the SpotON sample port), avoiding the introduction of air bubbles.	
☐ Mix the prepared library gently by pipetting up and down just prior to loading.	
Add 75 µl of the prepared library to the flow cell via the SpotON sample port in a dropwise fashion. Ensure each drop flows into the port before adding the next.	
Gently replace the SpotON sample port cover, making sure the bung enters the SpotON port, close the priming port and replace the MinION or GridION device lid.	
Ending the experiment	
After your sequencing experiment is complete, if you would like to reuse the flow cell, please follow the Wash Kit instructions and store the washed flow cell at 2-8°C, OR	
☐ Follow the returns procedure to flush out the flow cell ready to send back to Oxford Nanopore.	

Page 4/5 nanoporetech.com

Version: PRB\_9188\_v114\_revA\_17May2023 Last update: 17/05/2023

low Cell Number:	DNA Samples:
INSTRUCTIONS	NOTES/OBSERVATIONS
IMPORTANT  If you encounter issues or have questions about your sequencing experiment, Troubleshooting Guide that can be found in the online version of this protocol.	please refer to the

Page 5/5 nanoporetech.com