
Introduction to USB




Alan Ott SCaLE 16x March 8-11, 2018



About the Presenter

- Platform Software at SoftIron
 - Data center appliances (storage, transcoding)
 - OverDrive 3000/1000 servers
 - HD04018 Storage Appliance
- OSS Development
 - Linux Kernel
 - Firmware
 - Training
 - USB
 - M-Stack USB Device Stack for PIC
 - 802.15.4 wireless



USB Overview



Universal Serial Bus


- Universal Serial Bus (USB)
- Standard for a high-speed, bi-directional, low-cost, dynamic bus.
- Created by the USB Implementers Forum (USB-IF)
 - USB-IF is a non-profit corporation formed by its member companies.
 - USB-IF develops and owns copyrights on the standards documents and logos.
 - http://www.usb.org



USB Bus Speeds

- Low Speed
 - 1.5 Mb/sec
- Full Speed
 - 12 Mb/sec
- High Speed
 - 480 Mb/sec
- Super Speed
 - 5.0 Gb/sec





USB Bus Speeds


- Bus speeds are the rate of bit transmission on the bus
- Bus speeds are **NOT** data transfer speeds
- USB protocol can have significant overhead
- USB overhead can be mitigated if your protocol is designed correctly.



USB Standards

- USB **1.1** 1998
 - Low Speed / Full Speed
- USB **2.0** 2000
 - High Speed added
- USB **3.0** 2008
 - SuperSpeed added
- USB Standards do NOT imply a bus speed!
 - A USB 2.0 device can be High Speed, Full Speed, or Low Speed






Host and Device

Host

- Often a PC, server, or embedded Linux system
- Responsible for control of the bus
- Responsible for initiating communication with devices
- Responsible for enumeration of attached devices.
- One host per bus






Host and Device

Device

- Provide functionality to the host
- Many devices per bus
- Can connect through hubs
 - Hubs are transparent to the device!
 - Hubs are transparent to host APIs
 - Hub drivers are built into the OS





The Bus

- USB is a Host-controlled bus
 - Nothing on the bus happens without the host first initiating it.
 - Devices cannot initiate a transaction.
 - The USB is a Polled Bus
 - The Host polls each device, requesting data or sending data.
 - Devices cannot interrupt the host!




Terminology

• In/Out

• In USB parlance, the terms **In** and **Out** indicate direction from the **Host** perspective.

- Out: Host to Device


- **In**: Device to Host





Logical USB Device

Configuration 1 Interface 0 Endpoint 1 OUT Endpoint 1 IN Endpoint 2 IN Interface 1 Endpoint 3 OUT Endpoint 3 IN



USB Terminology

- Device Logical or physical entity which performs a function.
 - Thumb drive, joystick, etc.
- Configuration A mode in which to operate.
 - Many devices have one configuration.
 - Only one configuration is active at a time.



USB Terminology


- Interface A related set of Endpoints which present a single feature or function to the host.
 - A configuration may have multiple interfaces
 - All interfaces in a configuration are active at the same time.
- Endpoint A source or sink of data
 - Interfaces often contain multiple endpoints, each active all the time.



Logical USB Device

- Important to note:
 - A device can have multiple configurations.
 - Only one active at a time
 - A configuration can have multiple interfaces.
 - All active at the same time
 - An interface can have multiple endpoints.
 - All active at the same time





Logical USB Device

- Most USB devices only have one Configuration.
- Only one configuration can be active at a time.
- All interfaces within a configuration are active at the same time.
 - This is how composite devices are implemented.



Endpoint Terminology


- An **Endpoint Number** is a 4-bit integer associated with an endpoint (0-15).
- An endpoint transfers data in a single direction.
- An Endpoint Direction is either IN or OUT.
- An Endpoint Address is the combination of an endpoint number and an endpoint direction. Examples:
 - EP 1 IN
 - EP 1 OUT
 - EP 3 IN



Endpoint Terminology

- Endpoint addresses are encoded with the direction and number in a single byte.
 - Direction is the MSb (1=IN, 0=OUT)
 - Number is the lower four bits.
 - Examples:
 - EP 1 IN = 0x81
 - EP 1 OUT = 0x01
 - EP 3 IN = 0x83
 - EP 3 OUT = 0x03
 - Tools like 1susb will show both






Endpoint Terminology

- Endpoint terminology is tricky (but important!)
 - A device can have up to 32 endpoints.
 - IN and OUT endpoints for numbers 0-15.
- The same Endpoint Number is used to describe TWO endpoints.
 - EP 1 IN and EP 1 OUT are separate endpoints!
 - There is no such thing as a physical and logical endpoint.



Real-Life Example



- Composite Device:
 - Communication
 Device Class (CDC)
 - Often virtual serial port
 - Two interfaces are required for this class (control and data).
 - Vendor-Defined class
 - Can be used for generic data transfer

- USB is a self-describing bus
 - Each USB device contains all the information required for the host to be able to communicate with it (drivers aside)
 - No manual setting of baud rates, IRQ lines, base addresses, etc.
 - Plug devices in and they work
 - Devices communicate this data to the host using descriptors.



- The host will ask for a set of standard descriptors during enumeration, immediately upon a device being attached.
- The descriptors describe:
 - The device identifier (vendor/product IDs)
 - The logical structure of the device
 - Configurations, interfaces, endpoints
 - Which device classes are supported (if any)



- Typically, devices contain at least:
 - Device descriptor
 - Configuration descriptor
 - Interface descriptor
 - Class-specific descriptors
 - Endpoint descriptor
 - Chapter 9 of the USB spec describes these standard descriptors



 One tricky thing is that the host will request all descriptors which are part of a configuration as a single block.

• This includes Configuration, Interface, class-specific, and endpoint descriptors

The Get Descriptor (Configuration) request means all descriptors of a configuration



Device Descriptor

```
const struct device descriptor this device descriptor =
     sizeof(struct device descriptor), // bLength
     DESC DEVICE, // bDescriptorType
     0x0200, // USB Version: 0x0200 = USB 2.0, 0x0110 = USB 1.1
     0x00, // Device class (0 = defined at interface level)
     0x00, // Device Subclass
     0x00, // Protocol
     EP 0 LEN, // bMaxPacketSize0 (endpoint 0 in/out length)
     0xA0A0, // Vendor ID (Fake VID!! Don't use this one!)
     0x0001, // Product ID
     0x0001, // device release (BCD 1.0)
     1, // Manufacturer String Index
     2, // Product String Index
     0, // Serial Number String Index
     NUMBER OF CONFIGURATIONS // NumConfigurations
};
```

Configuration Descriptor

```
/* The Configuration Packet, in this example, consists
    of four descriptor structs. Note that there is
    a single configurarion, a single interface, and two
    endpoints.
 * /
struct configuration_1_packet {
        struct configuration_descriptor
                                          config;
        struct interface_descriptor
                                          interface;
        struct endpoint_descriptor
                                          ep;
        struct endpoint_descriptor
                                          ep1_out;
};
```

Configuration Descriptor (cont'd)

```
static const struct configuration 1_packet configuration_1 =
     // Members from struct configuration descriptor
     sizeof(struct configuration descriptor),
     DESC CONFIGURATION,
     sizeof(configuration 1), // wTotalLength (length of the whole packet)
     1, // bNumInterfaces
     1, // bConfigurationValue
     2, // iConfiguration (index of string descriptor)
     0X80, // bmAttributes
     100/2, // 100/2 indicates 100mA
     },
```

Configuration Descriptor (cont'd)

```
// Members from struct interface descriptor
sizeof(struct interface descriptor), // bLength;
DESC INTERFACE,
0x0, // InterfaceNumber
0x0, // AlternateSetting
0x2, // bNumEndpoints (num besides endpoint 0)
Oxff, // bInterfaceClass: 0xFF=VendorDefined
0x00, // bInterfaceSubclass
0x00, // bInterfaceProtocol
0x02, // iInterface (index of string describing interface)
```

Configuration Descriptor (cont'd)

```
// Members of the Endpoint Descriptor (EP1 IN)
sizeof(struct endpoint descriptor),
DESC ENDPOINT,
0x01 | 0x80, // endpoint #1 0x80=IN
EP_BULK, // bmAttributes
64, // wMaxPacketSize
1. // bInterval in ms.
},
// Members of the Endpoint Descriptor (EP1 OUT)
sizeof(struct endpoint_descriptor),
DESC ENDPOINT,
0x01, // endpoint #1 OUT (msb clear => OUT)
EP BULK, // bmAttributes
64, // wMaxPacketSize
1. // bInterval in ms.
},
```

};

Configuration Descriptor

- Preceding configuration descriptor described:
 - One Configuration
 - One interface (vendor defined)
 - Two Bulk Endpoints
- See examples in usb_descriptors.c in any of the M-Stack examples.



- Four types of Endpoints
 - Control
 - Bi-directional pair of endpoints
 - Multi-stage transfers
 - Transfers acknowledged on the software level
 - Not just hardware!
 - Status stage can return success/failure
 - Used during enumeration
 - Can also be used for application
 - Mostly used for configuration items
 - Most robust type of endpoint



Interrupt

- Transfers a **small amount** of **low-latency** data
- Reserves bandwidth on the bus
- Used for time-sensitive data (HID).

Bulk

- Used for large, time-insensitive data (Network packets, Mass Storage, etc).
- Does not reserve bandwidth on bus
 - Uses whatever time is left over



Isochronous

- Transfers a large amount of time-sensitive data
- Delivery is not guaranteed
 - No ACKs are sent
- Used for Audio and Video streams
 - Late data is as good as no data
 - Better to drop a frame than to delay and force a re-transmission




- Reserved Bandwidth
 - Different endpoint types will cause the bus to reserve bandwidth when devices are connected.
 - This is how guaranteed, bounded latency is implemented.
- Interrupt, Isochronous, and Control endpoints reserve bandwidth.
- **Bulk** gets whatever bandwidth is left unused each frame.



Endpoint Length

- The maximum amount of data an endpoint can support sending or receiving per transaction.
- Max endpoint sizes:
 - Full-speed:
 - Bulk/Interrupt: 64
 - Isoc: 1024
 - High-Speed:
 - Bulk: **512**
 - Interrupt: **3072**
 - Isoc: 1024 x3





Transactions

- Basic process of moving data to and from a device.
- USB is host-controlled. All transactions are initiated by the host.
 - Much like everything else in USB
- A single transaction on an endpoint can move bytes up to the Endpoint Length



- Transactions have three phases
 - Token Phase
 - Host sends a token packet to the device
 - Indicates start of transaction
 - Indicates type of transaction (IN/OUT/SETUP)
 - Data Phase
 - Host or Device sends data
 - Handshake Phase
 - Device or host sends acknowledgement (ACK/NAK/Stall)



- Transactions are handled on the Hardware level.
 - Strict timing is necessary
 - Software will configure the hardware to handle the transaction conditions before they occur.
 - This means the software/firmware must be prepared for what is coming!
 - not reacting to what has happened
 - Hardware will NAK if not configured



- Endpoints are typically implemented in a hardware peripheral
 - Typically the USB hardware device is called the Serial Interface Engine (SIE)
 - SIE contains registers for each endpoint.
 - Pointer to data buffer (and length)
 - Firmware will configure these registers for transactions which are expected
 - SIE generates Interrupts when transactions complete



Token Phase

- The host will initiate every transaction by sending a token. Tokens contain a token type and an endpoint number.
- The device SIE will handle receipt of the token and will handle the data and handshake phases automatically.
 - This means the SIE endpoint will need to be configured *before* the token comes from the host.



For most cases, the token types are:

IN

 The transaction will be an IN transaction, where the device sends data to the host using an IN endpoint.

Data phase will be device-to-host (ie: in)

 Handshake phase (ack) will be host-to-device



Token types (cont'd):

OUT

 The transaction will be an OUT transaction, where the host sends data to the device using an OUT endpoint.

Data phase will be host-to-device (ie: out)

Handshake phase (ack) will be device-to-host.



- Token types (cont'd):
 - SETUP
 - The transaction will be an SETUP transaction
 - SETUP transactions are used to start a Control Transfer on a Control endpoint pair.
 - Usually endpoint 0
 - Setup transactions indicate there will be more transactions following, and what types they will be.
 - A Setup transaction is like an OUT transaction, and the data phase contains a SETUP packet.




- Data Phase
 - The data phase contains the data which is to be transferred.
 - The data phase packet can be from zero bytes up to the endpoint length.
 - For IN transactions, the data packet is sent from the device to the host
 - For OUT or SETUP transactions, the data packet is sent from the host to the device.



- Data Phase (cont'd)
 - If there is no data to be sent, or if the device is unable to receive, the device can send a NAK as its data stage.
 - This ends the transaction prematurely.
 - A NAK tells the host to try again later.
 - It is **not a failure** of any kind.
 - NAKs are a normal part of the flow regulation of USB.
 - > The Host is often faster than the device!




• IN Transaction



- The device can NAK as long as it's not ready to send data.
- The Host will retry (up to a timeout) as long as the device NAKs.



OUT Transaction



Device is unable to receive data yet and Responds with NAK

Device has data to send and sends it

- The device can NAK as long as it's not ready to receive data.
- The Host will retry (up to a timeout) as long as the device NAKs.



- The timing between the phases is very tight
 - Too tight for software/firmware
- The hardware SIE handles this timing
 - The hardware endpoint needs to be setup before the IN token arrives.
- This means you must be *ahead* of the host, in a manner of speaking.



- For IN transactions (device-to-host)
 - Device firmware will put data to send in the hardware SIE buffer
 - Host will (sometime later) send the IN token
 - Device SIE will send the data (data stage)
 - Device SIE will resend until ACK is received
 - Host will send and ACK to the device
 - Note that the data will not get sent until the host initiates the transaction by sending the IN token to the device



- For OUT transactions (host-to-device)
 - Device firmware configures a hardware SIE buffer to receive data
 - Host will (sometime later) send the OUT token
 - Host will send the data.
 - Device SIE will send an ACK
 - Device SIE will interrupt the MCU/CPU.





Transactions and Transfers

Transaction

- Delivery of service to an endpoint
- Max data size: Endpoint length

Transfer

- One or more transactions moving information between host and device.
- Transfers can be large, even on small endpoints!



Small Transfers

Transfer

Transaction

Transfer

Transaction

Transfer

 The simplest transfer contains a single transaction.

 A transaction's size can be any length from zero bytes up to the endpoint length.



Transfer

Transaction

Transaction

Transaction

Transaction

Transaction

 Transfers can contain more than one transaction.

- Transfers are ended by:
 - A short transaction
 OR
 - When the desired amount of data has been transferred
 - As requested by the host



- Transfers are ended when:
 - A short transaction happens
 - The requested amount of data has been transfered
- A **short transaction** is one which is smaller than the endpoint length.
 - This means in a multi-transaction transfer, all transactions except the last must be the endpoint length



- Sometimes a host **does not know** the number of bytes it is asking for.
 - For example a string descriptor.
- The host will ask for the maximum number of bytes it can accept and will rely on the device to end the transfer early.
- This gives an interesting edge case



 There are four cases of large transfers. Let's consider IN transfers:

Case 1:


- Host asks for a number of bytes which is not a multiple of the endpoint length.
- device returns this many bytes.
- Case 2:
 - Host asks for a multiple of the endpoint length.
 - device returns this many bytes.




- Four cases (cont'd):
 - Case 3:
 - Host asks for a number of bytes
 - device returns fewer than requested, which is not a multiple of the endpoint length.
 - Case 4:
 - Host asks for a number of bytes
 - device returns fewer than
 requested, but it is a multiple of the endpoint length



• In cases #1, #2, and #3, the device can simply return the number of bytes it intends to return.







- Case 1:
 - Host asks for a number of bytes which is **not a multiple** of the endpoint length.
 - Device Returns this many bytes.
- Transfer is ended by:
 - A short transaction AND
 - The desired amount of data has been transferred
 - 16-byte endpoint length
 - Requested 76 bytes
 - 4x 16-byte transactions
 - 1x 12-byte transaction



Transfer

Transaction

Transaction

Transaction

- Case 2:
 - Host asks for a number of bytes which is a multiple of the endpoint length.
 - Device Returns this many bytes.
- Transfer is ended by:
 - The requested amount of data has been transferred

- 16-byte endpoint length
- Requested 64 bytes
- 4x 16-byte transactions



Transfer

Transaction

Transaction




- Host asks for a number of bytes.
- Device returns fewer than requested, which is not a multiple of the endpoint length.
- Transfer is ended by:
 - A short transaction
 - 16-byte endpoint length
 - Requested 255 bytes
 - Device returns 44 bytes
 - 2x 16-byte transactions
 - 1x 12-byte transaction



- Case #4 is an edge case
 - Host requested a number of bytes
 - Device returns fewer than requested, which is a multiple of the endpoint length.
 - Since the number of bytes being returned **is a multiple** of the endpoint length, the transfer will not naturally end with a short transaction.
 - Device must add a zero-length packet!





- Case 4:
 - Host asks for a number of bytes.
 - Device returns fewer than requested, which is a multiple of the endpoint length.
- Transfer is ended by:
 - A short transaction, in this case a zero-length packet
 - 16-byte endpoint length
 - Requested 255 bytes
 - Device returns 32 bytes
 - 2x 16-byte transactions
 - 1x 0-byte transaction




- The transfers discussed so far have been Bulk or Interrupt transfers.
- Control transfers are different and more complicated.
 - Control transfers have additional structure and are bi-directional.
 - Information is sent both ways (IN and OUT)



- Control transfers begin with a SETUP transaction.
 - A SETUP transaction is like an OUT transaction except that the data stage is an 8-byte SETUP packet.
 - The SETUP packet has information on:
 - The logical **recipient** of the transfer
 - The direction of the transfer
 - The number of bytes which will be sent or requested
 - The **identifier** or **type** of the request




- Chapter 9 of the USB specification defines standard requests which are used during enumeration of a device.
 - Set Address
 - Get Descriptor
 - Get Configuration
 - Set Configuration others...





- Device classes also define their own requests:
 - CDC (Communication Device Class)
 - Set Line Coding
 - Set Control Line State
 - Send Break
 - **HID** (Human Interface Device)
 - Get Report Descriptor
 - Get Report
 - Set Report





Linux USB Gadget



USB Gadget Subsystem

- In addition to providing the USB host subsystem you are familiar with, Linux also provides a device subsystem, called gadget.
 - Gadget is a Linux-specific name.
- The gadget subsystem provides a framework for creating USB devices using a Linux system.
 - If the hardware supports it. Most embedded USB controllers do.



USB Gadget Subsystem

- USB gadget subsystem provides:
 - Framework
 - USB Device Controller (UDC) drivers
 - Hardware drivers
 - USB device class implementations
 - Software drivers (so to speak)
 - Configuration through configfs
 - Pseudo-filesystem for configuring certain kernel services



Configfs

- Configfs is a pseudo-filesystem used to manage kernel objects.
 - Pseudo-filesystems contain files which are not present on any disk.
 - The files are backed by objects in the running kernel.
 - Creating, deleting, or changing files and directories will immediately have an effect in the kernel



Configfs

- Configfs (cont'd)
 - Data integrity is enforced by mechanism.
 - Only valid file / directory names will be allowed to be created
 - Invalid values will not be allowed to be written to files
 - System calls (read/write/mkdir,etc) will simply fail if invalid names or values are used.
 - > This is far better than silent failure



- To configure your USB Gadget:
 - Mount configfs (if not already done)
 - Create a directory for the gadget
 - Set the vid/pid/strings
 - Create a directory for the configuration
 - Create a directory for the function
 - Mass storage, HID, CDC/ACM, etc
 - Link the function to the configuration
 - Enable the gadget



```
#!/bin/sh -ex
modprobe libcomposite
# Mount configfs locally
mkdir -p config
mount none config -t configfs
# Create the USB gadget configuration
mkdir -p config/usb_gadget/
cd config/usb_gadget/
# Create a gadget called g1
mkdir q1
cd g1
# Set the VID/PID/Strings
echo 0x1a0a >idVendor
echo Oxbadd >idProduct
mkdir strings/0x409
```



```
# Set the VID/PID/Strings (cont'd)
echo 12345 >strings/0x409/serialnumber
echo "Signal 11" >strings/0x409/manufacturer
echo "Test" >strings/0x409/product
# Create a configuration called c.1
mkdir configs/c.1
mkdir configs/c.1/strings/0x409
echo "Config1" >configs/c.1/strings/0x409/configuration
# Create a function (tty CDC/ACM) named usb0
mkdir functions/acm.usb0
# Link that function to configuration c.1
ln -s functions/acm.usb0 configs/c.1
# Enable the USB device. Find the device
# name in /sys/class/udc/ .
echo musb-hdrc.0 >UDC
```




- The above example will create a CDC/ACM device.
 - A Linux host will identify this device as /dev/ttyACMn.
 - The device/gadget side will create a device node at /dev/ttyGs0.
 - Read and write to/from this node from the gadget to communicate with the host.



- Walk-through lab
 - On the device:
 - Run the script from the previous slides
 - On the host, run:
 - dmesg
 - Check for the new device name
 - sudo picocom /dev/ttyACMn
 - On the device, run:
 - echo "some text" >/dev/ttyGS0
 - cat /dev/ttyGS0





- In theory, the device can be disabled, changed, and re-enabled.
- In practice, on many parts, this is fraught with oopses, hangups, and other peril.
- Generally, you will want to setup your gadget and leave it.
 - Those who disagree have never actually done it.



- The previous example is designed to be as simple as possible
 - No source code, even!
- CDC/ACM is the best solution for emulating a serial port, and that's all.
- Don't use CDC/ACM as an arbitrary solution for connectivity
 - It's inefficient
 - Its burdensome on the end user



- We showed ACM, but what other protocols are implemented?
 - Start in Kernel source at:
 Documentation/filesystems/gadget_configfs.txt
 - Which references: Documentation/ABI/testing
 - Where you can: ls *usb-gadget*



As of 4.15, these gadgets are documented:

```
configfs-usb-gadget
                                  configfs-usb-gadget-phonet
configfs-usb-gadget-acm
                                  configfs-usb-gadget-printer
                                  configfs-usb-gadget-rndis
configfs-usb-gadget-ecm
configfs-usb-gadget-eem
                                  configfs-usb-gadget-serial
configfs-usb-gadget-ffs
                                  configfs-usb-gadget-sourcesink
configfs-usb-gadget-hid
                                  configfs-usb-gadget-subset
configfs-usb-gadget-loopback
                                  configfs-usb-gadget-tcm
configfs-usb-gadget-mass-storage
                                  configfs-usb-gadget-uac1
configfs-usb-gadget-midi
                                  configfs-usb-gadget-uac2
configfs-usb-gadget-ncm
                                  configfs-usb-gadget-uvc
configfs-usb-gadget-obex
```

See these files in: Documentation/ABI/testing/



- Briefly, some supported functions are:
 - acm CDC/ACM virtual serial port
 - ecm/eem/ncm/phonet/rndis/subset Virtual network device
 - ffs function filesystem
 - Define a custom class from userspace
 - hid Human interface device
 - loopback for testing
 - mass-storage present drives to the host



- Supported functions (cont'd):
 - midi musical instrument
 - printer printers
 - serial serial interface on the gadget side, but bulk interface on the host side
 - sourcesink source and sink for testing
 - tcm USB-attached SCSI
 - uac1/2 USB audio class, v1 and v2
 - uvc video



• Find more information about each gadget in it's respective source file:

```
drivers/usb/gadget/function/f_*.c
```

 As usual in the kernel, documentation is hit-ormiss



FunctionFS

- The gadget subsystem provides a function called FunctionFS, which allows complete configuration of the device through a user space application.
- The user space application provides:
 - All the descriptors/strings
- Functionfs will then use the descriptors to create device nodes for each endpoint.



FunctionFS

- The user space application can then read and write to/from these device nodes to move data across the bus.
- This is better than using ACM because there is no TTY layer in the way.
 - The TTY layer will chop up your write()s
 - Using FFS, one write() is one USB transfer.
 - This will get you close to wire speed



FunctionFS

- Modifying the script above, add the ffs function instead of the acm function.
- After this, mount the FunctionFS pseudo filesystem for your device.
 - This filesystem will give you an ep0 pseudo-file.
- Start your user space program which will configure the gadget
- Enable the USB device



FunctionFS Example

```
# Setup the function, FunctionFS (named usb0)
mkdir functions/ffs.usb0
ln -s functions/ffs.usb0 configs/c.1
# Mount the function filesystem for usb0
cd ../../
mkdir -p ffs
mount usb0 ffs -t functionfs
# From inside the mounted ffs directory, run your
# user space program and wait until it's started.
cd ffs
../ffs-test/ffs-test & # from the Linux kernel
sleep 3
cd ...
# Enable the USB device
echo musb-hdrc.0 >config/usb_gadget/g1/UDC
```

FunctionFS Example

- The kernel provides a sample user space program for FunctionFS.
- Unfortunately, it's more of a test program than an example to learn from.
 - Few comments
 - Complex design and indirection
 - Ambiguous naming
- Find it in: tools/usb/ffs-test.c



FunctionFS Example


- The kernel sample creates:
 - Ep0 (unused for this example)
 - Ep1 Bulk IN, 512 bytes (high speed)
 - EP2 Bulk OUT, 512 bytes (high speed)
- Ep1 creates an endless source of data
- Ep2 sinks an endless stream of data
- Also note that it's explicitly GPL.



FunctionFS Lab

- Walk-through Lab
 - Modify the gadget script for functionFS
 - Build the ffs-test program from the kernel
 - Copy it to the target's home directory
 - Run the gadget script.
 - Observe the device is detected on the host







- libusb is a multi-platform host-side USB library
 - Linux, BSD, OS X, Windows, others
- Runs in user space. No kernel programming required.
- Easy to use synchronous API
- High-performance asynchronous API
- Supports all versions of USB



 Unlike an M-Stack device, a libusb host runs on a general purpose multi-process OS.

 Sufficient permissions are required to open a device

 Opening a device or interface may be exclusive (only one process at a time).



- From a host perspective, the basic unit of a USB connection is the USB interface, not the device.
 - This is because devices can have multiple interfaces, each of which may require a different driver.
 - Some composite devices may have some standard interfaces (eg: CDC) and also some vendor-defined interfaces (eg: earlier example)



libusb Example

```
int main(int argc, char **argv)
{
        libusb_device_handle *handle;
        unsigned char buf[64];
        int length = 64, actual_length, i, res;
        /* Init libusb */
        if (libusb_init(NULL))
                return -1;
        /* Open the device. This is a shortcut function. */
        handle = libusb_open_device_with_vid_pid(
                                         NULL, 0xa0a0, 0x0001);
        if (!handle) {
                perror("libusb_open failed: ");
                return 1;
        /* Claim the interface for this process */
        res = libusb_claim_interface(handle, 0);
        if (res < 0) {
                perror("claim interface");
                return 1;
```

libusb Example (cont'd)

```
/* Initialize the data */
my_init_data_function(buf, length);
/* Send some data to the device */
res = libusb_bulk_transfer(
           handle, 0x01, buf, length, &actual_length, 5000);
if (res < 0) {
        fprintf(stderr, "bulk transfer (out): %s\n",
                                      libusb error name(res));
        return 1;
}
/* Receive data from the device */
res = libusb_bulk_transfer(handle, 0x81, buf, length,
                                           &actual length, 5000);
if (res < 0) {
        fprintf(stderr, "bulk transfer (in): %s\n",
                                         libusb_error_name(res));
        return 1;
}
/* Process the data */
my_process_received_data_function(buf, &actual_length);
return 0;
```

- Observations:
 - libusb, and libusb_bulk_transfer() deal with transfers, not transactions.
 - The length can be arbitrarily long and longer than the endpoint length.
 - If so, libusb will behave as expected, initiating transactions until the required amount of data has been transferred.
 - If the device returns a short packet, the transfer will end, and actual_length will indicate the actual amount of data received.

- Observations (cont'd):
 - The libusb_bulk_transfer() function is used for both IN and OUT transfers
 - The endpoint address (which contains the direction) is used to determine whether it's an IN or OUT transfer.



- Observations (cont'd):
 - The interface must be claimed before it can be used.
 - If another process, or a kernel driver, is using this interface, it will kick the other driver off.
 - This can be good or bad depending on your point of view.



- Observations (cont'd):
 - The libusb functions take a timeout parameter.
 - This timeout is how long the device has to complete the transfer.
 - It can be any value the host desires
 - The host is in charge of the bus!
 - 5 seconds is good for general purposes, but the author recently made one over 90 seconds!
 - It all depends on the use case!



- The previous example was very easy to use, and may be good for many use cases.
- However, repeatedly sending transfers using libusb's syncrhonous API is not the best method in performance-critical situations.
- Why is this?



Synchronous API Issues

USB Bus

- After one transfer completes, nothing happens on the bus until the next libusb transfer function is called.
- One might think it's good enough to call libusb_bulk_transfer() in a tight loop.
 - Tight loops are not tight enough!
 - For short transfers time spent in software will be more than time spent in hardware!
 - All time spent in software is time a transfer is not active!



Asynchronous API

- Fortunately libusb and the kernel provide an asynchronous API.
 - Create multiple transfer objects
 - Submit transfer objects to the kernel
 - Receive a callback when transfers complete
- When a transfer completes, there is another (submitted) transfer already queued.
 - No downtime between transfers!



Asynchronous API Example

```
static struct libusb_transfer
*create_transfer(libusb_device_handle *handle, size_t length) {
        struct libusb_transfer *transfer;
        unsigned char *buf;
        /* Set up the transfer object. */
        buf = malloc(length);
        transfer = libusb_alloc_transfer(0);
        libusb_fill_bulk_transfer(transfer,
                handle,
                0x81 /*ep*/,
                buf,
                length,
                read_callback,
                NULL/*cb data*/,
                5000/*timeout*/);
        return transfer;
}
```

Asynchronous API Example (cont'd)

```
static void read callback(struct libusb transfer *transfer)
        int res;
        if (transfer->status == LIBUSB_TRANSFER_COMPLETED) {
                /* Success! Handle data received */
        else {
                printf("Error: %d\n", transfer->status);
        }
        /* Re-submit the transfer object. */
        res = libusb_submit_transfer(transfer);
        if (res != 0) {
                printf("submitting. error code: %d\n", res);
        }
```



Asynchronous API Example (cont'd)

```
/* Create Transfers */
for (i = 0; i < 32; i++) {
        struct libusb transfer *transfer =
                create_transfer(handle, buflen);
        libusb submit transfer(transfer);
}
/* Handle Events */
while (1) {
        res = libusb handle events(usb context);
        if (res < 0) {
                printf("handle_events()error # %d\n",
                       res);
                /* Break out of this loop only on fatal error.*/
                if (res != LIBUSB ERROR BUSY &&
                    res != LIBUSB ERROR TIMEOUT &&
                    res != LIBUSB_ERROR_OVERFLOW &&
                    res != LIBUSB_ERROR_INTERRUPTED) {
                        break;
```

Asynchronous API

- This example creates and queues 32 transfers.
- When a transfer completes, the completed transfer object is re-queued.
- All the transfers in the queue can conceivably complete without a trip to user space.



Asynchronous API

- For All types of Endpoint:
 - The Host will not send any IN or OUT tokens on the bus unless a transfer object is active.
 - The bus is **idle** otherwise
 - Create and submit a transfer object using the functions on the preceding slides.



Performance

 For more information on USB performance, see my ELC 2014 presentation titled *USB and the Real World*

http://www.signal11.us/oss/elc2014/

> Several devices and methods compared



API Summary

- All traffic is initiated by the Host
- In user space, this is done from **libusb**:
 - Synchronous:

```
libusb_control_transfer()
libusb_bulk_transfer()
libusb_interrupt_transfer()
```

Asynchronous:

```
libusb_submit_transfer()
```





Libusb Lab

- Lab
 - Create a user space application to talk to the FunctionFS gadget device you created earlier
 - Remember:
 - Find the VID/PID from the script
 - Ep1 is bulk IN, Ep2 is bulk OUT







Alan Ott

alan@softiron.com

www.softiron.com

+1 407-222-6975 (GMT -5)

Slides and labs Copyright 2018 Alan Ott Distributed under Creative Commons CC BY-SA 4.0