# **Experiment 6**

<u>Title</u>: To generate 1 sec delay using timer

<u>Aim</u>: To utilize timer interrupts on an STM32 Microcontroller to create precise timing events.

**Tool used:** The tool used for this assignment is **STM32CubeIDE** 

## **Procedure:**

- 1. Create a new STM32 project with a suitable project name.
- 2. IOC UI will open in that configure desired pins as input/output.
- 3. In system core select TIM2.
- 4. In parameter settings give prescaler 15999 and counter period as 999.
- 5. Press Ctrl+S to generate the code.
- 6. In the main.c file add the desired code.
- 7. Go to Project-> Build Project
- 8. PG14 LED is given normal delay of 1000ms and PG13 is used to generate 1 sec delay using timer.
- 9. Connect the discovery Board and go to Run-> Run.

## **CubeMX pin diagram:**



### Code:

```
/* USER CODE BEGIN Header */
******************************
* @file : main.c 
* @brief : Main program body
*********************************
* @attention
* Copyright (c) 2023 STMicroelectronics.
* All rights reserved.
* This software is licensed under terms that can be found in the LICENSE file
* in the root directory of this software component.
* If no LICENSE file comes with this software, it is provided AS-IS.
******************************
*/
/* USER CODE END Header */
/* Includes -----*/
#include "main.h"
/* Private includes -----*/
/* USER CODE BEGIN Includes */
/* USER CODE END Includes */
/* Private typedef -----*/
/* USER CODE BEGIN PTD */
/* USER CODE END PTD */
/* Private define -----*/
/* USER CODE BEGIN PD */
/* USER CODE END PD */
/* Private macro -----*/
/* USER CODE BEGIN PM */
/* USER CODE END PM */
/* Private variables -----*/
```

```
TIM_HandleTypeDef htim2;
/* USER CODE BEGIN PV */
/* USER CODE END PV */
/* Private function prototypes -----*/
void SystemClock_Config(void);
static void MX_GPIO_Init(void);
static void MX_TIM2_Init(void);
/* USER CODE BEGIN PFP */
/* USER CODE END PFP */
/* Private user code -----*/
/* USER CODE BEGIN 0 */
/* USER CODE END 0 */
 * @brief The application entry point.
 * @retval int
int main(void)
 /* USER CODE BEGIN 1 */
/* USER CODE END 1 */
/* MCU Configuration-----*/
 /* Reset of all peripherals, Initializes the Flash interface and the Systick. */
HAL_Init();
/* USER CODE BEGIN Init */
 /* USER CODE END Init */
 /* Configure the system clock */
SystemClock_Config();
 /* USER CODE BEGIN SysInit */
/* USER CODE END SysInit */
 /* Initialize all configured peripherals */
MX_GPIO_Init();
MX_TIM2_Init();
HAL_TIM_Base_Start_IT(&htim2);
 /* USER CODE BEGIN 2 */
```

```
/* USER CODE END 2 */
 /* Infinite loop */
 /* USER CODE BEGIN WHILE */
while (1)
{
  /* USER CODE END WHILE */
       HAL_GPIO_TogglePin(GPIOG, GPIO_PIN_14);
       HAL Delay(1000);
  /* USER CODE BEGIN 3 */
/* USER CODE END 3 */
/**
 * @brief System Clock Configuration
 * @retval None
void SystemClock_Config(void)
 RCC_OscInitTypeDef RCC_OscInitStruct = {0};
 RCC_ClkInitTypeDef RCC_ClkInitStruct = {0};
 /** Configure the main internal regulator output voltage
 __HAL_RCC_PWR_CLK_ENABLE();
__HAL_PWR_VOLTAGESCALING_CONFIG(PWR_REGULATOR_VOLTAGE_SCALE
3);
 /** Initializes the RCC Oscillators according to the specified parameters
 * in the RCC_OscInitTypeDef structure.
 RCC_OscInitStruct.OscillatorType = RCC_OSCILLATORTYPE_HSI;
 RCC_OscInitStruct.HSIState = RCC_HSI_ON;
 RCC OscInitStruct.HSICalibrationValue = RCC HSICALIBRATION DEFAULT;
 RCC_OscInitStruct.PLL.PLLState = RCC_PLL_NONE;
 if (HAL_RCC_OscConfig(&RCC_OscInitStruct) != HAL_OK)
 Error Handler();
 /** Initializes the CPU, AHB and APB buses clocks
 RCC_ClkInitStruct.ClockType =
RCC_CLOCKTYPE_HCLK|RCC_CLOCKTYPE_SYSCLK
               |RCC_CLOCKTYPE_PCLK1|RCC_CLOCKTYPE_PCLK2;
 RCC_ClkInitStruct.SYSCLKSource = RCC_SYSCLKSOURCE_HSI;
 RCC_ClkInitStruct.AHBCLKDivider = RCC_SYSCLK_DIV1;
```

```
RCC_ClkInitStruct.APB1CLKDivider = RCC_HCLK_DIV1;
 RCC_ClkInitStruct.APB2CLKDivider = RCC_HCLK_DIV1;
 if (HAL_RCC_ClockConfig(&RCC_ClkInitStruct, FLASH_LATENCY_0) != HAL_OK)
 Error_Handler();
 * @brief TIM2 Initialization Function
 * @param None
 * @retval None
static void MX_TIM2_Init(void)
 /* USER CODE BEGIN TIM2 Init 0 */
 /* USER CODE END TIM2 Init 0 */
 TIM ClockConfigTypeDef sClockSourceConfig = {0};
 TIM_MasterConfigTypeDef sMasterConfig = {0};
 /* USER CODE BEGIN TIM2_Init 1 */
 /* USER CODE END TIM2 Init 1 */
htim2.Instance = TIM2;
htim2.Init.Prescaler = 15999;
htim2.Init.CounterMode = TIM_COUNTERMODE_UP;
htim2.Init.Period = 999;
htim2.Init.ClockDivision = TIM_CLOCKDIVISION_DIV1;
htim2.Init.AutoReloadPreload = TIM AUTORELOAD PRELOAD DISABLE;
 if (HAL TIM Base Init(&htim2) != HAL OK)
 Error_Handler();
 sClockSourceConfig.ClockSource = TIM_CLOCKSOURCE_INTERNAL;
 if (HAL_TIM_ConfigClockSource(&htim2, &sClockSourceConfig) != HAL_OK)
 Error Handler();
 sMasterConfig.MasterOutputTrigger = TIM_TRGO_RESET;
 sMasterConfig.MasterSlaveMode = TIM_MASTERSLAVEMODE_DISABLE;
 if (HAL_TIMEx_MasterConfigSynchronization(&htim2, &sMasterConfig) != HAL_OK)
 Error_Handler();
 /* USER CODE BEGIN TIM2 Init 2 */
```

```
/* USER CODE END TIM2_Init 2 */
}
 * @brief GPIO Initialization Function
 * @param None
 * @retval None
static void MX_GPIO_Init(void)
 GPIO_InitTypeDef GPIO_InitStruct = {0};
 /* GPIO Ports Clock Enable */
 __HAL_RCC_GPIOG_CLK_ENABLE();
 /*Configure GPIO pin Output Level */
 HAL_GPIO_WritePin(GPIOG, GPIO_PIN_13|GPIO_PIN_14, GPIO_PIN_RESET);
 /*Configure GPIO pins : PG13 PG14 */
 GPIO _InitStruct.Pin = GPIO_PIN_13|GPIO_PIN_14;
 GPIO InitStruct.Mode = GPIO MODE OUTPUT PP;
 GPIO_InitStruct.Pull = GPIO_NOPULL;
 GPIO_InitStruct.Speed = GPIO_SPEED_FREQ_LOW;
 HAL_GPIO_Init(GPIOG, &GPIO_InitStruct);
}
/* USER CODE BEGIN 4 */
void HAL_TIM_PeriodElapsedCallback(TIM_HandleTypeDef* htim)
HAL_GPIO_TogglePin(GPIOG, GPIO_PIN_13);
}
/* USER CODE END 4 */
/**
 * @brief This function is executed in case of error occurrence.
 * @retval None
void Error Handler(void)
 /* USER CODE BEGIN Error_Handler_Debug */
 /* User can add his own implementation to report the HAL error return state */
 __disable_irq();
 while (1)
 /* USER CODE END Error Handler Debug */
```

# #ifdef USE\_FULL\_ASSERT /\*\* \* @brief Reports the name of the source file and the source line number \* where the assert\_param error has occurred. \* @param file: pointer to the source file name \* @param line: assert\_param error line source number \* @retval None \*/ void assert\_failed(uint8\_t \*file, uint32\_t line) { /\* USER CODE BEGIN 6 \*/ /\* User can add his own implementation to report the file name and line number, ex: printf("Wrong parameters value: file %s on line %d\r\n", file, line) \*/ /\* USER CODE END 6 \*/ } #endif /\* USE\_FULL\_ASSERT \*/

## **Output:**



# **Functions used:**

HAL\_GPIO\_TogglePin(GPIOx, GPIO Pin Number);

HAL\_Delay(In ms);

HAL\_TIM\_PeriodElapsedCallback(TIM\_HandleTypeDef\* htim)

# Result:

Basic STM32Cube project for generating 1 sec delay with timer was built using STM32CubeIDE.