Experiment 2

Title: Blink PG13 and PG14

Aim: Blinking 2 LED's using STM32CubeIDE using ReadPin(), WritePin() and TogglePin().

Tool used: Tool used for this assignment is **STM32CubeIDE**.

Procedure:

- 1. Create a new STM32 project with a suitable project name.
- 2. IOC UI will open in that configure desired pins as input/output.
- 3. Press Ctrl+S to generate the code.
- 4. In the main.c file add the desired code.
- 5. Go to Project-> Build Project.
- 6. Connect the discovery Board and go to Run-> Run.

CubeMx pin diagram:



Code:

/* USER CODE BEGIN Header */
/**

* @file : main.c

* @brief : Main program body

```
* @attention
* Copyright (c) 2023 STMicroelectronics.
* All rights reserved.
* This software is licensed under terms that can be found in the LICENSE file
* in the root directory of this software component.
* If no LICENSE file comes with this software, it is provided AS-IS.
************************************
***
*/
/* USER CODE END Header */
/* Includes -----*/
#include "main.h"
/* Private includes -----*/
/* USER CODE BEGIN Includes */
/* USER CODE END Includes */
/* Private typedef -----*/
/* USER CODE BEGIN PTD */
/* USER CODE END PTD */
/* Private define -----*/
/* USER CODE BEGIN PD */
/* USER CODE END PD */
/* Private macro -----*/
/* USER CODE BEGIN PM */
/* USER CODE END PM */
/* Private variables -----*/
/* USER CODE BEGIN PV */
/* USER CODE END PV */
/* Private function prototypes -----*/
void SystemClock_Config(void);
static void MX_GPIO_Init(void);
/* USER CODE BEGIN PFP */
```

```
/* USER CODE END PFP */
/* Private user code -----*/
/* USER CODE BEGIN 0 */
/* USER CODE END 0 */
/**
 * @brief The application entry point.
 * @retval int
 */
int main(void)
 /* USER CODE BEGIN 1 */
 /* USER CODE END 1 */
 /* MCU Configuration-----*/
 /* Reset of all peripherals, Initializes the Flash interface and the Systick. */
HAL Init();
 /* USER CODE BEGIN Init */
 /* USER CODE END Init */
 /* Configure the system clock */
SystemClock_Config();
 /* USER CODE BEGIN SysInit */
 /* USER CODE END SysInit */
 /* Initialize all configured peripherals */
 MX_GPIO_Init();
 /* USER CODE BEGIN 2 */
 /* USER CODE END 2 */
 /* Infinite loop */
 /* USER CODE BEGIN WHILE */
 while (1)
 {
      HAL_GPIO_TogglePin(GPIOG,GPIO_PIN_13);
      HAL_Delay(1000);
      HAL_GPIO_TogglePin(GPIOG,GPIO_PIN_14);
      HAL_Delay(1000);
 /* USER CODE END 3 */
```

```
}
/**
 * @brief System Clock Configuration
 * @retval None
void SystemClock Config(void)
 RCC_OscInitTypeDef RCC_OscInitStruct = {0};
 RCC ClkInitTypeDef RCC ClkInitStruct = {0};
 /** Configure the main internal regulator output voltage
 __HAL_RCC_PWR_CLK_ENABLE();
__HAL_PWR_VOLTAGESCALING_CONFIG(PWR_REGULATOR_VOLTAGE_SCALE
3);
 /** Initializes the RCC Oscillators according to the specified parameters
 * in the RCC_OscInitTypeDef structure.
 RCC_OscInitStruct.OscillatorType = RCC_OSCILLATORTYPE_HSI;
 RCC_OscInitStruct.HSIState = RCC_HSI_ON;
 RCC_OscInitStruct.HSICalibrationValue = RCC_HSICALIBRATION_DEFAULT;
 RCC_OscInitStruct.PLL.PLLState = RCC_PLL_NONE;
 if (HAL_RCC_OscConfig(&RCC_OscInitStruct) != HAL_OK)
 Error_Handler();
 /** Initializes the CPU, AHB and APB buses clocks
 RCC_ClkInitStruct.ClockType =
RCC_CLOCKTYPE_HCLK|RCC_CLOCKTYPE_SYSCLK
               |RCC_CLOCKTYPE_PCLK1|RCC_CLOCKTYPE_PCLK2;
 RCC_ClkInitStruct.SYSCLKSource = RCC_SYSCLKSOURCE_HSI;
 RCC ClkInitStruct.AHBCLKDivider = RCC SYSCLK DIV1;
 RCC_ClkInitStruct.APB1CLKDivider = RCC_HCLK_DIV1;
 RCC_ClkInitStruct.APB2CLKDivider = RCC_HCLK_DIV1;
 if (HAL RCC ClockConfig(&RCC ClkInitStruct, FLASH LATENCY 0) != HAL OK)
 Error_Handler();
 }
}
 * @brief GPIO Initialization Function
 * @param None
 * @retval None
```

```
*/
static void MX_GPIO_Init(void)
 GPIO InitTypeDef GPIO InitStruct = {0};
/* USER CODE BEGIN MX GPIO Init 1 */
/* USER CODE END MX_GPIO_Init_1 */
 /* GPIO Ports Clock Enable */
 __HAL_RCC_GPIOG_CLK_ENABLE();
 /*Configure GPIO pin Output Level */
 HAL_GPIO_WritePin(GPIOG, GPIO_PIN_13|GPIO_PIN_14, GPIO_PIN_RESET);
 /*Configure GPIO pins : PG13 PG14 */
 GPIO InitStruct.Pin = GPIO PIN 13|GPIO PIN 14;
 GPIO_InitStruct.Mode = GPIO_MODE_OUTPUT_PP;
 GPIO InitStruct.Pull = GPIO NOPULL;
 GPIO InitStruct.Speed = GPIO SPEED FREO LOW:
 HAL GPIO Init(GPIOG, &GPIO InitStruct);
/* USER CODE BEGIN MX_GPIO_Init_2 */
/* USER CODE END MX GPIO Init 2 */
}
/* USER CODE BEGIN 4 */
/* USER CODE END 4 */
 * @brief This function is executed in case of error occurrence.
 * @retval None
void Error_Handler(void)
 /* USER CODE BEGIN Error_Handler_Debug */
 /* User can add his own implementation to report the HAL error return state */
 disable irq();
 while (1)
 /* USER CODE END Error Handler Debug */
#ifdef USE FULL ASSERT
 * @brief Reports the name of the source file and the source line number
       where the assert_param error has occurred.
 * @param file: pointer to the source file name
 * @param line: assert param error line source number
 * @retval None
```

```
*/
void assert_failed(uint8_t *file, uint32_t line)
{
   /* USER CODE BEGIN 6 */
   /* User can add his own implementation to report the file name and line number,
        ex: printf("Wrong parameters value: file %s on line %d\r\n", file, line) */
   /* USER CODE END 6 */
}
#endif /* USE_FULL_ASSERT */
```

Output:



Functions used:

HAL_GPIO_TogglePin (GPIOx, GPIO_PIN_Number); HAL_Delay (In ms);

Result:

Basic STM32Cube project for blinking PG13 and PG14 LEDs was built using STM32CubeIDE.