## **Experiment 8**

**<u>Title</u>:** PWM and UART

<u>Aim</u>: To create a project in STM32Cube IDE to generate 70% duty cycle PWM signal and display the duty cycle in serial monitor using UART communication.

**Tool used:** The tool used for this assignment is: **STM32Cube IDE.** 

#### **Procedure:**

- 1. Create a new STM32 project with a suitable project name.
- 2. IOC UI will open in that configure default LED pins (PG13&PG14) as output.
- **3.** Enable timer 2 with PWM channel 1 enabled and load the prescaler and period according to the time delay you want to generate.
- **4.** Enable UART1 communication and set the required baud rate.
- **5.** Under system core select Serial-wire for Debug option.
- **6.** Press Ctrl+S to generate the code.
- 7. In the main.c file add the desired code.
- 8. Go to Project-> Build Project.
- **9.** Connect the discovery Board and go to Run-> Run.

### **CubeMx pin Diagram:**



# **Code:** /\* USER CODE BEGIN Header \*/ \* \* @file : main.c \* @brief : Main program body \* \* @attention \* Copyright (c) 2023 STMicroelectronics. \* All rights reserved. \* This software is licensed under terms that can be found in the LICENSE file \* in the root directory of this software component. \* If no LICENSE file comes with this software, it is provided AS-IS. /\* USER CODE END Header \*/ /\* Includes -----\*/ #include "main.h" #include "string.h"

/\* Private includes -----\*/

/\* USER CODE BEGIN Includes \*/

```
/* USER CODE END Includes */
/* Private typedef -----*/
/* USER CODE BEGIN PTD */
/* USER CODE END PTD */
/* Private define -----*/
/* USER CODE BEGIN PD */
/* USER CODE END PD */
/* Private macro -----*/
/* USER CODE BEGIN PM */
/* USER CODE END PM */
/* Private variables -----*/
TIM_HandleTypeDef htim2;
UART HandleTypeDef huart1;
/* USER CODE BEGIN PV */
/* USER CODE END PV */
/* Private function prototypes -----*/
void SystemClock Config(void);
static void MX_GPIO_Init(void);
```

```
static void MX_TIM2_Init(void);
static void MX_USART1_UART_Init(void);
/* USER CODE BEGIN PFP */
/* USER CODE END PFP */
/* Private user code -----*/
/* USER CODE BEGIN 0 */
/* USER CODE END 0 */
/**
* @brief The application entry point.
 * @retval int
 */
int main(void)
/* USER CODE BEGIN 1 */
/* USER CODE END 1 */
/* MCU Configuration-----*/
/* Reset of all peripherals, Initializes the Flash interface and the Systick. */
HAL Init();
/* USER CODE BEGIN Init */
/* USER CODE END Init */
```

```
/* Configure the system clock */
SystemClock_Config();
/* USER CODE BEGIN SysInit */
/* USER CODE END SysInit */
/* Initialize all configured peripherals */
MX GPIO Init();
MX TIM2 Init();
MX_USART1_UART_Init();
HAL TIM PWM Start(&htim2, TIM CHANNEL 1);
/* USER CODE BEGIN 2 */
/* USER CODE END 2 */
/* Infinite loop */
/* USER CODE BEGIN WHILE */
while (1)
 /* USER CODE END WHILE */
      if (HAL GPIO ReadPin(GPIOA, GPIO PIN 0) == 1)
      {
      /* USER CODE END WHILE */
      char *MutStr = "Duty cycle is 70\%\r\n";
      HAL UART Transmit(&huart1, (uint8 t*)MutStr, strlen (MutStr),
      1000);
      HAL GPIO TogglePin(GPIOA, GPIO PIN 0);
      }
      HAL GPIO TogglePin(GPIOG, GPIO PIN 13);
```

```
/* USER CODE BEGIN 3 */
 }
/* USER CODE END 3 */
}
/**
 * @brief System Clock Configuration
 * @retval None
 */
void SystemClock Config(void)
 RCC_OscInitTypeDef RCC_OscInitStruct = {0};
 RCC ClkInitTypeDef RCC ClkInitStruct = {0};
 /** Configure the main internal regulator output voltage
 HAL RCC PWR CLK ENABLE();
 _HAL_PWR_VOLTAGESCALING_CONFIG(PWR_REGULATOR_VOLTAGE_SCALE3
);
/** Initializes the RCC Oscillators according to the specified parameters
 * in the RCC OscInitTypeDef structure.
 */
 RCC OscInitStruct.OscillatorType = RCC OSCILLATORTYPE HSI;
 RCC_OscInitStruct.HSIState = RCC_HSI_ON;
 RCC OscInitStruct.HSICalibrationValue = RCC HSICALIBRATION DEFAULT;
 RCC_OscInitStruct.PLL.PLLState = RCC_PLL_NONE;
 if (HAL RCC OscConfig(&RCC OscInitStruct) != HAL OK)
 {
```

```
Error Handler();
 }
 /** Initializes the CPU, AHB and APB buses clocks
 */
 RCC ClkInitStruct.ClockType =
RCC CLOCKTYPE_HCLK|RCC_CLOCKTYPE_SYSCLK
               |RCC CLOCKTYPE PCLK1|RCC CLOCKTYPE PCLK2;
 RCC ClkInitStruct.SYSCLKSource = RCC SYSCLKSOURCE HSI;
 RCC ClkInitStruct.AHBCLKDivider = RCC SYSCLK DIV1;
 RCC_ClkInitStruct.APB1CLKDivider = RCC_HCLK_DIV1;
 RCC ClkInitStruct.APB2CLKDivider = RCC HCLK DIV1;
 if (HAL RCC ClockConfig(&RCC ClkInitStruct, FLASH LATENCY 0) != HAL OK)
  Error Handler();
}
/**
 * @brief TIM2 Initialization Function
 * @param None
 * @retval None
 */
static void MX TIM2 Init(void)
{
 /* USER CODE BEGIN TIM2 Init 0 */
 /* USER CODE END TIM2 Init 0 */
```

```
TIM ClockConfigTypeDef sClockSourceConfig = {0};
TIM MasterConfigTypeDef sMasterConfig = {0};
TIM OC InitTypeDef sConfigOC = \{0\};
/* USER CODE BEGIN TIM2 Init 1 */
/* USER CODE END TIM2 Init 1 */
htim2.Instance = TIM2;
htim2.Init.Prescaler = 15999;
htim2.Init.CounterMode = TIM COUNTERMODE UP;
htim2.Init.Period = 1000;
htim2.Init.ClockDivision = TIM CLOCKDIVISION DIV1;
htim2.Init.AutoReloadPreload = TIM AUTORELOAD PRELOAD DISABLE;
if (HAL TIM Base Init(&htim2) != HAL OK)
 Error Handler();
sClockSourceConfig.ClockSource = TIM CLOCKSOURCE INTERNAL;
if (HAL TIM ConfigClockSource(&htim2, &sClockSourceConfig) != HAL OK)
 Error Handler();
}
if (HAL TIM PWM Init(&htim2) != HAL OK)
 Error Handler();
}
sMasterConfig.MasterOutputTrigger = TIM TRGO RESET;
sMasterConfig.MasterSlaveMode = TIM MASTERSLAVEMODE DISABLE;
if (HAL TIMEx MasterConfigSynchronization(&htim2, &sMasterConfig) != HAL OK)
{
```

```
Error Handler();
 }
 sConfigOC.OCMode = TIM OCMODE PWM1;
 sConfigOC.Pulse = 700;
sConfigOC.OCPolarity = TIM OCPOLARITY HIGH;
 sConfigOC.OCFastMode = TIM OCFAST DISABLE;
if (HAL TIM PWM ConfigChannel(&htim2, &sConfigOC, TIM CHANNEL 1) !=
HAL OK)
 {
 Error Handler();
 }
/* USER CODE BEGIN TIM2 Init 2 */
/* USER CODE END TIM2 Init 2 */
HAL TIM MspPostInit(&htim2);
}
/**
 * @brief USART1 Initialization Function
 * @param None
 * @retval None
 */
static void MX USART1 UART Init(void)
{
/* USER CODE BEGIN USART1_Init 0 */
/* USER CODE END USART1_Init 0 */
/* USER CODE BEGIN USART1_Init 1 */
```

```
/* USER CODE END USART1 Init 1 */
 huart1.Instance = USART1;
 huart1.Init.BaudRate = 9600;
 huart1.Init.WordLength = UART WORDLENGTH 8B;
 huart1.Init.StopBits = UART STOPBITS 1;
 huart1.Init.Parity = UART PARITY NONE;
 huart1.Init.Mode = UART MODE TX RX;
 huart1.Init.HwFlowCtl = UART HWCONTROL NONE;
 huart1.Init.OverSampling = UART OVERSAMPLING 16;
 if (HAL_UART_Init(&huart1) != HAL_OK)
  Error_Handler();
 /* USER CODE BEGIN USART1 Init 2 */
 /* USER CODE END USART1 Init 2 */
}
 * @brief GPIO Initialization Function
 * @param None
 * @retval None
 */
static void MX GPIO Init(void)
{
 GPIO InitTypeDef GPIO InitStruct = {0};
/* USER CODE BEGIN MX GPIO Init 1 */
/* USER CODE END MX GPIO Init 1 */
```

```
/* GPIO Ports Clock Enable */
  _HAL_RCC_GPIOA_CLK_ENABLE();
 HAL_RCC_GPIOG_CLK_ENABLE();
 /*Configure GPIO pin Output Level */
 HAL GPIO WritePin(GPIOG, GPIO PIN 13, GPIO PIN RESET);
 /*Configure GPIO pin : PG13 */
 GPIO InitStruct.Pin = GPIO PIN 13;
 GPIO_InitStruct.Mode = GPIO_MODE_OUTPUT_PP;
 GPIO InitStruct.Pull = GPIO NOPULL;
 GPIO_InitStruct.Speed = GPIO_SPEED_FREQ_LOW;
 HAL GPIO Init(GPIOG, &GPIO InitStruct);
/* USER CODE BEGIN MX GPIO Init 2 */
/* USER CODE END MX GPIO Init 2 */
}
/* USER CODE BEGIN 4 */
/* USER CODE END 4 */
 * @brief This function is executed in case of error occurrence.
 * @retval None
 */
void Error Handler(void)
 /* USER CODE BEGIN Error Handler Debug */
```

```
/* User can add his own implementation to report the HAL error return state */
   _disable_irq();
 while (1)
 /* USER CODE END Error Handler Debug */
#ifdef USE FULL ASSERT
 * @brief Reports the name of the source file and the source line number
       where the assert param error has occurred.
 * @param file: pointer to the source file name
 * @param line: assert param error line source number
 * @retval None
 */
void assert_failed(uint8_t *file, uint32_t line)
 /* USER CODE BEGIN 6 */
 /* User can add his own implementation to report the file name and line number,
  ex: printf("Wrong parameters value: file %s on line %d\r\n", file, line) */
 /* USER CODE END 6 */
}
#endif /* USE FULL ASSERT */
```

## **Output:**



## **Functions used:**

HAL TIM PWM Start(&handle variable name, TIM CHANNEL 1);

HAL\_GPIO\_ReadPin(GPIOx, GPIO Pin Number);

HAL\_UART\_Transmit(&handle\_variable\_name, (typecasting)MutStr, strlen (MutStr), Timeout);

HAL\_GPIO\_TogglePin(GPIOx, GPIO Pin Number);

# **Result:**

Basic STM32Cube project for blinking LED at 70% duty cycle is implemented using PWM and the duty cycle is displayed using UART communication.