


RISC-V Instruction Formats

Instructor: Steven Ho



Great Idea #1: Levels of Representation/Interpretation



- Stored-Program Concept
- R-Format
- I-Format
- Administrivia
- S-Format
- SB-Format
- U-Format
- UJ-Format



Instructions and data both are stored as numbers in the memory is called stored-program concept.

Big Idea: Stored-Program Concept


INSTRUCTIONS ARE DATA

- programs can be stored in memory as numbers
- Before: a number can mean anything
- Now: make convention for interpreting numbers as instructions



Introduction to Machine Language

Instructor: Steven Ho



Instructions as Numbers

By convention, RISCV instructions are each
 1 word = 4 bytes = 32 bits

31 0

- Divide the 32 bits of an instruction into "fields"
 - regular field sizes → simpler hardware
 - will need some variation....
- Define 6 types of instruction formats:
 - R-Format I-Format S-Format U-Format

6


For dividing the instruction into different fields, various SB-Format formats have been introduced for different typs of CS61C Su18 - Lecture 7

The 6 Instruction Formats

- R-Format: instructions using 3 register inputs
- I-Format: instructions with immediates, loads
 - -addi, lw, jalr, slli
- S-Format: store instructions: sw, sb
- SB-Format: branch instructions: beq, bge
- U-Format: instructions with upper immediates
 - lui, auipcupper immediate is 20-bits
- UJ-Format: jump instructions: jal

The 6 Instruction Formats


| | 31 | | 27 | 26 | 25 | 24 | 20 | 19 | 15 | 14 | 12 | 11 | 7 | 6 | 0 |
|----|-------------------|--------------|--------|----|---------|--------|--------|----|-------------|--------|--------|-----|---|---|---|
| R | funct7 | | rs2 rs | | s1 | funct3 | | rd | | Opcode | | | | | |
| I | imm[11:0] | | | | rs1 | | funct3 | | t3 rd | | Opcode | | | | |
| S | imm[11:5] | | rs | s2 | rs1 | | funct3 | | 3 imm[4:0] | | opco | ode | | | |
| SB | | imm[12 10:5] | | rs | rs2 rs1 | | funct3 | | imm[4:1 11] | | opco | ode | | | |
| U | imm[31:12] | | | | | | | | rd | | opco | ode | | | |
| UJ | imm[20 10:1 11 19 | | | | 11 19: | 12] | | | rd | | opcode | | | | |




- Stored-Program Concept
- R-Format
- I-Format
- Administrivia
- S-Format
- SB-Format
- U-Format
- UJ-Format

R-Format Instructions (1/3)

• Define "fields" of the following number of bits each: 7 + 5 + 5 + 3 + 5 + 7 = 32




• Each field has a name:



- Each field is viewed as its own unsigned int
 - 5-bit fields can represent any number 0-31,
 while 7-bit fields can represent any number 0-128,
 etc.

Opcode determines the type of instruction and funct7 and funct3 will actually decide which instruction of that type.

R-Format Instructions (2/3)




- opcode (7): partially specifies operation
 - e.g. R-types have opcode = 0b0110011,SB (branch) types have opcode = 0b1100011
- funct7+funct3 (10): combined with opcode, these two fields describe what operation to perform
- How many R-format instructions can we encode?
 - with opcode fixed at 0b0110011, just funct varies: $(2^7) \times (2^3) = (2^{10}) = 1024$

11

5/27/2018 CS61C Su18 - Lecture 7

R-Format Instructions (3/3)



- rs1 (5): 1st operand ("source register 1")
- rs2 (5): 2nd operand (second source register)
- rd (5): "destination register" receives the result of computation
- Recall: RISCV has 32 registers
 - A 5 bit field can represent exactly $2^5 = 32$ things (interpret as the register numbers **x0-x31**)

Reading from the Green Sheet

add t0 t1 t2

RV64I BASE INTEGER INSTRUCTIONS, in alphabetical order


MNEMONIC FMT NAME

DESCRIPTION (in Verilog)


add, addw R ADD (Word)

R[rd] = R[rs1] + R[rs2]

OPCODES IN NUMERICAL ORDER BY OPCODE



R-Format Example



hex representation: $0 \times 0073 02B3$

decimal representation: 7,537,331

Called a Machine Language Instruction

All RV32 R-format instructions

| 0000000 | rs2 | rs1 | 000 | rd | 0110011 | ADD |
|---------|-----|-----|-----|----|---------|------|
| 0100000 | rs2 | rs1 | 000 | rd | 0110011 | SUB |
| 0000000 | rs2 | rs1 | 001 | rd | 0110011 | SLL |
| 0000000 | rs2 | rs1 | 010 | rd | 0110011 | SLT |
| 0000000 | rs2 | rs1 | 011 | rd | 0110011 | SLTU |
| 0000000 | rs2 | rs1 | 100 | rd | 0110011 | XOR |
| 0000000 | rs2 | rs1 | 101 | rd | 0110011 | SRL |
| 0100000 | rs2 | rs1 | 101 | rd | 0110011 | SRA |
| 0000000 | rs2 | rs1 | 110 | rd | 0110011 | OR |
| 0000000 | rs2 | rs1 | 111 | rd | 0110011 | AND |
| | | | | | 1/1 | 1 |

Different encoding in funct7 + funct3 selects different operations


- Stored-Program Concept
- R-Format
- I-Format
- Administrivia
- S-Format
- SB-Format
- U-Format
- UJ-Format

I-Format Instructions (1/4)


- What about instructions with immediates?
 - 5-bit field too small for most immediates
- Ideally, RISCV would have only one instruction format (for simplicity)
 - Unfortunately here we need to compromise
- Define new instruction format that is mostly consistent with R-Format
 - First notice that, if instruction has immediate,
 then it uses at most 2 registers (1 src, 1 dst)

I-Format Instructions (2/4)

• Define "fields" of the following number of bits each: 12 + 5 + 3 + 5 + 7 = 32 bits



Field names:




• **Key Concept:** Only **imm** field is different from R-format: rs2 and funct7 replaced by 12-bit signed immediate, **imm** [11:0]

I-Format Instructions (3/4)

- opcode (7): uniquely specifies the instruction
- rs1 (5): specifies a register operand
- rd (5): specifies destination register that receives result of computation

Immediate is taken to be signed here.

I-Format Instructions (4/4)



- immediate (12): 12 bit number
 - All computations done in words, so 12-bit immediate must be extended to 32 bits
 - always sign-extended to arithmetic operation
- Can represent 2¹² different immediates
 - $\text{ imm}[11:0] \text{ can hold values in range } [-2^{11}, +2^{11}]$


I-Format Example (1/2)

addi x15, x1, -50

| OPCODES IN | NUMER | RICAL ORDE | R BY OPCO | DE | |
|------------|-------|------------|-----------|--------------|----------------|
| MNEMONIC | FMT | OPCODE | FUNCT3 | FUNCT7 OR IM | IM HEXADECIMAL |
| fence.i | I | 0001111 | 001 | | 0F/1 |
| addi | I | 0010011 | 000 | | (13/0) |
| slli | I | 0010011 | 001 | 0000000 | 13/1/0 |
| | | | | | |

$$rd = x15$$

$$rs1 = x1$$




6/27/2018

I-Format Example (2/2)

• RISCV Instruction: addi x15, x1, -50

Field representation (binary):



decimal representation: 4,242,573,203

All RISCV I-Type Arithmatic Instructions

| | - | | | | | 1 |
|------------------|------------------------|--|-----|---------------------|---------|------------|
| imm[11:0] | 0] | rs1 | 000 | rd | 0010011 | ADDI |
| imm[11:0 | 0] | rs1 | 010 | rd | 0010011 | SLTI |
| imm[11:0 | 0] | rs1 | 011 | rd | 0010011 | SLTIU |
| imm[11:0 | 0] | rs1 | 100 | rd | 0010011 | XORI |
| imm[11:0 | 0] | rs1 | 110 | rd | 0010011 | ORI |
| imm[11:0 | 0] | rs1 | 111 | rd | 0010011 | ANDI |
| 0000000 | shamt | rs1 | 001 | rd | 0010011 | SLLI |
| 0000000 | shamt | rs1 | 101 | rd | 0010011 | SRLI |
| (1) 00000 | shamt | rs1 | 101 | rd | 0010011 | SRAI |
| N | | | | | | 10,000,000 |

One of the higher-order immediate bits is used to distinguish "shift right logical" (SRLI) from "shift right arithmetic" (SRAI) "Shift-by-immediate" instructions only use lower 5 bits of the immediate value for shift amount (can only shift by 0-31 bit positions)





- (A) There must be more R-type instructions
- (B) There must be less I-type instructions
- (C) Shift amounts would change to 0-63
- (D) I-type instructions could have 2 more immediate bits

| 3 <u>1</u> | 12 | 4 | 3 | ∄ | <u>7</u> o |
|------------|-----------|-----|-------|----------|------------|
| | imm[13:0] | rs1 | func3 | rd | opcode |

- Stored-Program Concept
- R-Format
- I-Format
- Administrivia
- S-Format
- SB-Format
- U-Format
- UJ-Format

Administrivia

- Guerrilla Session today! 4-6PM, Cory 540AB
- HW1 Due Thursday (6/28)
- Project Due on Friday (6/29)
 - Submission Policy:
 - Testing framework has been released
 - You can do it!! :D
- HW2 Due next Friday (7/06)
- Review Session this Saturday (6/30), 2-4PM
- Guerilla Session part 2, this Sunday (7/01)
 2-4PM, Cory 540AB
 - This will also be helpful for the midterm! (That's why we moved it up)

- Stored-Program Concept
- R-Format
- I-Format
- Administrivia
- S-Format
- SB-Format
- U-Format
- UJ-Format

Load Instructions are also I-Type

imm[11:0] rs1 func3 rd opcode

offset[11:0] base width dst LOAD

- The 12-bit signed immediate is added to the base address in register rs1 to form the memory address
 - This is very similar to the add-immediate operation but used to create address, not to create final result
- Value loaded from memory is stored in rd

I-Format Load Example

• lw x14, 8(x2)

| 3 | 1 | | | | 0 |
|---|--------------|-------|-------|-------|---------|
| | imm[11:0] | rs1 | func3 | rd | opcode |
| | | | | | |
| | offset[11:0] | base | width | dst | LOAD |
| | | | | | |
| | 00000001000 | 00010 | 010 | 01111 | 0000011 |
| | imm=+8 | rs1=2 | LW | rd=14 | LOAD |

All RV32 Load Instructions

| rs1 | 000 | rd | 0000011 | LB |
|-----|-------------------|-------------------------------|----------------------------------|--|
| rs1 | 001 | rd | 0000011 | LH |
| rs1 | 010 | rd | 0000011 | LW |
| rs1 | 100 | rd | 0000011 | LBU |
| rs1 | 101 | rd | 0000011 | LHU |
| | rs1 rs1 rs1 | rs1 001 rs1 010 rs1 100 | rs1 001 rd rs1 010 rd rs1 100 rd | rs1 001 rd 0000011 rs1 010 rd 0000011 rs1 100 rd 0000011 |


funct3 field encodes size and signedness of load data

- LBU is "load unsigned byte"
- LH is "load halfword", which loads 16 bits (2 bytes) and sign-extends to fill destination 32-bit register
- LHU is "load unsigned halfword", which zero-extends 16 bits to fill destination 32-bit register
- There is no LWU in RV32, because there is no sign/zero extension needed when copying 32 bits from a memory location into a 32-bit register

- Stored-Program Concept
- R-Format
- I-Format
- Administrivia
- S-Format
- SB-Format
- U-Format
- UJ-Format

S-Format Used for Stores

- Store needs to read two registers, rs1 for base memory address, and rs2 for data to be stored, as well as need immediate offset!
- Can't have both rs2 and immediate in same place as other instructions!
- Note: stores don't write a value to the register file, no rd!
- RISC-V design decision is **move low 5 bits of immediate** to where $\bf rd$ field was in other instructions keep rs1/rs2 fields in same place
- register names more critical than immediate bits in hardware design



S-Format Example

sw x14, 8(x2)31 imm[11:5] opcode rs1 func3 imm[4:0] rs2 0000000 00010 01000 0100011 off[11:5] off[4:0] SW STORE rs2=14 rs1=20000000 01000 combined 12-bit offset = 8

All RV32 Store Instructions

| imm[11:5] | rs2 | rs1 | 000 | imm[4:0] | 0100011 | SB |
|-----------|-----|-----|-----|----------|---------|----|
| imm[11:5] | rs2 | rs1 | 001 | imm[4:0] | 0100011 | SH |
| imm[11:5] | rs2 | rs1 | 010 | imm[4:0] | 0100011 | SW |

34

- Stored-Program Concept
- R-Format
- I-Format
- Administrivia
- S-Format
- SB-Format
- U-Format
- UJ-Format

Branching Instructions

- beq, bne, bge, blt
 - Need to specify an address to go to
 - Also take two registers to compare
 - Doesn't write into a register (similar to stores)
- How to encode label, i.e., where to branch to?

Branching Instruction Usage

- Branches typically used for loops (if-else, while, for)
 - Loops are generally small (< 50 instructions)
- Recall: Instructions stored in a localized area of memory (Code/Text)
 - Largest branch distance limited by size of code
 - Address of current instruction stored in the program counter (PC)

PC-Relative Addressing

- PC-Relative Addressing: Use the immediate field as a two's complement offset to PC
 - Branches generally change the PC by a small amount
 - Can specify ± 2¹¹ addresses from the PC

 Why not use byte address offset from PC as the immediate?

Branching Reach

- Recall: RISCV uses 32-bit addresses, and memory is byte-addressed
- Instructions are "word-aligned": Address is always a multiple of 4 (in bytes)
- PC ALWAYS points to an instruction
 - PC is typed as a pointer to a word
 - can do C-like pointer arithmetic
- Let immediate specify #words instead of #bytes
 - Instead of specifying $\pm 2^{11}$ bytes from the PC, we will now specify $\pm 2^{11}$ words = $\pm 2^{13}$ byte addresses around PC

Branch Calculation

If we don't take the branch:

```
PC = PC+4 = next instruction
```

If we do take the branch:

```
PC = PC + (immediate*4)
```

Observations:


 immediate is number of instructions to move (remember, specifies words) either forward (+) or backwards (-)

RISC-V Feature, n×16-bit instructions

- Extensions to RISC-V base ISA support 16-bit compressed instructions and also variable-length instructions that are multiples of 16-bits in length
- 16-bit = half-word
- To enable this, RISC-V scales the branch offset to be half-words even when there are no 16-bit instructions
- Reduces branch reach by half and means that ½ of possible targets will be errors on RISC-V processors that only support 32-bit instructions (as used in this class)
- RISC-V conditional branches can only reach $\pm 2^{10} \times 32$ -bit instructions either side of PC

RISC-V B-Format for Branches

- B-format is mostly same as S-Format, with two register sources (rs1/rs2) and a 12-bit immediate
- But now immediate represents values -2¹² to +2¹²-2 in 2-byte increments
- The 12 immediate bits encode even 13-bit signed byte offsets (lowest bit of offset is always zero, so no need to store it)



Branch Example (1/2)

RISCV Code:

```
Loop: beq x19,x10,End add x18,x18,x10 addi x19,x19,-1 j Loop
End: <target instr>
```

Start counting from instruction AFTER the branch


- Branch offset = 4×32-bit instructions = 16 bytes
- (Branch with offset of 0, branches to itself)

Branch Example (1/2)


```
• RISCV Code:

Loop: beq x19,x10,End
add x18,x18,x10
addi x19,x19,-1
j Loop
End: <target instr>

Start counting from instruction AFTER the branch
```



Branch Example (1/2)



RISC-V Immediate Encoding

Why is it so confusing?!?!

Upper bits sign-extended from inst[31] always

| | Instruction Encodings, inst[31:0] | | | | | | | | | | | | |
|----------|-----------------------------------|------------|----------|----------------------|-------------------------|------------|----------------------------------|-----------|-----------------|--|--|--|--|
| 31 | 30 25 | 24 21 | 0.00400 | 0000 | [BOADN - 81 - 17] (SOLD | 11 8 | 7 | 6 0 | 3 | | | | |
| f | unct7 | rs2 | | rs1 | funct3 | ro | i | opcode | R-type | | | | |
| | • [1 | 1 0] | | 1 | C 40 | | 1 | 1 | 1 . | | | | |
| | imm[1] | 1:0] | | rs1 | funct3 | ro | 1 | opcode | I-type | | | | |
| im | m[11:5] | rs2 | | rs1 | funct3 | imm | [4:0] | opcode |] S-type | | | | |
| [imm[12] | imm[10:5] | rs2 | | rs1 | funct3 | imm[4:1] | imm[11] | opcode | B-type | | | | |
| | | <u>32-</u> | bit imme | ediates _l | produced, ii | mm[31:0] | | | | | | | |
| 31 | 30 | 20 19 | 12 | 11 | 10 5 | 4 | 1 0 | | | | | | |
| | — i | nst[31] — | | | inst[30:25] | inst[24:2] | $1] \mid \operatorname{inst}[2]$ | 0] I-imm | nediate | | | | |
| | | | | | | | | | | | | | |
| | — i | nst[31] — | | | inst[30:25] | inst[11:8 | $\sin t [7]$ | S-imn | nediate | | | | |
| | — inst[3 | B1] — | | inst[7] | nst[30:25] | inst[11:8 | 8] 0 | B-imr | mediate | | | | |
| | | | | | Only bit 7 | of instruc | tion chan | nges role | in _s | | | | |

immediate between S and B

All RISC-V Branch Instructions

| imm[12 10:5] | rs2 | rs1 | 000 | imm[4:1 11] | 1100011 |
|--------------|-----|-----|-----|-------------|---------|
| imm[12 10:5] | rs2 | rs1 | 001 | imm[4:1 11] | 1100011 |
| imm[12 10:5] | rs2 | rs1 | 100 | imm[4:1 11] | 1100011 |
| imm[12 10:5] | rs2 | rs1 | 101 | imm[4:1 11] | 1100011 |
| imm[12 10:5] | rs2 | rs1 | 110 | imm[4:1 11] | 1100011 |
| imm[12 10:5] | rs2 | rs1 | 111 | imm[4:1 11] | 1100011 |

BEQ BNE BLT BGE BLTU BGEU

Questions on PC-addressing

- Does the value in branch immediate field change if we move the code?
 - If moving individual lines of code, then yes
 - If moving all of code, then no (why?)
- What do we do if destination is $> 2^{10}$ instructions away from branch?
 - Other instructions save us:

```
beq x10,x0,far bne x10,x0,next \rightarrow j far next: # next instr
```

Meet the \$taff

| | Sukrit | Suvansh |
|---------------------------|--------------------------------|------------------------------------|
| Roadside Sign | "Help, can't find my roadsign" | "Do not sushi enter" (put picture) |
| Greatest Weakness | Committing to too many things | Binging TV |
| Favorite artist | Kanye West | Joshua Radin |
| Favorite meme of all time | All Spongebob memes | Avocado kid |


Agenda

- Stored-Program Concept
- R-Format
- I-Format
- Administrivia
- S-Format
- SB-Format
- U-Format
- UJ-Format

Dealing With Large Immediates

- How do we deal with 32-bit immediates?
 - Our I-type instructions only give us 12 bits
- Solution: Need a new instruction format for dealing with the rest of the 20 bits.
- This instruction should deal with:
 - a destination register to put the 20 bits into
 - the immediate of 20 bits
 - the instruction opcode

U-Format for "Upper Immediate" instructions



- Has 20-bit immediate in upper 20 bits of 32-bit instruction word
- One destination register, rd
- Used for two instructions
 - LUI Load Upper Immediate
 - AUIPC Add Upper Immediate to PC

LUI to create long immediates

- lui writes the upper 20 bits of the destination with the immediate value, and clears the lower 12 bits
- Together with an addi to set low 12 bits, can create any 32-bit value in a register using two instructions (lui/addi).

```
lui x10, 0x87654 # x10 = 0x87654000 addi x10, x10, 0x321 # x10 = 0x87654321
```

Corner Case

How to set 0xDEADBEEF?

```
lui x10, 0xDEADB \# x10 = 0xDEADB000
addi x10, x10,0xEEF \# x10 = 0xDEADAEEF
```

addi 12-bit immediate is always sign-extended!

- if top bit of the 12-bit immediate is a 1, it will subtract -1 from upper 20 bits

Solution

How to set 0xDEADBEEF?

```
lui x10, 0xDEADC \# x10 = 0xDEADC000
addi x10, x10,0xEEF \# x10 = 0xDEADBEEF
```

Pre-increment value placed in upper 20 bits, if sign bit will be set on immediate in lower 12 bits.

Assembler pseudo-op handles all of this:

li x10, 0xDEADBEEF # Creates two instructions

AUIPC

- Adds upper immediate value to PC and places result in destination register
- Used for PC-relative addressing

- Label: auipc x10, 0
 - Puts address of label into $\times 10$


Agenda

- Stored-Program Concept
- R-Format
- I-Format
- Administrivia
- S-Format
- SB-Format
- U-Format
- UJ-Format

UJ-Format Instructions (1/3)

- For branches, we assumed that we won't want to branch too far, so we can specify a change in the PC
- For general jumps (jal), we may jump to anywhere in code memory
 - Ideally, we would specify a 32-bit memory address to jump to
 - Unfortunately, we can't fit both a 7-bit opcode
 and a 32-bit address into a single 32-bit word
- Also, when linking we must write to an rd register

UJ-Format Instructions (2/3)



- jal saves PC+4 in register rd (the return address)
- Set PC = PC + offset (PC-relative jump)
- Target somewhere within ±2¹⁹ locations, 2 bytes apart
- ±2¹⁸ 32-bit instructions
- Reminder: "j" jump is a pseudo-instruction—the assembler will instead use jal but sets rd=x0 to discard return address
- Immediate encoding optimized similarly to branch instruction to reduce hardware cost


UJ-Format Instructions (2/3)

```
31 imm[20|10:1|11|19:12] rd opcode

20 5 7
offset[31:12] dest JAL
```

- # j pseudo-instruction
- j Label = jal x0, Label # Discard return address
- # Call function within 2 instructions of PC
- jal ra, FuncName
- Why is the immediate so funky?
 - Similar reasoning as for branch immediates

jalr Instruction (I-Format)



- jalr rd, rs1, offset
- Writes PC+4 to rd (return address)
- Sets PC = rs1 + offset
- Uses same immediates as arithmetic & loads
 - no multiplication by 2 bytes

Uses of jalr

```
imm[11:0] rs1 func3 rd opcode
offset base 0 dest JALR
```


```
# ret and jr psuedo-instructions
ret = jr ra = jalr x0, ra, 0
# Call function at any 32-bit absolute address
lui x1, <hi 20 bits>
jalr ra, x1, <lo 12 bits>
# Jump PC-relative with 32-bit offset
auipc x1, <hi 20 bits>
jalr x0, x1, <lo 12 bits>
```



Question: When combining two C files into one executable, we can compile them independently and then merge them together.

When merging two or more binaries:

- 1) Jump instructions don't require any changes
- 2) Branch instructions don't require any changes



Summary of RISC-V Instruction Formats

| 31 | 30 | 25 | 24 | 21 | 20 | 19 | 1 | 5 1 | 4 | 12 | 11 | 8 | 7 | 7 | 6 | 0 | |
|-------|--------------------------|-------|-------------|--------|-------|----|------|-----|--------|----|-----|-----------------------|------|-------|-----|-----|--------|
| | funct7 | | | rs2 | | 1 | rs1 | | funct3 | 3 | | rd | l | | opc | ode | R-type |
| | | | | | | | | 722 | | | | | | | 500 | | |
| | im | m[11 | :0] | | |] | rs1 | | funct3 | 3 | | rd | L | | opc | ode | I-type |
| | | | | | | | | | | | | | | | | | |
| i | mm[11:5] | | | rs2 | | 1 | rs1 | | funct3 | 3 | | $\operatorname{imm}[$ | 4:0] | | opc | ode | S-type |
| 1020 | | | | | | | | | | | | | | | 10 | | |
| imm[1 | $2] \mid \text{imm}[10]$ |):5] | | rs2 | |] | rs1 | | funct3 | 3 | imn | n[4:1] | imm | 1[11] | opc | ode | B-type |
| | | | | | | | | | | | | | | | | | |
| | | | $_{ m imm}$ | [31:1: | 2] | | | | | | | rd | L | | opc | ode | U-type |
| | | | | | | | | | | | | | | | | | |
| imm[2 | 0] im | m[10] |):1] | im | m[11] | | imm[| 19 | 12] | | | rd | L | | opc | ode | J-type |

Summary

- The Stored Program concept is very powerful
 - Instructions can be treated and manipulated the same way as data in both hardware and software
- RISCV Machine Language Instructions:

| | imm[31:12] | rd | 0110111 | LUI | | |
|--------------|-----------------|-----|---------|-------------|---------|-------|
| , | imm[31:12] | rd | 0010111 | AUIPC | | |
| i | mm[20 10:1 11 1 | rd | 1101111 | JAL | | |
| imm[| 11:0] | rs1 | 000 | rd | 1100111 | JALR |
| imm[12 10:5] | rs2 | rs1 | 000 | imm[4:1 11] | 1100011 | BEQ |
| imm[12 10:5] | rs2 | rs1 | 001 | imm[4:1 11] | 1100011 | BNE |
| imm[12 10:5] | rs2 | rs1 | 100 | imm[4:1 11] | 1100011 | BLT |
| imm[12 10:5] | rs2 | rs1 | 101 | imm[4:1 11] | 1100011 | BGE |
| imm[12 10:5] | rs2 | rs1 | 110 | imm[4:1 11] | 1100011 | BLTU |
| imm[12 10:5] | rs2 | rs1 | 111 | imm[4:1 11] | 1100011 | BGEU |
| imm[| 11:0] | rs1 | 000 | rd | 0000011 | LB |
| imm[| 11:0] | rs1 | 001 | rd | 0000011 | LH |
| imm[| | rs1 | 010 | rd | 0000011 | LW |
| imm[| 11:0] | rs1 | 100 | rd | 0000011 | LBU |
| imm[| 11:0] | rs1 | 101 | rd | 0000011 | LHU |
| imm[11:5] | rs2 | rs1 | 000 | imm[4:0] | 0100011 | SB |
| imm[11:5] | rs2 | rs1 | 001 | imm[4:0] | 0100011 | SH |
| imm[11:5] | rs2 | rs1 | 010 | imm[4:0] | 0100011 | SW |
| imm[| 11:0] | rs1 | 000 | rd | 0010011 | ADDI |
| imm[| 11:0] | rs1 | 010 | rd | 0010011 | SLTI |
| imm[| 11:0] | rs1 | 011 | rd | 0010011 | SLTIU |
| imm[| 11:0] | rs1 | 100 | rd | 0010011 | XORI |
| imm[| 11:0] | rs1 | 110 | rd | 0010011 | ORI |
| imm[| 11:0] | rs1 | 111 | rd | 0010011 | ANDI |
| 0000000 | 1 1 | | 001 | , | 0010011 | OTTT |

| 000000 | 0 | shamt | | rs1 | 001 | rd | 0010011 | SLLI | |
|----------------|---|--|---|--|--|--|---|---|--|
| 000000 | 0 | shamt | | rs1 | 101 | rd | 0010011 | SRLI | |
| 010000 | 0 | shamt | | rs1 | 101 | rd | 0010011 | SRAI | |
| 000000 | 0 | rs | 2 | rs1 | 000 | rd | 0110011 | ADD | |
| 010000 | 0 | rs | 2 | rs1 | 000 | $^{\mathrm{rd}}$ | 0110011 | SUB | |
| 000000 | 0 | rs | 2 | rs1 | 001 | rd | 0110011 | SLL | |
| 0000000 rs2 | | rs1 | 010 | rd | 0110011 | SLT | | | |
| 000000 | 0000000 rs2 | | rs1 | 011 | rd | 0110011 | SLTU | | |
| 000000 | 0000000 rs2 | | rs1 | 100 | rd | 0110011 | XOR | | |
| 000000 | 0000000 rs2 | | 2 | rs1 | 101 | rd | 0110011 | SRL | |
| 0100000 | | rs2 | | rs1 | 101 | rd | 0110011 | SRA | |
| 0000000 | | rs2 | | rs1 | 110 | rd | 0110011 | OR | |
| 000000 | 0 | rs2 | | rs1 | 111 | rd | 0110011 | AND | |
| 0000 | pred | d | succ | 00000 | 000 | 00000 | 0001111 | FENCE | |
| 0000 | 000 | 0 | 0000 | 00000 | 001 | 00000 | 0001111 | FENCE | |
| 000 | 0000000 | 000 | | 00000 | 000 | 00000 | 1110011 | ECALL | |
| 000 | 000000 | 001 | | 00000 | 000 | 00000 | 1110011 | EBREA | |
| | csr | | | rs1 | 001 | rd | 1110011 | CSRRW | |
| csr Vot | | | ns1 | 010 | rd | 1110011 | CSRRS | | |
| csr | | | rs1 | 011 | rd | 1110011 | CSRRC | | |
| csr | | | zimm | 101 | rd | 1110011 | CSRRW | | |
| | csr | | | zimm | 110 | rd | 1110011 | CSRRSI | |
| | csr | | | zimm | 111 | rd | 1110011 | CSRRC | |
| | 0000000 0100000 0100000 0000000 0000000 000000 | 0000000 0000000 0000000 0100000 0000000 000000 | 0000000 sha 0100000 sha 0000000 rs 0100000 rs 0000000 rs 0000 pred 0000 0000 000000000000 csr csr csr csr csr csr csr | 0000000 shamt 0100000 shamt 0000000 rs2 0100000 rs2 0000000 rs2 0000 rs2 <td< td=""><td>0000000 shamt rs1 0100000 shamt rs1 0000000 rs2 rs1 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 rs1 rs1 csr csr zimm csr zimm</td><td>0000000 shamt rs1 101 0100000 shamt rs1 101 0000000 rs2 rs1 000 0100000 rs2 rs1 001 0000000 rs2 rs1 010 0000000 rs2 rs1 011 0000000 rs2 rs1 100 0000000 rs2 rs1 101 0100000 rs2 rs1 101 0000000 rs2 rs1 110 0000000 rs2 rs1 110 0000000 rs2 rs1 111 0000 pred succ 00000 000 0000 0000 0000 0000 000 00000000000000 0000 0000 000 000 0000 rs1 rs1 001 001 csr csr zimm 101 csr zimm 101</td><td>0000000 shamt rs1 101 rd 0100000 shamt rs1 101 rd 0000000 rs2 rs1 000 rd 0100000 rs2 rs1 000 rd 0000000 rs2 rs1 001 rd 0000000 rs2 rs1 010 rd 0000000 rs2 rs1 101 rd 0000000 rs2 rs1 101 rd 0100000 rs2 rs1 101 rd 0000000 rs2 rs1 110 rd 0000000 rs2 rs1 110 rd 0000000 rs2 rs1 111 rd 0000 pred succ 00000 000 0000 0000 pred succ 00000 000 0000 0000 pred succ 00000 000 00000 00000 pred</td><td>$\begin{array}{c ccccccccccccccccccccccccccccccccccc$</td></td<> | 0000000 shamt rs1 0100000 shamt rs1 0000000 rs2 rs1 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 rs1 rs1 csr csr zimm csr zimm | 0000000 shamt rs1 101 0100000 shamt rs1 101 0000000 rs2 rs1 000 0100000 rs2 rs1 001 0000000 rs2 rs1 010 0000000 rs2 rs1 011 0000000 rs2 rs1 100 0000000 rs2 rs1 101 0100000 rs2 rs1 101 0000000 rs2 rs1 110 0000000 rs2 rs1 110 0000000 rs2 rs1 111 0000 pred succ 00000 000 0000 0000 0000 0000 000 00000000000000 0000 0000 000 000 0000 rs1 rs1 001 001 csr csr zimm 101 csr zimm 101 | 0000000 shamt rs1 101 rd 0100000 shamt rs1 101 rd 0000000 rs2 rs1 000 rd 0100000 rs2 rs1 000 rd 0000000 rs2 rs1 001 rd 0000000 rs2 rs1 010 rd 0000000 rs2 rs1 101 rd 0000000 rs2 rs1 101 rd 0100000 rs2 rs1 101 rd 0000000 rs2 rs1 110 rd 0000000 rs2 rs1 110 rd 0000000 rs2 rs1 111 rd 0000 pred succ 00000 000 0000 0000 pred succ 00000 000 0000 0000 pred succ 00000 000 00000 00000 pred | $\begin{array}{c ccccccccccccccccccccccccccccccccccc$ | |