


Task 2 & 3: Waveguide Mode simulations (Lumerical FDTD)

2.1. Checklist


- Lumerical 2024 R2.3 is installed and activated on your PC (if not, please follow the instructions below).

2.2. Lumerical Installation

- Visit the Lumerical Download Center:
<https://www.lumerical.com/downloads/>.



- Click on "**Customer Downloads**", follow the instructions to create an Ansys account, and use it to log in.




- Once logged in, you will see a list of available Lumerical software releases. Select the latest version (**Lumerical 2024 R2.3**) and click the **Download** button.

The screenshot shows the Ansys Customer Downloads page. At the top, there's a yellow banner with the text "Important Note for Future Releases" and "We're Moving!". Below this, there's a table titled "Lumerical 2024 R2.3" with columns for Description, Date, Download, and More. Two files are listed: "Lumerical 2024 R2.3 Win64" and "Lumerical 2024 R2.3 Mac". Further down, there's another table titled "Ansys License Manager" with two entries: "Ansly License Manager 2024 R2.3 Win64" and "Ansly License Manager 2024 R2.3 Mac".


- Unzip the downloaded file and run **Lumerical_Installer.exe** inside the extracted folder.




Name	Date modified	Type	Size
Ansys_Optics_Launcher	16/10/2024 07:33	File folder	
intel_mpi_runtime	16/10/2024 07:33	File folder	
MS-MPI	16/10/2024 07:33	File folder	
vcredist_x64	16/10/2024 07:33	File folder	
custom_install_utility.bat	16/10/2024 05:37	Windows Batch File	6 KB
Lumerical_data.msi	16/10/2024 07:39	Windows Installer	1,200,300 ...
Lumerical_Installer.exe	16/10/2024 07:33	Application	541 KB

- Proceed to install all the required components.




- Follow the step-by-step installation process.







- After the installation is complete, open the **Ansys Optics Launcher** from the Start menu.




- Select "**I have a license from Ansys already.**"




- Choose "**I want to configure my license only for Lumerical products.**"




- Click on "Go to the Licensing Setup."



- In the license configuration window, set the **License Manager server address** to lum-teach-lmserv.eng.cam.ac.uk, then click **Apply**.



- Restart the program. Lumerical is now ready to use!



2.3. Coupling Analysis using Lumerical FDTD

2.3.1 Analytical Solution of Coupled-Mode Equations

- Before using the simulation tool to model the coupling process, first mathematically solve the following set of coupled-mode equations [Include in your Report 2]:

$$\begin{cases} \frac{dA_0(z)}{dz} = -i\beta A_0(z) - i\kappa A_1(z) \\ \frac{dA_1(z)}{dz} = -i\beta A_1(z) - i\kappa A_0(z) \end{cases}$$

Assume that initially 70% of the optical power is within Waveguide 0 at the position $z = 0$ while the rest are in Waveguide 1, i.e., $A_0(0) = 0.837$ and $A_1(0) = 0.548$; and assume the values of β and κ to be $9.9892e + 06 \text{ m}^{-1}$ and 0.107, respectively. Please determine:


- The analytical expressions of the field amplitudes $A_0(0)$ and $A_1(0)$;
- The distances z at which the power is (i) equally distributed between the two waveguides, and (ii) fully transferred to Waveguide 1, respectively.

Hint: this is a second-order linear differential system. The solutions are expected to be sinusoidal.


2.3.2 Numerical Simulation Using Lumerical

- In Lumerical, create a pair of identical single-mode SOI waveguides placed side by side with a small gap, and run the simulation to observe the mode coupling phenomenon between them. Below are detailed steps:


- Launch Ansys Optics Launcher and open the FDTD solver.




- Add two **Rectangles** to represent waveguides.




- Rename them appropriately (e.g., wg_1, wg_2).




- Edit their **Geometry** so that each waveguide has dimensions of 500 nm (width) × 220 nm (thickness) × 10 μm (length), with a separation of 150 nm between them.





- Assign material: set to “Si (Silicon) – Palik”.







- Insert four S-bend **Waveguides** (use this guide: <https://optics.ansys.com/hc/en-us/articles/360034901673-Tips-for-creating-waveguide-bends-using-the-path-object>) and connect them to both ends of the two coupled waveguides. These fan-in/out S-bends bring the waveguides close together over the coupling region and separate them afterward, thereby controlling the coupling length. Rename these structures, edit their geometry, and assign appropriate materials. The exact shape of the S-bends has minimal impact on coupling but ensure that the bending radius and the separation between the fan-in/out waveguides are sufficiently large (>5 μm).







- Add another four **Rectangles** to extend the fan in/out waveguides. Make sure they are long enough (10 μm in the example).






- Specify the FDTD simulation region.







Ensure that all structures are contained within the simulation region with sufficient margin, and that the input/output waveguides extend through the region boundaries.





- Set the background material to “SiO₂ (Glass) – Palik”.




- Place a **ModeSource** at one input waveguide. Adjust its injection axis, mode, geometry, and wavelength.









Verify the mode source covers the entire optical power distribution. This can be checked through visualizing the input mode profile.




- Add two **DFTMonitors** at both output waveguides to measure transmitted intensity. Position monitors normal to propagation direction and ensure their size fully captures the output mode.




- Insert an additional **DFTMonitor** in the XY-plane to visualize electric field coupling clearly.





○ Define the simulation bandwidth.






- Run the simulation.



- Once finished, visualize the results.



Find the coupling length when approximately half/full optical power is transferred from one waveguide to the other. [Include in your Report 3]

Further explorations:

- Vary the waveguide width and the separation between them to study how these parameters affect the coupling strength. For example, at a fixed coupling length, stronger coupling will result in more optical power being

transferred from one waveguide to the other. After modifying these parameters, make sure to update the geometry of the fan-in/out waveguides accordingly, and adjust the positions of the mode source and monitors as needed. For convenience, you can use Lumerical's scripting language (<https://optics.ansys.com/hc/en-us/categories/360001998954-Scripting-Language>) to define and modify objects such as Rectangles, Waveguides, FDTD regions, ModeSources, and DFTMonitors. **[Include in your Report 3]**

- Based on your findings, design and optimize two directional couplers that achieve complete power transfer (>99%) from one waveguide to the other, operating at 1310 nm and 1550 nm, respectively. Start by selecting suitable waveguide widths and separations, then sweep the coupling length to maximize the transferred power. Note that, in practice, the minimum allowable gap between waveguides is typically 150 nm due to fabrication constraints. **[Include in your Report 3]**
- Try designing an asymmetric directional coupler, where the two coupled waveguides have different widths. In this case, is it still possible to achieve 100% power transfer between the waveguides? Comment on your observations. **[Include in your Report 3]**

(Hint, different waveguide widths lead to different propagation constants for the same mode, but what if different mode orders are involved...).