

Cleaning Procedures for Laboratory Material used in Lead Isotope Analysis

Cleaning Procedures for Laboratory Material used for Chemical Preparation/Column Separation in Lead Isotope Analysis

Λh	hra	110	tic	nc
\rightarrow	brev	///		1115

MQ water: Ultrapure water ("Milli-Q" water)

	•	*** = triple-distilled
1.	Cle	eaning reagent vessels/vials Rinse three times with MQ water Fill with 6% HNO ₃ , make sure that no air is trapped in beakers/vials, let it sit for at least 1 night Empty HNO ₃ , fill with MQ water, let it sit for at least 1 night Store until needed
2.	Cle	eaning Teflon ("Savillex") beakers
2.1	Pre	e-cleaning
		Place beakers in large beaker and fill it with a mixture of lab detergent (e.g., DECONEX) and deinoised water, let it sit for at least 1 night Rinse three times with deionised water Fill the large beaker with Aqua Regia (4/8 deionised water, 3/8 HCl p.a., 1/8 HNO ₃ p.a.), let it sit for at least 24 h on a hot plate at approx. 70–80 °C
		Rinse three times with deionised water Rinse once with MQ water Fill the large beaker with 6N HCl, let it sit for at least 24 h on a hot plate at approx. 70–80 °C Rinse three times with MQ water Take beakers out of large beaker and let them dry
2.2	Ble	eaching
		Fill 1 ml 6M HNO ₃ *** into the individual beakers, screw tightly, leave for at least one week on a hot plate Rinse three times with MQ water Fill with MQ water and add a few drops of HBr (to bind the lead), leave it for at least one night or until needed
		Dry beakers at least one day before needed (they should be cooled down to room temperature for weighing) Store until needed
3.	Cle	eaning columns
		Allow columns filled with old resin to dry Empty used resin (tap or rinse with water using a pipette repeatedly) Rinse with MQ water Place in sealable plastic container with a mixture of lab detergent (e.g., DECONEX) and deinoised water (make sure no air is trapped in the columns) and shake closed container
		Rinse three times with MQ water Put columns in large beaker filled with Aqua Regia (4/8 deionised water, 3/8 HCl p.a., 1/8 $\rm HNO_3$ p.a.), let it sit for at least 24 h on a hot plate at approx. 70–80 °C Rinse three times with MQ water
		Fill the large beaker with 6N HCl, let it sit for at least 24 h on a hot plate at approx. 70–80 °C Rinse three times with MQ water Take columns out of beaker and store them 5% HCl*** for at least 1 week or until needed



Rinse with MQ water before use



Cleaning Procedures for Laboratory Material used in Lead Isotope Analysis

4. Cleaning new resin (dry product)

Pour some spoons of resin (e.g., DOWEX AG1x8 or other in use) into a 1 L bottle
Fill up to approx. 500 ml with MQ water and 10 ml 6M HCl***
Shake several times
Decant
Repeat multiple times
Fill up again with approx. 500 ml of MQ water and 10 ml 6M HCl***
Store like this until needed

These procedures were adopted from the former isotope laboratory of Friedrich Begemann, Max-Planck-Institut für Chemie, Dept. Isotopenkosmologie, Mainz, Germany.

