Controller Synthesis

DESKTOP-H800RKQ

November 23, 2024

Contents

1	Loop Shaping	1
2	Integral Control	3
3	Lead-Lag Compensators	3
	3.1 Lead Controller	3
	3.2 Lag Controller	4
4	PID Controller	4
5	Root Locus	5
6	Pole Placement	6
7	State Feedback Control	7

1 Loop Shaping

Translating control specifications of the closed loop system into constraints of the Bode plots of the open loop system is loop shaping.

The steps involved in loop shaping are:

- 1. turn specifications from the time domain behaviour of F(s) to the frequency domain behaviour of L(s)
- 2. design the transfer function of the controller C(s) so that L(s) = C(s)G(s) has the desired frequency domain behaviour

For robust stability, a high K_m and high ϕ_m are desirable.

Delay is negative phase shift, which can decrease the phase margin and so $\phi_m > 0$ may no longer hold.

Integral action in a controller, that is some L(s) where

$$L(s) = \frac{\mu}{s^{\rho}}$$

gives a steady state gain of 1 in the closed-loop system.

Low bandwidth gives a slow response, high bandwidth gives a fast response.

The crossover frequency ω_c helps find which frequencies pass through and which get attenuated. Frequencies within the crossover frequency are within the bandwidth and frequencies above the crossover frequency are not within the bandwidth. This is because the bandwidth of F(s) (the closed-loop transfer function) is approximated by the crossover frequency of L(s) (the open-loop transfer function).

The closed-loop transfer function F(s) is approximated by 1 for $\omega \ll \omega_c$ of L(s) and L(s) for $\omega \gg \omega_c$ of L(s).

The **lower bound** on ω_c of L(s) is used to filter out noise, not the reference. The disturbance signals contain low frequencies and noise signals contain high frequencies.

Consider a system with open-loop transfer function L(s) = C(s)G(s) and corresponding closed loop transfer function F(s). To reject disturbance:

$$\left| \frac{G(j\omega)}{1 + C(j\omega)G(j\omega)} \right|$$

which is the lower bound on ω_c for L(s), should be kept low for ω contained in D, specifically low frequencies.

To attenuate noise:

$$\left| \frac{C(j\omega)G(j\omega)}{1 + C(j\omega)G(j\omega)} \right|$$

which is the upper bound on ω_c for L(s), should be kept low for ω contained in N, specifically high frequencies.

For L(s) = C(s)G(s), where C(s) is proper (in order to be realizable in state-space form), the slope of $|L(j\omega)|$ should be at most the slope of $|G(j\omega)|$ as $\omega \to \infty$

2 Integral Control

For a closed-loop system with open loop transfer function $L(s) = \overline{C(s)G(s)}$, for $C(s) = \frac{\mu}{s^{\rho}}$:

- if $\rho > 0$, there is an integrator in the loop, so the closed-loop transfer function F(s) has F(0) = 1
- if $\rho = 0$, there is no integrator in the loop, so μ must be high for F(0) to approach 1

3 Lead-Lag Compensators

3.1 Lead Controller

Consider a controller with transfer function

$$C(s) = \mu \frac{1 + Ts}{1 + \alpha Ts}$$

for $\mu > 0, T > 0, 0 < \alpha < 1$. This controller has a zero at $-\frac{1}{T}$ and a pole at $-\frac{1}{\alpha T}$, which adds a phase lead between the zero and the pole, which is an increase in the phase margin.

This controller has high frequency gain $\frac{\mu}{\alpha}$. A good value of α is 0.1, since this gives a 55° phase lead.

As $\alpha \to 0$, C(s) becomes $\mu(1+Ts)$. When $C(s) = \frac{E(s)}{U(s)}$, then this gives that the control action u(t) is made of 2 terms:

$$u(t) = \mu e(t) + \mu T \frac{de}{dt}(t)$$

where one term is proportional to the error and the other is proportional to the time derivative of the error, so this is a PD controller. For a noncontinuous space, the control action can be written as

$$u(t_k) = \mu e(t_k) + \mu T \frac{e(t_k) - e(t_{k-1})}{t_k - t_{k-1}}$$

Adding poles/zeros makes the controller realizable to get this approximation of the derivative until the frequency of the pole of error.

3.2 Lag Controller

Consider a controller with transfer function

$$C(s) = \mu \frac{1 + Ts}{1 + \alpha Ts}$$

for $\mu > 0, T > 0, \alpha > 1$. This controller has a zero at $-\frac{1}{T}$ and a pole at $-\frac{1}{\alpha T}$, which adds a phase lag between the zero and the pole, which is an decrease in the phase margin. The lag controller helps to improve static performance without losing stability.

A good value of α is 10. For $\frac{10}{T} < \omega_c$, this gives -6° at ω_c . At $\mu = \alpha$, the high frequency behaviour is unchanged. For $\mu = 1$, there is a lower ω_c and which increases ϕ_m . As $\alpha \to \infty$, the corresponding increase of the steady-state gain μ such that $\frac{\mu}{\alpha} = c$ is constant, gives the lag controller

$$C(s) = c + \frac{c}{Ts}$$

which is a PI controller.

4 PID Controller

Placing the zero and pole of a lead controller $1/\alpha$ decade away from ω_c requires

$$\omega_c = \frac{1}{\sqrt{\alpha}T}$$

$$\zeta \approx \frac{\phi_m}{100}$$

so if ϕ_m increases, there are less oscillations and less overshoot for the closed loop system.

For a lag controller, as $\alpha \to \infty$, the pole $-\frac{1}{\alpha T} \to 0$.

A Proportional-Integral-Derivative (PID) controller produces a control action u(t) proportional to the error e(t), as well as to its integral and derivative:

$$u(t) = K_P e(t) + K_I \int_0^t e(\tau) d\tau + K_D \frac{de}{dt}$$

where $K_P, K_I, K_D > 0$.

This has transfer function

$$C_{PID}(s) = K_P + \frac{K_I}{s} + K_D s = K_P \left(1 + \frac{1}{T_I s} + T_D s \right)$$

where $T_I = \frac{K_P}{K_I}$ is the **integration time** and $T_D = \frac{K_D}{K_P}$ is the **derivative** time.

The integral action gives 0 steady-state error and perfect disturbance rejection since infinite gain for $\omega \to 0$. The derivative action gives faster response due to phase lead, since infinite gain for $\omega \to \infty$.

With derivative action, $C_{PID}(s)$ is not realizable since it is improper. To make this realizable, add a pole at high frequency:

$$C_{PID}(s) = K_P \left(1 + \frac{1}{T_I s} + \frac{T_D s}{1 + \frac{T_D}{N} s} \right)$$

where N is chosen so that high-frequency pole at $-N/T_D$ is beyond the bandwidth of the control task.

Practical considerations of PID controllers include:

- limitation of derivative action (avoid spiking response to step reference)
- anti-windup of integral action for input saturation

A realizable controller is one that has a state-space representation.

A lead controller is a realizable PD and a lag controller is a realizable PI, which makes a lead-lag controller a realizable PID (pole at high frequency on lag).

5 Root Locus

Root refers to the roots of the denominator of the closed loop F(s) and the locus is of the geometric roots.

The goal is to find the poles of F(s) as a function of $K_P \in (0, \infty)$, which gives the root locus for positive controller gain.

Consider the open loop transfer function

$$L(s) = \mu \frac{N_0(s)}{D(s)}$$

The **root locus** for loop gain is the set of all points of the complex plane which are roots of 1 + L(s) for some $\mu \in (-\infty, 0) \cup (0, \infty)$.

Using a proportionally controlled simple system, it can be found that using the phase

$$\sum_{i=1}^{m} \angle(s-z_i) - \sum_{i=1}^{n} \angle(s-p_i) = (2k+1)\pi$$

where there are m open loop zeros and n open loop poles.

The rules to plot a root locus for $\mu > 0$ are:

- 1. the locus has n branches, one per pole
- 2. the locus is symmetric with respect to the real axis
- 3. the branches of the locus start at the poles of L(s)
- 4. for $\mu \to \infty$

$$\begin{cases} m \text{ branches} & \to \text{ zeros of } L(s) \\ n - m \text{ branches} & \to \infty \end{cases}$$

5. the asymptotes of the root locus meet on the real axis at

$$x_a = \frac{1}{n-m} \left(\sum_{i=1}^n p_i - \sum_{i=1}^m z_i \right)$$

and have slope

$$\psi_a = \frac{2k+1}{n-m}\pi, k = 0, \dots, n-m-1$$

6. the locus includes all points of the real axis on the left of an odd number of poles/zeros

6 Pole Placement

The root locus for loop gain shows how the poles of the closed-loop system move on the complex plane as a function of the gain of the open-loop transfer function. The position of the dominant poles determine performance:

• OS\% =
$$100e^{-\xi\pi/\sqrt{1-\xi^2}}$$

$$\bullet \ T_p = \frac{1}{\omega_n \sqrt{1-\xi^2}}$$

- Oscillation frequency = $\omega_n \sqrt{1-\xi^2}$
- Settling time = $\frac{\ln(0.01\varepsilon)}{\xi\omega_n} = \frac{\ln(0.01\varepsilon)}{\sigma}$
- Phase margin $\approx 100\xi$
- Crossover frequency $\approx \omega_n$

where $\xi, \omega_n, \sigma = -\xi \omega_n$ are the damping, natural frequency, and real part of the pair of complex conjugate poles.

The damping of dominant poles ξ controls the overshoot, peak time, frequency of oscillations, settling time, and phase margin. This creates a cone on the complex plane at the angle $\omega \cos(\bar{\xi})$ from the negative real axis.

The natural frequency of the dominant poles ω_n controls the peak time, frequency of oscillations, settling time, and crossover frequency. This occurs on the left side of the complex plane, with a hole going through $j\omega_n$, $-\omega_n$, and $-j\omega_n$.

The real part of the dominant poles σ controls the settling time. This occurs to the left of σ on the complex plane.

Using the root locus, try to keep the parameters in the regions specified by the preferred performance metrics.

7 State Feedback Control

Sometimes the static feedback of the output is not sufficient to stabilize a system. For such cases, static state feedback might be better to stabilize a system.

Consider a transfer function

$$G(s) = \frac{b_{n-1}s^{n-1} + \dots + b_1s + b_0}{s^n + a_{n-1}s^{n-1} + \dots + a_1s + a_0}$$

This has controllable canonical state space form

$$\dot{x} = \begin{bmatrix} 0 & 1 & 0 & \cdots & 0 \\ \vdots & 0 & 1 & & \vdots \\ \vdots & & \ddots & \ddots & 0 \\ 0 & \cdots & \cdots & 0 & 1 \\ -a_0 & -a_1 & -a_2 & \cdots & a_{n-1} \end{bmatrix} x + \begin{bmatrix} 0 \\ 0 \\ \vdots \\ 0 \\ 1 \end{bmatrix} u$$

$$y = \begin{bmatrix} b_0 & b_1 & \cdots & b_{n-1} \end{bmatrix} x$$

A static state feedback controller is

$$u = -Kx$$

for $K^T \in \mathbb{R}^n$. Controlling a system

$$\dot{x} = Ax + Bu$$

$$y = Cx$$

with the controller yields

$$\dot{x} = (A - BK)x$$
$$y = Cx$$

so the state-feedback controlled closed-loop system behaves according to the eigenvalues of the matrix A-BK.

Pole placement via state feedback: Given a system in controllable canonical form and n complex numbers $\lambda_1, \ldots, \lambda_n$ (either real or pairs of complex conjugate numbers), there exists $K^T \in \mathbb{R}^n$ such that the eigenvalues of A - BK are $\lambda_1, \ldots, \lambda_n$.

For some $\lambda_1, \ldots, \lambda_n$, the desired characteristic polynomial of A - BK is

$$P(\lambda) = \lambda^n + c_{n-1}\lambda^{n-1} + \dots + c_1\lambda + c_0$$

for some c_0, c_1, \dots, c_{n-1} .

K should be chosen so that $a_{i-1} + K_i = c_{i-1}$ for $i \in [1, n]$ to result in a closed-loop system with eigenvalues at $\lambda_1, \ldots, \lambda_n$.