

ABOUT DAVID LAWSON

# DSHOT in the Dark

Posted on 2017-12-04 by david

I was excited to start attempting to make the motor turn. It has proved to be more tricky than expected, however.

Everything I'd skim-read up until now had suggested that ESCs used Pulse Wave Modulation (PWM) for their input signals. This generally means creating an on-off signal at some frequency and varying the duty cycle (the amount of time an on-off signal is in the 'on' state) to communicate what percentage of power should be sent to the motor. I now understand that this was the case until fairly recently, but the ESCs I have bought use a digital protocol called DSHOT instead (it's in the product name, but I had no idea what it meant at the time). As far as I can tell this protocol was conceived by some engineers/enthusiasts on a forum (the original thread, I think) and has become a somewhat popular standard for controlling ESCs for quadcopters/multicopters.

Through reading through a number of articles about the protocol (e..g here and here) I think I have a basic understanding of it. The code that runs on the ESCs is available here and the code that runs on popular flight controllers is here, so in theory it's possible to figure out exactly what's going on, but the ESC code is written in assembly for an architecture I've never studied and the flight controller software is in C which runs on an embedded system I'm also not familiar with.

Using the articles and a bit of the flight controller code I think I've pretty much figured out what's expected which I'll explain shortly. The only problem is that it's made me realise a bit of an issue with my original plan – the protocol requires the input signal to be toggled with sub-microsecond accuracy. Given that Linux is a multi-tasking operating system, you cannot rely on your code being run uninterrupted and I'm worried that a context switch at the wrong time might lead to a physical crash.

The DSHOT protocol consists of transmitting 16-bit packets to the ESCs: an 11-bit throttle value; one bit to request telemetry (or to indicate you want to change a setting) and a 4-bit checksum. Originally, at least, there were three defined speeds for the protocol, DSHOT 150, DSHOT 300 and DSHOT 600. The numbers refer to the theoretical maximum speeds of data transfer in kilobits. Given the timing concerns above I am going to focus on the slowest version, DSHOT 150.

Search & hit enter...

## **Recent Posts**

kerl: Ubuntu 22.04 build dependencies DSHOT with Python DSHOT in the Dark Some soldering later Motoring On

## **Recent Comments**

david on DSHOT in the Dark
Brian Tremaine on DSHOT in the Dark
david on DSHOT in the Dark
Brian Tremaine on DSHOT in the Dark
david on DSHOT in the Dark
david on DSHOT in the Dark

## **Archives**

April 2024 March 2018 December 2017 November 2017


## Categories

Drone

Each bit of a DSHOT packet is transmitted by setting the signal voltage high and then low. To communicate a '1' the high portion of the wave must be longer than the low portion, and vice-versa to communicate a '0'. There are oscilloscope images at some of the above links which illustrate this a bit better. The eleven throttle bits are send first, starting with the most significant bit, then the telemetry bit and finally the four checksum bits. The code to calculate the checksum can be found in the cleanflight flight control software.

I haven't found any articles listing the expected timings for DSHOT 150, but this article lists them for DSHOT 600. I them multiplied by four to get the DSHOT 150 timings, but I think they are calculated as follows:

- 150000 bits ber second = 1/150000 = -6.67 microseconds (µs) per bit
- This matches the timings from the above article multiplied by four, so approximate timings for the waveforms are:
  - T0H (time for the high portion of a zero bit) = 2500µs
  - TOL (time for the low portion of a zero bit) = 4180µs
  - T1H (time for the high portion of a one bit) =  $5000\mu$ s
  - T1L (time for the low portion of a one bit) = 1680µs



None of the articles I've read have explained *why* the timings are this way. It seems that the zero bit just needs to have a longer low portion and viceversa for the one bit, and I think the whole idea is that the exact timings for each is not that important. This is one of the touted advantages over PWM based protocols (of which there are a few) in that timing variations do not lead to incorrect throttle values being sent to the ESCs.


Now I've explained how zeroes and ones are transmitted, I've prepared some example frames that could be sent to an ESC:

In DSHOT, the throttle values 0-47 are reserved, so 48-2047 give 2000 steps of throttle resolution. Of the reserved values, 0 is reset or disarmed and the others are various settings or requests for information. There is a concept of bidirectional communication using some output on the ESC but I'm not sure whether my ESCs have this output (certainly not without removing the shrink-wrap plastic) and I'm not interested in it for now. When sending any values 1-47 the telemetry bit should apparently be set. In the betaflight code the only settings that seem to be implemented are the spin direction (normal or reversed) but not the save settings command, so I'm not sure

Programming

## Meta

Log in Entries feed Comments feed WordPress.org what's going on. Settings commands should apparently be sent at least 10 times, presumably for reliability. It's difficult to gather whether the things that the flight controller software do are required for interfacing with a DSHOT ESC or if it's just best practice.



In the above image, the first frame, 00000000000000 is the special 'reset' packet. I'm not sure of its precise function. The second two frames are valid throttle values, 111111111111 and 0101010101010101. These were just convenient examples and represent maximum throttle (2047) and a throttle value of 682. The second two examples include the "telemetry" bit set to one.

The last four bits are the checksum which is supposed to provide a some assurance that the bits read were the bits sent (if there were any bit misread the checksum won't match the data). I couldn't find the definition for this checksum anywhere other than the cleanflight/betaflight code, so here is an intuitive explanation. The related code is here:

```
// compute checksum
int csum = 0;
int csum_data = packet;
for (int i = 0; i < 3; i++) {
  csum ^= csum_data; // xor data by nibbles
  csum_data >>= 4;
}
csum &= 0xf;
// append checksum
packet = (packet << 4) | csum;</pre>
```

Taken from the cleanflight code on github.

So essentially start with 0 and XOR the 12 bits of data we want to send (11 throttle bits, 1 telemetry request bit) with that (and basically get the same thing, **0 XOR 0** = **0** and **1 XOR 0** = **1**). We then right-shift the data by four bits and XOR the result with the value obtained in the previous step and repeat this again. An easier (but less generic) way of looking at it might be this:

```
csum = (csum_data ^ (csum_data >> 4) ^ (csum_data >>
```

The first bit of the checksum is therefore made up of the first bit of the data XORed with the 5th and the 9th, the second bit is made up of the second bit of the data XORed with the sixth and the tenth etc. In theory if any one of those bits gets read as the opposite value, the the checksum will be incorrect.

As described above, each bit takes 6680ns to transmit. This means a frame takes 16\*6680=106880ns to transmit. This means that the maximum rate that we can update the ESC's speed is 1/0.000106880=~9356Hz, however that would be with no gaps in between frames. Various articles state that the theoretical maximum update rate for DSHOT 150 is 8kHz, which would mean a (1/8000)-0.000106880=0.00001812s gap between frames (just under 2 microseconds), however the betaflight wiki page for DSHOT states that the maximum rate used for DSHOT 150 in betaflight is 4kHz. This means a (1/4000)-0.000106880=0.00014312s gap (~14 microseconds) in between frames. It sounds like the exact spacing isn't too important and for my experimentation a lower value would be useful (to allow some time to do some other computations), so we'll see what happens.

From the product name of the ESCs I bought (listed in the first post) you can that part of it is "BLHeli\_S". This is the firmware installed on the ESCs, and the code (in assembly) can be found here. Inside the "BLHeli\_S SiLabs" directory there is a PDF manual which describes some things about the firmware, though it does not seem as if it was written to help people interface with it.

With that all out of the way, the next post will go into some experiments I've been trying in an attempt to control an ESC with my Raspberry Pi.

**Update 2017-12-04:** added a bit about update rates.

Post Views: 20,939

Posted in **Drone** 

#### **DSHOT** with Python

### Some soldering later

13 thoughts on "DSHOT in the Dark"



#### Dhamdhawach Horsuwan

2019-03-07 at 03:01

Can I use your picture in my blog? I'll gie a credit ,thank!



#### david

2019-03-07 at 10:24

Yes, no problem. Thanks!

Reply

Reply



### Vishvapathi

2019-05-05 at 08:59

Thanks for the blog, It was very informative and useful. I have a BL\_Heli 32 and planning to use it with Dshot 600. As per Dshot we have to send a throttle value start of arming(i have send 1024) and next a 0 value for complete the arming sequence. But when i try the same my ESC is not getting armed. I have cross checked my data, telemery and CRC. They seem to be correct. Is the sequence i am sending is correct or i am missing something. Thanks

Reply



#### david

2019-05-07 at 09:21

I'm not sure if my ESCs are different, but I found that the arming process didn't require setting the throttle value at all. I can just send 0 for a while and the ESCs will play the arming sounds via the motors, then sending throttle values will work. My assumption is that flight controllers generally implement the arming procedure. It's quite dangerous to start sending high throttle values because the motors can start unexpectedly, maybe start with 49 and work up.

Reply



#### **Brian Tremaine**

2019-10-29 at 17:07

Any specs on how long the 0 should be sent? I'm using a BLHeli in an industrial application (non-flying) and just want to spin a motor. I'm doing the control with FPGA code. I've sent 0, 48, 100, 200 then loop on sending 300. I'm waiting 1.5ms between commands. Can't seem to BLHeli to respond at all.

Reply



#### david

#### 2019-10-30 at 09:26

I don't know any specifics. What works for me is sending 0 repeatedly for a few seconds, then moving to >= 48. My ESCs play some tones through the motors which let you know they're ready.

AFAIK sending 0 isn't completely necessary, though I'm not sure I've tried without as I'm quite cautious of the spinning propellers.

Are you able to look at the output from the FPGA on an oscilloscope?

Reply



#### **Brian Tremaine**

#### 2019-10-30 at 12:15

- 1. Send repeated throttle values (My case I sent every 1.5ms) because without repeating the BLHeli code will shut down the motor.
- 2. Before sending 48, send a series of 0′, not just a single command. In my case I sent 0 ever 1.5ms for
- 1.5 seconds. Sending just 1 did not work.
- 3. Final command set:
- a. sent 0 every 1.5ms for 1.5sec.
- b. sent 100, wait 1.5ms
- c. sent 200, wait 1.5ms
- d. send 300 every 1.5ms forever.

Thanks for your blog !!!!!



#### david

#### 2019-11-04 at 10:37

Nice work!! Glad it was helpful. Are you able to share your FPGA implementation at all? I'd be interested to see it.



#### Ole-Hjalmar Kristensen

2019-07-11 at 21:20

" None of the articles I've read have explained why the timings are this way. It seems that the zero bit just needs to have a longer low portion and vice-versa for the one bit, and I think the whole idea is that the exact timings for each is not that important."

It's a pretty standard self-clocking format. The receiver detects the rising edge of each pule, and samples the value 2500 ns after that, giving 1 or 0. This means that timing errors will not build up. As long as the pulse width is approximately correct, the signal will be decoded correctly even if the pulse frequency is off.

Reply



#### david

#### 2019-07-12 at 09:08

Ah, that makes sense. Thanks for the explanation! I'd been imagining that the receiver was timing each period rather than sampling after a fixed time.

Reply



#### Brian

2019-10-18 at 19:16

Very helpful info, hard to find in the hobby market 😊



Reply



#### brian

2019-10-18 at 19:47

I have a question on timing between packets. If I have a servo controller that is computing updates at a 330 Hz rate (3ms) and am using Dshot150 can the time between packets be 3ms or do I need to "fill in" with repeat data?

Thanks, Brian





#### david

2019-10-21 at 09:30

I haven't tested extensively, but that might be a bit long. My strategy has been to repeat the packets until the value needs to change.

Reply

## Leave a Reply

Your email address will not be published. Required fields are marked \*

Comment *	
	//
Name *	
Email *	
Website	
Post Comment	