Program Status Word

- The program status word (PSW)
   register, also referred to as the *flag* register, is an 8 bit register
  - Only 6 bits are used
    - These four are CY (carry), AC (auxiliary carry), P (parity), and OV (overflow)
      - They are called *conditional flags*, meaning that they indicate some conditions that resulted after an instruction was executed
    - The PSW3 and PSW4 are designed as RS0 and RS1, and are used to change the bank
  - > The two unused bits are user-definable

Program Status Word (cont')

The result of signed number operation is too large, causing the high-order bit to overflow into the sign bit

СУ	AÇ	F0	RS1	RS0	OV		Р	]
CY PSV	V.7	Carry flag.			A carry from D3 to D4			
AC PSV	V.6	Auxilia	ry carry	flag.	Carry	out fro	m the	d7 bit
PSV	W.5	Availab	ole to th	e user f	or gene	ral purp	ose	
RS1 PSV	W.4	Registe	r Bank	selecto	r bit 1.			
RS0 PSV	W.3	Registe	r Bank	selecto	r bit 0.			
OV PSV	V.2	Overflo	w flag.	T	Reflect 1	the num	her of	10
/ PSV	<b>V</b> .1	User de	finable	1 .	n regist			13
P PSV	W.0	Parity flag. Set/cleared by hardware each						
instruction cycle to indicate an odd/even number of 1 bits in the accumulator.								

RS0	Register Bank	Address
0	0	00H – 07H
1	1	08H – 0FH
0	2	10H – 17H
1	3	18H – 1FH
	0 1 0 1	RSO Register Bank  0 0  1 1  0 2  1 3



ADD Instruction And PSW

## Instructions that affect flag bits

Instruction	CY	OV	AC
ADD	Х	Х	Χ
ADDC	Х	Х	Χ
SUBB	Х	Χ	Χ
MUL	0	Х	
DIV	0	Χ	
DA	Х		
RPC	Χ		
PLC	Х		
SETB C	1		
CLR C	0		
CPL C	Χ		
ANL C, bit	Χ		
ANL C, /bit	Χ		
ORL C, bit	Χ		
ORL C, /bit	Х		
MOV C, bit	Χ		
CJNE	Χ		



ADD Instruction And PSW (cont')

# The flag bits affected by the ADD instruction are CY, P, AC, and OV

## Example 2-2

Show the status of the CY, AC and P flag after the addition of 38H and 2FH in the following instructions.

#### **Solution:**

$$+2F$$
 00101111

CY = 0 since there is no carry beyond the D7 bit

AC = 1 since there is a carry from the D3 to the D4 bi

P = 1 since the accumulator has an odd number of 1s (it has five 1s)



ADD Instruction And PSW (cont')

## Example 2-3

Show the status of the CY, AC and P flag after the addition of 9CH and 64H in the following instructions.

#### **Solution:**

CY = 1 since there is a carry beyond the D7 bit

AC = 1 since there is a carry from the D3 to the D4 bi

P = 0 since the accumulator has an even number of 1s (it has zero 1s)



ADD Instruction And PSW (cont')

## Example 2-4

Show the status of the CY, AC and P flag after the addition of 88H and 93H in the following instructions.

#### **Solution:**

11B 00011011

CY = 1 since there is a carry beyond the D7 bit

AC = 0 since there is no carry from the D3 to the D4 bi

P = 0 since the accumulator has an even number of 1s (it has four 1s)

