## Default MQTT

Default MQTT module receives telemetry from specific MQTT topics.

 $\textbf{Implementing class:} \verb|com.arrow.selene.device.mqtt.DefaultMqttDeviceModule|\\$ 

OS dependency: None Requirements: None

Properties:

Name	Data type	Unit of measurement	Valid values	Default value	Description
mqttTopics	string	N/A	N/A	N/D	Defines comma-separated list of MQTT topics that device should subscribe to
payloadFormatted	boolean	N/A	true/false	false	Defines that payload received from topic is JSON-formatted and can be parsed before sending telemetry, otherwise it is assumed that telemetry contains raw payload
mqttUrl	string	N/A	<url></url>	tcp://localhost:1883	Defines address of MQTT server
mqttUserName	string	N/A	N/A		Defines MQTT user name
mqttPassword	string	N/A	N/A		Defines MQTT user password