### Effective dynamics of an aircraft

### Art L. Gower, Matheus de Carvalho Loures, Paulo Piva

July 24, 2025

#### Abstract

To plan optimal aircraft routes we can not completely solve and describe 3D fluid structure interaction. This would be computationally very intense and unnecessary. Instead, we need to capture the main features related to fuel consumption, ability to turn, and affects from the atmosphere such as drag and lift. To achieve this we develop effective dynamical equations, together with a simple numerical scheme to solve these equations. The method is simple enough to using nonlinear optimisation to plan routes with minimal fuel, or distance, or time.

### 1 Equations of motion

The main forces acting on the aircraft are due to thrust, drag, lift, and a turning force. More accurately: an aircraft turns by rolling and then using lift, however we will not model these details, and instead have a turning force which is similar to a lift force. See fig. 1 for a sketch.




Figure 1: A sketch showing that the aircraft velocity vector is given by v (relative to the ground), and the velocity of the wind (relative to the ground) is given by u.

To describe the aircraft dynamics it is useful to use a local coordinate system with basis vectors:

$$e_a$$
 (aligned with the direction of travel) (1)

$$e_r$$
 (radial direction from earth centre to aircraft) (2)

$$e_p = e_r \times e_v$$
 (perpendicular to travel direction) (3)

where we will only model the 2D dynamics and assume the altitude is fixed, so that  $e_a$  is always orthogonal to  $e_r$ . Note that changes of altitude based on balance of lift with gravity can easily be accommodated without modelling the motion that leads to that change.

There are two main forces on the aircraft, those that can be controlled by the pilot f and those that external w. The forces that can be controlled are:

$$f = T(\dot{m})e_a + L_p(v - u, \alpha)e_p + L_r(v - u, \beta)e_r,$$
(4)

where  $\dot{m}$  is the rate of change of mass in time (from using fuel), v = |v|,  $T(\dot{m})$  is the force from thrust,  $L_p(v,\alpha)$  is a force which leads to turns in the  $e_p$  direction, where  $\alpha$  captures the amount the pilot tries to turn, and  $L_r(v,\beta)$  are the lift forces, where  $\beta$  is the amount to pilot tries to lift.

A simple and effective choice for thrust is

$$T(\dot{m}) = -\dot{m}C_T,\tag{5}$$

where  $C_T$  is a constant which describes how efficiently burning fuel  $\dot{m}$  is converted into a thrust. More accurately,

$$C_T = (\text{exhaust velocity}) - (\text{relative airspeed}),$$

for subsonic flight [1, Chapter 4], where exhaust velocity is the speed of exhaust relative to the aircraft, and relative airspeed is equal to |v - u|.

A simple and effective formula for the turning force is

$$L_p(v,\alpha) = |(v - u) \cdot e_a|^2 \alpha. \tag{6}$$

In practive, turning is due to rolling and then lift. The forces that lead to rolling and lift are due to wind drag, which is proportional to the relative airspeed in the direction of travel. The variable  $\alpha$  is bounded:  $\alpha \in [-C_{\alpha}, C_{\alpha}]$ , where the positive constant  $C_{\alpha}$  depends on the type of aircraft.

The dynamics of the aircraft are now governed by balance of momentum p = mv:

$$\frac{d}{dt}\mathbf{p} = \mathbf{f} + \mathbf{w} \implies 
\dot{\mathbf{p}} = T(\dot{m})\mathbf{e}_a + L_p(\mathbf{v} - \mathbf{u}, \alpha)\mathbf{e}_p + L_r(\mathbf{v} - \mathbf{u}, \beta)\mathbf{e}_r + \mathbf{w}, \tag{7}$$

where w are the forces due to external factors, such as the wind and altitude. It is generally a function of the relative airspeed v-u, however we do not need to give explicit forms for this forces.

For the lift force  $L_r$ , we assume it is enough to balance the external vertical, or radial, forces such as gravity. That is, by taking the dot product of  $e_r$  on the right side of (8) we reach that

$$\boldsymbol{w} \cdot \boldsymbol{e}_r = -L_r(\boldsymbol{v} - \boldsymbol{u}, \beta).$$

The simplest way to enforce this is to write the external forces in the form:

$$\boldsymbol{w} = w_a \boldsymbol{e}_a + w_p \boldsymbol{e}_p + w_r \boldsymbol{e}_r,$$

then the two equations above substituted into (7) lead to

$$\dot{\boldsymbol{p}} = (T(\dot{m}) + w_a)\boldsymbol{e}_a + (L_p(\boldsymbol{v} - \boldsymbol{u}, \alpha) + w_p)\boldsymbol{e}_p. \tag{8}$$

Equation (8) can be used to update the momentum p in time, which we show in more detail in the next section.

Finally, we need to calculate how the plane's orientation  $e_a$  changes. If the pilot does not actively turn the plan and  $L_p = 0$ , then the plane will change its orientation with the flow. In others words,

$$\frac{d}{dt} \left[ \boldsymbol{e}_a \cdot (\boldsymbol{v} - \boldsymbol{u}) \right] = 0 \implies \dot{\boldsymbol{e}}_a \cdot (\boldsymbol{v} - \boldsymbol{u}) = -\boldsymbol{e}_a \cdot (\dot{\boldsymbol{v}} - \dot{\boldsymbol{u}}),$$

which can be used to update the direction  $e_a$ .

NOTE: Below is a work in progress. In fact, it is not clear the aircraft's orientation follows the flow as shown above. For example a spherical rock would not change its orientation with the flow, but a paper airplane would. The aircraft is probably more like a paper airplane.

Turning the plane also changes its orientation, which as a consequence changes the basis vectors  $e_a$  and  $e_p$ . We assume that there is a linear relationship between turning force  $L_p$  and the torque force that causes the plane to rotate. Then, depending on the moment of inertia of aircraft, this torque will cause a rotation. To calculate this rotation, let choose a position x for the aircraft in a spherical coordinate system  $(r, \theta, \phi)$  with

$$\mathbf{x} = r[\sin\phi\cos\theta, \sin\phi\sin\theta, \cos\phi]. \tag{9}$$

Then we can write the orientation of the aircraft in the form

$$e_a = \cos \tau e_\theta + \sin \tau e_\phi$$

where we call  $\tau$  the angle of orientation of the aircraft, and note that the basis vectors  $e_{\theta}$  and  $e_{\phi}$  can be defined from:

$$\frac{d}{dt}\mathbf{x} = \mathbf{v} = r\sin\phi\mathbf{e}_{\theta}\dot{\theta} + r\mathbf{e}_{\phi}\dot{\phi}.$$
 (10)

Now the rotation of the plane is given from

$$\ddot{\tau} = C_{\tau} L_p \alpha,\tag{11}$$

for some constant  $C_{\tau}$  which depends on the type of aircraft.

#### 1.1 Forward marching numerical method

Then the velocity vector of the aircraft is given by  $\dot{\boldsymbol{x}} = \boldsymbol{v}$ , with  $\boldsymbol{v}$ . Rewriting in spherical coordinates we get

$$\mathbf{v} = r\sin\phi\mathbf{e}_{\theta}\dot{\theta} + r\mathbf{e}_{\phi}\dot{\phi},$$

by assuming that the height r is fixed. Then, from the above we deduce that

$$r \sin \phi \dot{\theta} = \boldsymbol{v} \cdot \boldsymbol{e}_{\theta} \quad \text{and} \quad r \dot{\phi} = \boldsymbol{v} \cdot \boldsymbol{e}_{\phi}.$$
 (12)

From the above we can see that it is convenient to write the components v in terms of the local coordinate system  $e_{\theta}$ ,  $e_{\phi}$ ,  $e_r$  coordinate system. That is, in the code,

$$v[1] = v \cdot e_{\theta}, \quad v[2] = v \cdot e_{\phi}, \quad v[3] = v \cdot e_r.$$

We can then use the equations (12) to calculate  $\theta(t+h)$  and  $\phi(t+h)$  by substituting

$$\dot{\theta} = \frac{\theta(t+h) - \theta(t)}{h}$$
 and  $\dot{\phi} = \frac{\phi(t+h) - \phi(t)}{h}$ ,

into (12) and solving for  $\theta(t+h)$  and  $\phi(t+h)$ . For consistency, we have that the components of all vectors are given in terms of the local basis in the code.

The equations of motion (?? - ??) can now be turned into a forward marching numerical method to predict the trajectory of the aircraft, which we briefly summarise below.

Equation (??) can be used to update the speed v(t) by substituting

$$\dot{v}(t) = \frac{v(t+h) - v(t)}{h},$$

and then solving for v(t+h). From the second equation (??) we can update the direction  $e_v$  and as a consequence  $e_p$ . To start

$$\dot{\boldsymbol{e}}_v = a\boldsymbol{e}_p + b\boldsymbol{e}_r,$$

because  $\dot{e}_v$  is orthogonal to  $e_v$ . Substituting the above into (??) then leads to

$$a = \mathbf{e}_{p} \cdot \dot{\mathbf{e}}_{v} = (w_{n}(r, v, t) + L_{c}(\alpha(t), v(t)) / (m(t)v(t)). \tag{13}$$

To obtain b we use

$$b = \dot{\boldsymbol{e}}_v \cdot \boldsymbol{e}_r = -\boldsymbol{e}_v \cdot \dot{\boldsymbol{e}}_r = -\boldsymbol{e}_v \cdot \boldsymbol{v}/r = -v/r, \tag{14}$$

where we also used the  $e_r = r/r \implies \dot{e}_r = v/r$  for fixed r.

To summarise we can use the above to update the direction  $e_v$ 

$$\mathbf{e}_{v}(t+h) = \mathbf{e}_{v}(t) + ah\mathbf{e}_{p}(t) - \frac{vh}{r}\mathbf{e}_{r}(t)$$
(15)

where using the coordinate system  $(\theta, \phi, r)$  we always have that  $e_r = [0, 0, 1]$ . As we have made first order approximations in h the norm of  $e_v(t+h)$  will only be approximately 1. It is better to correct this by taking  $e_v(t+h) \leftarrow e_v(t+h)/|e_v(t+h)|$ . Finally, we can then update the perpendicular direction:

$$\mathbf{e}_{p}(t+h) = \mathbf{e}_{r} \times \mathbf{e}_{v}(t+h). \tag{16}$$

## 2 Finding the right altitude to keep a certain speed above the tropopause

The tropopause is the height that separates the troposphere and the stratosphere

The force balance in normal direction gives equilibrium of the plane at a constant altitude H. The air density at a certain height can be approximated as

$$\rho = \rho_{\text{trop}} e^{-\left(\frac{g}{RT_{\text{trop}}}(H - h_{\text{trop}})\right)},\tag{17}$$

where the sub-index 'trop' means the tropopause value of the density, temperature, and altitude provided in the NATS guide. The pressure also follows the same behaviour.

$$P = P_{\text{trop}} e^{-\left(\frac{g}{RT_{\text{trop}}}(H - h_{\text{trop}})\right)}$$
(18)

The lift force is calculated as

$$L_u = \frac{\beta C_L}{2} \rho u^2 S \tag{19}$$

Where  $u = |\mathbf{v} - \mathbf{W}|$  is the speed of the plane related to the wind, m is the mass of the plane, g is gravity, S is the area of the wing projected at the plane normal to  $e_r$ , and  $C_L$  is the lift coefficient with  $\beta$  being its control parameter. From that we can see that the lift force is proportional to the density. So the Lift force is

$$L_u = \frac{\beta C_L}{2} \rho_{\text{trop}} e^{-\left(\frac{g}{RT_{\text{trop}}}(H - h_{\text{trop}})\right)} u^2 S$$
 (20)

So the total external force on the direction  $e_r$  is

$$w_r = -mg - PA \tag{21}$$

where A is the projected area of the whole plane.

$$-m(t)\frac{v(t)^{2}}{r} = -mg - PA + L_{u}$$
(22)

$$-m(t)\frac{v(t)^{2}}{r} = -mg - P_{\text{trop}}e^{-\left(\frac{g}{RT_{\text{trop}}}(H - h_{\text{trop}})\right)}A + \frac{\beta C_{L}}{2}\rho_{\text{trop}}e^{-\left(\frac{g}{RT_{\text{trop}}}(H - h_{\text{trop}})\right)}u^{2}S$$
 (23)

notice that  $r = R_{\text{earth}} + H$  and  $R_{\text{earth}} >> H$ , so we approximate  $r \approx R_{\text{earth}}$ 

$$-m\frac{v^2}{R_{\text{earth}}} = -mg - P_{\text{trop}}e^{-\left(\frac{g}{RT_{\text{trop}}}(H - h_{\text{trop}})\right)}A + \frac{\beta C_L}{2}\rho_{\text{trop}}e^{-\left(\frac{g}{RT_{\text{trop}}}(H - h_{\text{trop}})\right)}u^2S \tag{24}$$

$$\Rightarrow -m\frac{v^2}{R_{\text{earth}}} + mg = \left(-P_{\text{trop}}A + \frac{\beta C_L}{2}\rho_{\text{trop}}u^2S\right)e^{-\left(\frac{g}{RT_{\text{trop}}}(H - h_{\text{trop}})\right)}$$
(25)

$$\Rightarrow \frac{-m\frac{v^2}{R_{\text{earth}}} + mg}{\left(-P_{\text{trop}}A + \frac{\beta C_L}{2}\rho_{\text{trop}}u^2S\right)} = e^{-\left(\frac{g}{RT_{\text{trop}}}(H - h_{\text{trop}})\right)}$$
(26)

$$\Rightarrow \log \left( \frac{-m\frac{v^2}{R_{\text{earth}}} + mg}{\left( -P_{\text{trop}}A + \frac{\beta C_L}{2} \rho_{\text{trop}} u^2 S \right)} \right) = -\left( \frac{g}{RT_{\text{trop}}} (H - h_{\text{trop}}) \right)$$
 (27)

Isolating H and substituting u we have that

$$H = -\frac{RT_{\text{trop}}}{g} \log \left( \frac{-m\frac{v^2}{R_{\text{earth}}} + mg}{\left( -P_{\text{trop}}A + \frac{\beta C_L}{2} \rho_{\text{trop}} | \boldsymbol{v} - \boldsymbol{W}|^2 S \right)} \right) + h_{trop}$$
 (28)

But  $C_L$  in literature is given by

$$C_L = \frac{2mg}{\rho_{\text{trop}}|\boldsymbol{v} - \boldsymbol{W}|^2 S} \tag{29}$$

$$\Rightarrow H = -\frac{RT_{\text{trop}}}{g} \log \left( \frac{-m\frac{v^2}{R_{\text{earth}}} + mg}{-P_{\text{trop}}A + \beta mg} \right) + h_{trop}$$
 (30)

### 3 Finding the right altitude to keep a certain speed below the tropopause

The air density at a certain height can be approximated as

$$\rho = \rho_0 \left( \frac{T_0 - \frac{6.5h}{1000}}{T_0} \right)^{-\frac{g}{k_T R} - 1} \tag{31}$$

and the pressure is

$$P = P_0 \left( \frac{T_0 - \frac{6.5h}{1000}}{T_0} \right)^{-\frac{g}{k_T R}} \tag{32}$$

So the total external force on the direction  $\boldsymbol{e}_r$  is

$$w_r = -mg - PA \tag{33}$$

where A is the projected area of the whole plane.

$$-m(t)\frac{v(t)^2}{r} = -mg + L_u \tag{34}$$

were we dropped the pressure term just to have an estimate height

$$\Rightarrow \frac{-m\frac{v^2}{R_{\text{earth}}} + mg}{\frac{\beta C_L}{2}\rho_0 u^2 S} = \left(\frac{T_0 - \frac{6.5h}{1000}}{T_0}\right)^{-\frac{g}{k_T R} - 1}$$
(35)

# References

[1] John David Anderson and Mary L Bowden. *Introduction to flight*. Vol. 582. McGraw-Hill Higher Education New York, NY, USA, 2005.