Introduction: Computer Fundamental

Computer

Why do we use Computer?

How Computer Works?

-- Model of Computer


Work

Work: Buy 1kg Alu


Action:

- 1. Take Bag, Money
- 2. Goto Market
- 3. Search for good Alu
- 4. Buy 1kg Alu
- 5. Go home

Model



Computer Model




Algorithm: Procedure/Method to achieve desired result

Computer Program:
Set of Instructions
Executes in Sequence

Body --- Hardware

Life --- Software

• Operating System, Compiler, editor, other tools



Computer Programming Languages:

High Level Language: User Readable and understandable (C, Pascal, Java, Cobol.....)


Assembly Language: (mnemonics: add, mov, mul, div, etc...)

Machine Language: sequence of 0s & 1s

Von Neumann

- Stored Program concept
- Main memory storing programs and data
- ALU operating on binary data
- Control unit interpreting instructions from memory and executing
- Input and output equipment operated by control unit
- Princeton Institute for Advanced Studies
 —IAS
- Completed 1952

Structure of Von Neumann machine



Computer: Structure & Function


- Structure is the way in which components relate to each other
- Function is the operation of individual components as part of the structure

Function


- All computer functions are:
 - —Data processing
 - —Data storage
 - —Data movement
 - -Control

Functional View


Operating Environment (source and destination of data)




Operations (a) Data movement




Operations (b) Storage




Operation (c) Processing from/to storage




Operation (d) Processing from storage to I/O




Structure - Top Level



Structure - The CPU




Structure - The Control Unit




Von Neumann

- Stored Program concept
- Main memory storing programs and data
- ALU operating on binary data
- Control unit interpreting instructions from memory and executing
- Input and output equipment operated by control unit
- Princeton Institute for Advanced Studies
 —IAS
- Completed 1952

Structure of Von Neumann machine



CPU Internal Structure




What is a program?


- A sequence of steps
- For each step, an arithmetic or logic operation is done
- For each operation, a different set of control signals is needed

Instruction Cycle


- Two steps:
 - —Fetch
 - —Execute




Instruction Cycle with Indirect




Structure of Von Neumann machine



Computer Components: Top Level View



CPU With Systems Bus



Data Bus and Address Bus

• Size of Address Bus:

SIZE	BINARY	DEC	HEXA	
8	0000 0000	0	00	
8	1111 1111	255	FF	
8	0101 0111	87	57	
8	0000 0110	6	06	
10	11 1111 1111	1023	3FF	
12	1111 1111 1111	4095	FFF	
16	1111 1111 1111 1111	2 ¹⁶ -1	FFFF	
20	1111 1111 1111 1111 1111	2 ²⁰ -1	FFFFF	
30	11 1111	2 ³⁰ -1	3FFFFFF	
32	1111 1111	2 ³² -1	FFFFFFF	

Data Bus and Address Bus

Size of Address Bus and Memory Capacity:


SIZE	BINARY	DEC	HEXA	
8	0000 0000	0	00	
8	1111 1111	255	FF	256
10	11 1111 1111	1023	3FF	1K
12	1111 1111 1111	4095	FFF	4K
16	1111 1111 1111 1111	216 -1	FFFF	64K
20	1111 1111 1111 1111 1111	2 ²⁰ -1	FFFFF	1M
30	11 1111	2 ³⁰ -1	3FFFFFF	1G
32	1111 1111	2 ³² -1	FFFFFFF	4G

Data Bus and Address Bus


Size of Data Bus/Memory Location:

SIZE	BINARY	DEC	HEXA
8	1111 1111 0111 1111	-127 +127	00 - FF
12	1111 1111 1111 0111 1111 1111	-2047 +2047	000 - FFF
16	1111 1111 1111 1111 0111 1111 1111 1111	$-(2^{15}-1)$ $+(2^{15}-1)$	0000- FFFF
20	1111 1111 1111 1111 1111 0111 1111 1111	$-(2^{19}-1)$ $+(2^{19}-1)$	00000 - FFFFF
32	1111	$-(2^{31}-1)$ $+(2^{31}-1)$	00000000 - FFFFFFF

Instruction Cycle with Indirect



Instruction Cycle with Interrupts



Indirect Cycle

- May require memory access to fetch operands
- Indirect addressing requires more memory accesses
- Can be thought of as additional instruction subcycle


Fetch Cycle

- Program Counter (PC) holds address of next instruction to fetch
- Processor fetches instruction from memory location pointed to by PC
- Increment PC
 - —Unless told otherwise
- Instruction loaded into Instruction Register (IR)
- Processor interprets instruction and performs required actions

Execute Cycle


- Processor-memory
 - —data transfer between CPU and main memory
- Processor I/O
 - —Data transfer between CPU and I/O module
- Data processing
 - —Some arithmetic or logical operation on data
- Control
 - Alteration of sequence of operations
 - —e.g. jump
- Combination of above

Example of Program Execution



CPU Organization

CPU



Machine Instruction

Machine	Instruction Format				Assembly
Instruction	Operation	Address			Code
1940	0001	1001	0100	0000	LDA M
5941	0101	1001	0100	0001	ADD M
2941	0010	1001	0100	0001	STA M


(LDA M) LOAD AC: Load the accumulator by the contents of memory location specified in the instruction

(ADD M) ADD AC: Add the contents of memory location specified in the instruction to accumulator and store the result in accumulator

(STA M) STORE AC: Store the contents of accumulator the memory location specified in the instruction

High Level Code	Assembly Code	Machine Code (HEX)
Y = X + Y	LDA X	1940
	ADD Y	5941
	STA Y	2941

CPU Internal Structure



Registers

- CPU must have some working space (temporary storage)
- Called registers
- Number and function vary between processor designs
- One of the major design decisions
- Top level of memory hierarchy

User Visible Registers

- General Purpose
- Data
- Address
- Condition Codes


How Many GP Registers?

- Between 8 32
- Fewer = more memory references
- More does not reduce memory references and takes up processor space
- Large enough to hold full address
- Large enough to hold full word
- Often possible to combine two data registers
 - —C programming
 - —double int a;
 - —long int a;

Control & Status Registers

- Program Counter
- Instruction Decoding Register
- Memory Address Register
- Memory Buffer Register

Computer Components: Top Level View



Condition Code Registers

- Sets of individual bits
 - —e.g. result of last operation was zero
- Can be read (implicitly) by programs
 - —e.g. Jump if zero
- Can not (usually) be set by programs
- Needs for conditional instructions

Program Status Word

- A set of bits
- Includes Condition Codes
- Sign of last result
- Zero
- Carry
- Equal
- Overflow
- Interrupt enable/disable
- Supervisor


Function of Control Unit

- For each operation a unique code is provided
 - -e.g. ADD, MOVE
- A hardware segment accepts the code and issues the control signals

Components

- The Control Unit and the Arithmetic and Logic Unit constitute the Central Processing Unit
- Data and instructions need to get into the system and results out
 - —Input/output
- Temporary storage of code and results is needed
 - —Main memory

Computer Components: Top Level View



Connecting

- All the units must be connected
- Different type of connection for different type of unit
 - —Memory
 - —Input/Output
 - -CPU

Memory Connection

- Receives and sends data
- Receives addresses (of locations)
- Receives control signals
 - —Read
 - —Write
 - —Timing

Input/Output Connection(1)

- Similar to memory from computer's viewpoint
- Output
 - —Receive data from computer
 - —Send data to peripheral
- Input
 - Receive data from peripheral
 - —Send data to computer

What is a Bus?

- A communication pathway connecting two or more devices
- Usually broadcast
- Often grouped
 - —A number of channels in one bus
 - —e.g. 32 bit data bus is 32 separate single bit channels

Data Bus

- Carries data
 - —Remember that there is no difference between "data" and "instruction" at this level
- Width is a key determinant of performance
 - -8, 16, 32, 64 bit


Address bus

- Identify the source or destination of data
- e.g. CPU needs to read an instruction (data) from a given location in memory
- Bus width determines maximum memory capacity of system
 - —e.g. 8080 has 16 bit address bus giving 64k address space

Control Bus

- Control and timing information
 - —Memory read/write signal
 - —Interrupt request
 - —Clock signals

CPU With Systems Bus



Program Concept

- Hardwired systems are inflexible
- General purpose hardware can do different tasks, given correct control signals

Program Concept

- Operating Systems
 - Viewed as an Extended Machine

What is a program?

- A sequence of steps
- For each step, an arithmetic or logic operation is done
- For each operation, a different set of control signals is needed