Integration of Raspberry Pi on Create

Use this guide in addition to the "Converting Create to Use RealSense.pdf" document by Alec Newport (acn55) & Zhilong Li (zl242).

You will need access to the Lab Admin Folders drive, and the AMR github.

Changes to assembly:

- 1. Power regulator:
 - a. DC to DC adapterhttps://www.amazon.com/dp/B00QTJWRFW?ref = pe 1815430 211938580
 - b. D25 plug connector https://www.mcmaster.com/2146t58

Solder the regulator input wires to the battery power pin and GND pin according to the Create cargo bay connector pinout.

2. Platform:

Modified by Patrick to leave 4 mounting holes and 2 holes for the camera bracket. The drawing is in ...\Lab Admin Folders\MAE 4180\Spring 19 Realsense and RasPi\Platform drawing.

3. Camera bracket:

Machined by Joe Adas. Drawing in

- ...\Lab Admin Folders\MAE 4180\Spring 19 Realsense and RasPi\Camera\Bracket.
- 4. Pi enclosure and Power regulator attached underneath the platform with Velcro.

Camera:

1. Update Firmware:

Firmware Updater, firmware bin file and instructions found in

...\Lab Admin Folders\MAE 4180\Spring 19 Realsense and RasPi\Camera\Firmware update

Network:

1. TP-Link Access point:

AP information in ...\Lab Admin Folders\Computer Support\TP-LINK Access Point SSID = AMR_wifi
Password = 4180-5180

MicroSD card image:

1. Configure auto login to user 'create', so it doesn't wait before connecting to wifi:

Edit /usr/share/lightdm/lightdm.conf.d/60-lightdm-gtk-greeter.conf

Add 'autologin-user=create' in the end of the file.

2. Remove password requirement for sudo for user 'create':

sudo visudo (to edit /etc/sudoers)

Add as the LAST line: 'create ALL = NOPASSWD: ALL'

3. Disable Bluetooth and keep turbo mode in low voltage:

Edit /boot/config.txt

Add 'dtoverlay=pi3-disable-bt' and 'avoid_warnings=2' to the end of the file

4. Change account password if needed:

System – Administration – Users and Groups

Password is 'AMRobot'

- 5. Automatic Wifi connection settings:
 - a. Edit /etc/network/interfaces

```
Before 'auto lo' add
```

'auto wlan0'

In the end of the file add

'allow-hotplug wlan0'

'iface wlan0 inet dhcp'

'wpa-conf /etc/wpa_supplicant/wpa_supplicant.conf'

b. Edit /etc/wpa_supplicant/wpa_supplicant.conf (create the file if it doesn't exist)

Add

```
network={
		ssid="AMR_wifi"
		psk="4180-5180"
}
```

5. Disable sound:

Edit /etc/modprop.d/raspi-blacklist.conf

Add 'blacklist snd_bcm2835'

Python files:

1. Download the latest version of the two python scripts on the Pi from Github:

https://github.com/autonomousmobilerobots/

Save 'robot' to create home

Save 'RSonCreate.py to create/apriltag/python

Clone the MicroSD card:

- 1. On Windows use Win32DiskImager: https://sourceforge.net/projects/win32diskimager/
- 2. On the Pi use rpi-clone
- 3. See How To in
 - ...\ Lab Admin Folders\MAE 4180\Spring 19 Realsense and RasPi\Raspberry Pi Image