ENGG 202 Engineering Statics

Andy Smit

Winter 2019

1 Equilibrium Equation:

$$\sum F_x = 0 \ \sum F_y = 0 \ \sum M = 0$$

1.1 Free Body Diagram

Diagram representation of the isolated system treated as a single body. We model forces exerted on the body to be isolated by the body removed. If a support prevents translation (or rotation) in a given direction

2 Statical Determinacy

Constraint: Restriction of movement

Statically Determinant System: All unknown external effects can be determined from equilibrium conditions. **Degree of Statical Indeterminacy:** The number of redundant reaction forces is equal to the number of all constraints minus the number of equilibrium conditions.

Two and Three Force Members: A body is in equilibrium under the action of two (three) forces only. A force member must have equal, opposite and colinear forces.

Three Force Member:

Figure 1: A 3 force Member




Figure 2: A 2 Force Member

3 3D Vectors

Dot Product:

If \vec{A} and \vec{B} are two vectors where $\vec{A} = \begin{pmatrix} A_1 \\ A_2 \\ A_3 \end{pmatrix}$ and $\vec{B} = \begin{pmatrix} B_1 \\ B_2 \\ B_3 \end{pmatrix}$ then the dot product between \vec{A} and \vec{B} is defined:

$$\vec{A} \cdot \vec{B} = A_1 B_1 + A_2 B_2 + A_3 B_3 = ||\vec{A}|| \, ||\vec{B}|| \cos \theta$$

Cross Product:

If $\vec{A} = \begin{pmatrix} A_1 \\ A_2 \\ A_3 \end{pmatrix}$ and $\vec{B} = \begin{pmatrix} B_1 \\ B_2 \\ B_3 \end{pmatrix}$ are two vectors in \mathbb{R}^3 then the cross product $\vec{A} \times \vec{B}$ is defined either geometrically

$$||\vec{A} \times \vec{B}|| = ||\vec{A}|| \, ||\vec{B}|| \sin \theta$$

or algebraically as

$$\vec{A} \times \vec{B} = \begin{vmatrix} \hat{i} & \hat{j} & \hat{k} \\ A_1 & A_2 & A_3 \\ B_1 & B_2 & B_3 \end{vmatrix}$$

Projections:

 $F_n = F\cos\theta = \vec{F} \cdot \vec{n}$

Moment In 3D:

$$\vec{M_O} = \vec{r} \times \vec{F}$$

Moment about an Arbitrary axis:

Let λ be some arbitrary axis passing through point O then the moment about point O about λ is

$$M_{\lambda} = (\vec{r} \times \vec{F}) \cdot \vec{n}$$

where \vec{n} is a unit vector in the direction of λ , \vec{r} is the position vector between the application of the Force and O, and \vec{F} is the force applied. In 2 and 3D the moment produced by a force going through a point A about point A is O. In 3D if a force is parallel or concurrent with the axis λ then the moment about λ is O.

Couple's In 3D:

$$M_O = \vec{r_A} \times \vec{F} = \vec{r_B} \times \vec{F} = \vec{r} \times \vec{F}$$

Force Couple System in 3D:

Resultants in 3D:

General case (Non-concurrent Forces):

System of concurrent Forces:

$$\sum \vec{F} = \vec{R}$$

$$\vec{M_O} = 0$$

System of Coplanar Forces: Same as 2D problem

4 Trusses

A truss is a group of members in tension and compression. Consists of many zero force members.

4.1 Method of sections:

Cut through members of a structure and consider its section. Determine all external reactions acting on the the truss system (This step may or may not be necessary). Make a cut creating two sections of 3 members max. Choose either side of the truss after cutting to solve for the forces acting on it.

5 Centroids and Center of Gravity

5.1 Centroids:

The geometric center of a body

5.2 Center of Mass (CoM):

A point about which the every particle of its mass is equally distributed (center of a sphere). The of all mass of an object.

5.3 Center of Gravity (CoG):

A point in the body where the whole weight of the body is acting.

$$W = mg$$

Generally the center of mass is the same as the center of gravity for a uniform gravitational field. In all circumstances dealt with in this course center of mass is the same as center of gravity. In a homogeneous (uniform density) body the center of mass and the centroid are located at the same point.

5.4 Determining the center of gravity

5.4.1 Experimental Determination:

Hanging Mass Experiment: Hang a mass on a string in multiple orientations. When it reaches equilibrium the tension in the cable will be colinear with the weight of the object. After doing this at 3 points the center of mass can be determined.

5.4.2 Mathematical Derivation:

Consider a body as a infinite number of particles with differential weight dW. The resultant weight is equal to the sum of all the infinitesimal weights.

$$W = \int dW$$

In this case we can create a couple system between the origin and each particle. This couple has a force $W=\int dW$ and a moment

$$\sum M_x = -\int y_c \, dW$$

From this we can determin that

$$M_x = -\bar{y_c}W$$

where $\bar{y_c}$ is the distance from the axis to the center of gravity. Then understanding that the sum of moments is the same as the moment of sum, the following result can be obtained

$$\bar{y} = \frac{\int y_c \, dW}{W}$$

. For all coordinets the center of gravity is

$$\bar{x} = \frac{\int x_c dW}{W} \quad \bar{y} = \frac{\int y_c dW}{W} \quad \bar{z} = \frac{\int z_c dW}{W}$$

3

5.5 Center of Mass Location:

The center of mass is determined using the same formula as center of gravity

$$\bar{x} = \frac{\int x_c \, dW}{W} \quad \bar{y} = \frac{\int y_c \, dW}{W} \quad \bar{z} = \frac{\int z_c \, dW}{W}$$

Now as express W=mg and $dW=g\cdot dm$, then the formula becomes

$$\bar{x} = \frac{\int x_c dm}{m}$$
 $\bar{y} = \frac{\int y_c dm}{m}$ $\bar{z} = \frac{\int z_c dm}{m}$

Finally recall that $m = \rho V$ and $dm = \rho dV$

$$\bar{x} = \frac{\int x_c \, \rho dV}{\int \rho dV} \quad \bar{y} = \frac{\int y_c \, \rho dV}{\int \rho dV} \quad \bar{z} = \frac{\int z_c \, \rho dV}{\int \rho dV}$$

The vector form the the location of the center of mass is given by

$$\begin{pmatrix} \bar{x} \\ \bar{y} \\ \bar{z} \end{pmatrix}$$

When computing center of gravity choose the easiest coordinate system to use and planes of symmetry. If it makes things easier convert the coordinate system to a polar coordinate system

$$\begin{cases} x = r\cos\theta \\ y = r\sin\theta \end{cases}$$

5.6 Non-table Cases: Choice of Element of Integration:

For a 2D shape we can either take a differential area of dx, dy and take the integral

$$\iint dx \, dy = A$$

or we can take the integral over a changing length with respect to y and take the integral

$$\int l\,dy = A$$

For a 3D shape we can take the integral of a differential volume $dV = dx \, dy \, dz$ to obtain

$$\iiint dx \, dy \, dz = V$$

or we can take the integral over a infinitely thin cross section of the volume

$$\int A \, dy = V$$

Centroidal Coordinate Of Differential Element

$$\bar{x} = \frac{\int x_c \, \rho dV}{\int \rho dV} \qquad \qquad \bar{z} = \frac{\int z_c \, \rho dV}{\int \rho dV} \qquad \qquad \bar{z} = \frac{\int z_c \, \rho dV}{\int \rho dV}$$

6 Concentrated And Distributed Forces

6.1 Distributed Force:

A force distributed over a finite area

6.1.1 Distributed force over Line:

A force distributed over a long line Ex. vertical load supported by a suspended cable

6.1.2 Distributed force over Area:

6.1.3 Distributed Force over Volume:

6.2 Concentrated Force:

A force

7 Beams

A beam is a structural member which offers resistance to bending due to applied loads. Beams can be used to support either concentrated loads or distributed loads

7.1 External Effects:

7.1.1 Distributed Forces

Let f(x) be the force acting on the bar at distance x from O, the moment about the point O is now given by

$$M = \sum_{i=0}^{\infty} x_i f(x) = \int x f(x) \, dx$$

The resultant force is then given similarly by

$$R = \sum f(x) = \int f(x) \, dx$$

The position \bar{x} to which this resultant force is then applied is given by

$$\bar{x} = \frac{M}{R} = \frac{\int x f(x) dx}{\int f(x) dx}$$

7.1.2 Internal Effects:

The forces acting on a beam are trasfered to the reaction points by methods of internal reactions (forces). Internal forces

- 1. Axial Forces
- 2. Shear Forces
- 3. Bending Moment
- 4. Torsional moment

It is important to calculate internal forces at any point of the beam when designing beam shape and size to resist certain sets of loads. It is important when calculating distributed forces to keep distributed forces distributed.

7.1.3 Axial Internal Forces:

7.1.4 Internal Bending Moment:

7.1.5 Internal Torsional Moment:

7.1.6 Internal Shear Force:

We will only look at bending moments and shear forces in statics. Torsion is always neglected and normal forces are often neglected because loads are usually perpendicular to axis of the beam and the beams resistance to bending and shear is more important in design.

7.1.7 Sign conventions

	Positive	Negative
Axial Force	Tension	compression
Shear Force	Left side up	Left side Down
Moment	Concave Up	Concave Down

8 Shear Force and Bending Moment Diagrams

Shear force V and bending moment M plotted at each point of the beam for design purposes max and min values of V, M are important.

8.1 Methods

http://learnaboutstructures.com

8.1.1 Section - Cuts

Determine the external reactions acting on the body. Introduce a right handed coordinate system.

Starting from the left make a new cut within every type of beam section (at arbitrary x), isolate the cut section, draw a free body diagram and determine V, and M as functions of x. Plot the results. Sometimes it is easier to start from the right then the left. Do not cut at a point with a reaction force, or beginning or end of a distributed force. Use the positive sign convention.

8.1.2 Integration - Mathematical

A method based on the relationship between loadings, shearforce and bending moment.

Let's isolate a portion of the loaded beam using appropriate signs from x to x+dx. As dx is very small the load force w is constant on [x,x+dx]. The resultant force through point x* on the interval [x,x+dx] is given by

$$R = w dx$$

Apply equilibrium equations to obtained

$$\sum F_y = 0 = V - V - dV - w dx$$
$$dV = -w dx$$

Integrating both sides of the previous expression obtains

$$\int dV = -\int w \, dx \Rightarrow V = C_1 - \int w \, dx$$

where C_1 is the value of the shear force at the beginning of the distributed load.

8.1.3 Integration - Graphical

$$\int_{v_1}^{v_2} dV = -\int_{x_1}^{x_2} w \, dx$$

$$V_2 - V_1 = \Delta V = -\int_{x_1}^{x_2} w \, dx$$

Change in shear force in between x_1 , and x_2 is negative of the area under the distributed loading curves between x_1 and x_2 .

$$\frac{dV}{dx} = -w$$

The slope of the shear force at a point is the negative intensity at that point.

8.2 Bending Moment and Shear Force Relations

$$\sum M_A = 0$$

$$0 = M + dM - M - (V + dV)dx - w dx \frac{dx}{2}dM = V dx$$

8.2.1 Mathematical Approach

$$M = C_2 + \int V \, dx$$

where C_2 is the value of the bending moment at the beginning of the load.

8.2.2 Graphical Approach

$$\Delta M = \int_{x_1}^{x_2} V \, dx$$

The change in bending moment between x_1 and x_2 is the area under the shear force diagram.

$$\frac{dM}{dx} = V$$

The slope of the bending moment at a point is equal to the value of the shear force at a point. This implies that if V=0 then M must be constant.

$$\frac{d^2M}{dx^2} = \frac{dV}{dx} = W$$

This allows you to find where the bending moment is at a maximum by the second derivative test.

9 Frames And Machines:

Two common structures composed of pin-connected members with at least one multiforce members.

9.1 Frame:

A stationary object, used to support loads

9.2 Machines:

Contains moving parts, designed to transmit and alternate the effect of force.

10 Friction

Force of resistance acting on a body and preventing or retarding its slipping relative to a second body or surface. It is simply the tangent contact force directed so as to oppose possible or existing motion.

10.1 Dry Friction

The friction between two bodies When the body is not in in motion the force of friction can be found by

$$F < F_{max} = \mu_s N$$

F should be found from equilibrium equations and conditions. As $F = F_{max}$ there is impending friction and

$$F = F_{max} = \mu_s N$$

If the body is in motion then

$$F = F_K = \mu_k N$$

and if the velocity of the object is not constant equilibrium does not hold in the direction of motion.

10.2 Fluid Friction

10.3 Internal Friction

11 Wedges

Block with two flat faces that make a small angle with each other. They are machines used to produce small adjustments in the position of the body or to apply large forces.

11.1 Self Locking Feature

The wedge remains in place without force applied.