




Apple II Reference Manual

January 1978



Reference Manual

APPLE II

Reference Manual

January 1978

APPLE Computer Inc.
10260 Bandley Dr.
Cupertino, CA
95014

APPLE II Reference Manual

TABLE OF CONTENTS

A. GETTING STARTED WITH YOUR APPLE II	1	13. Additional BASIC Program Examples	55
1. Unpacking	1	a. Rod's Color Pattern (4K)	55
2. Warranty Registration Card	1	b. Pong (4K)	56
3. Check for Shipping Damage	2	c. Color Sketch (4K)	57
4. Power Up	2	d. Mastermind (8K)	59
5. APPLE II Speaks Several Languages ..	3	e. Biorhythm (4K)	61
6. APPLE Integer BASIC	3	f. Dragon Maze (4K)	63
7. Running Your First and Second Programs	3	C. APPLE II FIRMWARE	67
8. Running 16K Startrek	3	1. System Monitor Commands	68
9. Loading a Program Tape	4	2. Control and Editing Characters	72
10. Breakout and Color Demos Tapes ..	6	3. Special Controls and Features	74
11. Breakout and Color Demos Program Listings	12	4. Annotated Monitor and Dis-assembler Listing	76
12. How to Play Startrek	14	5. Binary Floating Point Package	94
13. Loading HIRES Demo Tape	15	6. Sweet 16 Interpreter Listing	96
B. APPLE II INTEGER BASIC	17	7. 6502 Op Codes	100
1. BASIC Commands	18	D. APPLE II HARDWARE	106
2. BASIC Operators	19	1. Getting Started with Your APPLE II Board	107
3. BASIC Functions	22	2. APPLE II Switching Power Supply ..	110
4. BASIC Statements	23	3. Interfacing with the Home TV	112
5. Special Control and Editing	28	4. Simple Serial Output	114
6. Table A — Graphics Colors	29	5. Interfacing the APPLE — Signals, Loading, Pin Connections	122
7. Special Controls and Features	30	6. Memory — Options, Expansion, Map, Address	133
8. BASIC Error Messages	32	7. System Timing	140
9. Simplified Memory Map	33	8. Schematics	141
10. Data Read/Save Subroutines	34		
11. Simple Tone Subroutines	43		
12. High Resolution Graphics Subroutines and Listings	46		

GETTING STARTED WITH YOUR APPLE II

Unpacking

Don't throw away the packing material. Save it for the unlikely event that you may need to return your Apple II for warranty repair. If you bought an Apple II Board only, see hardware section in this manual on how to get started. You should have received the following:

1. Apple II system including mother printed circuit board with specified amount of RAM memory and 8K of ROM memory, switching power supply, keyboard, and case assembly.
2. Accessories Box including the following:
 - a. This manual including warranty card.
 - b. Pair of Game Paddles
 - c. A.C. Power Cord
 - d. Cassette tape with "Breakout" on one side and "Color Demos" on the other side.
 - e. Cassette recorder interface cable (miniature phone jack type)
3. If you purchased a 16K or larger system, your accessory box should also contain:
 - a. 16K Startrek game cassette with High Resolution Graphics Demo ("HIRES") on the flipside.
 - b. Applesoft Floating Point Basic Language Cassette with an example program on the other side.
 - c. Applesoft reference manual
4. In addition other items such as a vinyl carrying case or hobby board peripheral may have been included if specifically ordered as "extras".

Notify your dealer or Apple Computer, Inc. immediately if you are missing any items.

Warranty Registration Card

Fill this card out immediately and completely and mail to Apple in order to register for one year warranty and to be placed on owners club mailing list. Your Apple II's serial number is located on the bottom near the rear edge. You model number is:

A2S00MMX

MM is the amount of memory you purchased. For Example:

A2S0008X

is an 8K Byte Apple II system.

Check for Damage

Inspect the outside case of your Apple for shipping damage. Gently lift up on the top rear of the lid of the case to release the lid snaps and remove the lid. Inspect the inside. Nothing should be loose and rattling around. Gently press down on each integrated circuit to make sure that each is still firmly seated in its socket. Plug in your game paddles into the Apple II board at the socket marked "GAME I/O" at location J14. See hardware section of this manual for additional detail. The white dot on the connector should be face forward. Be careful as this connector is fragile. Replace the lid and press on the back top of it to re-snap it into place.

Power Up

First, make sure that the power ON/OFF switch on the rear power supply panel on your Apple II is in the "OFF" position. Connect the A.C. power cord to the Apple and to a 3 wire 120 volt A.C. outlet. Make sure that you connect the third wire to ground if you have only a two conductor house wiring system. This ground is for your safety if there is an internal failure in the Apple power supply, minimizes the chance of static damage to the Apple, and minimizes RFI problems.

Connect a cable from the video output jack on the back of the Apple to a TV set with a direct video input jack. This type of set is commonly called a "Monitor". If your set does not have a direct video input, it is possible to modify your existing set. Write for Apple's Application note on this. Optionally you may connect the Apple to the antenna terminals of your TV if you use a modulator. See additional details in the hardware section of this manual under "Interfacing with the Home TV".

Now turn on the power switch on the back of the Apple. The indicator light (it's not a switch) on the keyboard should now be ON. If not, check A.C. connections. Press and release the "Reset" button on the keyboard. The following should happen: the Apple's internal speaker should beep, an asterisk ("*") prompt character should appear at the lower left hand corner of your TV, and a flashing white square should appear just to the right of the asterisk. The rest of the TV screen will be made up of random text characters (typically question marks).

If the Apple beeps and garbage appears but you cannot see an "*" and the cursor, the horizontal or vertical height settings on the TV need to be adjusted. Now depress and release the "ESC" key, then hold down the "SHIFT" key while depressing and releasing the P key. This should clear your TV screen to all black. Now depress and release the "RESET" key again. The "*" prompt character and the cursor should return to the lower left of your TV screen.

Apple Speaks Several Languages

The prompt character indicates which language your Apple is currently in. The current prompt character, an asterisk ("*"), indicates that you are in the "Monitor" language, a powerful machine level language for advanced programmers. Details of this language are in the "Firmware" section of this manual.

Apple Integer BASIC

Apple also contains a high level English oriented language called Integer BASIC, permanently in its ROM memory. To switch to this language hold down the "CTRL" key while depressing and releasing the "B" key. This is called a control-B function and is similiar to the use of the shift key in that it indicates a different function to the Apple. Control key functions are not displayed on your TV screen but the Apple still gets the message. Now depress and release the "RETURN" key to tell Apple that you have finished typing a line on the keyboard. A right facing arrow (">") called a caret will now appear as the prompt character to indicate that Apple is now in its Interger BASIC language mode.

Running Your First and Second Program

Read through the next three sections that include:

1. Loading a BASIC program Tape
2. Breakout Game Tape
3. Color Demo Tape

Then load and run each program tape. Additional information on Apple II's interger BASIC is in the next section of this manual.

Running 16K Startrek

If you have 16K Bytes or larger memory in your Apple, you will also receive a "STARTREK" game tape. Load this program just as you did the previous two, but before you "RUN" it, type in "HIMEM: 16384" to set exactly where in memory this program is to run.

LOADING A PROGRAM TAPE

INTRODUCTION

This section describes a procedure for loading BASIC programs successfully into the Apple II. The process of loading a program is divided into three sections; System Checkout, Loading a Tape and What to do when you have Loading Problems. They are discussed below.

When loading a tape, the Apple II needs a signal of about 2 1/2 to 5 volts peak-to-peak. Commonly, this signal is obtained from the "Monitor" or "earphone" output jack on the tape recorder. Inside most tape recorders, this signal is derived from the tape recorder's speaker. One can take advantage of this fact when setting the volume levels. Using an Apple Computer pre-recorded tape, and with all cables disconnected, play the tape and adjust the volume to a loud but un-distorted level. You will find that this volume setting will be quite close to the optimum setting.

Some tape recorders (mostly those intended for use with hi-fi sets) do not have an "earphone" or high-level "monitor" output. These machines have outputs labeled "line output" for connection to the power amplifier. The signal levels at these outputs are too low for the Apple II in most cases.

Cassette tape recorders in the \$40 - \$50 range generally have ALC (Automatic Level Control) for recording from the microphone input. This feature is useful since the user doesn't have to set any volume controls to obtain a good recording. If you are using a recorder which must be adjusted, it will have a level meter or a little light to warn of excessive recording levels. Set the recording level to just below the level meter's maximum, or to just a dim indication on the level lamp. Listen to the recorded tape after you've saved a program to ensure that the recording is "loud and clear".

Apple Computer has found that an occasional tape recorder will not function properly when both Input and Output cables are plugged in at the same time. This problem has been traced to a ground loop in the tape recorder itself which prevents making a good recording when saving a program. The easiest solution is to unplug the "monitor" output when recording. This ground loop does not influence the system when loading a pre-recorded tape.

Tape recorder head alignment is the most common source of tape recorder problems. If the playback head is skewed, then high frequency information on pre-recorded tapes is lost and all sorts of errors will result. To confirm that head alignment is the problem, write a short program in BASIC. >10 END is sufficient. Then save this program. And then rewind and load the program. If you can accomplish this easily but cannot load pre-recorded tapes, then head alignment problems are indicated.

Apple Computer pre-recorded tapes are made on the highest quality professional duplicating machines, and these tapes may be used by the service technician to align the tape recorder's heads. The frequency response of the tape recorder should be fairly good; the 6 KHz tone should be not more than 3 db down from a 1 KHz tone, and a 9 KHz tone should be no more than 9 db down. Note that recordings you have made yourself with mis-aligned heads may not play properly with the heads properly aligned. If you made a recording with a skewed record head, then the tiny magnetic fields on the tape will be skewed as well, thus playing back properly only when the skew on the tape exactly matches the skew of the tape recorder's heads. If you have saved valuable programs with a skewed tape recorder, then borrow another tape recorder, load the programs with the old tape recorder into the Apple, then save them on the borrowed machine. Then have your tape recorder properly aligned.

Listening to the tape can help solve other problems as well. Flaws in the tape, excessive speed variations, and distortion can be detected this way. Saving a program several times in a row is good insurance against tape flaws. One thing to listen for is a good clean tone lasting for at least 3 1/2 seconds is needed by the computer to "set up" for proper loading. The Apple puts out this tone for about 10 seconds when saving a program, so you normally have 6 1/2 seconds of leeway. If the playback volume is too high, you may pick up tape noise before getting to the set-up tone. Try a lower playback volume.

SYSTEM CHECKOUT

A quick check of the Apple II computer system will help you spot any problems that might be due to improperly placed or missing connections between the Apple II, the cassette interface, the Video display, and the game paddles. This checkout procedure takes just a few seconds to perform and is a good way of insuring that everything is properly connected before the power is turned on.

1. POWER TO APPLE - check that the AC power cord is plugged into an appropriate wall socket, which includes a "true" ground and is connected to the Apple II.
2. CASSETTE INTERFACE - check that at least one cassette cable double ended with miniature phone tip jacks is connected between the Apple II cassette Input port and the tape recorder's MONITOR plug socket.
3. VIDEO DISPLAY INTERFACE -
 - a) for a video monitor - check that a cable connects the monitor to the Apple's video output port.
 - b) for a standard television - check that an adapter (RF modulator) is plugged into the Apple II (either in the video output (K 14) or the video auxillary socket (J148), and that a cable runs between the television and the Adapter's output socket.
4. GAME PADDLE INTERFACE - if paddles are to be used, check that they are connected into the Game I/O connector (J14) on the right-hand side of the Apple II mainboard.
5. POWER ON - flip on the power switch in back of the Apple II, the "power" indicator on the keyboard will light. Also make sure the video monitor (or TV set) is turned on.

After the Apple II system has been powered up and the video display presents a random matrix of question marks or other text characters the following procedure can be followed to load a BASIC program tape:

1. Hit the RESET key.
An asterick, "*", should appear on the lefthand side of the screen below the random text pattern. A flashing white cursor will appear to the right of the asterick.
2. Hold down the CTRL key, depress and release the B key, then depress the "RETURN" key and release the "CTRL" key. A right facing arrow should appear on the lefthand side of the screen with a flashing cursor next to it. If it doesn't, repeat steps 1 and 2.
3. Type in the word "LOAD" on the keyboard. You should see the word in between the right facing arrow and the flashing cursor. Do not depress the "RETURN" key yet.
4. Insert the program cassette into the tape recorder and rewind it.
5. If not already set, adjust the Volume control to 50-70% maximum. If present, adjust the Tone control to 80-100% maximum.

6. Start the tape recorder in "PLAY" mode and now depress the "RETURN" key on the Apple II.
7. The cursor will disappear and Apple II will beep in a few seconds when it finds the beginning of the program. If an error message is flashed on the screen, proceed through the steps listed in the Tape Problem section of this paper.
8. A second beep will sound and the flashing cursor will reappear after the program has been successfully loaded into the computer.
9. Stop the tape recorder. You may want to rewind the program tape at this time.
10. Type in the word "RUN" and depress the "RETURN" key.

The steps in loading a program have been completed and if everything has gone satisfactorily the program will be operating now.

LOADING PROBLEMS

Occasionally, while attempting to load a BASIC program Apple II beeps and a memory full error is written on the screen. At this time you might wonder what is wrong with the computer, with the program tape, or with the cassette recorder. Stop. This is the time when you need to take a moment and checkout the system rather than haphazardly attempting to resolve the loading problem. Thoughtful action taken here will speed in a program's entry. If you were able to successfully turn on the computer, reset it, and place it into BASIC then the Apple II is probably operating correctly. Before describing a procedure for resolving this loading problem, a discussion of what a memory full error is in order.

The memory full error displayed upon loading a program indicates that not enough (RAM) memory workspace is available to contain the incoming data. How does the computer know this? Information contained in the beginning of the program tape declares the record length of the program. The computer reads this data first and checks it with the amount of free memory. If adequate workspace is available program loading continues. If not, the computer beeps to indicate a problem, displays a memory full error statement, stops the loading procedure, and returns command of the system to the keyboard. Several reasons emerge as the cause of this problem.

Memory Size too Small

Attempting to load a 16K program into a 4K Apple II will generate this kind of error message. It is called loading too large of a program. The solution is straight forward: only load appropriately sized programs into suitably sized systems.

Another possible reason for an error message is that the memory pointers which indicate the bounds of available memory have been preset to a smaller capacity. This could have happened through previous usage of the "HIMEN :" and "LOMEN :" statements. The solution is to reset the pointers by B^C (CTRL B) command. Hold the CTRL key down, depress and release the B key, then depress the RETURN key and release the CTRL key. This will reset the system to maximum capacity.

Cassette Recorder Inadjustment

If the Volume and Tone controls on the cassette recorder are not properly set a memory full error can occur. The solution is to adjust the Volume to 50-70% maximum and the Tone (if it exists) to 80-100% maximum.*

A second common recorder problem is skewed head azimuth. When the tape head is not exactly perpendicular to the edges of the magnetic tape some of the high frequency data on tape can be skipped. This causes missing bits in the data sent to the computer. Since the first data read is record length an error here could cause a memory full error to be generated because the length of the record is inaccurate. The solution: adjust tape head azimuth. It is recommended that a competent technician at a local stereo shop perform this operation.

Often times new cassette recorders will not need this adjustment.

*Apple Computer Inc. has tested many types of cassette recorders and so far the Panasonic RQ-309 DS (less than \$40.00) has an excellent track record for program loading.

Tape Problems

A memory full error can result from unintentional noise existing in a program tape. This can be the result of a program tape starting on its header which sometimes causes a glitch going from a nonmagnetic to magnetic recording surface and is interpreted by the computer as the record length. Or, the program tape can be defective due to false erasure, imperfections in the tape, or physical damage. The solution is to take a moment and listen to the tape. If any imperfections are heard then replacement of the tape is called for. Listening to the tape assures that you know what a "good" program tape sounds like. If you have any questions about this please contact your local dealer or Apple for assistance.

If noise or a glitch is heard at the beginning of a tape advance the tape to the start of the program and re-Load the tape.

Dealing with the Loading Problem

With the understanding of what a memory full error is an efficient way of dealing with program tape loading problems is to perform the following procedure:

1. Check the program tape for its memory requirements.
Be sure that you have a large enough system.

2. Before loading a program reset the memory pointers
with the B_C (control B) command.

3. In special cases have the tape head azimuth
checked and adjusted.

4. Check the program tape by listening to it.
 - a) Replace it if it is defective, or
 - b) start it at the beginning of the program.

5. Then re-LOAD the program tape into the Apple II.

In most cases if the preceeding is followed a good tape load will result.

UNSOLVED PROBLEMS

If you are having any unsolved loading problems, contact your nearest local dealer or Apple Computer Inc.

BREAKOUT GAME TAPE

PROGRAM DESCRIPTION

Breakout is a color graphics game for the Apple II computer. The object of the game is to "knock-out" all 160 colored bricks from the playing field by hitting them with the bouncing ball. You direct the ball by hitting it with a paddle on the left side of the screen. You control the paddle with one of the Apple's Game Paddle controllers. But watch out: you can only miss the ball five times!

There are eight columns of bricks. As you penetrate through the wall the point value of the bricks increases. A perfect game is 720 points; after five balls have been played the computer will display your score and a rating such as "Very Good", "Terrible!", etc. After ten hits of the ball, its speed will double, making the game more difficult. If you break through to the back wall, the ball will rebound back and forth, racking up points.

Breakout is a challenging game that tests your concentration, dexterity, and skill.

REQUIREMENTS

This program will fit into a 4K or greater system.

BASIC is the programming language used.

PLAYING BREAKOUT

1. Load Breakout game following instructions in the "Loading a BASIC Program from Tape" section of this manual.
2. Enter your name and depress RETURN key.
3. If you want standard BREAKOUT colors type in Y or Yes and hit RETURN. The game will then begin.
4. If the answer to the previous questions was N or No then the available colors will be displayed. The player will be asked to choose colors, represented by a number from 0 to 15, for background, even bricks, odd bricks, paddle and ball colors. After these have been chosen the game will begin.

5. At the end of the game you will be asked if they want to play again. A Y or Yes response will start another game. A N or No will exit from the program.

NOTE: A game paddle (150k ohm potentiometer) must be connected to PDL (0) of the Game I/O connector for this game.

COLOR DEMO TAPE

PROGRAM DESCRIPTION

COLOR DEMO demonstrates some of the Apple II video graphics capabilities. In it are ten examples: Lines, Cross, Weaving, Tunnel, Circle, Spiral, Tones, Spring, Hyperbola, and Color Bars. These examples produce various combinations of visual patterns in fifteen colors on a monitor or television screen. For example, Spiral combines colorgraphics with tones to produce some amusing patterns. Tones illustrates various sounds that you can produce with the two inch Apple speaker. These examples also demonstrate how the paddle inputs (PDL(X)) can be used to control the audio and visual displays. Ideas from this program can be incorporated into other programs with a little modification.

REQUIREMENTS

4K or greater Apple II system, color monitor or television, and paddles are needed to use this program. BASIC is the programming language used.

BREAKOUT GAME

PROGRAM LISTING

PROGRAM LISTING

```

5 GOTO 15
10 Q=( PDL (0)-20)/6: IF Q<0 THEN
  Q=0: IF Q>34 THEN Q=34: COLOR=R:
  VLIN Q,Q+5 AT 0: COLOR=R:
  IF P>Q THEN 175: IF Q THEN
    VLIN 0,0-1 AT 0:P=Q: RETURN

15 DIM A$(15),B$(10):A=1:B=13:
C=9:D=6:E=15: TEXT : CALL -
  936: VTAB 4: TAB 10: PRINT
  "*** BREAKOUT ***": PRINT
20 PRINT "      OBJECT IS TO DESTROY
      ALL BRICKS": PRINT : INPUT
  "HI, WHAT'S YOUR NAME? ",A$:

25 PRINT "STANDARD COLORS ";A$:
  ;: INPUT " Y/N? ",B$: GR : CRL
  -936: IF B$(1,1)>"N" THEN 40
  : FOR I=0 TO 39: COLOR=I/2*
  (I\32): VLIN 0,39 AT I
30 NEXT I: POKE 34,20: PRINT :
  PRINT : PRINT : FOR I=0 TO
  15: VTAB 21+I MOD 2: TAB I+
  I+1: PRINT I:; NEXT I: POKE
  34,20: VTAB 24: PRINT : PRINT
  "BACKGROUND":

35 GOSUB 95:A=E: PRINT "EVEN BRICK" '
  ;: GOSUB 95:B=E: PRINT "ODD BRIC
  K":; GOSUB 95:C=E: PRINT "PADDLE
  ";; GOSUB 95:D=E: PRINT "BALL"
  ;: GOSUB 95

40 POKE 34,20: COLOR=R: FOR I=
  0 TO 39: VLIN 0,39 AT I: NEXT
  I: FOR I=20 TO 34 STEP 2: TAB
  I+1: PRINT I/2-9:; COLOR=B:
  VLIN 0,39 AT I: COLOR=C: FOR
  J-I MOD 4 TO 39 STEP 4

45 VLIN J,J+1 AT I: NEXT J,I: TAB
  5: PRINT "SCORE = 0": PRINT
  : PRINT : POKE 34,21:I=5:P=
  S:L=S:X=19:Y=19:L=6
  50 COLOR=R: PLOT X,Y/3:X=19:Y=
  RND (120):Y=-1:W= RND (5)-
  2:L=L-1: IF L<1 THEN 120: TAB
  6: IF L>1 THEN PRINT L;" BALLS L
  EFT"
  55 IF L=1 THEN PRINT "LAST BALL, "
  ;A$: PRINT : FOR I=1 TO 100
  : GOSUB 10: NEXT I:N=1:N=0
  60 J=Y+W: IF J>0 AND J<120 THEN
  65:W=0:J=Y: FOR I=1 TO 6:K=
  PEEK (-16336): NEXT I
  65 I=X+V: IF I<0 THEN 180: GOSUB
  170: COLOR=R:K=J/3: IF I>39
  THEN 75: IF SCRNL(I,K)=R THEN
  85: IF I THEN 100:N=N+1:V=(
  N>5)+1:W=(K-P)*2-5:N=1
  70 Z= PEEK (-16336)- PEEK (-16336
  )+ PEEK (-16336)- PEEK (-16336
  )+ PEEK (-16336): GOTO 85
  75 FOR I=1 TO 6:N= PEEK (-16336
  ): NEXT I:I=X:N=0
  80 V=-V
  85 PLOT X,Y/3: COLOR=E: PLOT I,
  K:X=I:Y=J: GOTO 60
  90 PRINT "INVALID. REENTER":
  95 INPUT " COLOR (0 TO 15)",E:
  IF E<0 OR E>15 THEN 90: RETURN
  100 IF N THEN V= ABS (V): VLIN
  K/2*2,K/2*2+1 AT I:5=S+I/2-
  9: VTAB 21: TAB 13: PRINT S
  105 Q= PEEK (-16336)- PEEK (-16336
  )+ PEEK (-16336)- PEEK (-16336
  )+ PEEK (-16336)- PEEK (-16336
  )+ PEEK (-16336)- PEEK (-16336
  )
  110 IF S<20 THEN 80
  115 PRINT "CONGRATULATIONS, ";A$
  ;" YOU WIN!": GOTO 165
  120 PRINT "YOUR SCORE OF ";S;" IS "
  ;: GOTO 125*(S/100)+5
  125 PRINT "TERRIBLE!": GOTO 165

130 PRINT "LOUSY.": GOTO 165
  135 PRINT "POOR.": GOTO 165
  140 PRINT "FAIR.": GOTO 165
  145 PRINT "GOOD.": GOTO 165
  150 PRINT "VERY GOOD.": GOTO 165
  155 PRINT "EXCELLENT.": GOTO 165
  160 PRINT "NEARLY PERFECT."
  165 PRINT "ANOTHER GAME ";A$;" (Y/N)
  ;: INPUT A$: IF A$(1,1)!="Y"
  THEN 25: TEXT : CALL -936:
  VTAB 10: TAB 10: PRINT "GAME OV
  ER": END
  170 Q=( PDL (0)-20)/6: IF Q<0 THEN
  Q=0: IF Q>34 THEN Q=34: COLOR=
  D: VLIN 0,0+5 AT 0: COLOR=R:
  IF P>Q THEN 175: IF Q THEN
    VLIN 0,0-1 AT 0:P=Q: RETURN

  175 IF P=Q THEN RETURN : IF Q>34
  THEN VLIN Q+6,39 AT 0:P=Q:
  RETURN
  180 FOR I=1 TO 80:Q= PEEK (-16336
  ): NEXT I: GOTO 50

```

COLOR DEMO PROGRAM

LISTING

PROGRAM LISTING

```

10 DIM C(4): POKE 2,173: POKE
   3,48: POKE 4,192: POKE 5,165
   : POKE 6,0: POKE 7,32: POKE
   8,168: POKE 9,252: POKE 10,
   165: POKE 11,1: POKE 12,200
   300 J=J+1: J=J MOD 22+1: FOR I=1
      TO 1295: COLOR=I MOD J+7: PLOT
      (2*I) MOD 37,(3*I) MOD 35: NEXT
      I: GOSUB 10000: GOTO 300
   400 FOR I=1 TO 4:C(I)= RND (16)
      : NEXT I
   410 FOR I=3 TO 1 STEP -1:C(I+1)
      =C(I): NEXT I:C(1)= RND (16)
      : FOR I=1 TO 5: FOR J=1 TO
      4
   420 COLOR=C(J): L=J*5+14+I: K=39-
      L: HLIN K,L AT K: VLIN K,L AT
      L: HLIN K,L AT L: VLIN K,L AT
      K: NEXT J,I: GOSUB 10000: GOTO
      410
   500 Z=28: GOTO 900
   600 COLOR= RND (16): FOR I=0 TO
      18 STEP 2: J=39-I: HLIN I,J AT
      I: GOSUB 640: VLIN I,J AT J:
      GOSUB 640
   610 HLIN I+2,J AT J: GOSUB 640:
      VLIN I+2,J AT I+2: GOSUB 640
      : NEXT I
   620 COLOR= RND (16): FOR I=18 TO
      0 STEP -2: J=39-I: VLIN I+2,
      J AT I+2: GOSUB 640: HLIN I+
      2,J AT J: GOSUB 640
   630 VLIN I,J AT J: GOSUB 640: HLIN
      I,J AT I: GOSUB 640: NEXT I:
      GOSUB 10000: GOTO 600
   640 K=I+7:L=K*K*5+K*26+70:L=32767
      /L*( PDL (0)/10): POKE 0,K:
      POKE 1,L MOD 256: POKE 24,
      L/256+1: CALL 2: RETURN
   700 I= RND (30)*3: J=I*I*5+I*26+
      70: K=32767/J*( PDL (0)/10):
      POKE 0,I: POKE 1,K MOD 256
      : POKE 24,(K>255)+1: CALL 2
      : GOSUB 10000: GOTO 700
   800 X=3: A=1000: P=A:L=20: W=4: Y=0
      : J=1: COLOR=6: HLIN 0,39 RT
      4: COLOR=9: GOSUB 880: COLOR=
      12: VLIN 5,M-2 RT X
   810 N=2*A-P-A/W: COLOR=0: GOSUB
      880: VLIN 5,39 RT X:X=X+1: IF
      X<39 THEN 820:X=3: VLIN 5,39
      AT 1: VLIN 5,39 RT 2
   820 P=A: R=N: Y=A/100: COLOR=12: GOSUB
      880: COLOR=9: VLIN 5,M-2 RT
      X: COLOR=15: PLOT X-2,M: FOR
      I=0 TO J: NEXT I: GOSUB 10000
      : GOTO 810
   830 M=L-Y: L1=M-1: L2=M+1: VLIN L1,
      L2 AT X-1: VLIN L1,L2 AT X:
      VLIN L1,L2 AT X+1: RETURN
   900 I=I+1 MOD 15: FOR Y=0 TO 39
      : FOR X=0 TO 39: COLOR=I+( ABS
      (20-X)-Z)*( ABS (20-Y)-Z)/25
      : PLOT X,Y: NEXT X,Y: GOSUB
      10000: GOTO 900
   1000 CALL -936
   1010 J=I+J MOD 32: COLOR=J/2: VLIN
      0,39 RT 3+J: VTRB 21+(J/2) MOD
      2: TAB 3+J: IF J MOD 2 THEN
      PRINT J/2;; GOSUB 10000: GOTO
      1010
   2000 COLOR= RND (16): HLIN 0,39 AT
      J: COLOR= RND (16): VLIN 0,
      39 AT J: RETURN
   10000 IF PEEK (-16384)<128 THEN RETURN
      : POKE -16368,0: POP : GOTO
      30

```

-.-.-.-.-.-.- -.-.- -.-.-.-.-

THIS IS A SHORT DESCRIPTION OF HOW TO PLAY STARTREK ON THE
APPLE COMPUTER.

THE UNIVERSE IS MADE UP OF 64 QUADRANTS IN AN 8 BY 8 MATRIX.
THE QUADRANT IN WHICH YOU "THE ENTERPRISE" ARE, IS IN WHITE,
AND A BLOW UP OF THAT QUADRANT IS FOUND IN THE LOWER LEFT
CORNER. YOUR SPACE SHIP STATUS IS FOUND IN A TABLE TO
THE RIGHT SIDE OF THE QUADRANT BLOW UP.

THIS IS A SEARCH AND DESTROY MISSION. THE OBJECT IS TO LONG-RANGE
SENSE FOR INFORMATION AS TO WHERE KLINGONS (K) ARE, MOVE TO THAT QUADRANT,
AND DESTROY.

NUMBERS DISPLAYED FOR EACH QUADRANT DENOTE:

* OF STARS IN THE ONES PLACE

* OF BASES IN THE TENS PLACE

* OF KLINGONS IN THE HUNDREDS PLACE

AT ANY TIME DURING THE GAME, FOR INSTANCE BEFORE ONE TOTALLY
RUNS OUT OF ENERGY, OR NEEDS TO REGENERATE ALL SYSTEMS, ONE MOVES TO A
QUADRANT WHICH INCLUDES A BASE, IONS NEXT TO THAT BASE (B) AT WHICH TIME
THE BASE SELF-DESTRUCTS AND THE ENTERPRISE (E) HAS ALL SYSTEMS "GO"
AGAIN.

TO PLAY:

1. THE COMMANDS CAN BE OBTAINED BY TYPING A "0" (ZERO) AND RETURN.
THEY ARE:

- | | |
|---------------------------|-------------------|
| 1. PROPULSION | 2. REGENERATE |
| 3. LONG RANGE SENSORS | 4. PHASERS |
| 5. PHOTON TORPEDOES | 6. GALAXY RECORD |
| 7. COMPUTER | 8. FROB |
| 9. SHIELD ENERGY | 10. DAMAGE REPORT |
| 11. LOAD PHOTON TORPEDOES | |

2. THE COMMANDS ARE INVOKED BY TYPING THE NUMBER REFERING TO THEM
FOLLOWED BY A "RETURN".

A. IF RESPONSE IS 1 THE COMPUTER WILL ASK WARP OR ION AND
EXPECTS "W" IF ONE WANTS TO TRAVEL IN THE GALAXY
BETWEEN QUADRANTS AND AN "I" IF ONE WANTS ONLY
INTERNAL QUADRANT TRAVEL.
DURATION OR WARP FACTOR IS THE NUMBER OF SPACES OR
QUADRANTS THE ENTERPRISE WILL MOVE.
COURSE IS COMPASS READING IN DEGREES FOR THE DESI-
RED DESTINATION.

B. A 2 REGENERATES THE ENERGY AT THE EXPENSE OF TIME.
C. A 3 GIVES THE CONTENTS OF THE IMMEDIATE ADJACENT QUADRANTS.
THE GALAXY IS WRAP-AROUND IN ALL DIRECTIONS.
D. A 4 FIRES PHASERS AT THE EXPENSE OF AVAILABLE ENERGY.

E. 5 INITIATES A SET OF QUESTIONS FOR TORPEDO FIRING.
THEY CAN BE FIRED AUTOMATICALLY IF THEY HAVE
BEEN LOCKED ON TARGET WHILE IN THE COMPUTER
MODE, OR MAY BE FIRED MANUALLY IF THE TRAJECTORY ANGLE
IS KNOWN.

F. 6, 8 AND 10 ALL GIVE INFORMATION ABOUT THE STATUS OF THE SHIP
AND ITS ENVIRONMENT.

G. 9 SETS THE SHIELD ENERGY/AVAILABLE ENERGY RATIO.

H. 11 ASKS FOR INFORMATION ON LOADING AND UNLOADING OF
PHOTON TORPEDOES AT THE EXPENSE OF AVAILABLE ENERGY.
THE ANSWER SHOULD BE A SIGNED NUMBER. FOR EXAMPLE
+5 OR -2.

I. 7 ENTERS A COMPUTER WHICH WILL RESPOND TO THE FOLLOWING
INSTRUCTIONS:

- | | |
|--------------------------|---------------------------|
| 1. COMPUTE COURSE | 2. LOCK PHASERS |
| 3. LOCK PHOTON TORPEDOES | |
| 4. LOCK COURSE | 5. COMPUTE TRAJECTORY |
| 6. STATUS | 7. RETURN TO COMMAND MODE |

IN THE FIRST FIVE ONE WILL HAVE TO GIVE COORDINATES.
COORDINATES ARE GIVEN IN MATHEMATICAL NOTATION WITH
THE EXCEPTION THAT THE "Y" VALUE IS GIVEN FIRST.
AN EXAMPLE WOULD BE "Y,X".

COURSE OR TRAJECTORY:

0
!
!
!
270-----+-----90
!
!
180

-.-.-.-.- THIS EXPLANATION WAS WRITTEN BY ELWOOD -.-.-.-.-
NOT RESPONSIBLE FOR
ERRORS

LOADING THE HI-RES DEMO TAPE

PROCEDURE

1. Power up system - turn the AC power switch in the back of the Apple II on. You should see a random matrix of question marks and other text characters. If you don't, consult the operator's manual for system checkout procedures.
2. Hit the RESET key. On the left hand side of the screen you should see an asterisk and a flashing cursor next to it below the text matrix.
3. Insert the HI-RES demo tape into the cassette and rewind it. Check Volume (50-70%) and Tone (80-100%) settings.
4. Type in "C00.FFFR" on the Apple II keyboard. This is the address range of the high resolution machine language sub-program. It extends from \$C00 to \$FFF. The R tells the computer to read in the data. Do not depress the "RETURN" key yet.
5. Start the tape recorder in playback mode and depress the "RETURN" key. The flashing cursor disappears.
6. A beep will sound after the program has been read in. STOP the tape recorder. Do not rewind the program tape yet.
7. Hold down the "CTRL" key, depress and release the B key, then depress the "RETURN" key and release the "CTRL" key. You should see a right facing arrow and a flashing cursor. The BC command places the Apple into BASIC initializing the memory pointers.
8. Type in "LOAD", restart the tape recorder in playback mode and hit the "RETURN" key. The flashing cursor disappears. This begins the loading of the BASIC subprogram of the HI-RES demo tape.
9. A beep will sound to indicate the program is being loaded.

10. A second beep will sound, and the right facing arrow will reappear with the flashing cursor. STOP the tape recorder. Rewind the tape.
11. Type in "HIMEM:8192" and hit the "RETURN" key. This sets up memory for high resolution graphics.
12. Type in "RUN" and hit the "RETURN" key. The screen should clear and momentarily a HI-RES demo menu table should appear. The loading sequence is now completed.

SUMMARY OF HI-RES DEMO TAPE LOADING

1. RESET
2. Type in C00.FFFR
3. Start tape recorder, hit RETURN
4. Asterick or flashing cursor reappear
B^C (CTRL B) into BASIC
5. Type in "LOAD", hit RETURN
6. BASIC prompt (7) and flashing cursor reappear. Type in "HIMEN:8192", hit RETURN
7. Type in "RUN", hit RETURN
8. STOP tape recorder, rewind tape.

APPLE II INTEGER BASIC

1. BASIC Commands
2. BASIC Operators
3. BASIC Functions
4. BASIC Statements
5. Special Control and Editing
6. Table A — Graphics Colors
7. Special Controls and Features
8. BASIC Error Messages
9. Simplified Memory Map
10. Data Read/Save Subroutines
11. Simple Tone Subroutines
12. High Resolution Graphics
13. Additional BASIC Program Examples

BASIC COMMANDS

Commands are executed immediately; they do not require line numbers. Most Statements (see Basic Statements Section) may also be used as commands. Remember to press Return key after each command so that Apple knows that you have finished that line. Multiple commands (as opposed to statements) on same line separated by a " : " are NOT allowed.

COMMAND NAME

<u>AUTO</u> <i>num</i>	Sets automatic line numbering mode. Starts at line number <i>num</i> and increments line numbers by 10. To exit AUTO mode, type a control X*, then type the letters "MAN" and press the return key.
<u>AUTO</u> <i>num1, num2</i>	Same as above except increments line numbers by number <i>num2</i> .
<u>CLR</u>	Clears current BASIC variables; undimensions arrays. Program is unchanged.
<u>CON</u>	Continues program execution after a stop from a control C*. Does not change variables.
<u>DEL</u> <i>num1</i>	Deletes line number <i>num1</i> .
<u>DEL</u> <i>num1, num2</i>	Deletes program from line number <i>num1</i> through line number <i>num2</i> .
<u>DSP</u> <i>var</i>	Sets debug mode that will display variable <i>var</i> every time that it is changed along with the line number that caused the change. (NOTE: RUN command clears DSP mode so that DSP command is effective only if program is continued by a CON or GOTO command.)
<u>HIMEM:</u> <i>expr</i>	Sets highest memory location for use by BASIC at location specified by expression <i>expr</i> in decimal. HIMEM: may not be increased without destroying program. HIMEM: is automatically set at maximum RAM memory when BASIC is entered by a control B*.
<u>GOTO</u> <i>expr</i>	Causes immediate jump to line number specified by expression <i>expr</i> .
<u>GR</u>	Sets mixed color graphics display mode. Clears screen to black. Resets scrolling window. Displays 40x40 squares in 15 colors on top of screen and 4 lines of text at bottom.
<u>LIST</u>	Lists entire program on screen.
<u>LIST</u> <i>num1</i>	Lists program line number <i>num1</i> .
<u>LIST</u> <i>num1, num2</i>	Lists program line number <i>num1</i> through line number <i>num2</i> .

<u>LOAD</u> <i>expr.</i>	Reads (Loads) a BASIC program from cassette tape. Start tape recorder before hitting return key. Two beeps and a ">" indicate a good load. "ERR" or "MEM" FULL ERR message indicates a bad tape or poor recorder performance.
<u>LOMEM:</u> <i>expr</i>	Similar to HIMEM: except sets lowest memory location available to BASIC. Automatically set at 2048 when BASIC is entered with a control B*. Moving LOMEM: destroys current variable values.
<u>MAN</u>	Clears AUTO line numbering mode to all manual line numbering after a control C* or control X*.
<u>NEW</u>	Clears (Scratches) current BASIC program.
<u>NO DSP</u> <i>var</i>	Clears DSP mode for variable <i>var</i> .
<u>NO TRACE</u>	Clears TRACE mode.
<u>RUN</u>	Clears variables to zero, undimensions all arrays and executes program starting at lowest statement line number.
<u>RUN</u> <i>expr</i>	Clears variables and executes program starting at line number specified by expression <i>expr</i> .
<u>SAVE</u>	Stores (saves) a BASIC program on a cassette tape. Start tape recorder in record mode prior to hitting return key.
<u>TEXT</u>	Sets all text mode. Screen is formatted to display alpha-numeric characters on 24 lines of 40 characters each. TEXT resets scrolling window to maximum.
<u>TRACE</u>	Sets debug mode that displays line number of each statement as it is executed.

- * Control characters such as control X or control C are typed by holding down the CTRL key while typing the specified letter. This is similar to how one holds down the shift key to type capital letters. Control characters are NOT displayed on the screen but are accepted by the computer. For example, type several control G's. We will also use a superscript C to indicate a control character as in X^C.

BASIC Operators

<u>Symbol</u>	<u>Sample Statement</u>	<u>Explanation</u>
Prefix Operators		
()	10 X= 4*(5 + X)	Expressions within parenthesis () are always evaluated first.
+	20 X= 1+4*5	Optional; +1 times following expression.
-	30 ALPHA = -(BETA +2)	Negation of following expression.
NOT	40 IF A NOT B THEN 200	Logical Negation of following expression; 0 if expression is true (non-zero), 1 if expression is false (zero).

Arithmetic Operators

↑	60 Y = X↑3	Exponentiate as in X^3 . NOTE: ↑ is shifted letter N.
*	70 LET DOTS=A*B*N2	Multiplication. NOTE: Implied multiplication such as $(2 + 3)(4)$ is not allowed thus N2 in example is a variable not $N * 2$.
/	80 PRINT GAMMA/S	Divide
MOD	90 X = 12 MOD 7 100 X = X MOD(Y+2)	Modulo: Remainder after division of first expression by second expression.
+	110 P = L + G	Add
-	120 XY4 = H-D	Subtract
=	130 HEIGHT=15 140 LET SIZE=7*5 150 A(8) = 2 155 ALPHA\$ = "PLEASE"	Assignment operator; assigns a value to a variable. LET is optional

Relational and Logical Operators

The numeric values used in logical evaluation are "true" if non-zero, "false" if zero.

<u>Symbol</u>	<u>Sample Statement</u>	<u>Explanation</u>
=	160 IF D = E THEN 500	Expression "equals" expression.
=	170 IF A\$(1,1)= "Y" THEN 500	String variable "equals" string variable.
# or < >	180 IF ALPHA #X*Y THEN 500	Expression "does not equal" expression.
#	190 IF A\$ # "NO" THEN 500	String variable "does not equal" string variable. NOTE: If strings are not the same length, they are considered un-equal. < > not allowed with strings.
>	200 IF A>B THEN GO TO 50	Expression "is greater than" expression.
<	210 IF A+1<B-5 THEN 100	Expression "is less than" expression.
>=	220 IF A>=B THEN 100	Expression "is greater than or equal to" expression.
<=	230 IF A+1<=B-6 THEN 200	Expression "is less than or equal to" expression.
AND	240 IF A>B AND C<D THEN 200	Expression 1 "and" expression 2 must both be "true" for statements to be true.
OR	250 IF ALPHA OR BETA+1 THEN 200	If either expression 1 or expression 2 is "true", statement is "true".

BASIC FUNCTIONS

Functions return a numeric result. They may be used as expressions or as part of expressions. PRINT is used for examples only, other statements may be used. Expressions following function name must be enclosed between two parenthesis signs.

FUNCTION NAME

ABS (<i>expr</i>)	300 PRINT ABS(X)	Gives absolute value of the expression <i>expr</i> .
ASC (<i>str\$</i>)	310' PRINT ASC("BACK") 320 PRINT ASC(B\$) 330 PRINT ASC(B\$(4,4)) 335 PRINT ASC(B\$(Y))	Gives decimal ASCII value of designated string variable <i>str\$</i> . If more than one character is in designated string or sub-string, it gives decimal ASCII value of first character.
LEN (<i>str\$</i>)	340 PRINT LEN(B\$)	Gives current length of designated string variable <i>str\$</i> ; i.e., number of characters.
PDL (<i>expr</i>)	350 PRINT PDL(X)	Gives number between 0 and 255 corresponding to paddle position on game paddle number designated by expression <i>expr</i> and must be legal paddle (0,1,2,or 3) or else 255 is returned.
PEEK (<i>expr</i>)	360 PRINT PEEK(X)	Gives the decimal value of number stored of decimal memory location specified by expression <i>expr</i> . For MEMORY locations above 32676, use negative number; i.e., HEX location FFF0 is -16
RND (<i>expr</i>)	370 PRINT RND(X)	Gives random number between 0 and (expression <i>expr</i> -1) if expression <i>expr</i> is positive; if minus, it gives random number between 0 and (expression <i>expr</i> +1).
SCRN(<i>expr1</i> , <i>expr2</i>)	380 PRINT SCRN (X1,Y1)	Gives color (number between 0 and 15) of screen at horizontal location designated by expression <i>expr1</i> and vertical location designated by expression <i>expr2</i> . Range of expression <i>expr1</i> is 0 to 39. Range of expression <i>expr2</i> is 0 to 39 if in standard mixed colorgraphics display mode as set by GR command or 0 to 47 if in all color mode set by POKE -16304 ,0: POKE - 16302,0.
SGN (<i>expr</i>)	390 PRINT SGN(X)	Gives sign (not sine) of expression <i>expr</i> i.e., -1 if expression <i>expr</i> is negative, zero if <i>expr</i> is zero and +1 if <i>expr</i> is positive.

BASIC STATEMENTS

Each BASIC statement must have a line number between 0 and 32767. Variable names must start with an alpha character and may be any number of alphanumeric characters up to 100. Variable names may not contain buried any of the following words: AND, AT, MOD, OR, STEP, or THEN. Variable names may not begin with the letters END, LET, or REM. String variables names must end with a \$ (dollar sign). Multiple statements may appear under the same line number if separated by a : (colon) as long as the total number of characters in the line (including spaces) is less than approximately 150 characters. Most statements may also be used as commands. BASIC statements are executed by RUN or GOTO commands.

NAME

<u>CALL</u> <i>expr</i>	10 CALL-936	Causes execution of a machine level language subroutine at <u>decimal</u> memory location specified by expression <i>expr</i> . Locations above 32767 are specified using negative numbers; i.e., location in example 10 is hexadecimal number \$FC53
<u>COLOR=</u> <i>expr</i>	30 COLOR=12	In standard resolution color (GR) graphics mode, this command sets screen TV color to value in expression <i>expr</i> in the range 0 to 15 as described in Table A. Actually expression <i>expr</i> may be in the range 0 to 255 without error message since it is implemented as if it were expression <i>expr</i> MOD 16.
DIM <i>var1</i> (<i>expr1</i>) <i>str\$</i> (<i>expr2</i>) <i>var2</i> (<i>expr3</i>)	50 DIM A(20),B(10) 60 DIM B\$(30) 70 DIM C (2) Illegal: 80 DIM A(30) Legal: 85 DIM C(1000)	The DIM statement causes APPLE II to reserve memory for the specified variables. For number arrays APPLE reserves approximately 2 times <i>expr</i> bytes of memory limited by available memory. For string arrays - <i>str\$</i> (<i>expr</i>) must be in the range of 1 to 255. Last defined variable may be redimensioned at any time; thus, example in line is illegal but 85 is allowed.
<u>DSP</u> <i>var</i>	Legal: 90 DSP AX: DSP L Illegal: 100 DSP AX,B 102 DSP AB\$ 104 DSP A(5) Legal: 105 A=A(5): DSP A	Sets debug mode that DSP variable <i>var</i> each time it changes and the line number where the change occurred.

<u>NAME</u>	<u>EXAMPLE</u>	<u>DESCRIPTION</u>
<u>END</u>	110 END	Stops program execution. Sends carriage return and "> " BASIC prompt) to screen.
<u>FOR</u> <i>var</i> = <i>expr1</i> TO <i>expr2</i> STEP <i>expr3</i>	110 FOR L=0 to 39 120 FOR X=Y1 TO Y3 130 FOR I=39 TO 1 150 GOSUB 100 *J2	Begins FOR...NEXT loop, initializes variable <i>var</i> to value of expression <i>expr1</i> then increments it by amount in expression <i>expr3</i> each time the corresponding "NEXT" statement is encountered, until value of expression <i>expr2</i> is reached. If STEP <i>expr3</i> is omitted, a STEP of +1 is assumed. Negative numbers are allowed.
<u>GOSUB</u> <i>expr</i>	140 GOSUB 500	Causes branch to BASIC subroutine starting at legal line number specified by expression <i>expr</i> . Subroutines may be nested up to 16 levels.
<u>GOTO</u> <i>expr</i>	160 GOTO 200 170 GOTO ALPHA+100	Causes immediate jump to legal line number specified by expression <i>expr</i> .
<u>GR</u>	180 GR 190 GR: POKE -16302,0	Sets mixed standard resolution color graphics mode. Initializes COLOR = 0 (Black) for top 40x40 of screen and sets scrolling window to lines 21 through 24 by 40 characters for four lines of text at bottom of screen. Example 190 sets all color mode (40x48 field) with no text at bottom of screen.
<u>HLIN</u> <i>expr1</i> , <i>expr2</i> AT <i>expr3</i>	200 HLIN 0,39 AT 20 210 HLIN Z,Z+6 AT I	In standard resolution color graphics mode, this command draws a horizontal line of a predefined color (set by COLOR=) starting at horizontal position defined by expression <i>expr1</i> and ending at position <i>expr2</i> at vertical position defined by expression <i>expr3</i> . <i>expr1</i> and <i>expr2</i> must be in the range of 0 to 39 and <i>expr1</i> < = <i>expr2</i> . <i>expr3</i> be in the range of 0 to 39 (or 0 to 47 if not in mixed mode).

Note: HLIN 0, 19 AT 0 is a horizontal line at the top of the screen extending from left corner to center of screen and HLIN 20,39 AT 39 is a horizontal line at the bottom of the screen extending from center to right corner.

IF *expression* 220 IF A > B THEN
THEN *statement* PRINT A
 230 IF X=0 THEN C=1
 240 IF A#10 THEN
 GOSUB 200
 250 IF A\$(1,1) # "Y"
 THEN 100
Illegal:
 260 IF L > 5 THEN 50:
 ELSE 60
Legal:
 270 IF L > 5 THEN 50
 GO TO 60

If *expression* is true (non-zero) then execute *statement*; if false do not execute *statement*. If *statement* is an expression, then a GOTO *expr* type of statement is assumed to be implied. The "ELSE" in example 260 is illegal but may be implemented as shown in example 270.

INPUT *var1,*
var2, str\$ 280 INPUT X,Y,Z(3)
 290 INPUT "AMT",
 DLLR
 300 INPUT "Y or N?", A\$

Enters data into memory from I/O device. If number input is expected, APPLE will output "?"; if string input is expected no "?" will be outputted. Multiple numeric inputs to same statement may be separated by a comma or a carriage return. String inputs must be separated by a carriage return only. One pair of " " may be used immediately after INPUT to output prompting text enclosed within the quotation marks to the screen.

IN# *expr* 310 IN# 6
 320 IN# Y+2
 330 IN# 0

Transfers source of data for subsequent INPUT statements to peripheral I/O slot (1-7) as specified as by expression *expr*. Slot 0 is not addressable from BASIC. IN#0 (Example 330) is used to return data source from peripheral I/O to keyboard connector.

LET 340 LET X=5

Assignment operator. "LET" is optional

LIST *num1,*
num2 350 IF X > 6 THEN
 LIST 50

Causes program from line number *num1* through line number *num2* to be displayed on screen.

NEXT *var1,*
var2 360 NEXT I
 370 NEXT J,K

Increments corresponding "FOR" variable and loops back to statement following "FOR" until variable exceeds limit.

NO DSP *var* 380 NO DSP I

Turns-off DSP debug mode for variable

NO TRACE 390 NO TRACE

Turns-off TRACE debug mode

<u>PLOT</u> , <i>expr1, expr2</i>	400 PLOT 15, 25 400 PLT XV,YV	In standard resolution color graphics, this command plots a small square of a predefined color (set by COLOR=) at horizontal location specified by expression <i>expr1</i> in range 0 to 39 and vertical location specified by expression <i>expr2</i> in range 0 to 39 (or 0 to 47 if in all graphics mode) NOTE: PLOT 0 0 is upper left and PLOT 39, 39 (or PLOT 39, 47) is lower right corner.
<u>POKE</u> <i>expr1, expr2</i>	420 POKE 20, 40 430 POKE 7*256, XMOD255	Stores <u>decimal</u> number defined by expression <i>expr2</i> in range of 0 255 at <u>decimal</u> memory location specified by expression <i>expr1</i> . Locations above 32767 are specified by negative numbers.
<u>POP</u>	440 POP	"POPS" nested GOSUB return stack address by one.
<u>PRINT</u> <i>var1, var, str\$</i>	450 PRINT L1 460 PRINT L1, X2 470 PRINT "AMT=";DX 480 PRINT A\$;B\$; 490 PRINT 492 PRINT "HELLO" 494 PRINT 2+3	Outputs data specified by variable <i>var</i> or string variable <i>str\$</i> starting at current cursor location. If there is not trailing "," or ";" (Ex 450) a carriage return will be generated. Commas (Ex. 460) outputs data in 5 left justified columns. Semi-colon (Ex. 470) inhibits print of any spaces. Text imbedded in " " will be printed and may appear multiple times.
<u>PR#</u> <i>expr</i>	500 PR# 7	Like IN#, transfers output to I/O slot defined by expression <i>expr</i> . PR# 0 is video output not I/O slot 0.
<u>REM</u>	510 REM REMARK	No action. All characters after REM are treated as a remark until terminated by a carriage return.
<u>RETURN</u>	520 RETURN 530 IFX= 5 THEN RETURN	Causes branch to statement following last GOSUB; i.e., RETURN ends a subroutine. Do not confuse "RETURN" statement with Return key on keyboard.

<u>TAB</u> <i>expr</i>	530 TAB 24 540 TAB I+24 550 IF A#B THEN TAB 20	Moves cursor to absolute horizontal position specified by expression <i>expr</i> in the range of 1 to 40. Position is left to right
<u>TEXT</u>	550 TEXT 560 TEXT: CALL-936	Sets all text mode. Resets scrolling window to 24 lines by 40 characters. Example 560 also clears screen and homes cursor to upper left corner
<u>TRACE</u>	570 TRACE 580 IFN > 32000 THEN TRACE	Sets debug mode that displays each line number as it is executed.
<u>VLIN</u> <i>expr1</i> , <i>expr2</i> AT <i>expr3</i>	590 VLIN 0, 39AT15 600 VLIN Z,Z+6ATY	Similar to HLIN except draws vertical line starting at <i>expr1</i> and ending at <i>expr2</i> at horizontal position <i>expr3</i> .
<u>VTAB</u> <i>expr</i>	610 VTAB 18 620 VTAB Z+2	Similar to TAB. Moves cursor to absolute vertical position specified by expression <i>expr</i> in the range 1 to 24. VTAB 1 is top line on screen; VTAB24 is bottom.

SPECIAL CONTROL AND EDITING CHARACTERS

"Control" characters are indicated by a super-scripted "C" such as G^C. They are obtained by holding down the CTRL key while typing the specified letter. Control characters are NOT displayed on the TV screen. B^C and C must be followed by a carriage return. Screen editing characters are indicated by a sub-scripted "E" such as D_E. They are obtained by pressing and releasing the ESC key then typing specified letter. Edit characters send information only to display screen and does not send data to memory. For example, UC moves to cursor to right and copies text while AE moves cursor to right but does not copy text.

<u>CHARACTER</u>	<u>DESCRIPTION OF ACTION</u>
RESET key	Immediately interrupts any program execution and resets computer. Also sets all text mode with scrolling window at maximum. Control is transferred to System Monitor and Apple prompts with a "*" (asterisk) and a bell. Hitting RESET key does NOT destroy existing BASIC or machine language program.
Control B	If in System Monitor (as indicated by a "*"), a control B and a carriage return will transfer control to BASIC, <u>scratching (killing) any existing BASIC program and set HIMEM: to maximum installed user memory and LOMEM: to 2048.</u>
Control C	If in BASIC, halts program and displays line number where stop occurred*. Program may be continued with a CON command. If in <u>System Monitor</u> , (as indicated by "*"), control C and a carriage return will enter BASIC <u>without killing current program.</u>
Control G	Sounds bell (beeps speaker)
Control H	Backspaces cursor and deletes any overwritten characters from computer but not from screen. Apply supplied keyboards have special key " <u>←</u> " on right side of keyboard that provides this functions without using control button.
Control J	Issues line feed only
Control V	Compliment to H ^C . Forward spaces cursor and copies over written characters. Apple keyboards have " <u>→</u> " key on right side which also performs this function.
Control X	Immediately deletes current line.

* If BASIC program is expecting keyboard input, you will have to hit carriage return key after typing control C.

<u>CHARACTER</u>	<u>DESCRIPTION OF ACTION</u>
A _E	Move cursor to right
B _E	Move cursor to left
C _E	Move cursor down
D _E	Move cursor up
E _E	Clear text from cursor to end of line
F _E	Clear text from cursor to end of page
@ _E	Home cursor to top of page, clear text to end of page.

Table A: APPLE II COLORS AS SET BY COLOR =

Note: Colors may vary depending on TV tint (hue) setting and may also be changed by adjusting trimmer capacitor C3 on APPLE II P.C. Board.

0 = Black	8 = Brown
1 = Magenta	9 = Orange
2 = Dark Blue	10 = Grey
3 = Light Purple	11 = Pink
4 = Dark Green	12 = Green
5 = Grey	13 = Yellow
6 = Medium Blue	14 = Blue/Green
7 = Light Blue	15 = White

Special Controls and Features

<u>Hex</u>	<u>BASIC Example</u>	<u>Description</u>
Display Mode Controls		
C050	10 POKE -16304,0	Set color graphics mode
C051	20 POKE -16303,0	Set text mode
C052	30 POKE -16302,0	Clear mixed graphics
C053	40 POKE -16301,0	Set mixed graphics (4 lines text)
C054	50 POKE -16300,0	Clear display Page 2 (BASIC commands use Page 1 only)
C055	60 POKE -16299,0	Set display to Page 2 (alternate)
C056	70 POKE -16298,0	Clear HIRES graphics mode
C057	80 POKE -16297,0	Set HIRES graphics mode
TEXT Mode Controls		
0020	90 POKE 32,L1	Set left side of scrolling window to location specified by L1 in range of 0 to 39.
0021	100 POKE 33,W1	Set window width to amount specified by W1. L1+W1<40. W1>0
0022	110 POKE 34,T1	Set window top to line specified by T1 in range of 0 to 23
0023	120 POKE 35,B1	Set window bottom to line specified by B1 in the range of 0 to 23. B1>T1
0024	130 CH=PEEK(36) 140 POKE 36,CH 150 TAB(CH+1)	Read/set cursor horizontal position in the range of 0 to 39. If using TAB, you must add "1" to cursor position read value; Ex. 140 and 150 perform identical function.
0025	160 CV=PEEK(37) 170 POKE 37,CV 180 VTAB(CV+1)	Similar to above. Read/set cursor vertical position in the range 0 to 23.
0032	190 POKE 50,127 200 POKE 50,255	Set inverse flag if 127 (Ex. 190) Set normal flag if 255 (Ex. 200)
FC58	210 CALL -936	(@E) Home cursor, clear screen
FC42	220 CALL -958	(F_E) Clear from cursor to end of page

<u>Hex</u>	<u>BASIC Example</u>	<u>Description</u>
FC9C	23Ø CALL -868	(E _E) Clear from cursor to end of line
FC66	24Ø CALL -922	(J ^C) Line feed
FC7Ø	25Ø CALL -912	Scroll up text one line


Miscellaneous

CØ3Ø	36Ø X=PEEK(-16336) 365 POKE -16336,Ø	Toggle speaker
CØØØ	37Ø X=PEEK(-16384)	Read keyboard; if X>127 then key was pressed.
CØ1Ø	38Ø POKE -16368,Ø	Clear keyboard strobe - always after reading keyboard.
CØ61	39Ø X=PEEK(16287)	Read PDL(Ø) push button switch. If X>127 then switch is "on".
CØ62	4ØØ X=PEEK(-16286)	Read PDL(1) push button switch.
CØ63	41Ø X=PEEK(-16285)	Read PDL(2) push button switch.
CØ58	42Ø POKE -16296,Ø	Clear Game I/O ANØ output
CØ59	43Ø POKE -16295,Ø	Set Game I/O ANØ output
CØ5A	44Ø POKE -16294,Ø	Clear Game I/O AN1 output
CØ5B	45Ø POKE -16293,Ø	Set Game I/O AN1 output
CØ5C	46Ø POKE -16292,Ø	Clear Game I/O AN2 output
CØ5D	47Ø POKE -16291,Ø	Set Game I/O AN2 output
CØ5E	48Ø POKE -16290,Ø	Clear Game I/O AN3 output
CØ5F	49Ø POKE -16289,Ø	Set Game I/O AN3 output

APPLE II BASIC ERROR MESSAGES

*** SYNTAX ERR	Results from a syntactic or typing error.
*** > 32767 ERR	A value entered or calculated was less than -32767 or greater than 32767.
*** > 255 ERR	A value restricted to the range 0 to 255 was outside that range.
*** BAD BRANCH ERR	Results from an attempt to branch to a non-existent line number.
*** BAD RETURN ERR	Results from an attempt to execute more RETURNS than previously executed GOSUBs.
*** BAD NEXT ERR	Results from an attempt to execute a NEXT statement for which there was not a corresponding FOR statement.
*** 16 GOSUBS ERR	Results from more than 16 nested GOSUBs.
*** 16 FORS ERR	Results from more than 16 nested FOR loops.
*** NO END ERR	The last statement executed was not an END.
*** MEM FULL ERR	The memory needed for the program has exceeded the memory size allotted.
*** TOO LONG ERR	Results from more than 12 nested parentheses or more than 128 characters in input line.
*** DIM ERR	Results from an attempt to DIMension a string array which has been previously dimensioned.
*** RANGE ERR	An array was larger than the DIMensioned value or smaller than 1 or HLIN,VLIN, PLOT, TAB, or VTAB arguments are out of range.
*** STR OVFL ERR	The number of characters assigned to a string exceeded the DIMensioned value for that string.
*** STRING ERR	Results from an attempt to execute an illegal string operation.
RETYPE LINE	Results from illegal data being typed in response to an INPUT statement. This message also requests that the illegal item be retyped.

Simplified Memory Map



READ/SAVE DATA SUBROUTINE

INTRODUCTION

Valuable data can be generated on the Apple II computer and sometimes it is useful to have a software routine that will allow making a permanent record of this information. This paper discusses a simple subroutine that serves this purpose.

Before discussing the Read/Save routines a rudimentary knowledge of how variables are mapped into memory is needed.

Numeric variables are mapped into memory with four attributes. Appearing in order sequentially are the Variable Name, the Display Byte, the Next Variable Address, and the Data of the Variable. Diagrammatically this is represented as:

VN	DSP	NVA	DATA(0)	DATA(1) . . .	DATA(N)
1			h_1	h_2	h_{n+1}

VARIABLE NAME - up to 100 characters represented in memory as ASCII equivalents with the high order bit set.

DSP (DISPLAY) BYTE - set to $\emptyset 1$ when DSP set in BASIC initiates a process that displays this variable with the line number every time it is changed within a program.

NVA (NEXT VARIABLE ADDRESS) - two bytes (first low order, the second high order) indicating the memory location of the next variable.

DATA - hexadecimal equivalent of numeric information, represented in pairs of bytes, low order byte first.

String variables are formatted a bit differently than numeric ones. These variables have one extra attribute - a string terminator which designates the end of a string. A string variable is formatted as follows:

VN	DSP	NVA	DATA(0)	DATA(1), ...	DATA(n)	ST
1			h_1	h_2		h_{n+1}

VARIABLE NAME - up to 100 characters represented in memory as ASCII equivalents with the high order bit set.

DSP (DISPLAY) BYTE - set to 01 when DSP set in BASIC, initiates a process that displays this variable with the line number every time it is changed within a program.

NVA (NEXT VARIABLE ADDRESS) - two bytes (first low order, the second high order) indicating the memory location of the next variable.

DATA - ASCII equivalents with high order bit set.

STRING TERMINATOR (ST) - none high order bit set character indicating END of string.

There are two parts of any BASIC program represented in memory. One is the location of the variables used for the program, and the other is the actual BASIC program statements. As it turns out, the mapping of these within memory is a straightforward process. Program statements are placed into memory starting at the top of RAM memory* unless manually shifted by the "HIMEM:" command, and are pushed down as each new (numerically larger) line numbered statement is entered into the system. Figure 1a illustrates this process diagrammatically. Variables on the other hand are mapped into memory starting at the lowest position of RAM memory - hex \$800 (2048) unless manually shifted by the "LOMEM :" command. They are laid down from there (see Figure 1b) and continue until all the variables have been mapped into memory or until they collide with the program statements. In the event of the latter case a memory full error will be generated

*Top of RAM memory is a function of the amount of memory. 16384 will be the value of "HIMEM:" for a 16K system.

The computer keeps track of the amount of memory used for the variable table and program statements. By placing the end memory location of each into \$CC-CD(204-205) and \$CA-CB(203-204), respectively. These are the BASIC memory program pointers and their values can be found by using the statements in Figure 2. CM defined in Figure 1 as the location of the end of the variable tape is equal to the number resulting from statement a of Figure 2. PP, the program pointer, is equal to the value resulting from statement 2b. These statements(Figure 2) can then be used on any Apple II computer to find the limits of the program and variable table.

FINDING THE VARIABLE TABLE FROM BASIC

First, power up the Apple II, reset it, and use the CTRL B (control B) command to place the system into BASIC initializing the memory pointers. Using the statements from Figure 2 it is found that for a 16K Apple II CM is equal to 2048 and PP is equal to 16384. These also happen to be the values of LOMEN and HIMEN: But this is expected because upon using the B^C command both memory pointers are initialized indicating no program statements and no variables.

To illustrate what a variable table looks like in Apple II memory suppose we want to assign the numeric variable A (\$C1 is the ASCII equivalent of a with the high order bit set) the value of -1 (FF FF in hex) and then examine the memory contents. The steps in this process are outlined in example I. Variable A is defined as equal to -1 (step 1). Then for convenience another variable - B - is defined as equal to 0 (step 2). Now that the variable table has been defined use of statement 2a indicates that CM is equal to 2060 (step 3). LOMEN has not been readjusted so it is equal to 2048. Therefore the variable table resides in memory from 2048 (\$800 hex) to 2060 (\$80C). Depressing the "RESET" key places the Apple II into the monitor mode (step 4).

We are now ready to examine the memory contents of the variable table. Since the variable table resides from \$800 hex to \$80C hex typing in "800.80C" and then depressing the "RETURN" key (step 5) will list the memory contents of this range. Figure 3 lists the contents with each memory location labelled. Examining these contents we see that C1 is equal to the variable name and is the memory equivalent of "A" and that FF FF is the equivalent of -1. From this, since the variable name is at the beginning of the table and the data is at the end, the variable table representation of A extends from \$800 to \$805. We have then found

the memory range of where the variable A is mapped into memory. The reason for this will become clear in the next section.

READ/SAVE ROUTINE

The READ/SAVE subroutine has three parts. The first section (lines 0-10) defines variable A and transfers control to the main program. Lines 20 through 26 represents the Write data to tape routine and lines 30-38 represent the Read data from tape subroutine. Both READ and SAVE routines are executable by the BASIC "GOSUB X" (where X is 20 for write and 30 is for read) command. And as listed these routines can be directly incorporated into almost any BASIC program for read and saving a variable table. The limitation of these routines is that the whole part of a variable table is processed so it is necessary to maintain exactly the dimension statements for the variables used.

The variables used in this subroutine are defined as follows:

A = record length, must be the first variable defined
CM= the value obtained from statement a of figure 2
LM= is equal to the value of "LOMEM:"
Nominally 2048

SAVING A DATA TABLE

The first step in a hard copy routine is to place the desired data onto tape. This is accomplished by determining the length of the variable table and setting A equal to it. Next within the main program when it is time to write the data a GOSUB20 statement will execute the write to tape process. Record length, variable A, is written to tape first (line 22) followed by the desired data (line 24). When this process is completed control is returned to the main program.

READING A DATA TABLE

The second step is to read the data from tape. When it is time a GOSUB30 statement will initiate the read process. First, the record length is read in and checked to see if enough memory is available (line 32-34). If exactly the same dimension statements are used it is almost guaranteed that there will be enough memory available. After this the variable table is read in (line 34) and control is then returned to the main program (line 36). If not enough memory is available then an error is generated and control is returned to the main program (line 38)

EXAMPLE OF READ/SAVE USAGE

The Read/Save routines may be incorporated directly into a main program. To illustrate this a test program is listed in example 2. This program dimensions a variable array of twenty by one, fills the array with numbers, writes the data table to tape, and then reads the data from tape listing the data on the video display. To get a feeling for how to use these routines enter this program and explore how the Read/Save routines work.

CONCLUSION

Reading and Saving data in the format of a variable table is a relatively straight forward process with the Read/Save subroutine listed in figure 4. This routine will increase the flexibility of the Apple II by providing a permanent record of the data generated within a program. This program can be reprocessed. The Read/Save routines are a valuable addition to any data processing program.




Figure 1

a) PRINT PEEK(204) + PEEK(205)*256 → PP

b) PRINT PEEK(202) + PEEK(203)*256 → CM

Figure 2




Figure 3
\$800..80C rewritten with labelling

FIGURE 4b

READ/SAVE PROGRAM	COMMENTS
0 A=0	This must be the first statement in the program. It is initially 0, but if data is to be saved, it will equal the length of the data base.
10 GOTO 100	This statement moves command to the main program.
20 PRINT "REWIND TAPE THEN START TAPE RECORDER": INPUT "THEN HIT RETURN", B\$	Lines 20-26 are the write data to tape subroutine.
22 A=CM-LM: POKE 60,4: POKE 61,8: POKE 62,5: POKE 63,8: CALL -307	
24 POKE 60,LM MOD 256: POKE 61, LM/256: POKE 62, CM MOD 256: POKE 63, CM/256: CALL -307	Writing data table to tape
26 PRINT "DATA TABLE SAVED": RETURN	Returning control to main program.
30 PRINT "REWIND THE TAPE THEN START TAPE RECORDER": INPUT "AND HIT RETURN", B\$	Lines 30-38 are the READ data from tape subroutine.
32 POKE 60,4: POKE 61,8: POKE 62,5: POKE 63,8: CALL -259	
34 IF A<0 THEN 38: P=LM+A: IF P>HM THEN 38: CM=P: POKE 60, LM MOD 256: POKE 61, LM/256: POKE 62, CM MOD 256: POKE 63, CM/256: CALL -259	Checking the record length (A) for memory requirements if everything is satisfactory the data is READ in.
36 PRINT "DATA READ IN": RETURN	
38 PRINT "***TOO MUCH DATA BASE***": RETURN	Returning control to main program.

NOTE: CM, LM and A must be defined within the main program.

1 >A=1	Define variable A=-1, then hit RETURN
>	
2 >B=Ø	Define variable B=Ø, then hit RETURN
>	
3 >PRINT PEEK (204) + PEEK (205) * 256	Use statement 2a to find the end of the VARIABLE TABLE
computer responds with= 2Ø6Ø	
4 > *	Hit the RESET key, Apple moves into Monitor mode.
5 *8ØØ.8ØC	Type in VARIABLE TABLE RANGE and HIT the RETURN KEY.

Computer responds with:

Ø8ØØ- C1 ØØ 86 Ø8 FF FF C2 ØØ

Ø8Ø8 ØC Ø8 ØØ ØØ ØØ

Example 1

Example 2

```
>LIST  
0 R=0  
10 GOTO 100  
20 REM WRITE DATA TO TAPE ROUTINE  
22 R=CH-LM: POKE 60,4: POKE 61  
,8: POKE 62,5: POKE 63,8: CALL  
-387  
24 POKE 60,LM MOD 256: POKE 61  
,LM/256: POKE 62,CH MOD 256  
: POKE 63,CH/256: CALL -387  
  
26 RETURN  
30 REM READ DATA SUBROUTINE  
32 POKE 60,4: POKE 61,8: POKE  
62,5: POKE 63,8: CALL -259  
34 IF R<0 THEN 38:P=LM+R: IF P>  
HM THEN 38:CH=P: POKE 60,LM MOD  
256: POKE 61,LM/256: POKE 62  
,CH MOD 256: POKE 63,CH/256  
: CALL -259  
36 RETURN  
38 PRINT "*** TOO MUCH DATA BASE **  
**": END  
100 DIM R$(1),X(20)  
105 FOR I=1 TO 20:X(I)=I: NEXT  
I  
108 LM=2048:CH=2106:R=58:HM=16383  
  
110 PRINT "20 NUMBERS GENERATED"  
  
120 PRINT "NOW WE ARE GOING TO SAVE  
THE DATA": PRINT "WHEN YOU ARE R  
EADY START THE RECORDER IN RECOR  
D MODE": INPUT "AND HIT RETURN"  
,R$  
130 CALL -936: PRINT "NOW WRITING DA  
TA TO TAPE": GOSUB 28  
135 PRINT "NOW THE DATA IS SAVED"  
  
140 PRINT "NOW WE ARE GOING TO CLEAR  
THE X(20) TABLE AND READ THE DA  
TA FROM TAPE"  
150 FOR I=1 TO 20:X(I)=0: PRINT  
"X(";I;")= ";X(I): NEXT I  
160 PRINT "NOW START TAPE RECORDER"  
: INPUT "AND THEN HIT RETURN"  
,R$  
165 PRINT "A ",A  
170 GOSUB 30  
180 PRINT "ALL THE DATA READ IN"  
  
190 FOR I=1 TO 20: PRINT "X ",I;  
")= ";X(I): NEXT I  
195 PRINT "THIS IS THE END"  
200 END
```

A SIMPLE TONE SUBROUTINE

INTRODUCTION

Computers can perform marvelous feats of mathematical computation at well beyond the speed capable of most human minds. They are fast, cold and accurate; man on the other hand is slower, has emotion, and makes errors. These differences create problems when the two interact with one another. So to reduce this problem humanizing of the computer is needed. Humanizing means incorporating within the computer procedures that aid in a program's usage. One such technique is the addition of a tone subroutine. This paper discusses the incorporation and usage of a tone subroutine within the Apple II computer.

Tone Generation

To generate tones in a computer three things are needed: a speaker, a circuit to drive the speaker, and a means of triggering the circuit. As it happens the Apple II computer was designed with a two-inch speaker and an efficient speaker driving circuit. Control of the speaker is accomplished through software.

Toggling the speaker is a simple process, a mere PEEK - 16336 (\$C030) in BASIC statement will perform this operation. This does not, however, produce tones, it only emits clicks. Generation of tones is the goal, so describing frequency and duration is needed. This is accomplished by toggling the speaker at regular intervals for a fixed period of time. Figure 1 lists a machine language routine that satisfies these requirements.

Machine Language Program

This machine language program resides in page 0 of memory from \$02 (2) to \$14 (20). \$00 (00) is used to store the relative period (P) between toggling of the speaker and \$01 (01) is used as the memory location for the value of relative duration (D). Both P and D can range in value from \$00 (0) to \$FF (255). After the values for frequency and duration are placed into memory a CALL2 statement from BASIC will activate this routine. The speaker is toggled with the machine language statement residing at \$02 and then a

delay in time equal to the value in \$00 occurs. This process is repeated until the tone has lasted a relative period of time equal to the duration (value in \$01) and then this program is exited (statement \$14).

Basic Program

The purpose of the machine language routine is to generate tones controllable from BASIC as the program dictates. Figure 2 lists the appropriate statement that will deposit the machine language routine into memory. They are in the form of a subroutine and can be activated by a GOSUB 32000 statement. It is only necessary to use this statement once at the beginning of a program. After that the machine language program will remain in memory unless a later part of the main program modifies the first 20 locations of page 0.

After the GOSUB 32000 has placed the machine language program into memory it may be activated by the statement in Figure 3. This statement is also in the form of a GOSUB because it can be used repetitively in a program. Once the frequency and duration have been defined by setting P and D equal to a value between 0 and 255 a GOSUB 25 statement is used to initiate the generation of a tone. The values of P and D are placed into \$00 and \$01 and the CALL2 command activates the machine language program that toggles the speaker. After the tone has ended control is returned to the main program.

The statements in Figures 2 and 3 can be directly incorporated into BASIC programs to provide for the generation of tones. Once added to a program an infinite variety of tone combinations can be produced. For example, tones can be used to prompt, indicate an error in entering or answering questions, and supplement video displays on the Apple II computer system.

Since the computer operates at a faster rate than man does, prompting can be used to indicate when the computer expects data to be entered. Tones can be generated at just about any time for any reason in a program. The programmer's imagination can guide the placement of these tones.

CONCLUSION

The incorporation of tones through the routines discussed in this paper will aid in the humanizing of software used in the Apple computer. These routines can also help in transforming a dull program into a lively one. They are relatively easy to use and are a valuable addition to any program.

0000-	FF	???
0001-	FF	???
0002-	AD 30 C0	LDR \$C030
0005-	88	DEY
0006-	D8 04	BNE \$000C
0008-	C6 01	DEC \$01
000A-	F0 08	BEQ \$0014
000C-	CA	DEX
000D-	D8 F6	BNE \$0005
000F-	A6 00	LDX \$00
0011-	4C 02 00	JMP \$0002
0014-	60	RTS

FIGURE 1. Machine Language Program
adapted from a program by P. Lutas.

32000 POKE 2,173: POKE 3,48: POKE
4,192: POKE 5,136: POKE 6,200
: POKE 7,4: POKE 8,198: POKE
9,1: POKE 10,240
32005 POKE 11,8: POKE 12,202: POKE
13,208: POKE 14,246: POKE 15
,166: POKE 16,8: POKE 17,76
: POKE 18,2: POKE 19,0: POKE
20,96: RETURN

FIGURE 2. BASIC "POKES"

25 POKE 0,P: POKE 1,D: CALL 2:
RETURN

FIGURE 3. GOSUB

High-Resolution Operating Subroutines

These subroutines were created to make programming for High-Resolution Graphics easier, for both BASIC and machine-language programs. These subroutines occupy 757 bytes of memory and are available on either cassette tape or Read-Only Memory (ROM). This note describes use and care of these subroutines.

There are seven subroutines in this package. With these, a programmer can initialize High-Resolution mode, clear the screen, plot a point, draw a line, or draw and animate a predefined shape on the screen. There are also some other general-purpose subroutines to shorten and simplify programming.

BASIC programs can access these subroutines by use of the CALL statement, and can pass information by using the POKE statement. There are special entry points for most of the subroutines that will perform the same functions as the original subroutines without modifying any BASIC pointers or registers. For machine language programming, a JSR to the appropriate subroutine address will perform the same function as a BASIC CALL.

In the following subroutine descriptions, all addresses given will be in decimal. The hexadecimal substitutes will be preceded by a dollar sign (\$). All entry points given are for the cassette tape subroutines, which load into addresses C00 to FFF (hex). Equivalent addresses for the ROM subroutines will be in *italic type face*.

High-Resolution Operating Subroutines

INIT Initializes High-Resolution Graphics mode.

From BASIC: CALL 3072 (or CALL -12288)

From machine language: JSR \$C00 (or JSR \$D00)

This subroutine sets High-Resolution Graphics mode with a 280 x 160 matrix of dots in the top portion of the screen and four lines of text in the bottom portion of the screen. INIT also clears the screen.

CLEAR Clears the screen.

From BASIC: CALL 3086 (or CALL -12274)

From machine language: JSR \$C0E (or JSR \$D00E)

This subroutine clears the High-Resolution screen without resetting the High-Resolution Graphics mode.

PLOT Plots a point on the screen.

From BASIC: CALL 3780 (or CALL -11580)

From machine language: JSR \$C7C (or JSR \$D07C)

This subroutine plots a single point on the screen. The X and Y coordinates of the point are passed in locations 800, 801, and 802 from BASIC, or in the A, X, and Y registers from machine language. The Y (vertical) coordinate can be from 0

High-Resolution Operating Subroutines

PLOT (continued)

(top of screen) to 159 (bottom of screen) and is passed in location 802 or the A-register; but the X (horizontal) coordinate can range from 0 (left side of screen) to 279 (right side of screen) and must be split between locations 800 (X MOD 256) and 801 (X/256). or, from machine language, between registers X (X LO) and Y (X HI). The color of the point to be plotted must be set in location 812 (\$32C). Four colors are possible: 0 is BLACK, 85 (\$55) is GREEN, 170 (\$AA) is VIOLET, and 255 (\$FF) is WHITE.

POSN Positions a point on the screen.

From BASIC: CALL 3761 (or CALL -11599)

From machine language: JSR \$C26 (or JSR \$D026)

This subroutine does all calculations for a PLOT, but does not plot a point (it leaves the screen unchanged). This is useful when used in conjunction with LINE or SHAPE (described later). To use this subroutine, set up the X and Y coordinates just the same as for PLOT. The color in location 812 (\$32C) is ignored.

LINE Draw a line on the screen.

High-Resolution Operating Routines

LINE Draws a line on the screen.

From BASIC: CALL 3786 (or CALL -11574)

From machine language: JSR \$C95 (or JSR \$D95)

This subroutine draws a line from the last point PLOTted or POSN'ed to the point specified. One endpoint is the last point PLOTted or POSN'ed; the other endpoint is passed in the same manner as for a PLOT or POSN. The color of the line is set in location 812 (\$32C). After the line is drawn, the new endpoint becomes the base endpoint for the next line drawn.

SHAPE Draws a predefined shape on the screen.

From BASIC: CALL 3805 (or CALL -11555)

From machine language: JSR \$DBC (or JSR \$DIBC)

This subroutine draws a predefined shape on the screen at the point previously PLOTted or POSN'ed. The shape is defined by a *table of vectors* in memory. (How to create a vector table will be described later). The starting address of this table should be passed in locations 804 and 805 from BASIC or in the Y and X registers from machine language. The color of the shape should be passed in location 28 (\$1C).

There are two special variables that are used only with shapes: the scaling factor and the rotation factor. The scaling factor determines the relative size of the shape. A scaling factor of


High-Resolution Operating Subroutines

SHAPE (continued)

1 will cause the shape to be drawn true size, while a scaling factor of 2 will draw the shape double size, etc. The scaling factor is passed in location 806 from BASIC or \$32F from machine language. The rotation factor specifies one of 64 possible angles of rotation for the shape. A rotation factor of 0 will cause the shape to be drawn right-side up, where a rotation factor of 16 will draw the shape rotated 90° clockwise, etc. The rotation factor is passed in location 807 from BASIC or in the A-register from machine language.

The table of vectors which defines the shape to be drawn is a series of bytes stored in memory. Each byte is divided into three sections, and each section specifies whether or not to plot a point and also a direction to move (up, down, left, or right). The SHAPE subroutine steps through the vector table byte by byte, and then through each byte section by section. When it reaches a FF byte, it is finished.

The three sections are arranged in a byte like this:



OD = φ & Move ↑
01 " " →
1φ " " ↓
11 " " ←

Each bit pair DD specifies a direction to move, and the two bits P specify whether or not to plot a point before moving. Notice that the last section (most significant bits) does not have a P field, so it can only be a move without plotting. The SHAPE

High-Resolution Operating Subroutines

SHAPE (continued)

subroutine processes the sections from right to left (least significant bit to most significant bit). IF THE REMAINING SECTIONS OF THE BYTE ARE ZERO, THEN THEY ARE IGNORED. Thus, the byte cannot end with sections of $\emptyset\emptyset$ (move up without plotting).

Here is an example of how to create a vector table:

Suppose we want to draw a shape like this:



First, draw it on graph paper, one dot per square. Then decide where to start drawing the shape. Let's start this one in the center. Next, we must draw a path through each point in the shape, using only 90° angles on the turns:



Next, re-draw the shape as a series of vectors, each one moving one place up, down, left, or right, and distinguish the vectors that plot a point before moving:



Now "unwrap" those vectors and write them in a straight line.

$\downarrow \downarrow \leftarrow \leftarrow \uparrow \uparrow \uparrow \uparrow \rightarrow \rightarrow \rightarrow \rightarrow \downarrow \downarrow \downarrow \downarrow \leftarrow \leftarrow$

Now draw a table like the one in Figure 1. For each vector in the line, figure the bit code and place it in the next available section in the table. If it will not fit or is a $\emptyset\emptyset$ at the end of a byte, then skip that section and go on to the next. When you have finished

High-Resolution Operating Subroutines

SHAPE (continued)

coding all vectors, check your work to make sure it is accurate. Then make another table (as in figure 2) and re-copy the coded vectors from the first table. Then decode the vector information into a series of hexadecimal bytes, using the hexidecimal code table in figure 3. This series of hexidecimal bytes is your shape definition table, which you can now put into the Apple II's memory and use to draw that shape on the screen.

Shape vectors: ↓↓←←↑↑↑↑→→→→↓↓↓↓←←




Figure 1.

	C	B	A	=
0	000	001	001 \emptyset	12
1	0011	1111		3F
2	0010	0000		20
3	0110	0100		64
4	0010	1101		2D
5	0001	0101		15
6	00110	1110		36
7	0001	1110		1E
8	0000	0111		87
9	0000	0000		\emptyset

Empty;
denotes end
of vector table.

Figure 2.

Hex-decimal Codes

0000	\rightarrow 0
0001	\rightarrow 1
0010	\rightarrow 2
0011	\rightarrow 3
0100	\rightarrow 4
0101	\rightarrow 5
0110	\rightarrow 6
0111	\rightarrow 7
1000	\rightarrow 8
1001	\rightarrow 9
1010	\rightarrow A
1011	\rightarrow B
1100	\rightarrow C
1101	\rightarrow D
1110	\rightarrow E
1111	\rightarrow F

```

>REM HIRES DEMO-BASIC LISTING

XLIST
1 INIT=3072:CLEAR=3086:POSN=3761
: PLOT=3780:LINE=3786:SHAPE=
3005:FIND=3667:SINTBL=3940
5 DIM X(10),Y(10)
10 TEXT : CALL -936: VTAB 4: TAB
10: PRINT "*** 16K APPLE II ***"
: PRINT " *** HIGH RESOLUTION G
RAPHICS DEMOS ***": PRINT
15 PRINT "1 RANDOM LINE DRAW AT BAS
IC SPEED": PRINT "2 RANDOM SHAPE
PROJECTED INTO CORNER"
20 PRINT "3 CHRIS' MAD FOLLY":
PRINT "4 RANDOM SHAPE SPIRALING
INTO POINT": PRINT "5 SPIROGRAP
H"
25 PRINT "6 HI-RES DONUT": PRINT
"7 RANDOM WAVE FORM": PRINT
"8 SUM OF TWO SINE WAVES"
30 PRINT : PRINT "HIT ANY KEY FOR N
EW DEMO": PRINT "TYPE 'CONTROL C
' ; RETURN BUTTON THEN TYPE 'T
EXT AND RETURN BUTTON TO STOP"
50 PRINT : INPUT "WHICH DEMO # DO Y
OU WANT ",X1
90 IF X1<1 OR X1>8 THEN 10: CALL
INIT: GOTO 100*X1
100 CALL INIT:X=40:Y=X: GOSUB 2000
: POKE 812,255: CALL PLOT
110 X= RND (200):Y= RND (160): GOSUB
2000: CALL LINE: IF NOT RND
(300) THEN POKE 23,X: PEEK (
23)+ RND (3)+1 MOD 4+85: GOSUB
3000: GOTO 110
200 GOSUB 1000:X= RND (2)*279:Y=
RND (2)*159: CALL PLOT: FOR
J=1 TO 30: FOR I=1 TO R: POKE
800,X(I) MOD 256: POKE 801,
X(I)>255: POKE 802,Y(I): CALL
LINE
300 IF RND (500) THEN 500:X= RND (2)*159:Y=
RND (2)*85: CALL PLOT: IF
Y>0 AND Y<160 THEN 510:YDIR=
-YDIR:Y=-Y: IF Y<0 THEN Y=Y+
310: GOSUB 3000: GOTO 510
600 POKE -16382,0: POKE 768,5: POKE
769,0: POKE 800,140: POKE 801
,0: POKE 802,0: POKE 804,0:
POKE 805,3: POKE 812,255: CALL
POSN
610 FOR R=0 TO 4160: POKE 807,R MOD
64: POKE 806,2+6* NOT (R MOD
65): CALL SHAPE: NEXT R: GOSUB
3000: GOTO 610
700 J= RND (10)+ RND (10):K= RND
(33)+ RND (31)+ RND (60):L=
RND (9)/8: PRINT "FREQ#1= "
;J;" FREQ#2= ";K
710 GOSUB 4000: GOSUB 3000: GOTO
700
800 INPUT "REL FREQ #1=",J: INPUT
"REL FREQ #2=",K: INPUT "MODE (0
=SOLID, 1=POINTS)",L
810 GOSUB 4000: GOSUB 3000: GOTO
800
1000 CALL CLEAR: POKE 812, RND (
3)*85+85:R= RND (3)+2+ RND
(2): FOR I=1 TO R:X(I)= RND
(160):Y(I)= RND (160): NEXT
I
1010 X=X(I):Y=Y(I): GOSUB 2000: RETURN
2000 POKE 800,X MOD 256: POKE 801
,X>255: POKE 802,Y: RETURN
3000 IF PEEK (-16384)*128 THEN RETURN
: POKE -16383,0: POP : GOTO
10
4000 CALL INIT: POKE 812,255:R=0
:I=0: FOR I=0 TO 279:R=(B+J)
MOD 256:B=(B+K) MOD 256:Y=
(PEEK (SINTBL+R)+ PEEK (SINTBL+
B))*5/16
4010 POKE 800,I MOD 256: POKE 801
,I>255: POKE 802,Y: CALL LINE-
6*( NOT I OR L): NEXT I: RETURN
510 X(I)=(X(I)-X)*9/10+X:Y(I)=(
Y(I)-Y)*9/10+Y: NEXT I,J: GOSUB
3000: GOTO 200
300 CALL INIT:X= RND (24)*10+20
:Y= RND (14)*10+20: POKE 812
, RND (3)*85+85: GOSUB 2000
: CALL PLOT
310 IF RND (1000)*1 THEN 300: IF
NOT RND (200) THEN POKE 28,
RND (4)*85
320 X1=X+( RND (3)-1)*25:Y1=Y+(

RND (3)-1)*15: IF X1<0 OR
X1>279 OR Y1<0 OR Y1>159 THEN
328
330 X=X1:Y=Y1: GOSUB 2000: CALL
LINE: GOSUB 3000: GOTO 310
400 GOSUB 1000: POKE 812, RND (
3)*85+85: CALL PLOT
410 FOR J=1 TO 25: FOR I=1 TO R:
POKE 800,X(I) MOD 255: POKE
801,X>255: POKE 802,Y(I): CALL
LINE
420 X=(X(I)-80+(Y(I)-80)/8)*9/10
+80:Y(I)=(Y(I)-80-(X(I)-80)
/8)*9/10+80:X(I)=X: NEXT I,
J: GOSUB 3000: GOTO 400
500 CALL INIT: POKE 800,0: CALL
PLOT:X=0:Y=0:YDIR=1:YDIR=1:
R=5:B=3:C=8
510 POKE 800,0: POKE 801,0: POKE
802,Y: CALL LINE: POKE 800,
(279-X) MOD 256: POKE 801,X(
34: POKE 802,159: CALL LINE:
POKE 800,23: POKE 801,1: POKE
802,159-Y: CALL LINE
515 IF RND (500) THEN 520:R=1+ RND
(13):B=2+ RND (8):C=4+ RND
(7)
520 POKE 800,X MOD 256: POKE 801
,X>255: POKE 802,0: CALL LINE:
X=X+YDIR*A: IF X>0 AND X<280
THEN 530:YDIR=-YDIR:X=X: IF
X<0 THEN X=X+550

```

ROD'S COLOR PATTERN

PROGRAM DESCRIPTION

ROD'S COLOR PATTERN is a simple but eloquent program. It generates a continuous flow of colored mosaic-like patterns in a 40 high by 40 wide block matrix. Many of the patterns generated by this program are pleasing to the eye and will dazzle the mind for minutes at a time.

REQUIREMENTS

4K or greater Apple II system with a color video display.

BASIC is the programming language used.

PROGRAM LISTING

```
100 GR
105 FOR W=3 TO 50
110 FOR I=1 TO 19
115 FOR J=0 TO 19
120 K=I+J
130 COLOR=J*3/(I+3)+I*W/12
135 PLOT I,K: PLOT K,I: PLOT 40
    -I,40-K
136 PLOT 40-K,40-I: PLOT K,40-I:
    PLOT 40-I,K: PLOT I,40-K: PLOT
    40-K,I
140 NEXT J,I
145 NEXT W: GOTO 105
```

PROGRAM LISTING: PONG

```

5 REM PONG BY WENDELL BITTER
10 REM 7/7/77
15 REM PADDLE SWITCHES CONTROL
    PADDLE SIZE AFTER A MISS
    OR DURING A HIT
20 GR
25 DIM P(3): DIM HP$(10)
30 R=39:B=1:C=-1
35 COLOR=13: HLINE 1,38 AT 0: HLINE
    1,38 AT 39
40 CALL -936: VTAB 23: INPUT "HANDLE
    ALL OR PONG ? ",HP$
45 INPUT "PADDLE SIZE (1-6) ",
    PS: IF PS<1 OR PS>6 THEN 45
    :S=PS-1
50 CALL -936
55 IF HP$(1)<>"H" THEN 285
60 H=1: COLOR=13: VLINE 0,39 AT
    39: GOTO 205
65 FOR X=R TO B STEP C
70 Y=YY+V: IF Y>1 AND Y<38 THEN
    80: IF Y<1 THEN Y=1: IF Y>38
        THEN Y=38
75 V=-V: FOR T=1 TO S:M= PEEK
    (-16336): NEXT T
80 IF X=C OR X=39+C THEN 85: COLOR=
    0: PLOT X-C,YY: COLOR=13: PLOT
    X,Y
85 YY=Y: IF X MOD 2=0 THEN GOSUB
    235: NEXT X
90 GOSUB 235
95 IF SCRNX,X,Y+V*(Y+V/40 AND Y+
    V)-1)=0 THEN 165
100 FOR T=1 TO 10:N= PEEK (-16336
    ): NEXT T
105 IF H AND C>0 THEN 130
110 PP=P(X/38)
115 IF Y=PP THEN V=0: IF Y=PP+1
        THEN V=2: IF Y=PP+2 THEN V=
            1
120 IF Y=PP+3 THEN V=-1: IF Y=PP+
    4 THEN V=-2: IF Y=PP+5 THEN
        V=-3
125 IF S=0 THEN V=3- RND (7)
130 COLOR=0: PLOT X-C,Y
135 IF (H AND C>0) OR (Y>0 ABS
    (Y) AND X=0) THEN V=4- RND
    (9)
140 IF X=0 THEN VY= ABS (Y)
145 R=39-R:B=39-B:C=-C
150 IF PEEK (-16286)>127 AND S#
    5 THEN S=S+1
155 IF PEEK (-16287)>127 AND S#
    0 THEN S=S-1
160 GOTO 65
165 COLOR=0: PLOT X-C,Y
170 COLOR=15: PLOT X,Y+V*(Y+V/-
    1 AND Y+V/40)
175 FOR T=1 TO 75:N= PEEK (-16336
    )+ PEEK (-16336)- PEEK (-16336
    ): NEXT T
180 IF X=0 THEN SR=SR+1: IF X=39
        THEN SL=SL+1
185 VTAB 23: TAB 7: PRINT SL;; TAB
    33: PRINT SR
190 COLOR=0: PLOT X-C,Y
195 IF SL=15 OR SR=15 THEN 260
200 COLOR=0: PLOT X,Y+V*(Y+V)-1
        AND Y+V/40)
205 FOR T=1 TO 75: IF T MOD 5#0
        THEN 210: IF PEEK (-16286)
        >127 AND S#5 THEN S=S+1: IF
        PEEK (-16287)>127 AND S#0 THEN
        S=S-1
210 GOSUB 235: NEXT T
215 YY=P(0): IF X=0 THEN YY=P(1
    )
220 IF H THEN YY= RND (37)+1
225 V=1- RND (3)
230 GOTO 65
235 IF H THEN 245:P(1)=(( PDL (
    1)-24)*20)/115: IF P(1)=P(3
    ) THEN 245: IF P(1)>0 THEN
        P(1)=0: IF P(1)>39 THEN P(
        1)=39-5
240 COLOR=6: VLINE P(1),P(1)+5 AT
    39: COLOR=0: IF P(1)>P(3) THEN
        VLINE 0,P(1)-1 AT 39: IF P(1
        )>P(3) THEN VLINE P(1)+5+1,39
        AT 39:P(3)=P(1)
245 P(0)=(( PDL (0)-24)*20)/115
    : IF P(0)<0 THEN P(0)=0: IF
        P(0)=P(2) THEN RETURN : IF
        P(0)+5>39 THEN P(0)=39-5
250 COLOR=6: VLINE P(0),P(0)+5 AT
    0: COLOR=0: IF P(0)>P(2) THEN
        VLINE 0,P(0)-1 AT 0: IF P(0
        )<P(2) THEN VLINE P(0)+5+1,39
        AT 0
255 COLOR=0: IF P(0)>P(2) THEN
        VLINE 0,P(0)-1 AT 0: IF P(0
        )<P(2) THEN VLINE P(0)+5+1,39
        AT 0:P(2)=P(0): RETURN
260 PRINT "": END
265 END

```

COLOR SKETCH

PROGRAM DESCRIPTION

Color Sketch is a little program that transforms the Apple II into an artist's easel, the screen into a sketch pad. The user as an artist has a 40 high by 40 wide (1600 blocks) sketching pad to fill with a rainbow of fifteen colors. Placement of colors is determined by controlling paddle inputs; one for the horizontal and the other for the vertical. Colors are selected by depressing a letter from A through P on the keyboard.

An enormous number of distinct pictures can be drawn on the sketch pad and this program will provide many hours of visual entertainment.

REQUIREMENTS

This program will fit into a 4K system in the BASIC mode.

PROGRAM LISTING: COLOR SKETCH

```

5 POKE 2,173: POKE 3,48: POKE
4,192: POKE 5,165: POKE 6,0
: POKE 7,32: POKE 8,168: POKE
9,252: POKE 10,165: POKE 11
,1: POKE 12,208: POKE 13,4
10 POKE 14,198: POKE 15,24: POKE
16,240: POKE 17,5: POKE 18,
198: POKE 19,1: POKE 20,76:
POKE 21,2: POKE 22,6: POKE
23,96:
15 DIM B$(40): TEXT : CALL -936
: GOTO 90
20 CALL -936: GOTO 90
25 R= LEN(B$): FOR Z=1 TO R: GOSUB
65: PRINT B$(Z,Z);: NEXT Z:
GOSUB 70: RETURN
30 B$="*****": RETURN
*****": RETURN
35 B$="COLOR SKETCH": RETURN
40 B$="COPYRIGHT APPLE COMPUTER 197
7": RETURN
45 B$="THIS PROGRAM ALLOWS YOU TO "
: RETURN
50 B$="SKETCH COLORED FIGURES IN"
: RETURN
55 B$="LOW RESOLUTION GRAPHICS WITH
PADDLES": RETURN
60 KK=20:TON=20: GOSUB 85: RETURN
65 KK=10:TON=10: GOSUB 85: RETURN
70 KK=20:TON=50: GOSUB 85:KK=30
:TON=90: GOSUB 85: RETURN
75 KK=20:TON=20: GOSUB 85: RETURN
80 KK=8:TON=250: GOSUB 85:KK=9
:TON=250: GOSUB 85: RETURN
85 POKE 1,TON MOD 256: POKE 24
,TON/256+1: POKE 0,KK: CALL
2: RETURN
90 GOSUB 30: GOSUB 25: PRINT :
TRB 13: GOSUB 35: GOSUB 25
: PRINT : GOSUB 30: GOSUB 25
: PRINT : TAB 5: GOSUB 40: GOSUB
25: PRINT : GOSUB 30: GOSUB
25
95 PRINT : GOSUB 70: GOSUB 45:
GOSUB 25: PRINT : GOSUB 50
: GOSUB 25: PRINT : GOSUB 55
: GOSUB 25: PRINT
100 PRINT : PRINT : GOSUB 70: INPUT
"WHEN READY HIT RETURN" |B$|
105 GR
110 B$="ABCDEFGHIJKLMNP": CALL
-936
115 FOR Z=0 TO 15: COLOR=Z: PLOT
Z*2+4,39: VTAB 21: GOSUB 75
: TRB Z*2+5: PRINT B$(Z+1,Z+
1);: GOSUB 75: NEXT Z: TAB
1
120 VTAB 22:B$="TYPE A LETTER TO CH
ANGE COLOR.": GOSUB 25: PRINT
:B$="TYPE SPACE BAR TO STOP PLOT
.": GOSUB 25: PRINT
125 Y= PDL (1)*39/255:X= PDL (0
)*39/255: VTAB 24: TAB 1: PRINT
"CURSOR POSITION: X=";X;" Y="
;Y;" "X";
130 IF PEEK (-16384)>127 THEN 145
: IF X1=X AND Y1=Y THEN 125
: COLOR=C2: PLOT X1,Y1: IF
NOT FLAG THEN 135: COLOR=C:
PLOT X,Y
135 C2= SCRN(X,Y):C3=15: IF C2=
15 THEN C3=5: COLOR=C3: PLOT
X,Y:X1=X:Y1=Y
140 GOTO 125
145 IF PEEK (-16384)>160 THEN 155
:FLAG=0: POKE -16368,0: POKE
34,20: COLOR=0: HLIN 0,39 RT
39: CALL -936
150 PRINT :B$="CONTINUE OR STOP"
: VTAB 24: GOSUB 25: INPUT
"(C/S) ",B$: IF B$(1,1)="C"
THEN 110: PRINT "END": END
155 FLAG=1:C= PEEK (-16384)-193
: POKE -16368,0: GOTO 125

```

MASTERMIND PROGRAM

PROGRAM DESCRIPTION

MASTERMIND is a game of strategy that matches your wits against Apple's. The object of the game is to choose correctly which 5 colored bars have been secretly chosen by the computer. Eight different colors are possible for each bar - Red (R), Yellow (Y), Violet (V), Orange (O), White (W), and Black (B). A color may be used more than once. Guesses for a turn are made by selecting a color for each of the five hidden bars. After hitting the RETURN key Apple will indicate the correctness of the turn. Each white square to the right of your turn indicates a correctly colored and positioned bar. Each grey square acknowledges a correctly colored but improperly positioned bar. No squares indicate you're way off.

Test your skill and challenge the Apple II to a game of MASTERMIND.

REQUIREMENTS

8K or greater Apple II computer system.

BASIC is the programming language.

PROGRAM LISTING: MASTERMIND

```

0 REM GAME OF MASTERMIND 8-25-77
  WOZ (APPLE COMPUTER)
10 DIM R(6),C(8),D(5),X(8),X$(8)
   X(1)=2;X(2)=12;X(3)=1;X(4)=13;X(5)=3;X(6)=9;X(7)=15
   :X(8)=5;X$="BGRYVWGX"
20 TEXT : CALL -384: PRINT "
  WELCO
  ME TO THE GAME OF MASTERMIND!
  YOUR OBJECT IS TO GUESS 5 COLOR
  S (WHICH"
30 PRINT "I WILL MAKE UP) IN THE NO
  NINUM NUMBER OF GUESSES. THER
  E ARE EIGHT DIFFERENT COLORS TO
  CHOSE FROM."
40 PRINT "
  FEWER THAN 7 GUESSES--EXC
  ELLENT": PRINT " 7 TO 9 GUESSE
  S-----GOOD": PRINT " 10 TO 14 G
  UESSES---AVERAGE"
50 PRINT "MORE THAN 14 GUESSES--POO
  R
  "; CALL -384: TAB 7: PRINT
  "HIT ANY KEY TO BEGIN PLAY"

100 CALL -384: IF PEEK (-16384)
   <132 THEN 100: POKE -16368,
  0: GR : PRINT : FOR I=1 TO
  8:D(I)= RND (8)+1: COLOR=X(
  I): HLIN I*4-2,I*4 AT 39: PRINT
   " ";X$(I,I): NEXT I
110 TRY=0: PRINT : PRINT " LETTER
  KEYS FOR COLOR CHANGE": PRINT
   " ARROW KEYS FOR ADVANCE AND BA
  CK": PRINT " HIT RETURN TO ACC
  EPT GUESS #";
200 Y=TRY*2 MOD 36+1:TRY=TRY+1:
   TAB 32: PRINT TRY;: COLOR=
  0: HLIN 0,39 AT Y:FLASH=1: FOR
  N=1 TO 5:R(N)=8: GOSUB 1000
   : NEXT N:N=1
300 FOR WAIT=1 TO 10:KEY= PEEK
   (-16384): IF KEY<132 THEN 310
   : POKE -16368,0:FLASH=1: FOR
  I=1 TO 8: IF KEY= RSC(X$(I))
   ) THEN NEXT I: IF I=9 THEN
  310:R(N)=I:KEY=149
310 GOSUB 1000: IF KEY=141 THEN
  400: IF KEY=136 AND N>1 OR
  KEY=149 AND N<6 THEN N=N+KEY/
  5-28: NEXT WAIT:FLASH=1-FLASH:
  GOTO 300
400 COLOR=15:N=0: FOR I=1 TO 5:
  D(I)=C(I);J=I: GOSUB 2000: NEXT
  I: IF N=5 THEN 500: COLOR=5
   : FOR J=1 TO 5: FOR I=1 TO
  5: GOSUB 2000: NEXT I,J: GOTO
  200
500 PRINT : PRINT "
  YOU GOT IT IN "
   ;TRY;" TRIES (";: IF TRY<7 THEN
  PRINT "EXCELLENT";: IF TRY>
  6 AND TRY<10 THEN PRINT "GOOD"
   :
510 IF TRY>9 AND TRY<15 THEN PRINT
   "AVERAGE";: IF TRY>14 THEN
  PRINT "POOR";: PRINT ")": CALL
  -384: TAB 5: PRINT "HIT ANY KEY
  TO PLAY AGAIN": GOTO 100
1000 IF N=6 THEN RETURN : COLOR=
  X(R(N))FLASH: HLIN N*4-2,N*
  4 AT Y: RETURN
2000 IF R(I)>D(J) THEN RETURN :
  N=N+1: PLOT 21+N,M,Y: PRINT
   " ";R(I)=0:D(J)=9: RETURN

```

BIORHYTHM PROGRAM

PROGRAM DESCRIPTION

This program plots three Biorhythm functions: Physical (P), Emotional (E), and Mental (M) or intellectual. All three functions are plotted in the color graphics display mode.

Biorhythm theory states that aspects of the mind run in cycles. A brief description of the three cycles follows:

Physical

The Physical Biorhythm takes 23 days to complete and is an indirect indicator of the physical state of the individual. It covers physical well-being, basic bodily functions, strength, coordination, and resistance to disease.

Emotional

The Emotional Biorhythm takes 28 days to complete. It indirectly indicates the level of sensitivity, mental health, mood, and creativity.

Mental

The mental cycle takes 33 days to complete and indirectly indicates the level of alertness, logic and analytic functions of the individual, and mental receptivity.

Biorhythms

Biorhythms are thought to affect behavior. When they cross a "baseline" the functions change phase - become unstable - and this causes Critical Days. These days are, according to the theory, our weakest and most vulnerable times. Accidents, catching colds, and bodily harm may occur on physically critical days. Depression, quarrels, and frustration are most likely on emotionally critical days. Finally, slowness of the mind, resistance to new situations and unclear thinking are likely on mentally critical days.

REQUIREMENTS

This program fits into a 4K or greater system.

BASIC is the programming language used.

PROGRAM LISTING: BIORHYTHM

```

5 POKE 2,173: POKE 3,48: POKE
4,192: POKE 5,165: POKE 6,0
: POKE 7,32: POKE 8,168: POKE
9,252: POKE 10,165: POKE 11
,1: POKE 12,208: POKE 13,4
10 POKE 14,198: POKE 15,24: POKE
16,240: POKE 17,5: POKE 18,
198: POKE 19,1: POKE 20,76:
POKE 21,2: POKE 22,0: POKE
23,96.

15 GOTO 85
20 TT=3: GOSUB 30: RETURN
25 PRINT "*****": RETURN
30 KK=8: TON=500: GOSUB 45: RETURN
35 KK=9: TON=250: GOSUB 45: RETURN
40 KK=8: TON=250: GOSUB 45: KK=9
: TON=250: GOSUB 45: RETURN
45 POKE 1,TON MOD 256: POKE 24
,TON/256+1: POKE 0,KK: CALL
2: RETURN
50 R=(19-(P*B(I)/100))*(P*100*
C(I))+(P*100*C(I))*(P*100<=
3*C(I))=((P*100-C(I))/100*B(
I)/100)
55 R=R+(P*100)*3*C(I)*(38-((P*
100-3*C(I))/100*B(I)/100)):
R=39*(R/39)+R*(R/40): RETURN
60 KK=8: TM=500: GOSUB 70: KK=9:
TM=250: GOSUB 70: RETURN
65 KK=7: TM=10: GOSUB 70: RETURN

70 POKE 1,TM MOD 256: POKE 24,
TM/256+1: POKE 0,KK: CALL 2
: RETURN
75 GOSUB 60: INPUT "DATE (M,D,Y) "
,M,D,Y:Y=Y+(Y(100)*1900
80 R=Y-(M*31):N=Y MOD 30+365-Y/
58*82+R/4-R/400*M*31-N/12-N/
7-N/5-3*(N\2)+D: IF N<0 THEN
N=N+21252: RETURN
85 DIM N$(10),B$(3),C(3),O(3),
BV(3):B(1)=348:B(2)=286:B(3)
)=242:C(1)=575:C(2)=700:C(3)
)=825:BV(1)=23:BV(2)=28
90 BV(3)=33: TEXT : CALL -936:
POKE 34,28: GOSUB 28: GOSUB
25: GOSUB 28: PRINT : TAB 10
: PRINT "APPLE II BIORHYTHM (4K)
": TAB 15: PRINT
95 GOSUB 25: TAB 5: PRINT "COPYRIGHT
1977 APPLE COMPUTER INC."
: POKE 34,24: VTAB 24
100 GOSUB 60: INPUT "NAME ",N$:
VTAB 22: PRINT N$: VTAB 24
: PRINT "BIRTH ";: GOSUB 75
: VTAB 22: TAB 21: PRINT "BIRTH
DATE ";M";";D";";Y: VTAB
24:N1=N: CALL -868
105 PRINT "FORECAST ";: GOSUB 75
:N=N-N1: IF N<0 THEN N=N+21252
: VTAB 23: TAB 18: PRINT "FORECA
ST DATE ";M";";D";";Y: VTAB
24: CALL -868

110 J=1: GR : POKE 34,23: FOR X=
18 TO 26: COLOR=3: HLIN 0,31
AT X: NEXT X: HLIN 1,3 AT
3: HLIN 1,3 AT 37: VLIN 2,4
AT 2: VTAB 21
115 FOR Y=1 TO 31 STEP 3: PRINT
Y: IF Y<10 THEN PRINT " ";
: PRINT " ";: NEXT Y: PRINT
" P E M": VTAB 24
120 VTAB 23: PRINT "DAYS LIVED "
;N: FOR I=1 TO 3: COLOR=1*(
I=1)+6*(I=2)+8*(I=3): VLIN
0,39 AT 33+I+I: VTAB 24
125 FOR X=0 TO 31:P=(N MOD BV(I)
+X) MOD BV(I): GOSUB 50: PLOT
X,R: GOSUB 65: NEXT X: NEXT
I
130 PRINT : INPUT "ANOTHER PLOT (Y/N
)":B$: IF B$(1,1)="Y" THEN
90: END

```

DRAGON MAZE PROGRAM

PROGRAM DESCRIPTION

DRAGON MAZE is a game that will test your skill and memory. A maze is constructed on the video screen. You watch carefully as it is completed. After it is finished the maze is hidden as if the lights were turned out. The object of the game is to get out of the maze before the dragon eats you. A reddish-brown square indicates your position and a purple square represents the dragon's.* You move by hitting a letter on the keyboard; U for up, D for down, R for right, and L for left. As you advance so does the dragon. The scent of humans drives the dragon crazy; when he is enraged he breaks through walls to get at you. DRAGON MAZE is not a game for the weak at heart. Try it if you dare to attempt out-smarting the dragon.

REQUIREMENTS

8K or greater Apple II computer system.

BASIC is the programming language.

* Color tints may vary depending upon video monitor or television adjustments.

PROGRAM LISTING: DRAGON MAZE

```

1 TEXT : CALL -936
2 PRINT "WELCOME TO THE DRAGON'S MAZE!"
3 PRINT "YOU MAY WATCH WHILE I BUILD A MAZE."
4 PRINT "BUT WHEN IT'S COMPLETE, I'LL ERASE."
5 PRINT "THE PICTURE. THEN YOU'LL ONLY SEE THE WALLS AS YOU BUMP INTO THEM."
6 PRINT "TO MOVE, YOU HIT 'R' FOR RIGHT."
7 PRINT "'L' FOR LEFT, 'U' FOR UP, AND 'D' FOR DOWN. DO NOT HIT RETURN!"
9 PRINT
10 PRINT "THE OBJECT IS FOR YOU (THE GREEN DOT)"
11 PRINT "TO GET TO THE DOOR ON THE RIGHT SIDE"
12 PRINT "BEFORE THE DRAGON (THE RED DOT) EATS"
13 PRINT "YOU."
14 PRINT "BEWARE!!!!!! SOMETIME THE DRAGON"
15 PRINT "GETS REAL MAD, AND CLIMBS OVER A WALL."
16 PRINT "BUT MOST OF THE TIME, HE CAN'T GO OVER"
17 PRINT "AND HAS TO GO AROUND."
18 PRINT
19 PRINT "(HINT: YOU CAN OFTEN TELL WHERE A WALL"
20 PRINT "IS, EVEN BEFORE YOU CAN SEE IT, BY"
21 PRINT "THE FACT THAT THE DRAGON CAN'T GET"
22 PRINT "THROUGH IT!)"
23 PRINT
99 DIM R$(3)
99 PRINT "TYPE 'GO' TO BEGIN"
;: INPUT R$
100 GR : COLOR=15
105 CALL -936: PRINT "DRAGON MAZE"
;: TAB (25): PRINT "GARY J. SHAW"
108 FOR I=0 TO 39 STEP 3: VLIN
     0,39 RT I: HLIN 0,39 RT I: NEXT
     I
120 COLOR=8
130 S=1000
1000 DIM M(169),T(169)
1001 FOR I=1 TO 169:T(I)=B: NEXT
     I
1010 FOR I=1 TO 169:M(I)=11: NEXT
     I
1030 X= RND (13)+1:Y= RND (13)+1
     :C=169
1035 IF C=1 THEN 1200
1040 R=0:D=0:L=0:U=0:K=X+13*(Y-1)
     ):M(K)= ABS (M(K)):C=C-1
1050 IF X=13 THEN 1060:R=M(K+1))
     0
1060 IF Y=13 THEN 1070:D=M(K+1))
     >0
1070 IF X=1 THEN 1080:L=M(K-1))0
     0
1080 IF Y=1 THEN 1090:U=M(K-1))0
     0
1090 Q=R+D+L+U
1100 IF (Q<3 AND RND (.10)<2) OR
     Q=0 THEN 1170
1110 DR= RND (4)
1120 GOTO 1130+10*DR
1130 IF NOT R THEN 1110:M(K)=M(K)
     +1:X=X+1
1135 VLIN 3*Y-2,3*X-1 AT 3*(X-1)
1136 GOTO 1035
1140 IF NOT D THEN 1110:M(K)=M(K)
     +10:Y=Y+1
1145 HLIN 3*X-2,3*X-1 AT 3*(Y-1)
1146 GOTO 1035
1150 IF NOT L THEN 1110:M(K-1)=M
     K-1)-1:X=X-1
1155 VLIN 3*Y-2,3*X-1 AT 3*X
1156 GOTO 1035
1160 IF NOT U THEN 1110:M(K-1)=
     M(K-1)-10:Y=Y-1
1165 HLIN 3*X-2,3*X-1 AT 3*Y: GOTO
     1035
1170 X= RND (13)+1:Y= RND (13)+1
1180 IF M(X+13*(Y-1))0 THEN 1170
1190 C=C+1: GOTO 1035
1200 GOSUB 5000: PRINT "THE MAZE IS READY"
1205 GR : COLOR=15
1210 VLIN 0,39 RT 0: VLIN 0,39 RT
     39: HLIN 0,39 RT 0: HLIN 0,
     39 RT 39
1220 X=1:Y= RND (13)+1: COLOR=8:
     PLOT 3*X-2,3*Y-2

```

DRAGON MAZE cont.

```

1225 HX=3*X-2:HY=3*Y-2      2520 GOTO 2020      7000 IF X>SX THEN 7005: IF Y>SY THEN
1230 WY= RND (13)+1          3000 DX=0:DY=-1      7050
1240 COLOR=0: VLIN 3*WY-2,3*WY-1 3010 IF M(X+13*(Y-2))/10 THEN 4200
1250 AT 39                      3020 GOTO 2020      7061 IF X<SX THEN 7100: IF Y<SY THEN
1260 QX=3*SX-2:QY=3*SY-2      3500 DX=0:DY=1      7150
1270 RD=1                      3510 IF M(X+13*(Y-1))/10 THEN 4300
1500 K= PEEK (-16384): IF K<128 THEN
1500                           3520 GOTO 2020      7065 IF SX=13 THEN 7050: IF T(SX+
1510 POKE -16368,0            4000 GOSUB 5000      13*(SY-1))>9 THEN 7010: IF
1515 QQ=K: GOSUB 7000:K=00      4010 COLOR=15      M(SX+13*(SY-1)) MOD 10 THEN
1516 IF SX=X AND SY=Y THEN 8000 4020 VLIN 3*(Y-1),3*X AT 3*X      7050
1520 IF K= ASC("R") THEN 2000 4030 GOTO 1500      7010 DX=1:DY=0
1530 IF K= ASC("L") THEN 2500 4100 GOSUB 5000      7020 COLOR=0
1540 IF K= ASC("U") THEN 3000 4110 COLOR=15      7022 RX=3*SX-2:RY=3*SY-2
1550 IF K= ASC("D") THEN 3500 4120 VLIN 3*(Y-1),3*X AT 3*(X-1)      7023 FOR I=1 TO 3:RX=RX+DX:RY=RY+
1560 GOSUB 5000: GOTO 1500      4130 GOTO 1500      DY
2000 DX=1:DY=0                  4200 GOSUB 5000      7024 COLOR=0
2010 IF M(X+13*(Y-1)) MOD 10 THEN
4000                           4210 COLOR=15      7025 FOR K=0 TO 1: FOR L=0 TO 1:
4000                           4220 HLIN 3*(X-1),3*X AT 3*(Y-1)      PLOT QX+K,QY+L: NEXT L,K: COLOR=
4000                           4230 GOTO 1500      RD: FOR K=0 TO 1: FOR L=0 TO
4040 COLOR=0                  4300 GOSUB 5000      1: PLOT RX+K,RY+L: NEXT L,K:
4060 FOR K=0 TO 1: FOR L=0 TO 1:
4060                           4310 COLOR=15      QX=RX:QY=RY
4060                           4320 HLIN 3*(X-1),3*X AT 3*X      7030 NEXT I
4060                           4330 GOTO 1500      7035 SX=SX+DX:SY=SY+DY
4060                           5000 S=5-1: FOR I=1 TO 20:R= PEEK
4060                           <-16336>: PEEK (-16336)>: PEEK
4060                           <-16336>: PEEK (-16336): NEXT
4060                           I: RETURN      7040 T(SX+13*(SY-1))=T(SX+13*(SY-
4060                           5000                   1))+1
4060                           6000 PRINT "YOU WIN!"      7045 RETURN
4060                           6010 GOSUB 5000: GOSUB 5000: GOSUB
4060                           5000      7050 IF SY=13 THEN 7100: IF T(SX+
4060                           6020 PRINT "SCORE=";S+3      13*(SY-1))>9 THEN 7060: IF
4060                           6030 END      M(SX+13*(SY-1)-1) MOD 10 THEN
4060                           7100 IF SX=1 THEN 7150: IF T(SX+
4060                           7150      7110: IF
4060                           7150      M(SX+13*(SY-1)-1) MOD 10 THEN
4060                           7150      7150

```

DRAGON MAZE cont.

```
7110 DX=-1:DY=0: GOTO 7620
7150 IF SY=1 THEN 7005; IF T(SX+
13*(SY-1))>9 THEN 7160: IF
N(SX+13*(SY-1)-13)/10 THEN
7005
7160 DX=0:DY=-1: GOTO 7620
8000 GOSUB 5000: GOSUB 5000: GOSUB
5000: GOSUB 5000: PRINT "THE DRA
GON GOT YOU!"
1999 END
```

>

APPLE II FIRMWARE

1. System Monitor Commands
2. Control and Editing Characters
3. Special Controls and Features
4. Annotated Monitor and Dis-assembler Listing
5. Binary Floating Point Package
6. Sweet 16 Interpreter Listing
7. 6502 Op Codes

System Monitor Commands

Apple II contains a powerful machine level monitor for use by the advanced programmer. To enter the monitor either press RESET button on keyboard or CALL-151 (Hex FF65) from Basic. Apple II will respond with an "*" (asterisk) prompt character on the TV display. This action will not kill current BASIC program which may be re-entered by a C^C (control C). NOTE: "adrs" is a four digit hexidecimal number and "data" is a two digit hexidecimal number. Remember to press "return" button at the end of each line.

<u>Command Format</u>	<u>Example</u>	<u>Description</u>
<u>Examine Memory</u>		
adrs	*C0F2	Examines (displays) single memory location of (adrs)
adrs1.adrs2	*1024.1048	Examines (displays) range of memory from (adrs1) thru (adrs2)
(return)	* (return)	Examines (displays) next 8 memory locations.
.adrs2	*.4096	Examines (displays) memory from current location through location (adrs2)
<u>Change Memory</u>		
adrs:data data data	*A256:EF 20 43	Deposits data into memory starting at location (adrs).
:data data data	*:F0 A2 12	Deposits data into memory starting after (adrs) last used for deposits.
<u>Move Memory</u>		
adrs1<adrs2. adrs3M	*100<B010.B410M	Copy the data now in the memory range from (adrs2) to (adrs3) into memory locations starting at (adrs1).
<u>Verify Memory</u>		
adrs1<adrs2. adrs3V	*100<B010.B410V	Verify that block of data in memory range from (adrs2) to (adrs3) exactly matches data block starting at memory location (adrs1) and displays differences if any.

<u>Command Format</u>	<u>Example</u>	<u>Description</u>
<u>Cassette I/O</u>		
adrs1.adrs2R	*300.4FFR	Reads cassette data into specified memory (adrs) range. Record length must be same as memory range or an error will occur.
adrs1.adrs2W	*800.9FFW	Writes onto cassette data from specified memory (adrs) range.
<u>Display</u>		
I	*I	Set inverse video mode. (Black characters on white background)
N	*N	Set normal video mode. (White characters on black background)
<u>Dis-assembler</u>		
adrsL	*C800L	Decodes 20 instructions starting at memory (adrs) into 6502 assembly mnemonic code.
L	*L	Decodes next 20 instructions starting at current memory address.
<u>Mini-assembler</u>		
(Turn-on)	*F666G	Turns-on mini-assembler. Prompt character is now a "!" (exclamation point).
\$(monitor command)	:\$C800L	Executes any monitor command from mini-assembler then returns control to mini-assembler. Note that many monitor commands change current memory address reference so that it is good practice to retype desired address reference upon return to mini-assembler.
adrs:(6502 MNEMONIC instruction)	:C010:STA 23FF	Assembles a mnemonic 6502 instruction into machine codes. If error, machine will refuse instruction, sound bell, and reprint line with up arrow under error.

<u>Command Format</u>	<u>Example</u>	<u>Description</u>
(space) (6502 mnemonic instruction)	: STA 01FF	Assembles instruction into next available memory location. (Note space between ":" and instruction)
(TURN-OFF)	: (Reset Button)	Exits mini-assembler and returns to system monitor.

Monitor Program Execution and Debugging

adrsG	*300G	Runs machine level program starting at memory (adrs).
adrsT	*800T	Traces a program starting at memory location (adrs) and continues trace until hitting a breakpoint. Break occurs on instruction 00 (BRK), and returns control to system monitor. Opens 6502 status registers (see note 1).
adrsS	*C050S	Single steps through program beginning at memory location (adrs). Type a letter S for each additional step that you want displayed. Opens 6502 status registers (see Note 1).
(Control E)	*E ^C	Displays 6502 status registers and opens them for modification (see Note 1).
(Control Y)	*Y ^C	Executes user specified machine language subroutine starting at memory location (3F8).

Note 1:

6502 status registers are open if they are last line displayed on screen. To change them type ":" then "data" for each register.

Example: A = 3C X = FF Y = 00 P = 32 S = F2
 *: FF Changes A register only
 *:FF 00 33 Changes A, X, and Y registers

To change S register, you must first retype data for A, X, Y and P.

Hexidecimal Arithmetic

data1+data2	*78+34	Performs hexidecimal sum of data1 plus data2.
data1-data2	*AE-34	Performs hexidecimal difference of data1 minus data2.

<u>Command Format</u>	<u>Example</u>	<u>Description</u>
<u>Set Input/Output Ports</u>		
(X) (Control P)	*5PC	Sets printer output to I/O slot number (X). (see Note 2 below)
(X) (Control K)	*2KC	Sets keyboard input to I/O slot number (X). (see Note 2 below)

Note 2:

Only slots 1 through 7 are addressable in this mode. Address 0 (Ex: 0PC or 0KC) resets ports to internal video display and keyboard. These commands will not work unless Apple II interfaces are plugged into specified I/O slot.

Multiple Commands

*100L 400G AFFT	Multiple monitor commands may be given on same line if separated by a "space".
*LLLL	Single letter commands may be repeated without spaces.

SPECIAL CONTROL AND EDITING CHARACTERS

"Control" characters are indicated by a super-scripted "C" such as G^C. They are obtained by holding down the CTRL key while typing the specified letter. Control characters are NOT displayed on the TV screen. B^C and C^C must be followed by a carriage return. Screen editing characters are indicated by a sub-scripted "E" such as D_E. They are obtained by pressing and releasing the ESC key then typing specified letter. Edit characters send information only to display screen and does not send data to memory. For example, UC moves cursor to right and copies text while AE moves cursor to right but does not copy text.

<u>CHARACTER</u>	<u>DESCRIPTION OF ACTION</u>
RESET key	Immediately interrupts any program execution and resets computer. Also sets all text mode with scrolling window at maximum. Control is transferred to System Monitor and Apple prompts with a "*" (asterisk) and a bell. Hitting RESET key does NOT destroy existing BASIC or machine language program.
Control B	If in System Monitor (as indicated by a "*"), a control B and a carriage return will transfer control to BASIC, <u>scratching (killing)</u> any existing BASIC program and set HIMEM: to maximum installed user memory and LOMEM: to 2048.
Control C	If in BASIC, halts program and displays line number where stop occurred*. Program may be continued with a CON command. If in <u>System Monitor</u> , (as indicated by "*"), control C and a carriage return will enter BASIC <u>without</u> killing current program.
Control G	Sounds bell (beeps speaker)
Control H	Backspaces cursor and deletes any overwritten characters from computer but not from screen. Apply supplied keyboards have special key "<" on right side of keyboard that provides this functions without using control button.
Control J	Issues line feed only
Control V	Compliment to H ^C . Forward spaces cursor and copies over written characters. Apple keyboards have ">" key on right side which also performs this function.
Control X	Immediately deletes current line.

* If BASIC program is expecting keyboard input, you will have to hit carriage return key after typing control C.

SPECIAL CONTROL AND EDITING CHARACTERS

(continued)

<u>CHARACTER</u>	<u>DESCRIPTION OF ACTION</u>
A _E	Move cursor to right
B _E	Move cursor to left
C _E	Move cursor down
D _E	Move cursor up
E _E	Clear text from cursor to end of line
F _E	Clear text from cursor to end of page
@ _E	Home cursor to top of page, clear text to end of page.

Special Controls and Features

<u>Hex</u>	<u>BASIC Example</u>	<u>Description</u>
<u>Display Mode Controls</u>		
C050	10 POKE -16304,0	Set color graphics mode
C051	20 POKE -16303,0	Set text mode
C052	30 POKE -16302,0	Clear mixed graphics
C053	40 POKE -16301,0	Set mixed graphics (4 lines text)
C054	50 POKE -16300,0	Clear display Page 2 (BASIC commands use Page 1 only)
C055	60 POKE -16299,0	Set display to Page 2 (alternate)
C056	70 POKE -16298,0	Clear HIRES graphics mode
C057	80 POKE -16297,0	Set HIRES graphics mode
<u>TEXT Mode Controls</u>		
0020	90 POKE 32,L1	Set left side of scrolling window to location specified by L1 in range of 0 to 39.
0021	100 POKE 33,W1	Set window width to amount specified by W1. L1+W1<40. W1>0
0022	110 POKE 34,T1	Set window top to line specified by T1 in range of 0 to 23
0023	120 POKE 35,B1	Set window bottom to line specified by B1 in the range of 0 to 23. B1>T1
0024	130 CH=PEEK(36) 140 POKE 36,CH 150 TAB(CH+1)	Read/set cursor horizontal position in the range of 0 to 39. If using TAB, you must add "1" to cursor position read value; Ex. 140 and 150 perform identical function.
0025	160 CV=PEEK(37) 170 POKE 37,CV 180 VTAB(CV+1)	Similar to above. Read/set cursor vertical position in the range 0 to 23.
0032	190 POKE 50,127 200 POKE 50,255	Set inverse flag if 127 (Ex. 190) Set normal flag if 255 (Ex. 200)
FC58	210 CALL -936	(@E) Home cursor, clear screen
FC42	220 CALL -958	(F_E) Clear from cursor to end of page

<u>Hex</u>	<u>BASIC Example</u>	<u>Description</u>
FC9C	23Ø CALL -868	(E _E) Clear from cursor to end of line
FC66	24Ø CALL -922	(J ^C) Line feed
FC7Ø	25Ø CALL -912	Scroll up text one line

Miscellaneous

CØ3Ø	36Ø X=PEEK(-16336) 365 POKE -16336,Ø	Toggle speaker
CØØØ	37Ø X=PEEK(-16384	Read keyboard; if X>127 then key was pressed.
CØ1Ø	38Ø POKE -16368,Ø	Clear keyboard strobe - always after reading keyboard.
CØ61	39Ø X=PEEK(16287)	Read PDL(Ø) push button switch. If X>127 then switch is "on".
CØ62	4ØØ X=PEEK(-16286)	Read PDL(1) push button switch.
CØ63	41Ø X=PEEK(-16285	Read PDL(2) push button switch.
CØ58	42Ø POKE -16296,Ø	Clear Game I/O ANØ output
CØ59	43Ø POKE -16295,Ø	Set Game I/O ANØ output
CØ5A	44Ø POKE -16294,Ø	Clear Game I/O AN1 output
CØ5B	45Ø POKE -16293,Ø	Set Game I/O AN1 output
CØ5C	46Ø POKE -16292,Ø	Clear Game I/O AN2 output
CØ5D	47Ø POKE -16291,Ø	Set Game I/O AN2 output
CØ5E	48Ø POKE -16290,Ø	Clear Game I/O AN3 output
CØ5F	49Ø POKE -16289,Ø	Set Game I/O AN3 output

```

*****
*          *
*      APPLE II          *
*      SYSTEM MONITOR      *
*          *
*      COPYRIGHT 1977 BY      *
*      APPLE COMPUTER, INC.      *
*          *
*      ALL RIGHTS RESERVED      *
*          *
*      S. WOZNIAK          *
*      A. BAUM          *
*          *
*****
```

TITLE	"APPLE II SYSTEM MONITOR"
LOC0	EPZ \$00
LOC1	EPZ \$01
WNDLFT	EPZ \$20
WNDWDTH	EPZ \$21
WNDTOP	EPZ \$22
WNDBTM	EPZ \$23
CH	EPZ \$24
CV	EPZ \$25
GBASL	EPZ \$26
GBASH	EPZ \$27
BASL	EPZ \$28
BASH	EPZ \$29
BAS2L	EPZ \$2A
BAS2H	EPZ \$2B
H2	EPZ \$2C
LMNEM	EPZ \$2C
RTNL	EPZ \$2C
V2	EPZ \$2D
RMNEM	EPZ \$2D
RTNH	EPZ \$2D
MASK	EPZ \$2E
CHKSUM	EPZ \$2E
FORMAT	EPZ \$2E
LASTIN	EPZ \$2F
LENGTH	EPZ \$2F
SIGN	EPZ \$2F
COLOR	EPZ \$30
MODE	EPZ \$31
INVFLG	EPZ \$32
PROMPT	EPZ \$33
YSAV	EPZ \$34
YSAV1	EPZ \$35
CSWL	EPZ \$36
CSWH	EPZ \$37
KSWL	EPZ \$38
KSWH	EPZ \$39
PCL	EPZ \$3A
PCH	EPZ \$3B
XQT	EPZ \$3C
A1L	EPZ \$3C
A1H	EPZ \$3D
A2L	EPZ \$3E
A2H	EPZ \$3F
A3L	EPZ \$40
A3H	EPZ \$41
A4L	EPZ \$42
A4H	EPZ \$43
A5L	EPZ \$44
A5H	EPZ \$45

	ACC	EPZ	\$45	
	XPEG	EPZ	\$46	
	YREG	EPZ	\$47	
	STATUS	EPZ	\$48	
	SPNT	EPZ	\$49	
	RNDL	EPZ	\$4F	
	FNDH	EPZ	\$4F	
	ACL	EPZ	\$50	
	ACH	EPZ	\$51	
	XTNDL	EPZ	\$52	
	XTNDH	EPZ	\$53	
	AUXL	EPZ	\$54	
	AUXH	EPZ	\$55	
	PICK	EPZ	\$95	
	IN	EOU	\$0200	
	USRADDR	EQU	\$03F8	
	MMI	EOU	\$03FB	
	IFOLOC	EOU	\$03FF	
	ICADR	EQU	SC000	
	KBD	EQU	SC000	
	KBDSTRR	EQU	SC010	
	TAPEOUT	EQU	SC020	
	SPKR	EQU	SC030	
	TXTCLR	EQU	SC050	
	TXTSET	EQU	SC051	
	MIXCLR	EQU	SC052	
	MIXSET	EQU	SC053	
	LOWSCR	EQU	SC054	
	HISCR	EQU	SC055	
	LORES	EQU	SC056	
	HIRES	EQU	SC057	
	TAPEIN	EQU	SC060	
	PADOL0	EQU	SC064	
	PTRIG	EQU	SC070	
	BASIC	EQU	SE000	
	BASIC2	EQU	SE003	
	ORG		\$F800	ROM START ADDRESS
F800:	4A	PLOT	LSR A	Y-COORD/2
F801:	08		PHP	SAVE LSB IN CARRY
F802:	20 47 F8		JSR GBASCALC	CALC BASE ADR IN GBASL,H
F805:	28		PLP	RESTORE LSB FROM CARRY
F806:	A9 0F		LDA #SOF	MASK SOF IF EVEN
F808:	90 02		BCC RTMASK	
F80A:	69 E0		ADC #SEO	MASK \$FO IF ODD
F80C:	85 2E	RTMASK	STA MASK	
F80E:	B1 26	PLOT1	LDA (GBASL),Y	DATA
F810:	45 30		EOP COLOR	XOR COLOP
F812:	25 2E		AND MASK	AND MASK
F814:	51 26		EOR (GRASL),Y	XOR DATA
F816:	91 26		STA (GRASL),Y	TO DATA
F818:	60		RTS	
F819:	20 00 F8	HLINE	JSR PLOT	PLOT SQUARE
F81C:	C4 2C	HLINE1	CPY H2	DONE?
F81E:	B0 11		BCS RTS1	YES, RETURN
F820:	C8		INY	NO, INCR INDEX (X-COORD)
F821:	20 0E F8		JSR PLOT1	PLOT NEXT SQUARE
F824:	90 F6		BCC HLINE1	ALWAYS TAKEN
F826:	69 01	VLINEZ	ADC #S01	NEXT Y-COORD
F828:	48	VLINE	PHA	SAVE ON STACK
F829:	20 00 F8		JSR PLOT	PLOT SQUARE
F82C:	68		PLA	
F82D:	C5 2D		CMP V2	DONE?
F82F:	90 F5		BCC VLINEZ	NO,LOOP.
F831:	60	RTS1	RTS	
F832:	A0 2F	CLRSCR	LDY #\$2F	MAX Y, FULL SCRN CLR
F834:	D0 02		PNE CLRSC2	ALWAYS TAKEN
F836:	A0 27	CLRTOP	LDY #\$27	MAX Y, TOP SCRN CLR
F838:	84 2D	CLRSC2	STY V2	STORE AS BOTTOM COORD
	*			FOR VLINE CALLS
F83A:	A0 27		LDY #\$27	RIGHTMOST X-COORD (COLUMN)
F83C:	A9 00	CLRPSC3	LDA #S0	TOP COORD FOR VLINE CALLS
F83E:	85 30		STA COLOR	CLEAR COLOR (BLACK)
F840:	20 28 F8		JSR VLINF	CPAW VLINE
F843:	88		DEY	NEXT LEFTMOST X-COORD
F844:	10 F6		BPL CLRSC3	LOOP UNTIL DONE.
F846:	60		RTS	
F847:	48	GBASCALC	PHA	FOR INPUT 000DEFFH
F848:	4A		LSR A	
F849:	29 03		AND *\$03	
F84B:	09 04		OPA #S04	GENERATE GRASH=000001FG
F84D:	85 27		STA GBASH	
F84F:	68		PLA	AND GRASL=H0EDF000
F850:	29 18		AND #S18	
F852:	90 02		BCC CRCALC	
F854:	69 7F		ADC #7F	
F856:	85 26	GBCALC	STA GRASL	

F858: 0A		ASL A	
F859: 0A		ASL A	
F85A: 05 26		ORA GBASL	
F85C: 85 26		STA GPASL	
F85E: 60		RTS	
F85F: A5 30	NXTCOL	LDA COLOR	INCREMENT COLOR BY 3
F861: 13		CLC	
F862: 69 03		ADC #\$03	
F864: 29 0F	SETCOL	AND #\$0F	SETS COLOR=17*A MOD 16
F866: 85 30		STA COLOR	
F868: 0A		ASL A	POTH HALF PYTES OF COLOR EQUAL
F869: 0A		ASL A	
F86A: 0A		ASL A	
F86B: 0A		ASL A	
F86C: 05 30		ORA COLOR	
F86E: 85 30		STA COLOR	
F870: 60		RTS	
F871: 4A	SCPN	LSR A	READ SCPEEN Y-COORD/2
F872: 08		PHP	SAVE LSB (CARRY)
F873: 20 47 F8		JSR GBASCALC	CALC BASE ADDRESS
F876: B1 26		LDA (GEASL),Y	GET BYTE
F878: 28		PLP	RESTORE LSP FROM CARRY
F879: 90 04	SCRN2	RCC RTMSKZ	IF EVEN, USE LO H
F87B: 4A		LSR A	
F87C: 4A		LSR A	
F87D: 4A		LSR A	SHIFT HIGH HALF BYTE DOWN
F87E: 4A		LSR A	
F87F: 29 0F	RTMSKZ	AND #\$0F	MASK 4-BITS
F881: 60		RTS	
F882: A6 3A	IMSOS1	LDX PCL	PRINT PCL,H
F884: A4 3B		LDY PCF	
F886: 20 96 FD		JSP PRYX2	
F889: 20 48 F9		JSR PRINLK	FOLLOWED BY A BLANK
F88C: A1 3A		LDA (PCL,X)	CET OP CODE
F88E: A8	INSOS2	TAY	
F88F: 4A		LSR A	EVEN/ODD TEST
F890: 90 09		BCC IEVEN	
F892: 6A		ROP A	BIT 1 TEST
F893: R0 10		BCS RPP	XXXXXXXX11 INVALID OP
F895: C9 A2		CMP #\$A2	
F897: FG 0C		BEQ RER	OPCODE \$69 INVALID
F899: 29 87		AND #\$87	MASK BITS
F893: 4A	IEVEN	LSR A	LSR INTO CARRY FOR I/P TEST
F89C: AA		TAX	
F89D: BD 62 F9		LDA FMT1,X	GET FORMAT INDEX BYTE
F8A0: 20 79 F8		JSR SCRN2	P/L H-BYTE ON CARRY
F8A3: D0 04		RNE GETF1T	
F8A5: A0 80	ERP	LDY #\$8C	SUBSTITUTE S80 FOR INVALID OPS
F8A7: A9 00		LDA #\$80	SFT PRINT FORMAT INDEX TO 0
F8A9: AA	GETFMT	TAX	
F8AA: BD A6 F9		LDA FMT2,X	INDEX INTO PFINT FORMAT TABLE
F8AD: 85 2E		STA FORMAT	SAVE FOR ADR FIELD FORMATTING
F8AF: 29 03		AND #\$03	MASK FOR 2-BIT LENGTH
	*	(P=1 BYTE, 1=2 BYTE, 2=3 BYTE)	
F8B1: 85 2F		STA LENGTH	
F8B3: 98		TYA	OPCODE
F8B4: 29 8F		AND #\$8F	MASK FOR 1XXX1010 TEST
F8B6: AA		TAX	SAVF IT
F8B7: 98		TYA	OPCODE TO A AGAIN
F8B8: A0 03		LDY #\$03	
F8BA: E0 8A		CPX #\$8A	
F8BC: F0 08		BEQ MNNDX3	
F8BE: 4A	MNNDX1	LSR A	
F8BF: 90 08		BCC MNNDX3	FORM INDEX INTO MNEMONIC TABLE
F8C1: 4A		LSR A	
F8C2: 4A	MNNDX2	LSP A	1) 1XXX1010=>00101XXX
F8C3: 09 20		ORA #\$20	2) XXXYYY01=>00111XXX
F8C5: 88		DEY	3) XXXYYY10=>00110XXX
F8C6: D0 FA		BNE MNNDX2	4) XXXYY100=>00100XXX
F8C8: C8		INY	5) XXXXX000=>000XXXXXX
F8C9: 88	MNNDX3	DEY	
F8CA: D0 F2		BNE MNNDX1	
F8CC: 60		RTS	
F8CD: FF FF FF		DFB \$FF,\$FF,\$FF	
F8D0: 20 82 F8	INSTDSP	JSR INSDS1	GEN FMT, LEN BYTES
F8D3: 48		PHA	SAVE MNEMONIC TABLE INDEX
F8D4: B1 3A	PRNTOP	LDA (PCL),Y	
F8D6: 20 DA FD		JSR PRBYTE	
F8D9: A2 01		LDX #\$01	PRINT 2 BLANKS
F8DB: 20 4A F9	PRNTBL	JSR PRBL2	
F8DE: C4 2F		CPY LENGTH	PRINT INST (1-3 BYTES)
F8E0: C8		INY	IN A 12 CHR FIELD
F8E1: 90 F1		BCC PRNTOP	
F8E3: A2 03		LDX #\$03	CHAR COUNT FOR MNEMONIC PRINT
F8E5: C0 04		CPY #\$04	

F8E7: 90 F2	BCC	PRNTBL	
F8E9: 68	PLA		RECOVER MNEMONIC INDEX
F8EA: A8	TAY		
F8EB: B9 C0 F9	LDA	MNEML,Y	
F8EE: 85 2C	STA	LMNEM	FETCH 3-CHAR MNEMONIC
F8F0: B9 00 FA	LDA	MNEMR,Y	(PACKED IN 2-BYTES)
F8F3: 85 2D	STA	RMNEM	
F8F5: A9 00	PRMN1	LDA	\$00
F8F7: A0 05		LDY	\$05
F8F9: 06 2D	PRMN2	ASL	RMNEM
F8FB: 26 2C		ROL	LMNEM
F8FD: 2A		ROL	A
F8FE: 88		DEY	(CLEAR CARRY)
F8FF: D0 F8		BNE	PRMN2
F901: 69 BF		ADC	#\$BF
F903: 20 ED FD		JSR	COUT
F906: CA		DEX	
F907: D0 EC		BNE	PRMN1
F909: 20 48 F9		JSR	PRBLNK
F90C: A4 2F		LDY	LENGTH
F90E: A2 06		LDX	#\$06
F910: E0 03	PRADR1	CPX	\$03
F912: F0 1C		BEQ	PRADR5 IF X=3 THEN ADDR.
F914: 06 2E	PRADR2	ASL	FORMAT
F916: 90 0E		BCC	PRADR3
F918: BD B3 F9		LDA	CHAR1-1,X
F91B: 20 ED FD		JSR	COUT
F91E: BD B9 F9		LDA	CHAR2-1,X
F921: F0 03		BEQ	PRADR3
F923: 20 ED FD		JSR	COUT
F926: CA	PRADR3	DEX	
F927: D0 E7		BNE	PRADR1
F929: 60		RTS	
F92A: 88	PRADR4	DEY	
F92B: 30 E7		BMI	PRADR2
F92D: 20 DA FD		JSR	PRRYTE
F930: A5 2E	PRADR5	LDA	FORMAT
F932: C9 E8		CMP	#\$E8
F934: B1 3A		LDA	(PCL),Y
F936: 90 F2		BCC	PRADR4
F938: 20 56 F9	RELADR	JSR	PCADJ3
F93B: AA		TAX	PCL,PCH+OFFSET+1 TO A,Y
F93C: E8		INX	
F93D: D0 01		BNE	PRNTYX +1 TO Y,X
F93F: C8		INY	
F940: 98	PRNTYX	TYA	
F941: 20 DA FD	PRNTAX	JSR	PRBYTE OUTPUT TARGET ADR
F944: 8A	PRNTX	TXA	OF BRANCH AND RETURN
F945: 4C DA FD		JMP	PRBYTE
F948: A2 03	PRBLNK	LDX	\$03 BLANK COUNT
F94A: A9 A0	PRBL2	LDA	#\$A0 LOAD A SPACE
F94C: 20 ED FD	PRBL3	JSR	COUT OUTPUT A BLANK
F94F: CA		DEX	
F950: D0 F8		BNE	PRBL2 LOOP UNTIL COUNT=0
F952: 60		RTS	
F953: 38	PCADJ	SEC	0=1-BYTE, 1=2-BYTE,
F954: A5 2F	PCADJ2	LDA	2=3-BYTE
F956: A4 3B	PCADJ3	LDY	PCH
F958: AA		TAX	TEST DISPLACEMENT SIGN
F959: 10 01		BPL	(FOR REL BRANCH)
F95B: 88		DEY	EXTEND NEG BY DECR PCH
F95C: 65 3A	PCADJ4	ADC	PCL
F95E: 90 01		BCC	RTS2 PCL+LENGTH(OR DISPL)+1 TO A
F960: C8		INY	CARRY INTO Y (PCH)
F961: 60	RTS2	RTS	
	*	FMT1 BYTES:	XXXXXXXX0 INSTRS
	*		IF Y=0 THEN LEFT HALF BYTE
	*		IF Y=1 THEN RIGHT HALF BYTE
	*		(X=INDEX)
F962: 04 20 54		DFB	\$04,\$20,\$54,\$30,\$0D
F965: 30 0D	FMT1	DFB	\$80,\$04,\$90,\$03,\$22
F967: 80 04 90		DFB	\$54,\$33,\$0D,\$80,\$04
F96A: 03 22		DFB	\$90,\$04,\$20,\$54,\$33
F96C: 54 33 0D		DFB	\$0D,\$80,\$04,\$90,\$04
F96F: 80 04		DFB	\$20,\$54,\$3B,\$0D,\$80
F971: 90 04 20		DFB	\$04,\$90,\$00,\$22,\$44
F974: 54 33		DFB	\$33,\$0D,\$C8,\$44,\$00
F976: 0D 80 04			
F979: 90 04			
F97B: 20 54 3B			
F97E: 0D 80			
F980: 04 90 00			
F983: 22 44			
F985: 33 0D C8			
F988: 44 00			

F98A: 11 22 44		
F98D: 33 0D	DFB	\$11,\$22,\$44,\$33,\$0D
F98F: C8 44 A9		
F992: 01 22	DFB	SC8,\$44,\$A9,\$01,\$22
F994: 44 33 0D		
F997: 80 04	DFB	\$44,\$33,\$0D,\$80,\$04
F999: 90 01 22		
F99C: 44 33	DFB	\$90,\$01,\$22,\$44,\$33
F99E: 0D 80 04		
F9A1: 90	DFB	\$0D,\$80,\$04,\$90
F9A2: 26 31 87		
F9A5: 9A	DFB	\$26,\$31,\$87,\$9A ZZZZZY01 INSTR'S
F9A6: 00	FMT2	DFB \$00 ERR
F9A7: 21		DFB \$21 IMM
F9A8: 81		DFB \$81 Z-PAGE
F9A9: 82		DFB \$82 ABS
F9AA: 00		DFB \$00 IMPLIED
F9AB: 00		DFB \$00 ACCUMULATOR
F9AC: 59		DFB \$59 (ZPAG,X)
F9AD: 4D		DFB \$4D (ZPAG),Y
F9AE: 91		DFB \$91 ZPAG,X
F9AF: 92		DFB \$92 ABS,X
F9B0: 8E		DFB \$8E ABS,Y
F9B1: 4A		DFB \$4A (ABS)
F9B2: 85		DFB \$85 ZPAG,Y
F9B3: 9D		DFB \$9D RELATIVE
F9B4: AC A9 AC		
A3 A8 A4	CHAR1	ASC ",),#(\$"
F9BA: D9 00 D8		
F9BD: A4 A4 00	CHAR2	DFB SD9,\$00,\$D8,\$A4,\$A4,\$00
*CHAR2:	"Y",0,"XSS",0	
*	MNEML	IS OF FORM:
*	(A)	XXXXX000
*	(B)	XXXYY100
*	(C)	1XXX1010
*	(D)	XXXYY10
*	(E)	XXXYY01
	*	(X=INDEX)
F9C0: 1C 8A 1C		
F9C3: 23 5D 8B	MNEML	DFB \$1C,\$8A,\$1C,\$23,\$5D,\$8B
F9C6: 1B A1 9D		
F9C9: 8A 1D 23		DFB \$1B,\$A1,\$9D,\$8A,\$1D,\$23
F9CC: 9D 8B 1D		
F9CF: A1 00 29		DFB \$9D,\$8B,\$1D,\$A1,\$00,\$29
F9D2: 19 AE 69		
F9D5: A8 19 23		DFB \$19,\$AE,\$69,\$A8,\$19,\$23
F9D8: 24 53 1B		
F9DB: 23 24 53		DFB \$24,\$53,\$1B,\$23,\$24,\$53
F9DE: 19 A1		DFB \$19,\$A1 (A) FORMAT ABOVE
F9E0: 00 1A 5B		
F9E3: 5B A5 69		DFB \$00,\$1A,\$5B,\$5B,\$A5,\$69
F9E6: 24 24		DFB \$24,\$24 (B) FORMAT
F9E8: AE AE A8		
F9EB: AD 29 00		DFB \$AE,\$AE,\$A8,\$AD,\$29,\$00
F9EE: 7C 00		DFB \$7C,\$00 (C) FORMAT
F9F0: 15 9C 6D		
F9F3: 9C A5 69		DFB \$15,\$9C,\$6D,\$9C,\$A5,\$69
F9F6: 29 53		DFB \$29,\$53 (D) FORMAT
F9F8: 84 13 34		
F9FB: 11 A5 69		DFB \$84,\$13,\$34,\$11,\$A5,\$69
F9FE: 23 A0		DFB \$23,\$A0 (E) FORMAT
FA00: D8 62 5A		
FA03: 48 26 62	MNEMR	DFB \$D8,\$62,\$5A,\$48,\$26,\$62
FA06: 94 88 54		
FA09: 44 C8 54		DFB \$94,\$88,\$54,\$44,\$C8,\$54
FA0C: 68 44 E8		
FA0F: 94 00 B4		DFB \$68,\$44,\$E8,\$94,\$00,\$B4
FA12: 08 84 74		
FA15: B4 28 6E		DFB \$08,\$84,\$74,\$B4,\$28,\$6E
FA18: 74 F4 CC		
FA1B: 4A 72 F2		DFB \$74,\$F4,SCC,\$4A,\$72,\$F2
FA1E: A4 8A		DFB \$A4,\$8A (A) FORMAT
FA20: 00 AA A2		
FA23: A2 74 74		DFB \$00,\$AA,\$A2,\$A2,\$74,\$74
FA26: 74 72		DFB \$74,\$72 (B) FORMAT
FA28: 44 68 B2		
FA2B: 32 B2 00		DFB \$44,\$68,\$B2,\$32,\$B2,\$00
FA2E: 22 00		DFB \$22,\$00 (C) FORMAT
FA30: 1A 1A 26		
FA33: 26 72 72		DFB \$1A,\$1A,\$26,\$26,\$72,\$72
FA36: 88 C8		
FA38: C4 CA 26		DFB \$88,\$C8 (D) FORMAT
FA3B: 48 44 44		
FA3E: A2 C8		DFB \$C4,\$CA,\$26,\$48,\$44,\$44
		DFB \$A2,\$C8 (E) FORMAT

FA40: FF FF FF	DFB \$FF,\$FF,\$FF
FA43: 20 D0 F8 STEP	JSR INSTDSP DISASSEMBLE ONE INST
FA46: 68	PLA AT (PCL,H)
FA47: 85 2C	STA RTNL ADJUST TO USER
FA49: 68	PLA STACK. SAVE
FA4A: 85 2D	STA RTNH RTN ADR.
FA4C: A2 08	LDX #\$08
FA4E: BD 10 FB XQINIT	LDA INITSL-1,X INIT XEO AREA
FA51: 95 3C	STA XQT,X
FA53: CA	DEX
FA54: D0 F8	BNE XQINIT
FA56: A1 3A	LDA (PCL,X) USER OPCODE BYTE
FA58: F0 42	BEO XBRK SPECIAL IF BREAK
FA5A: A4 2F	LDY LENGTH LEN FROM DISASSEMBLY
FA5C: C9 20	CMP #\$20
FA5E: F0 59	BEO XJSR HANDLE JSR, PTS, JMP,
FA60: C9 60	CMP #\$60 JMP (), RTI SPECIAL
FA62: F0 45	BEQ XRTS
FA64: C9 4C	CMP #\$4C
FA66: F0 5C	BEQ XJMP
FA68: C9 6C	CMP #\$6C
FA6A: F0 59	BEQ XJMPAT
FA6C: C9 40	CMP #\$40
FA6E: F0 35	BEO XRTI
FA70: 29 1F	AND #\$1F
FA72: 49 14	EOR #\$14
FA74: C9 04	CMP #\$04 COPY USFR INST TO XEO AREA
FA76: F0 02	BEQ XQ2 WITH TRAILING NOPS
FA78: B1 3A XQ1	LDA (PCL),Y CHANGE REL BRANCH
FA7A: 99 3C 00 XQ2	STA XQTNZ,Y DISP TO 4 FOR
FA7D: 88	DEY JMP TO BRANCH OR
FA7E: 10 F8	BPL XQ1 NBRANCH FROM XEQ.
FA80: 20 3F FF	JSR RESTORE RESTORE USER REG CONTENTS.
FA83: 4C 3C 00	JMP XQTNZ XEQ USER OP FROM RAM
FA86: 85 45 IRQ	STA ACC (RETURN TO NBRANCH)
FA88: 68	PLA
FA89: 48	PHA **IRQ HANDLER
FA8A: 0A	ASL A
FA8B: 0A	ASL A
FA8C: 0A	ASL A
FA8D: 30 03	BMI BREAK TEST FOR BREAK
FA8E: 6C FE 03	JMP (IROLOC) USER ROUTINE VECTOR IN RAM
FA92: 28 BREAK	PLP
FA93: 20 4C FF	JSR SAV1 SAVE REG'S ON BREAK
FA96: 68	PLA INCLUDING PC
FA97: 85 3A	STA PCL
FA99: 68	PLA
FA9A: 85 3B	STA PCH
FA9C: 20 82 F8 XBRK	JSR INSDS1 PRINT USER PC.
FA9F: 20 DA FA	JSR RGDSP1 AND REG'S
FAA2: 4C 65 FF	JMP MON GO TO MONITOR
FAA5: 18 XRTI	CLC
FAA6: 68	PLA SIMULATE RTI BY EXPECTING
FAA7: 85 48	STA STATUS STATUS FROM STACK, THEN RTS
FAA9: 68 XRTS	PLA RTS SIMULATION
FAAA: 85 3A	STA PCL EXTRACT PC FROM STACK
FAAC: 68	PLA AND UPDATE PC BY 1 (LEN=0)
FAAD: 85 3B PCINC2	STA PCH
FAAF: A5 2F PCINC3	LDA LENGTH UPDATE PC BY LEN
FAB1: 20 56 F9	JSR PCADJ3
FAB4: 84 3B	STY PCH
FAB6: 18	CLC
FAB7: 90 14	BCC NEWPCL
FAB9: 18 XJSR	CLC
FABA: 20 54 F9	JSR PCADJ2 UPDATE PC AND PUSH
FABD: AA	TAX ONTO STACK FOR
FABE: 98	TYA JSR SIMULATE
FABF: 48	PHA
FAC0: 8A	TXA
FAC1: 48	PHA
FAC2: A0 02	LDY #\$02
FAC4: 18 XJMP	CLC
FAC5: B1 3A XJMPAT	LDA (PCL),Y
FAC7: AA	TAX LOAD PC FOR JMP,
FAC8: 88	DEY (JMP) SIMULATE.
FAC9: B1 3A	LDA (PCL),Y
FACB: 86 3B	STX PCH
FACD: 85 3A NEWPCL	STA PCL
FACF: B0 F3	BCS XJMP
FAD1: A5 2D RTNJMP	LDA RTNH
FAD3: 48	PHA
FAD4: A5 2C	LDA RTNL
FAD6: 48	PHA
FAD7: 20 8E FD REGDSP	JSR CROUT DISPLAY USER REG
FADA: A9 45 RGDSP1	LDA #ACC CONTENTS WITH
FADC: 85 40	STA A3L LABELS

FADE: A9 00	LDA #ACC/256
FAE0: 85 41	STA A3H
FAE2: A2 FB	LDX #\$FB
FAE4: A9 A0 RDSP1	LDA #\$A0
FAE6: 20 ED FD	JSR COUT
FAE9: BD 1E FA	LDA RTBL-\$FB,X
FAEC: 20 ED FD	JSR COUT
FAEF: A9 BD	LDA #\$BD
FAF1: 20 ED FD	JSR COUT
FAF4: B5 4A	LDA ACC+5,X
FAF6: 20 DA FD	JSR PRBYTE
FAF9: E8	INX
FAFA: 30 E8	BMI RDSP1
FAFC: 60	RTS
FAFD: 18 BRANCH	CLC
FAFE: A0 01	LDY #\$01
FB00: B1 3A	LDA (PCL),Y
FB02: 20 56 F9	JSR PCADJ3
FB05: 85 3A	STA PCL
FB07: 98	TYA
FB08: 38	SEC
FB09: B0 A2	BCS PCINC2
FB0B: 20 4A FF NRRNCH	JSR SAVE
FB0E: 38	SEC
FB0F: B0 9E	RCS PCINC3
FB11: EA INITBL	NOP
FB12: EA	NOP
FB13: 4C 0B FB	JMP NBRNCH
FB16: 4C FD FA	JMP BRANCH
FB19: C1 RTBL	DFB SC1
FB1A: D8	DFB \$D8
FB1B: D9	DFB \$D9
FB1C: D0	DFB \$D0
FB1D: D3	DFB \$D3
FB1E: AD 70 C0 PREAD	LDA PTPIG
FB21: A0 00	LDY #\$00
FB23: EA	NOP
FB24: EA	NOP
FB25: BD 64 C0 PREAD2	LDA PADDL0,X COUNT Y-PEG EVERY
FB28: 10 04	BPL RTS2D
FB2A: C8	INY
FB2B: D0 F8	BNE PREAD2
FB2D: 88	DEY
FB2E: 60 RTS2D	RTS
FB2F: A9 00 INIT	LDA #\$00
FB31: 85 48	STA STATUS
FB33: AD 56 C0	LDA LORES
FB36: AD 54 C0	LDA LOWSCR
FB39: AD 51 C0 SETTXT	LDA TXTSET
FB3C: A9 00	LDA #\$00
FB3E: F0 0B	BEO SETWND
FB40: AD 50 C0 SETGR	LDA TXTCLR
FB43: AD 53 C0	LDA MIXSET
FB46: 20 36 F8	JSR CLPTOP
FB49: A9 14	LDA #\$14
FB4B: 85 22 SETWND	STA WNDTOP
FB4D: A9 00	LDA #\$00
FB4F: 85 20	STA WNDLFT
FB51: A9 28	LDA #\$28
FB53: 85 21	STA WNDWDT
FB55: A9 18	LDA #\$18
FB57: 85 23	STA WNDRTM
FB59: A9 17	LDA #\$17
FB5B: 85 25 TABV	STA CV
FB5D: 4C 22 FC	JMP VTAP
FB60: 20 A4 FB MULPM	JSR MD1
FB63: A0 10 MUL	LDY #\$10
FB65: A5 50 MUL2	LDA ACI
FB67: 4A	LSR A
FB68: 90 0C	BCC MUL4
FB6A: 18	CLC
FB6B: A2 FE	LDX #SFE
FB6D: B5 54 MUL3	LDA XTNDL+2,X ADD MPLCND (AUX)
FB6F: 75 56	ADC AUXL+2,X TO PARTIAL PROD
FB71: 95 54	STA XTNDL+2,X (XTND).
FB73: E8	INX
FB74: D0 F7	BNE MUL3
FB76: A2 03 MUL4	LDX #\$03
FB78: 76 MUL5	DFB #\$76
FB79: 50	DFB #\$50
FB7A: CA	DEX
FB7B: 10 FB	BPL MUL5
FB7D: 88	DEY
FB7E: D0 E5	BNE MUL2
FB80: 60	PTS

FB81: 20 A4 FB	DIVPM	JSR MD1	ABS VAL OF AC, AUX.
FB84: A0 10	DIV	LDY #\$10	INDEX FOR 16 BITS
FB86: 06 50	DIV2	ASL ACL	
FB88: 26 51		ROL ACH	
FB8A: 26 52		ROL XTNDL	YTND/AUX
FB8C: 26 53		ROL XTNDH	TO AC.
FB8E: 38		SEC	
FB8F: A5 52		LDA XTNDL	
FB91: E5 54		SPC AUXL	MOD TO XTND.
FB93: AA		TAX	
FB94: A5 53		LDA XTNDH	
FB96: E5 55		SEC AUXH	
FB98: 90 06		BCC DIV3	
FB9A: 86 52		STX XTNDL	
FB9C: 85 53		STA XTNDH	
FB9E: E6 50		INC ACL	
FBA0: 88	DIV3	DEY	
FBA1: D0 E3		BNE DIV2	
FBA3: 60		RTS	
FBA4: A0 00	MD1	LDY #\$00	ABS VAL OF AC, AUX
FBA6: 84 2F		STY SIGN	WITH RESULT SIGN
FBA8: A2 54		LDX #AUXL	IN LSB OF SIGN.
FBA9: 20 AF F2		JSR MD2	
FBAD: A2 50		LDX #ACL	
FBAF: B5 01	MD2	LDA LOC1,X	X SPECIFIES AC OR AUX
FBB1: 10 OD		BPL MDRTS	
FBB3: 38		SEC	
FBB4: 98	MD3	TYA	
FBB5: F5 00		SBC LOCO,X	COMPL SPECIFIED REG
FBB7: 95 00		STA LOCO,X	IF NEG.
FBB9: 98		TYA	
FBBB: F5 01		SBC LOC1,X	
FBBC: 95 01		STA LOC1,X	
FBBE: E6 2F		INC SIGN	
FBC0: 60	MDRTS	RTS	
FBC1: 48	BASCALC	PHA	CALC BASE ADR IN BASL,H
FBC2: 4A		LSR A	FOR GIVEN LINE NO.
FBC3: 29 03		AND #\$03	0<=LINE NO.<=\$17
FBC5: 09 04		ORA #\$04	ARG=000ABCDE, GENERATE
FBC7: 85 29		STA BASH	BASH=000001CD
FBC9: 68		PLA	AND
FBCA: 29 18		AND #\$18	PASL=EABAB000
FBCC: 90 02		BCC BSCLC2	
FBCE: 69 7F		ADC #\$7F	
FBD0: 85 28	BSCLC2	STA BASL	
FBD2: 0A		ASL A	
FBD3: 0A		ASL A	
FBD4: 05 28		ORA BASL	
FBD6: 85 28		STA BASL	
FBD8: 60		RTS	
FBD9: C9 87	BELL1	CMP #\$87	BELL CHAR? (CNTRL-G)
FBDB: D0 12		BNE RTS2B	NO, RETURN
FBDD: A9 40		LDA #\$40	DELAY .01 SECONDS
FBDF: 20 A8 FC		JSR WAIT	
FBE2: A0 C0		LDY #\$C0	
FBE4: A9 0C	BELL2	LDA #\$0C	TOGGLE SPEAKER AT
FBE6: 20 A8 FC		JSR WAIT	1 KHZ FOR .1 SEC.
FBE9: AD 30 C0		LDA SPKR	
FBEC: 88		DEY	
FBED: D0 F5		BNE BELL2	
FBEF: 60	RTS2B	RTS	
FBF0: A4 24	STOADV	LDY CH	CURSER H INDEX TO Y-REG
FBF2: 91 28		STA (BASL),Y	STOR CHAR IN LINE
FBF4: E6 24	ADVANCE	INC CH	INCREMENT CURSER H INDEX
FBF6: A5 24		LDA CH	(MOVE RIGHT)
FBF8: C5 21		CMP WNDWDTH	Beyond WINDOW WIDTH?
FBFA: B0 66		BCS CR	YES 'P' TO NFXT LINE
FBFC: 60	PTS3	RTS	NO, RETURN
FBFD: C9 A0	VIDOUT	CMP #\$A0	CONTROL CHAR?
FBFF: B0 EF		BCS STOADV	NO, OUTPUT IT.
FC01: A8		TAY	INVERSE VIDEO?
FC02: 10 EC		BPL STOADV	YES, OUTPUT IT.
FC04: C9 8D		CMP #\$8D	CR?
FC06: F0 5A		BEQ CR	YES.
FC08: C9 8A		CMP #\$8A	LINE FEED?
FC0A: F0 5A		BEQ LF	IF SO, DO IT.
FC0C: C9 88		CMP #\$88	BACK SPACE? (CNTRL-H)
FC0E: D0 C9		BNE BELL1	NO, CHECK FOR BELL.
FC10: C6 24	PS	DEC CH	DECREMENT CURSER H INDEX
FC12: 10 E8		BPL RTS3	IF POS, OK. ELSE MOVE UP
FC14: A5 21		LDA WNDWDTH	SFT CH TO WNDWDTH-1
FC16: 85 24		STA CH	
FC18: C6 24		DEC CH	(RIGHTMOST SCREEN POS)
FC1A: A5 22	UP	LDA WNDTOP	CURSER V INDEX
FC1C: C5 25		CMP CV	

FC1E: B0 0B		BCS	RTS4	IF TOP LINE THEN RETURN
FC20: C6 25		DEC	CV	DFCR CURSER V-INDEX
FC22: A5 25	VTAB	LDA	CV	GET CURSER V-INDEX
FC24: 20 C1 FB	VTABZ	JSR	PASCALC	GENERATE BASE ADDR
FC27: 65 20		ADC	WNDLFT	ADD WINDOW LEFT INDEX
FC29: 85 28		STA	BASL	TO BASL
FC2B: 60	RTS4	PTS		
FC2C: 49 C0	ESC1	EOR	#\$C0	ESC?
FC2E: F0 28		BFO	HOME	IF SO, DO HOME AND CLEAR
FC30: 69 FD		ADC	#\$FD	ESC-A OR B CHECK
FC32: 90 C0		BCC	ADVANCF	A, ADVANCE
FC34: F0 DA		BEO	BS	B, BACKSPACE
FC36: 69 FD		ADC	#\$FD	ESC-C OR D CHECK
FC38: 90 2C		BCC	LF	C,DOWN
FC3A: F0 DE		BEQ	UP	D, GO UP
FC3C: 69 FD		ADC	#\$FD	ESC-E OR F CHECK
FC3E: 90 5C		BCC	CLREOL	E, CLEAR TO END OF LINE
FC40: D0 E9		BNE	RTS4	NOT F, RETURN
FC42: A4 24	CLREOP	LDY	CH	CURSOR H TO Y INDEX
FC44: A5 25		LDA	CV	CURSOR V TO A-REGISTER
FC46: 48	CLEOP1	PHA		SAVE CURRENT LINE ON STK
FC47: 20 24 FC		JSR	VTABZ	CALC BASE ADDRESS
FC4A: 20 9E FC		JSR	CLEOLZ	CLEAR TO EOL, SET CARRY
FC4D: A0 00		LDY	#\$00	CLEAR FROM H INDEX=0 FOR REST
FC4F: 68		PLA		INCREMENT CURRENT LINE
FC50: 69 00		ADC	#\$00	(CARRY IS SET)
FC52: C5 23		CMP	WNDETM	DONE TO BOTTOM OF WINDOW?
FC54: 90 F0		BCC	CLEOP1	NC, KEEP CLEAPING LINES
FC56: B0 CA		PCS	VTAR	YES, TAB TO CURRENT LINE
FC58: A5 22	HOME	LDA	WNDTOP	INIT CURSOR V
FC5A: 85 25		STA	CV	AND H-INDICES
FC5C: A0 00		LDY	#\$00	
FC5E: 84 24		STY	CH	THEN CLEAR TO END OF PAGE
FC60: F0 E4		BEO	CLEOP1	
FC62: A9 00	CR	LDA	#\$00	CURSOR TO LEFT OF INDEX
FC64: 85 24		STA	CH	(PET CURSOR H=0)
FC66: B6 25	LF	INC	CV	INCR CURSOR V(DOWN 1 LINE)
FC68: A5 25		LDA	CV	
FC6A: C5 23		CMP	WNDETM	OFF SCRFN?
FC6C: 90 B6		BCC	VTARZ	NO, SET BASE ADDR
FC6E: C6 25		DEC	CV	DEC CURSOR V(BACK TO BOTTOM LINE)
FC70: A5 22	SCROLL	LDA	WNDTOP	START AT TOP OF SCRL WNDW
FC72: 48		PHA		
FC73: 20 24 FC		JSR	VTARZ	GENERATE BASE ADDRESS
FC76: A5 28	SCRL1	LDA	BASL	COPY BASL,H
FC78: 85 2A		STA	BAS2L	TO BAS2L,H
FC7A: A5 29		LDA	BAS4	
FC7C: 85 2B		STA	BAS2H	
FC7E: A4 21		LDY	WNDETDTH	INIT Y TO RIGHTMOST INDEX
FC80: 88		DEY		OF SCROLLING WINDOW
FC81: 68		PLA		
FC82: 69 01		ADC	#\$01	INCR LINE NUMBER
FC84: C5 23		CMP	WNDETM	DONE?
FC86: B0 0D		BCS	SCRL3	YES, FINISH
FC88: 48		PHA		
FC89: 20 24 FC		JSR	VTABZ	FORM BASL,H (BASE ADDR)
FC8C: B1 28	SCRL2	LDA	(BASL),Y	MOVE A CHR UP ON LINE
FC8E: 91 2A		STA	(BAS2L),Y	
FC90: 88		DEY		NEXT CHAR OF LINE
FC91: 10 F9		BPL	SCRL2	
FC93: 30 E1		BMI	SCRL1	NEXT LINE
FC95: A0 00	SCRL3	LDY	#\$00	CLEAR BOTTOM LINE
FC97: 20 9E FC		JSR	CLEOLZ	GET PASE ADDR FOR BOTTOM LINE
FC9A: B0 86		BCS	VTAR	CARRY IS SET
FC9C: A4 24	CLREOL	LDY	CH	CURSOR H INDEX
FC9E: A9 A0	CLEOLZ	LDA	#\$A0	
FCA0: 91 28	CLEOL2	STA	(BASL),Y	STORE BLANKS FROM 'HERE'
FCA2: C8		INY		TO END OF LINES (WNDETDTH)
FCA3: C4 21		CPY	WNDETDTH	
FCA5: 90 F9		RCC	CLEOL2	
FCA7: 60		PTS		
FCA8: 38	WAIT	SEC		
FCA9: 48	WAIT2	PHA		
FCAA: E9 01	WAIT3	SBC	#\$01	
FCAC: D0 FC		PNE	WAIT3	1.0204 USEC . (13+2712*A+512*A*A)
FCAE: 68		PLA		
FCAF: E9 01		SBC	#\$01	
FCB1: D0 F6		BNE	WAIT2	
FCB3: 60		PTS		
FCB4: E6 42	NXTA4	INC	A4L	INCR 2-BYTE A4
FCB6: D0 02		PNE	NXTA1	AND A1
FCB8: E6 43		INC	A4H	
FCBA: A5 3C	NXTA1	LDA	A1L	INCR 2-BYTE A1.
FCBC: C5 3E		CMP	A2L	
FCBE: A5 3D		LDA	A1H	AND COMPARE TO A2

FCC0: E5 3F		SBC A2H	
FCC2: E6 3C		INC \$1L	(CARPY SET IF >=)
FCC4: D0 02		BNE RTS4B	
FCC6: E6 3D		INC A1H	
FCC8: 60	RTS4B	RTS	
FCC9: A0 48	HEADR	LDY #\$4P	WRITE A*256 'LONG 1'
FCCB: 20 DB FC		JSR ZERDLY	HALF CYCLES
FCCE: D0 F9		BNE HEADP	(650 USEC EACH)
FCDO: 69 FE		ADC #\$FF	
FCD2: E0 F5		RCS HEADR	THEN A 'SHORT 0'
FCD4: A0 21		LDY #\$21	(400 USEC)
FCD6: 20 DB FC	WRBIT	JSR ZERDLY	WRITE TWO HALF CYCLES
FCD9: C8		INY	OF 250 USEC ('0')
FCDA: C8		INY	OR 500 USEC ('0')
FCDB: 88	ZERDLY	DEY	
FCDC: D0 FD		BNE ZERDLY	
FCDE: 90 05		RCC WRTAPE	Y IS COUNT FOR
FCE0: A0 32		LDY #\$32	TIMING LOOP
FCE2: 88	ONEDLY	DEY	
FCE3: D0 FD		BNE ONEDLY	
FCE5: AC 20 C0	WRTAPE	LDY TAPEOUT	
FCE8: A0 2C		LDY #\$2C	
FCEA: CA		DEX	
FCEB: 60		RTS	
FCEC: A2 08	RDBYTE	LDX #\$08	8 BITS TO READ
FCEE: 48	RDBYT2	PHA	READ TWO TRANSITIONS
FCEF: 20 FA FC		JSP RD2BIT	(FIND EDGE)
FCF2: 68		PLA	
FCF3: 2A		ROL A	NEXT BIT
FCF4: A0 3A		LDY #\$3A	COUNT FOR SAMPLES
FCF6: CA		DEX	
FCF7: D0 F5		BNE RDBYT2	
FCF9: 60		RTS	
FCFA: 20 FD FC	RD2BIT	JSR RD2BIT	
FCFD: 88	RDPIT	DEY	DECR Y UNTIL
FCFE: AD 60 C0		LDA TAPKIN	TAPE TRANSITION
FD01: 45 2F		EOR LASTIN	
FD03: 10 F8		BPL RDBIT	
FD05: 45 2F		EOR LASTIN	
FD07: 85 2F		STA LASTIN	
FD09: C0 80		CPY #\$80	SET CARRY ON Y-REG.
FD0B: 60		RTS	
FD0C: A4 24	RDKEY	LDY CH	
FD0E: B1 28		LDA (\$A8L),Y	SET SCREEN TO FLASH
FD10: 48		PHA	
FD11: 29 3F		AND #\$3F	
FD13: 09 40		ORA #\$40	
FD15: 91 28		STA (\$A8L),Y	
FD17: 68		PLA	
FD18: 6C 38 00		JMP (KSML)	GO TO USER KEY-IN
FD1E: E6 4E	KEYIN	INC ENDL	
FD1D: D0 02		BNE KEYIN2	INCR RND NUMBER
FD1F: E6 4F		INC RNDH	
FD21: 2C 00 C0	KEYIN2	BIT KBD	KEY DOWN?
FD24: 10 F5		BPL KEYIN	LOOP
FD26: 91 28		STA (\$A8L),Y	REPLACE FLASHING SCREEN
FD28: AD 00 C0		LDA KBD	CET KEYCODE
FD2B: 2C 10 C0		BIT KBDSTPR	CLR KEY STPORE
FD2E: 60		RTS	
FD2F: 20 0C FD	ESC	JSR PDKEY	GET KEYCODE
FD32: 20 2C FC		JSR ESC1	HANDLE ESC FUNC.
FD35: 20 0C FD	RDCHAR	JSP RDKEY	READ KFY
FD38: C9 93		CMP #\$93	ESC?
FD3A: F0 F3		BEQ FSC	YES, DON'T RETURN
FD3C: 60		RTS	
FD3D: A5 32	NOTCR	LDA INVFLG	
FD3F: 48		PHA	
FD40: A9 FF		LDA #\$FF	
FD42: 85 32		STA INVFLG	ECHO USER LINE
FD44: BD 00 02		LDA IN,X	NON INVERSE
FD47: 20 ED FD		JSR COUT	
FD4A: 68		PLA	
FD4B: 85 32		STA INVFLG	
FD4D: BD 00 02		LDA IN,X	
FD50: C9 88		CMP #\$88	CHECK FOR EDIT KEYS
FD52: F0 1D		BEQ BCKSPC	BS, CTRL-X.
FD54: C9 98		CMP #\$98	
FD56: F0 0A		BEQ CANCEL	
FD58: E0 F8		CPX #\$F8	MARGIN?
FD5A: 90 03		BCC NOTCR1	
FD5C: 20 3A FF		JSR RELL	YES, SOUND PELL
FD5F: E8	NOTCR1	INX	ADVANCE INPUT INDEX
FD60: D0 13		BNE NXTCCHAR	
FD62: A9 DC	CANCEL	LDA #\$DC	BACKSLASH AFTER CANCELLED LINE
FD64: 20 ED FD		JSR COUT	

FD67: 20 8E FD	GETLNZ	JSR CROUT	OUTPUT CR
FD6A: A5 33	GETLN	LDA PROMPT	
FD6C: 20 ED FD		JSR COUT	OUTPUT PROMPT CHAR
FD6F: A2 01		LDX #S01	INIT INPUT INDEX
FD71: 8A	BCKSPC	TXA	WILL BACKSPACE TO 0
FD72: F0 F3		BEQ GETLNZ	
FD74: CA		DEX	
FD75: 20 35 FD	NXTCHAF	JSP PDCHAR	
FD78: C9 95		CMP #PICK	USE SCREEN CHAR
FD7A: D0 02		BNE CAPTST	FOR CTRL-U
FD7C: B1 28		LDA (BASL),Y	
FD7E: C9 E0	CAPTST	CMP #\$E0	
FD80: 90 02		BCC ADDINP	CONVERT TO CAPS
FD82: 29 DF		AND #\$DF	
FD84: 9D 00 02	ADDINP	STA IN,X	ADD TO INPUT BUF
FD87: C9 8D		CMP #\$8D	
FD89: D0 B2		BNE NOTCR	
FD8B: 20 9C FC		JSR CLREOL	CLR TO EOL IF CR
FD8E: A9 8D	CROUT	LDA #\$8D	
FD90: D0 5B		BNE COUT	
FD92: A4 3D	PRA1	LDY A1H	PRINT CR,A1 IN HEX
FD94: A6 3C		LDX A1L	
FD96: 20 8E FD	PRYX2	JSR CROUT	
FD99: 20 40 F9		JSR PRNTYX	
FD9C: A0 00		LDY #\$00	
FD9E: A9 AD		LDA #\$AD	PRINT '-'
FDA0: 4C ED FD		JMP COUT	
FDA3: A5 3C	XAM8	LDA A1L	
FDA5: 09 07		ORA #\$07	SET TO FINISH AT
FDA7: 85 3E		STA A2L	MOD P=7
FDA9: A5 3D		LDA A1H	
FDAB: 85 3F		STA A2H	
FDAD: A5 3C	MOD8CHK	LDA A1L	
FDAF: 29 07		AND #\$07	
FDB1: D0 03		BNE DATAOUT	
FDB3: 20 92 FD	XAM	JSR PRA1	
FDB6: A9 A0	DATAOUT	LDA #\$A0	
FDB8: 20 ED FD		JSR COUT	OUTPUT BLANK
FDDB: B1 3C		LDA (A1L),Y	
FDBD: 20 DA FD		JSR PRBYTE	OUTPUT BYTE IN HEX
FDC0: 20 BA FC		JSR NXTA1	
FDC3: 90 E8		BCC MOD8CHK	CHECK IF TIME TO,
FDC5: 60	RTS4C	RTS	PRINT ADDR
FDC6: 4A	XAMP'M	LSR A	DETERMINE IF MON
FDC7: 90 EA		BCC XAM	MODE IS XAM
FDC9: 4A		LSR A	ADD, OR SUB
FDCA: 4A		LSR A	
FDCB: A5 3E		LDA A2L	
FDCD: 90 02		BCC ADD	
FDCF: 49 FF		eor #\$FF	SUB: FORM 2'S COMPLEMENT
FDD1: 65 3C	ADD	ADC A1L	
FDD3: 48		PHA	
FDD4: A9 BD		LDA #\$SD	
FDD6: 20 ED FD		JSR COUT	PRINT '=' , THEN RESULT
FDD9: 68		PLA	
FDDA: 48	PRBYTE	PHA	PRINT BYTE AS 2 HEX
Fddb: 4A		LSR A	DIGITS, DESTROYS A-REG
FDDC: 4A		LSR A	
FDDD: 4A		LSP A	
FDDE: 4A		LSR A	
FDDF: 20 E5 FD		JSR PRHEXZ	
FDE2: 68		PLA	
FDE3: 29 0F	PRHEX	AND #\$0F	PRINT HEX DIG IN A-REG
FDE5: 09 B0	PRHEXZ	ORA #\$E0	LSB'S
FDE7: C9 BA		CMP #\$BA	
FDE9: 90 02		BCC COUT	
FDEB: 69 06		ADC #\$06	
FDED: 6C 36 00	COUT	JMP (CSWL)	VECTOR TO USER OUTPUT ROUTINE
FDF0: C9 A0	COUT1	CMP #\$A0	
FDF2: 90 02		BCC COUTZ	DON'T OUTPUT CTRL'S INVERSE
FDF4: 25 32		AND INVFLG	MASK WITH INVERSE FLAG
FDF6: 84 35	COUTZ	STY YSAV1	SAV Y-REG
FDF8: 48		PHA	SAV A-REG
FDF9: 20 FD FB		JSR VIDOUT	OUTPUT A-REG AS ASCII
FDFC: 68		PLA	RESTORE A-REG
FDFD: A4 35		LDY YSAV1	AND Y-REG
Fdff: 60		RTS	THEN RETURN
FE00: C6 34	BL1	DEC YSAV	
FE02: F0 9F		BEQ XAM8	
FE04: CA	BLANK	DEX	BLANK TO MON
FE05: D0 16		BNE SETMDZ	AFTER BLANK
FE07: C9 BA		CMP #\$BA	DATA STORE MODE?
FE09: D0 BB		BNE XAMPM	NO, XAM, ADD OR SUB
FE0B: 85 31	STOR	STA MODE	KEEP IN STORE MODE
FE0D: A5 3E		LDA A2L	

FE0F: 91 40		STA (A3L),Y	STORE AS LOW BYTE AS (A3)
FE11: E6 40		INC A3L	
FE13: D0 02		BNE RTS5	INCR A3, RETURN
FE15: E6 41		INC A3H	
FE17: 60	RTS5	RTS	
FE18: A4 34	SFTMODE	LDY YSAV	SAVE CONVERTED ':', '+',
FE1A: B9 FF 01		LDA IN-1,Y	'-', '.' AS MODE.
FE1D: 85 31	SETMDZ	STA MODE	
FE1F: 60		RTS	
FE20: A2 01	LT'	LDX #\$01	
FE22: B5 3E	LT2	LDA A2L,X	COPY A2 (2 BYTES) TO
FE24: 95 42		STA A4L,X	A4 AND A5
FE26: 95 44		STA A5L,X	
FE28: CA		DEX	
FE29: 10 F7		BPL LT2	
FE2B: 60		RTS	
FE2C: B1 3C	MOVE	LDA (A1L),Y	MOVE (A1 TO A2) TO
FE2E: 91 42		STA (A4L),Y	(A4)
FE30: 20 B4 FC		JSR NXTA4	
FE33: 90 F7		BCC MOVE	
FE35: 60		RTS	
FE36: B1 3C	VFY	LDA (A1L),Y	VERIFY (A1 TO A2) WITH
FE38: D1 42		CMP (A4L),Y	(A4)
FE3A: F0 1C		BEQ VFYOK	
FE3C: 20 92 FD		JSR PRA1	
FE3F: B1 3C		LDA (A1L),Y	
FE41: 20 DA FD		JSR PRBYTE	
FE44: A9 A0		LDA #SA0	
FE46: 20 ED FD		JSR COUT	
FE49: A9 A8		LDA #SA8	
FE4B: 20 ED FD		JSR COUT	
FE4E: B1 42		LDA (A4L),Y	
FE50: 20 DA FD		JSR PRBYTE	
FE53: A9 A9		LDA #SA9	
FE55: 20 ED FD		JSR COUT	
FE58: 20 B4 FC	VFYOK	JSR NXTA4	
FE5B: 90 D9		BCC VFY	
FE5D: 60		RTS	
FE5E: 20 75 FE	LIST	JSP A1PC	"^VE A1 (2 BYTES) TO
FE61: A9 14		LDA #\$14	PC IF SPEC'D AND
FE63: 48	LIST2	PHA	DISSEMBLE 20 INSTRS
FE64: 20 D0 F8		JSR INSTDSP	
FE67: 20 53 F9		JSR PCADJ	ADJUST PC EACH INSTR
FE6A: 85 3A		STA PCL	
FE6C: 84 3B		STY PCH	
FE6E: 68		PLA	
FE6F: 38		SEC	
FE70: E9 01		SBC #\$01	NEXT OF 20 INSTRS
FE72: D0 EF		BNE LIST2	
FE74: 60		RTS	
FE75: 8A	A1PC	TXA	
FE76: F0 07		EEQ A1PCRTS	IF USR SPEC'D ADR
FE78: B5 3C	A1PCLP	LDA A1L,X	COPY FROM A1 TO PC
FE7A: 95 3A		STA PCL,X	
FE7C: CA		DEX	
FE7D: 10 F9		FPL A1PCLP	
FE7F: 60	A1PCRTS	RTS	
FE80: A0 3F	SETINV	LDY #\$3F	SET FOR INVERSE VID
FE82: D0 02		BNE SETIFLG	VIA COUT1
FE84: A0 FF	SETNORM	LDY #FFF	SET FOR NORMAL VID
FE86: 84 32	SETIFLG	STY INVFLG	
FE88: 60		RTS	
FE89: A9 00	SETKBD	LDA #\$00	SIMULATE PORT #0 INPUT
FE8B: 85 3E	IMPORT	STA A2L	SPFCIFIED (KEYIN ROUTINE)
FE8D: A2 38	INPR	LDX #KSWL	
FE8F: A0 1B		LDY #KEYIN	
FE91: D0 08		BNE IOPRT	
FE93: A9 00	SETVID	LDA #\$00	SIMULATE PORT #0 OUTPUT
FE95: 85 3E	OUTPORT	STA A2L	SPECIFIED (COUT1 ROUTINE)
FE97: A2 36	OUTPRT	LDX #CSWL	
FE99: A0 F0		LDY #COUT1	
FE9B: A5 3E	IOPRT	LDA A2L	SET RAM IN/OUT VECTORS
FE9D: 29 0F		AND #\$0F	
FE9F: F0 06		BEQ IOPRT1	
FEA1: 09 C0		OFA #IOPADR/256	
FEA3: A0 00		LDY #\$00	
FEA5: F0 02		PEQ IOPRT2	
FEA7: A9 FD	IOPRT1	LDA #COUT1/256	
FEA9: 94 00	IOPRT2	STY LOC0,X	
FEAB: 95 01		STA LOC1,X	
FEAD: 60		PTS	
FEAE: EA		NOF	
FEAF: EA		NOP	
FEBO: 4C 00 E0	X BASIC	JMP BASIC	TO BASIC WITH SCRATCH
FE83: 4C 03 E0	BASCONT	JMP BASIC2	CONTINUE BASIC

FEB6: 20 75 FE GO	JSR A1PC	ADR TO PC IF SPEC'D
FEB9: 20 3F FF	JSR RESTORE	RESTORE META REGS
FEBC: 6C 3A 00	JMP (PCL)	GO TO USER SUBR
FEB2: 4C D7 FA REGZ	JMP REGDSP	TO REG DISPLAY
FEC2: C6 34 TPACE	DEC YSAV	
FEC4: 20 75 FE STEPZ	JSR A1PC	ADR TO PC IF SPEC'D
FEC7: 4C 43 FA	JMP STFP	TAKE ONE STEP
FECA: 4C F8 03 USP	JMP USRADR	TO USP SUBR AT USRADR
FECD: A9 40 WRITE	LDA #\$40	
FECF: 20 C9 FC	JSR HEADR	WRITE 10-SEC HEADER
FED2: A0 27	LDY #\$27	
FED4: A2 00 WR1	LDX #\$00	
FED6: 41 3C	EOP (ALL,X)	
FED8: 48	PHA	
FED9: A1 3C	LDA (ALL,X)	
FEDB: 20 ED FE	JSR WRBYTE	
FEDE: 20 BA FC	JSR NXTA1	
FEE1: A0 1D	LDY #\$10	
FEE3: 68	FLA	
FEE4: 90 EE	BCC WR1	
FEE6: A0 22	LDY #\$22	
FEE8: 20 ED FE	JSR WRBYTE	
FEEB: F0 40	BEC BELL	
FEED: A2 10 WRBYTE	LDX #\$10	
FEEF: 0A WRBYT2	ASL A	
FEF0: 20 D6 FC	JSR WRBIT	
FEF3: D0 FA	BNE WRBYT2	
FEF5: 60	RTS	
FEF6: 20 00 FE CRMON	JSR BL1	HANDLE CR AS PLANK
FEF9: 68	PLA	THEN POP STACK
FEFA: 68	PLA	AND RTN TO MON
FEFB: D0 6C	BNE MONZ	
FEFD: 20 FA FC READ	JSR RD2BIT	FIND TAPEIN EDGE
FF00: A9 16	LDA #\$16	
FF02: 20 C9 FC	JSR HEADR	DEJAY 3.5 SECONDS
FF05: 85 2E	STA CHKSUM	INIT CHKSUM=\$FF
FF07: 20 FA FC	JSR RD2BIT	FIND TAPEIN EDGE
FF0A: A0 24 RD2	LDY #\$24	LOOK FOR SYNC BIT (SHORT 0)
FF0C: 20 FD FC	JSR RD2BIT	LOOP UNTIL FOUND
FF0F: B0 F9	BCS RD2	
FF11: 20 FD FC	JSR RD2BIT	SKIP SECOND SYNC H-CYCLE
FF14: A0 3B	LDY #\$3B	INDEX FOR 0/1 TEST
FF16: 20 EC FC RD3	JSR RD2BYIE	READ A BYTE
FF19: 81 3C	STA (ALL,X)	STORE AT (A1)
FF1B: 45 2E	EOR CHKSUM	
FF1D: 85 2E	STA CHKSUM	UPDATE RUNNING CHKSUM
FF1F: 20 BA FC	JSR NXTA1	INCR A1, COMPARE TO A2
FF22: A0 35	LDY #\$35	COMPENSATE 0/1 INDEX
FF24: 90 F0	BCC RD3	LOOP UNTIL DONE
FF26: 20 EC FC	JSR RD2BYIE	READ CHKSUM' BYTE
FF29: C5 2E	CMP CHKSUM	
FF2B: F0 0D	BEQ BELL	GOOD, SOUND BELL AND RETURN
FF2D: A9 C5 PRERR	LDA #\$C5	
FF2F: 20 ED FD	JSR COUT	PRINT "ERR", THEN BELL
FF32: A9 D2	LDA #\$D2	
FF34: 20 ED FD	JSR COUT	
FF37: 20 ED FD	JSR COUT	
FF3A: A9 87 BELL	LDA #\$87	OUTPUT BELL AND RETURN
FF3C: 4C ED FD	JMP COUT	
FF3F: A5 48 RESTORE	LDA STATUS	RESTORE 6502 PEG CONTENTS
FF41: 48	PHA	USED BY DEBUG SOFTWARE
FF42: A5 45	LDA ACC	
FF44: A6 46 RESTRI	LDX XREG	
FF46: A4 47	LDY YREG	
FF48: 28	PLP	
FF49: 60	RTS	
FF4A: 85 45 SAVE	STA ACC	SAVE 6502 REG CONTENTS
FF4C: 86 46 SAV1	STX XREG	
FF4E: 84 47	STY YREG	
FF50: 08	PHP	
FF51: 68	PLA	
FF52: 85 48	STA STATUS	
FF54: BA	TSX	
FF55: 86 49	STX SPNT	
FF57: D8	CLO	
FF58: 60	PTS	
FF59: 20 84 FE RESET	JSR SETNORM	SET SCREEN MODE
FF5C: 20 2F FB	JSR INIT	AND INIT KBD/SCREEN
FF5F: 20 93 FE	JSR SETVID	AS I/O DEV'S
FF62: 20 89 FE	JSR SETKBD	
FF65: D8 MON	CLO	MUST SET HEX MODE!
FF66: 20 3A FF	JSR BELL	
FF69: A9 AA MONZ	LDA #\$AA	** PROMPT FOR MON
FF6B: 85 33	STA PROMPT	
FF6D: 20 67 FD	JSR GETLNZ	READ A LINE

FF70: 20 C7 FF		JSR ZMODE	CLEAR MON MODE, SCAN IDX
FF73: 20 A7 FF	NXTITM	JSR GETNUM	GET ITEM, NON-HEX
FF76: 84 34		STY YSAV	CHAR IN A-REG
FF78: A0 17		LDY #\$17	X-REG=0 IF NO HEX INPUT
FF7A: 88	CHRSCRH	DFY	
FF7B: 30 E8		BMI MON	NOT FOUND, GO TO MON
FF7D: D9 CC FF		CMP CHRTEL,Y	FIND CMND CHAR IN TEL
FF80: D0 F8		BNE CHRSPCH	
FF82: 20 BE FF		JSR TOSUB	FOUND, CALL CORRESPONDING
FF85: A4 34		LDY YSAV	SURROUNGE
FF87: 4C 73 FF		JMP NXITIM	
FF8A: A2 03	DIC	LDX #\$03	
FF8C: 0A		ASL A	
FF8D: 0A		ASL A	GOT HEX DIC,
FF8E: 0A		ASL A	SHIFT INTO A2
FF8F: 0A		ASL A	
FF90: 0A	NXTBIT	ASL A	
FF91: 26 3E		ROL A2L	
FF93: 26 3F		ROL A2H	
FF95: CA		DEX	LEAVE X=\$FF IF DIG
FF96: 10 F8		BPL NXTRIT	
FF98: A5 31	NXTBEAS	LDA MODE	
FF9A: D0 06		PNE NXTEAS2	IF MODE IS ZERO
FF9C: B5 3F		LDA A2H,X	THEN COPY A2 TO
FF9E: 95 3D		STA A1H,X	A1 AND A3
FFA0: 95 41		STA A3H,X	
FFA2: E8	NXTBS2	INX	
FFA3: F0 F3		BEQ NXTBAS	
FFA5: D0 06		BNE NXTCPR	
FFA7: A2 00	GETNUM	LDX #\$0C	CLEAR A2
FFA9: 86 3E		STX A2L	
FFAB: 86 3F		STX A2H	
FFAD: B9 00 02	NXTCPR	LDA IN,Y	GET CHAR
FFB0: C8		INY	
FFB1: 49 B0		FOR #\$B0	
FFB3: C9 0A		CMP #\$0A	
FFB5: 90 D3		BCC DIG	IF HEX DIG, THEN
FFB7: 69 88		ADC #\$88	
FFB9: C9 FA		CMP #\$FA	
FFB3: B0 CD		BCS DIG	
FFBD: 60		RTS	
FFBE: A9 FE	TOSUB	LDA \$C0/256	PUSH HIGH-ORDER
FFC0: 48		PHA	SURR ADR ON STK
FFC1: B9 E3 FF		LDA SURTPY	PUSH LOW ORDER
FFC4: 48		PHA	SUBN ADR ON STK
FFC5: A5 31		LDA MODE	
FFC7: A0 00	ZMODE	LDY #\$00	CLP MODE, CLR MODE
FFC9: 04 31		STY MODE	TO A-REG
FFCB: 60		RTS	GO TO SURR VIA RTS
FFCC: BC	CHRTEL	DFB \$BC	F("CTRL-C")
FFCD: B2		DFB \$B2	F("CTRL-Y")
FFCE: BE		DFB \$BE	F("CTRL-E")
FFCF: ED		DFB \$ED	F("T")
FFD0: EF		DFB \$EF	F("V")
FFD1: C4		DFB SC4	F("CTRL-K")
FFD2: EC		DFB SPC	F("S")
FFD3: A9		DFB SA9	F("CTRL-P")
FFD4: BB		DFB \$BB	F("CTRL-B")
FFD5: A6		DFB \$A6	F("-")
FFD6: A4		DFB \$A4	F("+")
FFD7: 06		DFB \$06	F("M") (F=EX-OR \$E0+\$89)
FFD8: 95		DFB \$95	F("<")
FFD9: 07		DFB \$07	F("N")
FFDA: 02		DFB \$02	F("I")
FFDB: 05		DFB \$05	F("L")
FFDC: F0		DFB \$F0	F("W")
FFDD: 00		DFB \$00	F("G")
FFDE: EB		DFB \$FB	F("R")
FFDF: 93		DFB \$93	F(":")
FFE0: A7		DFB SA7	F(".")
FFE1: C6		DFB SC6	F("CR")
FFE2: 99		DFB \$99	F(BLANK)
FFE3: B2	SURTPY	DFB #BASCONT-1	
FFE4: C9		DFB #USR-1	
FFE5: BE		DFB #REGZ-1	
FFE6: C1		DFB #TRACE-1	
FFE7: 35		DFB #VFY-1	
FFE8: 8C		DFB #INPRT-1	
FFE9: C3		DFB #STEPZ-1	
FFFA: 96		DFB #OUTPRT-1	
FFEB: AF		DFB #XPASIC-1	
FFEC: 17		DFB #SETMODE-1	
FFED: 17		DFB #SETMODE-1	
FFEE: 2B		DFB #MOVE-1	
FFEF: 1F		DFB #LT-1	

FFF0: 83	DFB #SETNORM-1
FFF1: 7F	DFB #SETINV-1
FFF2: 5D	DFB #LIST-1
FFF3: CC	DFB #WRITE-1
FFF4: E5	DFB #GO-1
FFF5: FC	DFB #READ-1
FFF6: 17	DFB #SETMODE-1
FFF7: 17	DFB #SETMODE-1
FFF8: F5	DFB #CRMON-1
FFF9: 03	DFB #BLANK-1
FFFA: FB	DFB #NMI NMI VECTOR
FFFB: 03	DFB #NMI/256
FFFC: 59	DFB #RESET RESET VECTOR
FFFD: FF	DFB #RESET/256
FFFE: 86	DFB #IRQ IRQ VECTOR
FFFF: FA	DFB #IRQ/256
XQTNC	EQU \$3C

```

*****
*          *
*      APPLE-II      *
*      MINI-ASSEMBLER  *
*          *
*      COPYRIGHT 1977 PY  *
*      APPLE COMPUTER INC.  *
*          *
*      ALL RIGHTS RESERVED  *
*          *
*      S. WOZNIAK      *
*      A. BAUM        *
*          *
*****
```

TITLE "APPLE-II MINI-ASSEMBLER"

FORMAT	EPZ	\$2E	
LENGTH	EPZ	\$2F	
MODE	EPZ	\$31	
PROMPT	EPZ	\$33	
YSAV	EPZ	\$34	
L	EPZ	\$35	
PCL	EPZ	\$3A	
PCH	EPZ	\$3B	
A1H	EPZ	\$3C	
A2L	EPZ	\$3E	
A2H	EPZ	\$3F	
A4L	EPZ	\$42	
A4H	EPZ	\$43	
FMT	EPZ	\$44	
IN	EQU	\$200	
INSDS2	EQU	\$F8&E	
INSTDSF	EQU	\$F6D0	
PR3L2	EQU	\$F94A	
PCADJ	EQU	\$F953	
CHAR1	EQU	\$F9B4	
CHAR2	EQU	\$F9FA	
MNEML	EQU	\$F9C0	
MNEAP	EQU	\$FA00	
CUFSUP	EQU	\$FC1A	
GETLNZ	EQU	\$FD67	
COUT	EQU	\$FDED	
BL1	EQU	\$FE00	
A1PCLP	EQU	\$FE78	
SELL	EQU	\$FF3A	
GETNUM	EQU	\$FFA7	
TOSUP	EQU	\$FFFF	
ZMODE	EQU	\$FFC7	
CHRTSL	EQU	\$FFCC	
ORG	ORG	\$F500	
F500: E9 81	REL	SPC #\$81	IS FMT COMPATIBLE
F502: 4A		LSP A	WITH RELATIVE MODE?
F503: D0 14		BNE LER3	NO.
F505: A4 3F		LDY A2:	
F507: A6 3E		LDY A2L	DOUBLE DECREMENT
F509: D0 01		BNE REL2	
F50B: 88		DEY	
F50C: CA	REL2	DEX	
F50D: 8A		TXA	
F50E: 18		CLC	
F50F: E5 3A		SBC PCL	FORM ADDR-PC-2
F511: 85 3E		STA A2L	
F513: 10 01		BPL PEL3	
F515: C8		INY	
F516: 98	REL3	TYA	

F517: E5 3B		SBC PCH	
F519: D0 6B	ERR3	BNE ERR	ERROR IF >1-BYTE BRANCH
F51B: A4 2F	FINDOP	LDY LENGTH	
F51D: B9 3D 00	FNDOP2	LDA A1H,Y	MOVE INST TO (PC)
F520: 91 3A		STA (PCL),Y	
F522: 88		DEY	
F523: 10 F8		BPL FNDOP2	
F525: 20 1A FC		JSR CURSUP	
F528: 20 1A FC		JSR CURSUP	RESTORE CURSOR
F52B: 20 D0 F8		JSR INSTDSP	TYPE FORMATTED LINE
F52E: 20 53 F9		JSR PCADJ	UPDATE PC
F531: 84 3B		STY PCH	
F533: 85 3A		STA PCL	
F535: 4C 95 F5		JMP NXTLINE	GET NEXT LINE
F538: 20 BE FF	FAKEMON3	JSR TOSUB	GO TO DELIM HANDLER
F53B: A4 34		LDY YSAV	RESTORE Y-INDEX
F53D: 20 A7 FF	FAKEMON	JSR GETNUM	READ PARAM
F540: 84 34		STY YSAV	SAVE Y-INDEX
F542: A0 17		LDY #\$17	INIT DELIMITER INDEX
F544: 88	FAKEMON2	DEY	CHECK NEXT DELIM
F545: 30 4B		BMI RESETZ	ERR IF UNRECOGNIZED DELIM
F547: D9 CC FF		CMP CHRTBL,Y	COMPARE WITH DELIM TABLE
F54A: D0 F8		BNE FAKEMON2	NO MATCH
F54C: C0 15		CPY #\$15	MATCH, IS IT CR?
F54E: D0 E8		BNE FAKEMON3	NO, HANDLE IT IN MONITOR
F550: A5 31		LDA MODE	
F552: A0 00		LDY #\$0	
F554: C6 34		DEC YSAV	
F556: 20 00 FE		JSR BL1	HANDLE CR OUTSIDE MONITOR
F559: 4C 95 F5		JMP NXTLINE	
F55C: A5 3D	TRYNEXT	LDA A1H	GET TRIAL OPCODE
F55E: 20 8E F8		JSR INSDS2	GET FMT+LENGTH FOR OPCODE
F561: AA		TAX	
F562: BD 00 FA		LDA MNEMR,X	GET LOWER MNEMONIC BYTE
F565: C5 42		CMP A4L	MATCH?
F567: D0 13		BNE NEXTOP	NO, TRY NEXT OPCODE
F569: BD C0 F9		LDA MNEML,X	GET UPPER MNEMONIC BYTE
F56C: C5 43		CMP A4H	MATCH?
F56E: D0 0C		BNE NEXTOP	NO, TRY NEXT OPCODE.
F570: A5 44		LDA FMT	
F572: A4 2E		LDY FORMAT	GET TRIAL FORMAT
F574: C0 9D		CPY #\$9D	TRIAL FORMAT RELATIVE?
F576: F0 88		BEQ REL	YES.
F578: C5 2E	NREL	CMP FORMAT	SAME FORMAT?
F57A: F0 9F		BEQ FINDOP	YES.
F57C: C6 3D	NEXTOP	DEC A1H	NO, TRY NEXT OPCODE
F57E: D0 DC		BNE TRYNEXT	
F580: E6 44		INC FMT	NO MORE, TRY WITH LEN=2
F582: C6 35		DEC L	WAS L=2 ALREADY?
F584: F0 D6		BEQ TRYNEXT	NO.
F586: A4 34	ERR	LDY YSAV	YES, UNRECOGNIZED INST.
F588: 98	ERR2	TYA	
F589: AA		TAX	
F58A: 20 4A F9		JSR PRBL2	PRINT ~ UNDER LAST READ
F58D: A9 DE		LDA #\$DE	CHAR TO INDICATE ERROR
F58F: 20 ED FD		JSR COUT	POSITION.
F592: 20 3A FF	RESETZ	JSR BELL	'!'
F595: A9 A1	NXTLINE	LDA #\$A1	
F597: 85 33		STA PROMPT	INITIALIZE PROMPT
F599: 20 67 FD		JSR GETLNZ	GET LINE.
F59C: 20 C7 FF		JSR ZMODE	INIT SCREEN STUFF
F59F: AD 00 02		LDA IN	GET CHAR
F5A2: C9 A0		CMP #\$A0	ASCII BLANK?
F5A4: F0 13	*	BEQ SPACE	YES
F5A6: C8		INY	
F5A7: C9 A4		CMP #\$A4	ASCII 'S' IN COL 1?
F5A9: F0 92		BEQ FAKEMON	YES, SIMULATE MONITOR
F5AB: 88		DEY	NO, BACKUP A CHAR
F5AC: 20 A7 FF		JSR GETNUM	GET A NUMBER
F5AF: C9 93		CMP #\$93	':' TERMINATOR?
F5B1: D0 D5	ERR4	BNJ ERR2	NO, ERR.
F5B3: 8A		TXA	
F5B4: F0 D2		BEQ ERR2	NO ADR PRECEDING COLON.
F5B6: 20 78 FE		JSR A1PCLP	MOVE ADR TO PCL, PCH.
F5B9: A9 03	SPACE	LDA #S3	COUNT OF CHARS IN MNEMONIC
F5BB: 85 3D		STA A1H	
F5BD: 20 34 F6	NXTMN	JSR GETNSP	CET FIRST MNEM CHAR.
F5C0: 0A	NXTM	ASL A	
F5C1: E9 BE		SEC #\$BE	SUBTRACT OFFSET
F5C3: C9 C2		CMP #\$C2	LEGAL CHAR?
F5C5: 90 C1		BCC ERR2	NO.
F5C7: 0A		ASL A	COMPRESS-LEFT JUSTIFY
F5C8: 0A		ASL A	
F5C9: A2 04		LDX #\$4	
F5CB: 0A	NXTM2	ASL A	DO 5 TRIPLE WORD SHIFTS

F5CC: 26 42		ROL A4L	
F5CE: 26 43		ROL A4H	
F5D0: CA		DEX	
F5D1: 10 F8		SPL NXTM2	
F5D3: C6 3D		DEC A1H	DONE WITH 3 CHARS?
F5D5: F0 F4		BEO NXTM2	YES, BUT DO 1 MORE SHIFT
F5D7: 10 E4		BPL NXTMN	NO
F5D9: A2 05	FORM1	LDX #\$5	5 CHARS IN ADDR MODE
F5DB: 20 34 F6	FORM2	JSR GETNSP	GPT FIRST CHAR OF ADDR
F5DE: 84 34		STY YSAV	
F5E0: DD B4 F9		CMP CHAR1,X	FIRST CHAR MATCH PATTERN?
F5E3: D0 13		BNE FORM3	NO
F5E5: 20 34 F6		JSR GETNSP	YES, GET SECOND CHAR
F5E8: DD BA F9		CMP CHAR2,X	MATCHES SECOND HALF?
F5EB: F0 0D		BFO FORM5	YES
F5ED: BD BA F9		LDA CHAR2,X	NO, IS SECOND HALF ZERO?
F5F0: F0 07		BEO FORM4	YES.
F5F2: C9 A4		CMP #\$A4	NO, SECOND HALF OPTIONAL?
F5F4: F0 03		BEO FORM4	YES.
F5F6: A4 34		LCY YSAV	
F5F8: 18	FORM3	CLC	CLEAR BIT-NO MATCH
F5F9: 88	FORM4	DEY	BACK UP 1 CHAR
F5FA: 26 44	FORM5	ROL FMT	FORM FORMAT BYTE
F5FC: E0 03		CPX #\$3	TIME TO CHECK FOR ADDR.
F5FE: D0 0D		BNE FORM7	NO
F600: 20 A7 FF		JSR GETNUM	YES
F603: A5 3F		LDA A2H	
F605: F0 01		BEQ FORM6	HIGH-ORDER BYTE ZERO
F607: E8		INX	NO, INCR FOR 2-BYTE
F608: 86 35	FORM6	STX L	STORE LENGTH
F60A: A2 03		LDX #\$3	RELOAD FORMAT INDEX
F60C: 88		DEY	BACKUP A CHAR
F60D: 86 3D	FORM7	STX A1H	SAVE INDEX
F60F: CA		DEX	DONE WITH FORMAT CHECK?
F610: 10 C9		SPL FORM2	NO.
F612: A5 44		LDA FMT	YES, PUT LENGTH
F614: 0A		ASL A	IN LOW BITS
F615: 0A		ASL A	
F616: 05 35		ORA L	
F618: C9 20		CMP #\$20	
F61A: B0 06		PCS FORM8	ADD '\$' IF NONZERO LENGTH
F61C: A6 35		LDX L	AND DON'T ALREADY HAVE IT
F61E: F0 02		BEQ FORM8	
F620: 09 80		ORA #\$80	
F622: 85 44	FORM8	STA FMT	
F624: 84 34		STY YSAV	
F626: B9 00 02		LDA IN,Y	GET NEXT NONBLANK
F629: C9 BB		CMP #\$BB	'; START OF COMMENT?
F62B: F0 04		BEQ FORM9	YES
F62D: C9 8D		CMP #\$8D	CARRIAGE RETURN?
F62F: D0 80		BNE ERF4	NO, ERR.
F631: 4C 5C F5	FORM9	JMP TRYNEXT	
F634: B9 00 02	GETNSP	LDA IN,Y	
F637: C8		INY	
F638: C9 A0		CMP #\$A0	GET NEXT NON BLANK CHAR
F63A: F0 F8		BEQ GETNSP	
F63C: 60		RTS	
F666: 4C 92 F5	MINASM	ORG \$F666	
		JMP RESETZ	

```

*****
*      *
*  APPLE-II FLOATING  *
*  POINT ROUTINES   *
*      *
*  COPYRIGHT 1977 BY  *
*  APPLE COMPUTER INC. *
*      *
*  ALL RIGHTS RESERVED *
*      *
*      S. WOZNIAK      *
*      *
*****
```

TITLE "FLOATING POINT ROUTINES"

SIGN	EPZ	\$F3	
X2	EPZ	\$F4	
M2	EPZ	\$F5	
X1	FPZ	\$F8	
M1	EPZ	\$F9	
E	EPZ	\$FC	
OVLOC	EDU	\$3F5	
	ORG	\$F425	
F425: 18	ADD	CLC	CLEAR CARRY.
F426: A2 02		LDX #\\$2	INDEX FOR 3-BYTE ADD.
F428: B5 F9	ADU1	LDA M1,X	
F42A: 75 F5		ADC M2,X	ADD A BYTE OF MANT2 TO MANT1.
F42C: 95 F9		STA M1,X	
F42E: CA		DEX	INDEX TO NEXT MORE SIGNIF. BYTE.
F42F: 10 F7		BPL ADD1	LOOP UNTIL DONE.
F431: 60		RTS	RETURN
F432: 06 F3	MD1	ASL SIGN	CLEAR LSP OF SIGN.
F434: 20 37 F4		JSR ABSWAP	ABS VAL OF M1, THEN SWAP WITH M2
F437: 24 F9	AESWAP	BIT M1	MANT1 NEGATIVE?
F439: 10 05		BPL ABSWAPI	NO, SWAP WITH MANT2 AND RETURN.
F43B: 20 A4 F4		JSR FCMPPL	YES, COMPLEMENT IT.
F43E: E6 F3		INC SIGN	INC SIGN, COMPLEMENTING LSB.
F440: 38	ABSWAPI	SEC	SET CARRY FOR RETURN TO MUL/DIV.
F441: A2 04	SWAP	LDX #\\$4	INDEX FOR 4-BYTE SWAP.
F443: 94 FB	SWAP1	STY E-1,X	
F445: F5 F7		LDA X1-1,X	SWAP A BYTE OF EXP/MANT1 WITH
F447: B4 F3		LDY X2-1,X	EXP/MANT2 AND LEAVE A COPY OF
F449: 94 F7		STY X1-1,X	MANT1 IN E (3 BYTES). E+3 USED
F44B: 95 F3		STA X2-1,X	
F44D: CA		DEX	ADVANCE INDEX TO NEXT BYTE.
F44E: D0 F3		BNE SWAP1	LOOP UNTIL DONE.
F450: 60		RTS	PETUPH
F451: A9 8E	FLOAT	LDA #\\$E	INIT EXP1 TO 14,
F453: 85 F8		STA X1	THEN NORMALIZE TO FLOAT.
F455: A5 F9	NOPM1	LOA M1	HIGH-ORDER MANT1 BYTE.
F457: C9 C0		CMP #\\$C0	UPPER TWO BITS UNEQUAL?
F459: 30 0C		BMI RTS1	YES, RETURN WITH MANT1 NORMALIZED
F45B: C6 F8		DEC X1	DECREMENT EXP1.
F45D: 06 FF		ASL M1+2	
F45F: 26 FA		ROL M1+1	SHIFT MANT1 (3 BYTES) LEFT.
F461: 26 F9		ROL M1	
F463: A5 F8	NORM	LDA X1	EXP1 ZERO?
F465: D0 EE		BNE NORM1	NO, CONTINUE NORMALIZING.
F467: 60	RTS1	PTS	RETURN.
F468: 20 A4 F4	FSUB	JSR FCMPPL	CMPL MANT1,CLEARS CARRY UNLESS 0
F46B: 20 7B F4	SWPALGN	JSR ALGNWP	RIGHT SHIFT MANT1 OR SWAP WITH
F46E: A5 F4	FADD	LDA X2	
F470: C5 F8		CMP X'	COMPARE EXP1 WITH EXP2.
F472: D0 F7		BNE SWPALGN	IF #,SWAP ADDENDS OF ALIGN MANTS.
F474: 20 25 F4		JSR ADD	ADD ALIGNED MANTISSAS.
F477: 50 EA	ADDEND	BVC NORM	NO OVERFLOW, NORMALIZE RESULT.
F479: 70 05		BVS RTLOG	OV: SHIFT M1 RIGHT, CARRY INTO SIGN

F47B: 90 C4	ALGNswap	BCC	SWAP	SWAP IF CARRY CLEAR, ELSE SHIFT RIGHT ARITH.
F47D: A5 F9	RTAR	LDA	X1	SIGN OF MANT1 INTO CARRY FOR RIGHT ARITH SHIFT.
F47F: 0A		ASL	A	INCR X1 TO ADJUST FOR RIGHT SHIFT
F480: E6 F8	RTLOC	INC	X1	EXPL OUT OF RANGE.
F482: F0 75		REC	OVFL	INDEX FOR 6:BYTE RIGHT SHIFT.
F484: A2 FA	RTLOGI	LOX	#\$FA	
F486: 76 FF	ROR1	ROR	E+3,X	
F488: E8		INX		NEXT BYTE OF SHIFT.
F489: D0 FB		BNE	ROR1	LOOP UNTIL DONE.
F48B: 60		RTS		RETURN.
F48C: 20 32 F4	FNUL	JSR	MD1	ABS VAL OF MANT1, MANT2.
F48F: 65 F8		ADC	X1	ADD EXP1 TO EXP2 FOR PRODUCT EXP
F491: 20 E2 F4		JSR	MD2	CHECK PROD. EXP AND PREP. FOR MUL
F494: 18		CLC		CLEAR CARRY FOR FIRST BIT.
F495: 20 84 F4	MULL	JSR	RTLOGI	M1 AND E RIGHT (PROD AND MPLIEP)
F498: 90 03		SCC	MUL2	IF CARRY CLEAR, SKIP PARTIAL PROD
F49A: 20 25 F4		JSR	ADD	ADD MULTIPLICAND TO PRODUCT.
F49D: 88	MUL2	DEY		NEXT MUL ITERATION.
F49E: 10 F5		9PL	MULL	LOOP UNTIL DONE.
F4A0: 46 F3	NDEND	LSR	SIGN	TEST SIGN LSR.
F4A2: 90 2F	NOPMX	PCC	NORM	IF EVEN, NORMALIZE PROD, ELSE COMP
F4A4: 38	FCOMPL	SEC		SET CARRY FOR SUBTRACT.
F4A5: A2 03		LDX	#\$3	INDEX FOR 3-BYTE SUBTRACT.
F4A7: A9 00	CO4PL1	LDA	#\$0	CLEAR A.
F4A9: F5 F8		SBC	X1,X	SUBTRACT BYTE OF EXP1.
F4AB: 95 F8		STA	X1,X	RESTORE IT.
F4AD: CA		DEX		NEXT MORE SIGNIFICANT BYTE.
F4AE: D0 F7		BNE	COMPL1	LOOP UNTIL DONE.
F4B0: F0 C5		REQ	ADDEND	NORMALIZE (OR SHIFT RT IF OVFL).
F4B2: 20 32 F4	FDIV	JSR	MD1	TAKE ABS VAL OF MANT1, MANT2.
F4B5: E5 F8		SRC	X1	SUBTRACT EXP1 FROM EXP2.
F4B7: 20 E2 F4		JSR	MD2	SAVE AS QUOTIENT EXP.
F4BA: 38	DIV1	SEC		SET CARRY FOR SUBTRACT.
F4BB: A2 02		LDX	#\$2	INDEX FOR 3-BYTE SUBTRACTION.
F4BD: B5 F5	DIV2	LDA	M2,X	
F4BF: F5 FC		SBC	E,X	SUBTRACT A BYTE OF E FROM MANT2.
F4C1: 48		PHA		SAVE ON STACK.
F4C2: CA		DEX		NEXT MORE SIGNIFICANT BYTE.
F4C3: 10 F8		SPL	DIV2	LOOP UNTIL DONE.
F4C5: A2 FD		LDX	#\$FD	INDEX FOR 3-BYTE CONDITIONAL MOVE
F4C7: 68	DIV3	PLA		PULL BYTF OF DIFFERENCE OFF STACK
F4C8: 90 02		BCC	DIV4	IF M2<E THEN DON'T RESTORE M2.
F4CA: 95 F8		STA	M2+3,X	
F4CC: E8	DIV4	INX		NEXT LESS SIGNIFICANT BYTE.
F4CD: D0 F8		BNE	DIV3	LOOP UNTIL DONE.
F4CF: 26 FB		ROL	M1+2	
F4D1: 26 FA		ROL	M1+1	ROLL QUOTIENT LEFT, CARRY INTO LSR
F4D3: 26 F9		ROL	M1	
F4D5: 06 F7		ASL	M2+2	
F4D7: 26 F6		ROL	M2+1	SHIFT DIVIDEND LEFT.
F4D9: 26 F5		ROL	M2	
F4DB: B0 1C		BCS	OVFL	OVFL IS DUE TO UNNORMED DIVISOR
F4DD: 88		DEY		NEXT DIVIDE ITERATION.
F4DE: D0 DA		BNE	DIV1	LOOP UNTIL DONE 23 ITERATIONS.
F4E0: F0 BE		BEO	MDFND	NORM. QUOTIENT AND CORRECT SIGN.
F4E2: 86 FB	MD2	STX	M1+2	
F4E4: 86 FA		STX	M1+1	CLEAR MANT1 (3 BYTES) FOR MUL/DIV.
F4E6: 86 F9		STX	M1	
F4E8: B0 0D		BCS	OVCHK	IF CALC. SET CARRY, CHECK FOR OVFL
F4EA: 30 04		BMI	MD3	IF NEG THEN NO UNDERFLOW.
F4EC: 68		PLA		POP ONE RETURN LEVEL.
F4ED: 68		PLA		
F4EE: 90 B2		BCC	NORMX	CLFAR X1 AND RETURN.
F4F0: 49 80	MD3	EOR	#\$80	COMPLEMENT SIGN BIT OF EXPONENT.
F4F2: 85 F8		STA	X1	STORE IT.
F4F4: A0 17		LDY	#\$17	COUNT 24 MUL/23 DIV ITERATIONS
F4F6: 60		RTS		RETURN.
F4F7: 10 F7	OVCHK	BPL	MD3	IF POSITIVE EXP THEN NO OVFL.
F4F9: 4C F5 03	OVFL	JMP	OVLOC	
		ORG	\$F63D	
F63D: 20 7D F4	FIX1	JSR	RTAR	
F640: A5 F8	FIX	LDA	X1	
F642: 10 13		BPL	UNDFL	
F644: C9 8E		CMP	#\$8E	
F646: D0 F5		DNE	FIX1	
F648: 24 F9		BIT	M1	
F64A: 10 0A		BPL	FIXPTS	
F64C: A5 FB		LDA	M1+2	
F64E: F0 06		BFO	FIXRTS	
F650: E6 FA		INC	M1+1	
F652: D0 02		BNE	FIXRTS	
F654: E6 F9		INC	M1	
F656: 60	FIXRTS	RTS		
F657: A9 00	UNDFL	LDA	#\$0	
F659: 85 F9		STA	M1	
F65B: 85 FA		STA	M1+1	
F65D: 60		RTS		

```

*****
*          *
*   APPLE-II PSEUDO  *
*   MACHINE INTERPRETER  *
*          *
*   COPYRIGHT 1977    *
*   APPLE COMPUTER INC  *
*          *
*   ALL RIGHTS RESERVED  *
*          *
*   S. WOZNIAK      *
*          *
*****  

        TITLE "SWEET16 INTERPRETER"  

ROL    EPZ $0  

R0H    EPZ $1  

R14H   EPZ $10  

R15L   EPZ $1E  

R15H   EPZ $1F  

S16PAG EQU $F7  

SAVE   EQU $FF4A  

RESTORE EQU $FF3F  

ORG   ORG $F689  

F689: 20 4A FF SW16 JSR SAVE PRESERVE 6502 REG CONTENTS  

F68C: 68 PLA  

F68D: 85 1E STA R15L INIT SWEET16 PC  

F68F: 68 PLA FROM RETURN  

F690: 85 1F STA F159 ADDRESS  

F692: 20 98 F6 SW16B JSP SW16C INTERPRET AND EXECUTE  

F695: 4C 92 F6 JMP SW16B ONE SWEET16 INSTR.  

F698: E6 1E SW16C INC R15L  

F69A: D0 02 BNE SW16D INCPC SWEET16 PC FOR FETCH  

F69C: E6 1F INC F159  

F69E: A9 F7 SW16D LDA #S16PAG  

F6A0: 48 PHA PUSH ON STACK FOR PTS  

F6A1: A0 00 LDY #$0  

F6A3: B1 1E LDA (R15L),Y FETCH INSTR  

F6A5: 29 0F AND #$F MASK REG SPECIFICATION  

F6A7: 0A ASL A DOUBLE FOR 2-BYTE REGISTERS  

F6A8: AA TAX TO X-REG FOR INDEXING  

F6A9: 4A LSR A  

F6AA: 51 1E EOR (R15L),Y NOW HAVE OPCODE  

F6AC: F0 0B BEQ T0R2 IF ZERO THEN NON-REG OP  

F6AE: 86 1D STX R14H INDICATE 'PRIOR RESULT REG'  

F6B0: 4A LSR A  

F6B1: 4A LSR A OPCODE*2 TO LSP'S  

F6B2: 4A LSR A  

F6B3: A8 TAY TO Y-REG FOR INDEXING  

F6B4: E9 E1 F6 LDA CPTBL-2,Y LOW-ORDER ADR BYTE  

F6B7: 48 PHA ONTO STACK  

F6B8: 60 RTS GOTO REG-OP ROUTINE  

F6B9: E6 1E T0R2 INC R15L  

F6B9: D0 02 BNE T0R2 INC PC  

F6BD: E6 1F INC R15H  

F6CF: BD E4 F6 T0R2 LDA SPTBL,X LOW-ORDER ADR BYTE  

F6C2: 48 PHA ONTO STACK FOR NON-REG OP  

F6C3: A5 1D LDA R14H 'PRIOR RESULT REG' INDEX  

F6C5: 4A LSR A PREPARE CARRY FOR BC, BNC.  

F6C6: 60 RTS GOTO NON-REG OP ROUTINE  

F6C7: 68 RTNZ PLA POP RETURN ADDRESS  

F6C8: 68 PLA  

F6C9: 20 3F FF JSR RESTORE RESTORE 6502 REG CONTENTS  

F6CC: 6C 1E 00 JMP (R15L) RETURN TO 6502 CODE VIA PC  

F6CF: B1 1F SETZ LDA (R15L),Y HIGH-ORDER BYTE OF CONSTANT

```

F6D1: 95 01		STA R0H,X	
F6D3: 88		DEY	
F6D4: B1 1E		LDA (\$15L),Y LOW-ORDER BYTE OF CONSTANT	
F6D6: 95 00		STA ROL,X	
F6D8: 98		TYA Y-REG CONTAINS 1	
F6D9: 38		SEC	
F6DA: 65 1E		ADC #15L ADD 2 TO PC	
F6DC: 85 1E		STA R15L	
F6DE: 90 02		BCC SET2	
F6E0: E6 1F		INC R15H	
F6E2: 60	SFT2	RTS	
F6E3: 02	OPTBL	DFF SET-1 (1X)	
6E4: F9	FRtbl	DFE RTN-1 (0)	
F6E5: 04		DFB LD-1 (2X)	
F6E6: 9D		DFP EZ-1 (1)	
F6E7: 0D		DFP ST-1 (3X)	
F6E8: 9E		DFB RNC-1 (2)	
F6E9: 25		DFB LDAT-1 (4X)	
F6EA: AF		DFB BC-1 (3)	
F6EB: 16		DFB STAT-1 (5X)	
F6EC: B2		DFB BP-1 (4)	
F6ED: 47		DFB LDDAT-1 (6X)	
F6EE: B9		DFP BM-1 (5)	
F6EF: 51		DFB STDAT-1 (7X)	
F6F0: C0		DFB NZ-1 (6)	
F6F1: 2F		DFB POP-1 (8X)	
F6F2: C9		DFB BNZ-1 (7)	
F6F3: 5B		DFB STPAT-1 (9X)	
F6F4: D2		DFB BM1-1 (8)	
F6F5: 85		DFB ADD-1 (AX)	
F6F6: DD		DFB BNM1-1 (9)	
F6F7: 6E		DFB SU3-1 (BX)	
F6F8: 05		DFB RK-1 (A)	
F6F9: 33		DFB PCPD-1 (CX)	
F6FA: E8		DFB RS-1 (B)	
F6FB: 70		DFB CPR-1 (DX)	
F6FC: 93		DFB BS-1 (C)	
F6FD: 1E		DFB INR-1 (EX)	
F6FE: E7		DFB NUL-1 (D)	
F6FF: 65		DFB DCR-1 (FX)	
F700: E7		DFB NUL-1 (E)	
F701: E7		DFB NUL-1 (UNUSED)	
F702: E7		DFB NUL-1 (F)	
F703: 10 CA	SET	BPL SETZ ALWAYS TAKEN	
F705: B5 00	LD	LDA ROL,X	
	BK	EQU *-1	
F707: 85 00		STA ROL	
F709: B5 01		LDA R0H,X MOVE RX TO R0	
F70B: 85 01		STA R0H	
F70D: 60		RTS	
F70E: A5 00	ST	LDA ROL	
F710: 95 00		STA ROL,X MOVE R0 TO RX	
F712: A5 01		LDA R0H	
F714: 95 01		STA R0H,X	
F716: 60		RTS	
F717: A5 00	STAT	LDA ROL	
F719: 81 00	STAT2	STA (ROL,X) STORE BYTE INDIRECT	
F71B: A0 00		LDY #\$0	
F71D: 84 1D	STAT3	STY R14H INDICATE R0 IS RESULT REG	
F71F: F6 00	INR	INC ROL,X	
F721: D0 02		SNE INR2 INCR RX	
F723: F6 01		INC R0H,X	
F725: 60	INR2	RTS	
F726: A1 00	LDAT	LDA (ROL,X) LOAD INDIRECT (RX)	
F728: 85 00		STA ROL TO R0	
F72A: A0 00		LDY #\$0	
F72C: 84 01		STY R0H ZERO HIGH-ORDER R0 BYTE	
F72E: F0 ED		BEO STAT3 ALWAYS TAKEN	
F730: A0 00	POP	LDY #\$0 HIGH ORDER BYTE = 0	
F732: F0 06		BEO POP2 ALWAYS TAKEN	
F734: 20 66 F7	POPD	JSR DCR DECR RX	
F737: A1 00		LDA (ROL,X) POP HIGH-ORDER BYTE @RX	
F739: A8		TAY SAVE IN Y-REG	
F73A: 20 66 F7	POP2	JSR DCP DECR RX	
F73D: A1 00		LDA (ROL,X) LOW-ORDER BYTE	
F73F: 85 00		STA ROL TO R0	
F741: 84 01		STY R0H	
F743: A0 00	POP3	LDY #\$0 INDICATE R0 AS LAST RSLT REG	
F745: 84 1D		STY R14H	
F747: 60		RTS	
F748: 20 26 F7	LDDAT	JSR LDAT LOW-ORDER BYTE TO R0, INCR RX	
F74B: A1 00		LDA (ROL,X) HIGH-ORDER BYTE TO R0	
F74D: 85 01		STA R0H	
F74F: 4C 1F F7		JMP INR INCR RX	
F752: 20 17 F7	STDAT	JSR STAT STORE INDIRECT LOW-ORDER	

F755: A5 01		LDA R0H	BYTE AND INCR RX. THEN
F757: 81 00		STA (R0L,X)	STORE HIGH-ORDER BYTE.
F759: 4C 1F F7		JMP INR	INCR RX AND RETURN
F75C: 20 66 F7	STPAT	JSR DCF	DECR RX
F75F: A5 00		LDA R0L	
F761: 81 00		STA (POL,X)	STORE R0 LOW BYTE ORX
F763: 4C 43 F7		JMP POP3	INDICATE R0 AS LAST RSLT REG
F766: B5 00	DCR	LDA R0L,X	
F768: D0 02		PNE DCR2	DECR RX
F76A: D6 01		DEC R0H,X	
F76C: D6 00	DCR2	DEC R0L,X	
F76E: 60		RTS	
F76F: A0 00	SUB	LDY #\$0	RESULT TO R0
F771: 38	CPR	SEC	NOTE Y-REG = 13*2 FOR CPR
F772: A5 00		LDA R0L	
F774: F5 00		SBC R0L,X	
F776: 99 00 00		STA R0L,Y	R0-RX TO RY
F779: A5 01		LDA R0H	
F77B: F5 01		SBC R0H,X	
F77D: 99 01 00	SUB2	STA R0H,Y	
F780: 98		TYA	LAST RESULT REG*2
F781: 69 00		ADC #\$0	CARRY TO LSP
F783: 85 1D		STA R14H	
F785: 60		RTS	
F786: A5 00	ADD	LDA R0L	
F788: 75 00		ADC R0L,X	
F78A: 85 00		STA R0L	R0+RX TO R0
F78C: A5 01		LDA R0H	
F78E: 75 01		ADC R0H,X	
F790: A0 00		LDY #\$0	R0 FOR RESULT
F792: F0 E9		BEO SUB2	FINISH ADD
F794: A5 1E	BS	LDA R15L	
F796: 20 19 F7		JSR STAT2	NOTE X-REG IS 12*2!
F799: A5 1F		LDA R15H	PUSH LOW PC BYTE VIA R12
F79B: 20 19 F7		JSR STAT2	PUSH HIGH-ORDER PC BYTE
F79E: 18	BR	CLC	
F79F: B0 0E	BNC	ECS BNC2	NO CARRY TEST
F7A1: B1 1E	BR1	LDA (R15L),Y	DISPLACEMENT BYTE
F7A3: 10 01		SPL BR2	
F7A5: 88		DEY	
F7A6: 65 1E	BR2	ADC R15L	ADD TO PC
F7A8: 85 1E		STA R15L	
F7AA: 98		TYA	
F7AB: 65 1F		ADC R15H	
F7AD: 85 1F		STA R15H	
F7AF: 60	SNC2	RTS	
F7B0: B0 EC	BC	BCS BR	
F7B2: 60		RTS	
F7B3: 0A	BP	ASL A	QUEUE RESULT-REG INDEX
F7B4: AA		TAX	TO X-REG FOR INDEXING
F7B5: B5 01		LDA R0H,X	TEST FOR PLUS
F7B7: 10 E8		BPL BP1	BRANCH IF SO
F7B9: 60		RTS	
F7BA: 0A	BR1	ASL A	DOUBLE RESULT-REG INDEX
F7B2: AA		TAX	
F7BC: B5 01		LDA R0H,X	TEST FOR MINUS
F7BE: 30 E1		BMI BR1	
F7C0: 60		RTS	
F7C1: 0A	BZ	ASL A	DOUBLE RESULT-REG INDEX
F7C2: AA		TAX	
F7C3: B5 00		LDA R0L,X	TEST FOR ZERO
F7C5: 15 01		ORA R0H,X	(BOTH BYTES)
F7C7: F0 D8		REQ BR1	BRANCH IF SO
F7C9: 60		PTS	
F7CA: 0A	BNZ	ASL A	DOUBLE RESULT-REG INDEX
F7CB: AA		TAX	
F7CC: B5 00		LDA R0L,X	TEST FOR NONZERO
F7CE: 15 01		ORA R0H,X	(BOTH BYTES)
F7D0: D0 CF		BNE BR1	BRANCH IF SO
F7D2: 60		RTS	
F7D3: 0A	BM1	ASL A	DOUBLE RESULT-REG INDEX
F7D4: AA		TAX	
F7D5: B5 00		LDA R0L,X	CHECK BOTH BYTES
F7D7: 35 01		AND R0H,X	FOR \$FF (MINUS 1)
F7D9: 49 FF		EOR #\$FF	
F7DB: F0 C4		BEO BR1	BRANCH IF SO
F7DD: 60		RTS	
F7DE: 0A	BNM1	ASL A	DOUBLE RESULT-REG INDEX
F7DF: AA		TAX	
F7E0: B5 00		LDA R0L,X	
F7E2: 35 01		AND R0H,X	CHECK BOTH BYTES FOR NO \$FF
F7E4: 49 FF		EOR #\$FF	
F7E6: D0 B9	NUL	BNE BR1	BRANCH IF NOT MINUS 1
F7E8: 60		RTS	
F7E9: A2 18	RS	LDX #\$18	12*2 FOR R12 AS STK POINTER

F7EB: 20 66 F7	JSR DCR	DECR STACK POINTER
F7EE: A1 00	LDA (ROL,X)	POP HIGH RETURN ADR TO PC
F7F0: 85 1F	STA R15H	
F7F2: 20 66 F7	JSR DCR	SAME FOR LOW-ORDER BYTE
F7F5: A1 00	LDA (ROL,X)	
F7F7: 85 1E	STA R15L	
F7F9: 60	RTS	
F7FA: 4C C7 F6 RTN	JMP RTNZ	

6502 MICROPROCESSOR INSTRUCTIONS

ADC	Add Memory to Accumulator with Carry	LDA	Load Accumulator with Memory
AND	"AND" Memory with Accumulator	LDX	Load Index X with Memory
ASL	Shift Left One Bit (Memory or Accumulator)	LDY	Load Index Y with Memory
BCC	Branch on Carry Clear	LSR	Shift Right one Bit (Memory or Accumulator)
BCS	Branch on Carry Set	NOP	No Operation
BEQ	Branch on Result Zero	ORA	"OR" Memory with Accumulator
BIT	Test Bits in Memory with Accumulator	PHA	Push Accumulator on Stack
BMI	Branch on Result Minus	PHP	Push Processor Status on Stack
BNE	Branch on Result not Zero	PLA	Pull Accumulator from Stack
BPL	Branch on Result Plus	PLP	Pull Processor Status from Stack
BRK	Force Break	ROL	Rotate One Bit Left (Memory or Accumulator)
BVC	Branch on Overflow Clear	ROR	Rotate One Bit Right (Memory or Accumulator)
BVS	Branch on Overflow Set	RTI	Return from Interrupt
CLC	Clear Carry Flag	RTS	Return from Subroutine
CLD	Clear Decimal Mode	SBC	Subtract Memory from Accumulator with Borrow
CLI	Clear Interrupt Disable Bit	SEC	Set Carry Flag
CLV	Clear Overflow Flag	SED	Set Decimal Mode
CMP	Compare Memory and Accumulator	SEI	Set Interrupt Disable Status
CPX	Compare Memory and Index X	STA	Store Accumulator in Memory
CPY	Compare Memory and Index Y	STX	Store Index X in Memory
DEC	Decrement Memory by One	STY	Store Index Y in Memory
DEX	Decrement Index X by One	TAX	Transfer Accumulator to Index X
DEY	Decrement Index Y by One	TAY	Transfer Accumulator to Index Y
EOR	"Exclusive-Or" Memory with Accumulator	TSX	Transfer Stack Pointer to Index X
INC	Increment Memory by One	TXA	Transfer Index X to Accumulator
INX	Increment Index X by One	TXS	Transfer Index X to Stack Pointer
INY	increment Index Y by One	TYA	Transfer Index Y to Accumulator
JMP	Jump to New Location		
JSR	Jump to New Location Saving Return Address		

THE FOLLOWING NOTATION APPLIES TO THIS SUMMARY:

A	Accumulator
X, Y	Index Registers
M	Memory
C	Borrow
P	Processor Status Register
S	Stack Pointer
✓	Change
—	No Change
+	Add
Λ	Logical AND
-	Subtract
▼	Logical Exclusive Or
↑	Transfer From Stack
↓	Transfer To Stack
→	Transfer To
←	Transfer To
V	Logical OR
PC	Program Counter
PCH	Program Counter High
PCL	Program Counter Low
OPER	Operand
#	Immediate Addressing Mode

FIGURE 1. ASL-SHIFT LEFT ONE BIT OPERATION




FIGURE 2. ROTATE ONE BIT LEFT (MEMORY OR ACCUMULATOR)







FIGURE 3.



NOTE 1: BIT — TEST BITS

Bit 6 and 7 are transferred to the status register. If the result of $A \wedge M$ is zero then $Z=1$, otherwise $Z=0$.

PROGRAMMING MODEL



INSTRUCTION CODES

Name Description	Operation	Addressing Mode	Assembly Language Form	HEX Op Code	No. Bytes	"P" Status Reg. N Z C I D V
ADC Add memory to accumulator with carry	A - M - C → A.C	Immediate Zero Page, X Absolute, X Absolute, Y (Indirect), Y	ADC #Oper ADC Oper, X ADC Oper, X ADC Oper, Y ADC (Oper, X) ADC (Oper, Y)	69 65 6D 7D 79 61	2 2 3 3 3 2	✓✓✓—✓—✓
AND "AND" memory with accumulator	A ∧ M → A	Immediate Zero Page, X Absolute, X Absolute, Y (Indirect) X (Indirect), Y	AND #Oper AND Oper, X AND Oper, X AND Oper, Y AND (Oper, X) AND (Oper, Y)	29 25 35 20 30 31	2 2 3 3 3 2	✓✓—✓—✓—
ASL Shift left one bit (Memory or Accumulator)	(See Figure 1)	Accumulator Zero Page, X Absolute, X Absolute, Y (Indirect) X (Indirect), Y	ASL A ASL Oper, X ASL Oper, X ASL Oper, X ASL Oper, X	0A 06 16 0E 1E	1	✓✓✓—✓—✓—
BCC Branch on carry clear	Branch on C=0	Relative	BCC Oper	90	2	—✓—✓—
BCS Branch on carry set	Branch on C=1	Relative	BCS Oper	B0	2	—✓—✓—
BEQ Branch on result zero	Branch on Z=1	Relative	BEQ Oper	F0	2	—✓—✓—
BIT Test bits in memory with accumulator	A ∧ M, M ₇ → N, M ₆ → V	Zero Page Absolute	BIT* Oper BIT* Oper	24 2C	2 3	M ₇ /—M ₆
BMI Branch on result minus	Branch on N=1	Relative	BMI Oper	30	2	—✓—✓—
BNE Branch on result not zero	Branch on Z=0	Relative	BNE Oper	D0	2	—✓—✓—
BPL Branch on result plus	Branch on N=0	Relative	BPL Oper	10	2	—✓—✓—
BRK Force Break	Forced Interrupt PC-2↓ P↓	Implied	BRK*	00	1	—1—
BVC Branch on overflow clear	Branch on V=0	Relative	BVC Oper	50	2	—✓—✓—

Note 1: Bits 5 and 4 are transferred to the status register if the result of V.M is then 1; otherwise Z = 0.

Note 2: A BRK command cannot be masked by setting

INSTRUCTION CODES

Name Description	Operation	Addressing Mode	Assembly Language Form	HEX OP Code	No. Bytes	"P" Status Reg. N Z C I D V
EOR "Exclusive-Or" memory with accumulator	A V M → A	Immediate Zero Page X Absolute X Absolute Y (Indirect X)	EOR #Oper EOR Oper,X EOR Oper,X EOR Oper,Y EOR (Oper,X) (Indirect Y)	49 55 40 50 59 51	2 2 3 3 3 2	✓✓/----
INC Increment memory by one	M + 1 → M	Zero Page Zero Page,X Absolute X	INC Oper,X INC Oper,X INC Oper,X	E6 F6 EE	2 2 3	✓✓/----
INX Increment index X by one	X + 1 → X	Implied	INX	E8	1	✓✓/----
INY Increment index Y by one	Y + 1 → Y	Implied	INY	C8	1	✓✓/----
JMP Jump to new location saving return address	PC-2 ↓ (PC+1) → PCL (PC+2) → PCH	Absolute Indirect	JMP Oper JMP (Oper)	4C 6C	3 3	-----
JSR	Jump to new location saving return address	PC-2 ↓ (PC+1) → PCL (PC+2) → PCH	Absolute	JSR Oper	20	3
LDA Load accumulator with memory	M → A	Immediate Zero Page X Absolute X Absolute Y (Indirect X) (Indirect Y)	LDA #Oper LDA Oper,X LDA Oper,X LDA Oper,Y LDA (Oper,X) LDA (Oper,Y)	A9 A5 B5 AD BD B9 A1 B1	2 2 2 3 3 3 2 2	✓✓/----
LDX Load index X with memory	M → X	Immediate Zero Page Y Absolute Y	LDX #Oper LDX Oper,Y LDX Oper,Y .LDX Oper,Y	A2 A6 B6 AE BE	2 2 3 3	✓✓/----
LDY Load index Y with memory	M → Y	Immediate Zero Page,X Absolute X	LDY #Oper LDY Oper,X LDY Oper,X LDY Oper,X	A0 A4 B4 AC BC	2 2 3 3	✓✓/----

Name Description	Operation	Addressing Mode	Assembly Language Form	HEX OP Code	No. Bytes	"P" Status Reg. N Z C I D V
LSR Shift right one bit (memory or accumulator)			(See Figure 1)	Accumulator Zero Page,X Absolute X	LSR A LSR Oper,X LSR Oper,X LSR Oper,X	4A 46 56 4E 5E
NOP No operation.			No Operation	Implied	NOP	EA
ORA "OR" memory with accumulator			A V M → A	Immediate Zero Page,X Absolute Absolute,Y (Indirect,X) (Indirect,Y)	ORA #Oper ORA Oper,X ORA Oper,Y ORA (Oper,X) ORA (Oper,Y)	08 05 15 00 10 19 01 11
PHA Push accumulator on stack			Push accumulator on stack	A ↑	Implied	PHA
PHP Push processor status on stack			Push processor status on stack	P ↑	Implied	PHP
PLA Pull accumulator from stack			Pull accumulator from stack	A ↑	Implied	PLA
PLP Pull processor status from stack			Pull processor status from stack	P ↑	Implied	PLP
ROL Rotate one bit left (memory or accumulator)			(See Figure 2)	Accumulator Zero Page,X Absolute X	ROL A ROL Oper,X ROL Oper,X ROL Oper,X	2A 26 36 2E
ROR Rotate one bit right (memory or accumulator)			(See Figure 3)	Accumulator Zero Page,X Absolute,X	ROR A ROR Oper,X ROR Oper,X ROR Oper,X	6A 66 76 6E

INSTRUCTION CODES

Name	Description	Operation	Addressing Mode	Assembly Language Form	HEX Op Code	No. Bytes	"P" Status Reg.	M Z C D V
RTI	Return from interrupt	P↑ PC↓	Implied	RTI	40	1	From Stack	-----
RTS	Return from subroutine	PC↑ PC+1 → PC	Implied	RTS	1	-----	X → A	Implied
SBC	Subtract memory from accumulator with borrow	A - M - C → A	Immediate Zero Page, X Absolute X Absolute Y (Indirect, X), Y	SBC #Oper SBC Oper, X SBC Oper, Y (Oper, X) (Oper, Y)	E9 E5 ED F9 E1	2 2 3 3 2	✓✓✓---	-----
SEC	Set carry flag	1 → C	Implied	SEC	38	1	-----	-----
SED	Set decimal mode	1 → D	Implied	SED	F8	1	-----	-----
SEI	Set interrupt disable status	1 → I	Implied	SEI	78	1	-----	-----
STA	Store accumulator in memory	A → M	Zero Page, X Absolute X Absolute Y (Indirect, X), Y	STA Oper STA Oper, X STA Oper, Y STA (Oper, X) (Oper, Y)	85 95 80 90 99 81 91	2 2 3 3 3 2 2	-----	-----
STX	Store index X in memory	X → M	Zero Page, Y Absolute	STX Oper STX Oper, Y STX Oper	86 96 8E	2 2 3	-----	-----
STY	Store index Y in memory	Y → M	Zero Page, X Absolute	STY Oper STY Oper, X STY Oper	84 94 8C	2 2 3	-----	-----
TAX	Transfer accumulator to index X	A → X	Implied	TAX	AA	1	-----	-----
TAY	Transfer accumulator to index Y	A → Y	Implied	TAY	A8	1	-----	-----
TSX	Transfer stack pointer to index X	S → X	Implied	TSX	BA	1	-----	-----

Name	Description	Operation	Addressing Mode	Assembly Language Form	HEX Op Code	No. Bytes	"P" Status Reg.	M Z C D V
TXA	Transfer index X to accumulator	X → A	Implied	TXA	-----	-----	-----	-----
TXS	Transfer index X to stack pointer	X → S	Implied	TXS	9A	1	-----	-----
TYA	Transfer index Y to accumulator	Y → A	Implied	TYA	98	1	-----	-----

HEX OPERATION CODES

00 — BRK	2F — NOP	5E — LSR — Absolute, X	8D — STA — Absolute	B4 — LDY — Zero Page, X
01 — ORA — (Indirect), X	30 — BMI	5F — NOP	8E — STX — Absolute	B5 — LDA — Zero Page, X
02 — NOP	31 — AND — (Indirect), Y	60 — RTS	8F — NOP	B6 — LDX — Zero Page, Y
03 — NOP	32 — NOP	61 — ADC — (Indirect), X	90 — BCC	B7 — NOP
04 — NOP	33 — NOP	62 — NOP	91 — STA — (Indirect), Y	B8 — CLV
05 — ORA — Zero Page	34 — NOP	63 — NOP	92 — NOP	B9 — LDA — Absolute, Y
06 — ASL — Zero Page	35 — AND — Zero Page, X	64 — NOP	93 — NOP	B0 — CPX — Immediate
07 — NOP	36 — ROL — Zero Page, X	65 — ADC — Zero Page	94 — STY — Zero Page, X	E1 — SBC — (Indirect), X
08 — PHP	37 — NOP	66 — ROR — Zero Page	95 — STA — Zero Page, X	E2 — NOP
09 — ORA — Immediate	38 — SEC	67 — NOP	96 — STX — Zero Page, Y	E3 — NOP
0A — ASL — Accumulator	39 — AND — Absolute, Y	68 — PLA	97 — NOP	E4 — CPX — Zero Page
0B — NOP	3A — NOP	69 — ADC — Immediate	98 — TYA	E5 — SBC — Zero Page
0C — NOP	3B — NOP	6A — ROR — Accumulator	99 — STA — Absolute, Y	E6 — INC — Zero Page
0D — ORA — Absolute	3C — NOP	6B — NOP	9A — TXS	E7 — NOP
0E — ASL — Absolute	3D — AND — Absolute, X	6C — JMP — Indirect	9B — NOP	E8 — INX
0F — NOP	3E — ROL — Absolute, X	6D — ADC — Absolute	9C — NOP	E9 — SBC — Immediate
10 — BPL	3F — NOP	6E — ROR — Absolute	9D — STA — Absolute, X	EA — NOP
11 — ORA — (Indirect), Y	40 — RTI	6F — NOP	9E — NOP	EB — NOP
12 — NOP	41 — EOR — (Indirect), X	70 — BVS	9F — NOP	EC — CPX — Absolute
13 — NOP	42 — NOP	71 — ADC — (Indirect), Y	A0 — LDY — Immediate	ED — SBC — Absolute
14 — NOP	43 — NOP	72 — NOP	A1 — LDA — (Indirect), X	EE — INC — Absolute
15 — ORA — Zero Page, X	44 — NOP	73 — NOP	A2 — LDX — Immediate	EF — NOP
16 — ASL — Zero Page, X	45 — EOR — Zero Page	74 — NOP	A3 — NOP	F0 — BEQ
17 — NOP	46 — LSR — Zero Page	75 — ADC — Zero Page, X	A4 — LDY — Zero Page	F1 — SBC — (Indirect), Y
18 — CLC	47 — NOP	76 — ROR — Zero Page, X	A5 — LDA — Zero Page	F2 — NOP
19 — ORA — Absolute, Y	48 — PHA	77 — NOP	A6 — LDX — Zero Page	F3 — NOP
1A — NOP	49 — EOR — Immediate	78 — SEI	A7 — NOP	F4 — NOP
1B — NOP	4A — LSR — Accumulator	79 — ADC — Absolute, Y	A8 — TAY	F5 — SBC — Zero Page, X
1C — NOP	4B — NOP	7A — NOP	A9 — LDA — Immediate	F6 — INC — Zero Page, X
1D — ORA — Absolute, X	4C — JMP — Absolute	7B — NOP	AA — TAX	F7 — NOP
1E — ASL — Absolute, X	4D — EOR — Absolute	7C — NOP	AB — NOP	F8 — SED
1F — NOP	4E — LSR — Absolute	7D — ADC — Absolute, X	AC — LDY — Absolute	F9 — SBC — Absolute, Y
20 — JSR	4F — NOP	7E — ROR — Absolute, X	AD — Absolute	FA — NOP
21 — AND — (Indirect), X	50 — BVC	7F — NOP	AE — LDX — Absolute	FB — NOP
22 — NOP	51 — EOR (Indirect), Y	80 — NOP	AF — NOP	FC — NOP
23 — NOP	52 — NOP	81 — STA — (Indirect), X	BD — BCS	FD — SBC — Absolute, X
24 — BIT — Zero Page	53 — NOP	82 — NOP	B1 — LDA — (Indirect), Y	FE — INC — Absolute, X
25 — AND — Zero Page	54 — NOP	83 — NOP	B2 — NOP	FF — NOP
26 — ROL — Zero Page	55 — EOR — Zero Page, X	84 — STY — Zero Page	D9 — CMP — Absolute, Y	
27 — NOP	56 — LSR — Zero Page, X	85 — STA — Zero Page	DA — NOP	
28 — PLP	57 — NOP	86 — STX — Zero Page		
29 — AND — Immediate	58 — CLI	87 — NOP		
2A — ROL — Accumulator	59 — EOR — Absolute, Y	88 — DEY		
2B — NOP	5A — NOP	89 — NOP		
2C — BIT — Absolute	5B — NOP	8A — TPA		
2D — AND — Absolute	5C — NOP	8B — NOP		
2E — ROL — Absolute	5D — EOR — Absolute, X	8C — STY — Absolute		

APPLE II HARDWARE

1. Getting Started with Your APPLE II Board
2. APPLE II Switching Power Supply
3. Interfacing with the Home TV
4. Simple Serial Output
5. Interfacing the APPLE —
 Signals, Loading, Pin Connections
6. Memory —
 Options, Expansion, Map, Address
7. System Timing
8. Schematics

GETTING STARTED WITH YOUR APPLE II BOARD

INTRODUCTION

ITEMS YOU WILL NEED:

Your APPLE II board comes completely assembled and thoroughly tested. You should have received the following:

- a. 1 ea. APPLE II P.C. Board complete with specified RAM memory.
- b. 1 ea. d.c. power connector with cable.
- c. 1 ea. 2" speaker with cable.
- d. 1 ea. Preliminary Manual
- e. 1 ea. Demonstration cassette tapes. (For 4K: 1 cassette (2 programs); 16K or greater: 3 cassettes.
- f. 2 ea. 16 pin headers plugged into locations A7 and J14.

In addition you will need:

- g. A color TV set (or B & W) equipped with a direct video input connector for best performance or a commercially available RF modulator such as a "Pixi-verter"TM Higher channel (7-13) modulators generally provide better system performance than lower channel modulators (2-6).
- h. The following power supplies (NOTE: current ratings do not include any capacity for peripheral boards.):
 1. +12 Volts with the following current capacity:
 - a. For 4K or 16K systems - 350mA.
 - b. For 8K, 20K or 32K - 550mA.
 - c. For 12K, 24K, 36K or 48K - 850mA.
 2. +5 Volts at 1.6 amps
 3. -5 Volts at 10mA.
4. OPTIONAL: If -12 Volts is required by your keyboard. (If using an APPLE II supplied keyboard, you will need -12V at 50mA.)

- i. An audio cassette recorder such as a Panasonic model RQ-309 DS which is used to load and save programs.
- j. An ASCII encoded keyboard equipped with a "reset" switch.
- k. Cable for the following:
 - 1. Keyboard to APPLE II P.C.B.
 - 2. Video out 75 ohm cable to TV or modulator
 - 3. Cassette to APPLE II P.C.B. (1 or 2)

Optionally you may desire:

- l. Game paddles or pots with cables to APPLE II Game I/O connector. (Several demo programs use PDL(0) and "Pong" also uses PDL(1)).
- m. Case to hold all the above

Final Assembly Steps

1. Using detailed information on pin functions in hardware section of manual, connect power supplies to d.c. cable assembly. Use both ground wires to minimize resistance. With cable assembly disconnected from APPLE II mother board, turn on power supplies and verify voltages on connector pins. Improper supply connections such as reverse polarity can severely damage your APPLE II.
2. Connect keyboard to APPLE II by unplugging leader in location A7 and wiring keyboard cable to it, then plug back into APPLE II P.C.B.
3. Plug in speaker cable.
4. Optionally connect one or two game paddles using leader supplied in socket located at J14.
5. Connect video cable.
6. Connect cable from cassette monitor output to APPLE II cassette input.
7. Check to see that APPLE II board is not contacting any conducting surface.
8. With power supplies turned off, plug in power connector to mother board then recheck all cableing.

POWER UP

1. Turn power on. If power supplies overload, immediately turn off and recheck power cable wiring. Verify operating supply voltages are within +3% of nominal value.
2. You should now have random video display. If not check video level pot on mother board, full clockwise is maximum video output. Also check video cables for opens and shorts. Check modulator if you are using one.
3. Press reset button. Speaker should beep and a "*" prompt character with a blinking cursor should appear in lower left on screen.
4. Press "esc" button, release and type a "@" (shift-P) to clear screen.. You may now try "Monitor" commands if you wish. See details in "Monitor" software section.

RUNNING BASIC

1. Turn power on; press reset button; type "control B" and press return button. A ">" prompt character should appear on screen indicating that you are now in BASIC.
2. Load one of the supplied demonstration cassettes into recorder. Set recorder level to approximately 5 and start recorder. Type "LOAD" and return. First beep indicates that APPLE II has found beginning of program; second indicates end of program followed by ">" character on screen. If error occurs on loading, try a different demo tape or try changing cassette volume level.
3. Type RUN and carriage return to execute demonstration program. Listings of these are included in the last section of this manual.

THE APPLE II SWITCHING POWER SUPPLY

Switching power supplies generally have both advantages and peculiarities not generally found in conventional power supplies. The Apple II user is urged to review this section.

Your Apple II is equipped with an AC line voltage filter and a three wire AC line cord. It is important to make sure that the third wire is returned to earth ground. Use a continuity checker or ohmmeter to ensure that the third wire is actually returned to earth. Continuity should be checked for between the power supply case and an available water pipe for example. The line filter, which is of a type approved by domestic (U.L. CSA) and international (VDE) agencies must be returned to earth to function properly and to avoid potential shock hazards.

The APPLE II power supply is of the "flyback" switching type. In this system, the AC line is rectified directly, "chopped up" by a high frequency oscillator and coupled through a small transformer to the diodes, filters, etc., and results in four low voltage DC supplies to run APPLE II. The transformer isolates the DC supplies from the line and is provided with several shields to prevent "hash" from being coupled into the logic or peripherals. In the "flyback" system, the energy transferred through from the AC line side to DC supply side is stored in the transformer's inductance on one-half of the operating cycle, then transferred to the output filter capacitors on the second half of the operating cycle. Similar systems are used in TV sets to provide horizontal deflection and the high voltages to run the CRT.

Regulation of the DC voltages is accomplished by controlling the frequency at which the converter operates; the greater the output power needed, the lower the frequency of the converter. If the converter is overloaded, the operating frequency will drop into the audible range with squeels and squawks warning the user that something is wrong.

All DC outputs are regulated at the same time and one of the four outputs (the +5 volt supply) is compared to a reference voltage with the difference error fed to a feedback loop to assist the oscillator in running at the needed frequency. Since all DC outputs are regulated together, their voltages will reflect to some extent unequal loadings.

For example; if the +5 supply is loaded very heavily, then all other supply voltages will increase in voltage slightly; conversely, very light loading on the +5 supply and heavy loading on the +12 supply will cause both it and the others to sag lightly. If precision reference voltages are needed for peripheral applications, they should be provided for in the peripheral design.

In general, the APPLE II design is conservative with respect to component ratings and operating temperatures. An over-voltage crowbar shutdown system and an auxilliary control feedback loop are provided to ensure that even very unlikely failure modes will not cause damage to the APPLE II computer system. The over-voltage protection references to the DC output voltages only. The AC line voltage input must be within the specified limits, i.e., 107V to 132V.

Under no circumstances, should more than 140 VAC be applied to the input of the power supply. Permanent damage will result.

Since the output voltages are controlled by changing the operating frequency of the converter, and since that frequency has an upper limit determined by the switching speed of power transistors, there then must be a minimum load on the supply; the Apple II board with minimum memory (4K) is well above that minimum load. However, with the board disconnected, there is no load on the supply, and the internal over-voltage protection circuitry causes the supply to turn off. A 9 watt load distributed roughly 50-50 between the +5 and +12 supply is the nominal minimum load.

Nominal load current ratios are: The +12V supply load is $\frac{1}{2}$ that of the +5V.
The - 5V supply load is $\frac{1}{10}$ that of the +5V.
The -12V supply load is $\frac{1}{10}$ that of the +5V.

The supply voltages are $+5.0 \pm 0.15$ volts, $+11.8 \pm 0.5$ volts, -12.0 ± 1 V, -5.2 ± 0.5 volts. The tolerances are greatly reduced when the loads are close to nominal.

The Apple II power supply will power the Apple II board and all present and forthcoming plug-in cards, we recommend the use of low power TTL, CMOS, etc. so that the total power drawn is within the thermal limits of the entire system. In particular, the user should keep the total power drawn by any one card to less than 1.5 watts, and the total current drawn by all the cards together within the following limits:

+ 12V	- use no more than 250 mA
+ 5V	- use no more than 500 mA
- 5V	- use no more than 200 mA
- 12V	- use no more than 200 mA

The power supply is allowed to run indefinitely under short circuit or open circuit conditions.

CAUTION: There are dangerous high voltages inside the power supply case. Much of the internal circuitry is NOT isolated from the power line, and special equipment is needed for service. NO REPAIR BY THE USER IS ALLOWED.

NOTES ON INTERFACING WITH THE HOME TV

Accessories are available to aid the user in connecting the Apple II system to a home color TV with a minimum of trouble. These units are called "RF Modulators" and they generate a radio frequency signal corresponding to the carrier of one or two of the lower VHF television bands; 61.25 MHz (channel 3) or 67.25 MHz (channel 4). This RF signal is then modulated with the composite video signal generated by the Apple II.

Users report success with the following RF modulators:

the "PixieVerter" (a kit)
ATV Research
13th and Broadway
Dakota City, Nebraska 68731

the "TV-1" (a kit)
UHF Associates
6037 Haviland Ave.
Whittier, CA 90601

the "Sup-r-Mod" by (assembled & tested)
M&R Enterprises
P.O. Box 1011
Sunnyvale, CA 94088

the RF Modulator (a P.C. board)
Electronics Systems
P.O. Box 212
Burlingame, CA 94010

Most of the above are available through local computer stores.

The Apple II owner who wishes to use one of these RF Modulators should read the following notes carefully.

All these modulators have a free running transistor oscillator. The M&R Enterprises unit is pre-tuned to Channel 4. The PixieVerter and the TV-1 have tuning by means of a jumper on the P.C. board and a small trimmer capacitor. All these units have a residual FM which may cause trouble if the TV set in use has a IF pass band with excessive ripple. The unit from M&R has the least residual FM.

All the units except the M&R unit are kits to be built and tuned by the customer. All the kits are incomplete to some extent. The unit from Electronics Systems is just a printed circuit board with assembly instructions. The kits from UHF Associates and ATV do not have an RF cable or a shielded box or a balun transformer, or an antenna switch. The M&R unit is complete.

Some cautions are in order. The Apple II, by virtue of its color graphics capability, operates the TV set in a linear mode rather than the 100% contrast mode satisfactory for displaying text. For this reason, radio frequency interference (RFI) generated by a computer (or peripherals) will beat with the

carrier of the RF modulator to produce faint spurious background patterns (called "worms") This RFI "trash" must be of quite a low level if worms are to be prevented. In fact, these spurious beats must be 40 to 50db below the signal level to reduce worms to an acceptable level. When it is remembered that only 2 to 6 mV (across 300Ω) is presented to the VHF input of the TV set, then stray RFI getting into the TV must be less than 50µV to obtain a clean picture. Therefore we recommend that a good, co-ax cable be used to carry the signal from any modulator to the TV set, such as RG/59u (with copper shield), Belden #8241 or an equivalent miniature type such as Belden #8218. We also recommend that the RF modulator be enclosed in a tight metal box (an unpainted die cast aluminum box such as Pomona #2428). Even with these precautions, some trouble may be encountered with worms, and can be greatly helped by threading the coax cable connecting the modulator to the TV set repeatedly through a Ferrite toroid core. Apple Computer supplies these cores in a kit, along with a 4 circuit connector/cable assembly to match the auxilliary video connector found on the Apple II board. This kit has order number A2M010X. The M&R "Sup-r-Mod" is supplied with a coax cable and toroids.

Any computer containing fast switching logic and high frequency clocks will radiate some radio frequency energy. Apple II is equipped with a good line filter and many other precautions have been taken to minimize radiated energy. The user is urged not to connect "antennas" to this computer; wires strung about carrying clocks and/data will act as antennas, and subsequent radiated energy may prove to be a nuisance.

Another caution concerns possible long term effects on the TV picture tube. Most home TV sets have "Brightness" and "Contrast" controls with a very wide range of adjustment. When an un-changing picture is displayed with high brightness for a long period ,a faint discoloration of the TV CRT may occur as an inverse pattern observable with the TV set turned off. This condition may be avoided by keeping the "Brightness" turned down slightly and "Contrast" moderate.

A SIMPLE SERIAL OUTPUT

The Apple II is equipped with a 16 pin DIP socket most frequently used to connect potentiometers, switches, etc. to the computer for paddle control and other game applications. This socket, located at J-14, has outputs available as well. With an appropriate machine language program, these output lines may be used to serialize data in a format suitable for a teletype. A suitable interface circuit must be built since the outputs are merely LS TTL and won't run a teletype without help. Several interface circuits are discussed below and the user may pick the one best suited to his needs.

The ASR - 33 Teletype

The ASR - 33 Teletype of recent vintage has a transistor circuit to drive its solenoids. This circuit is quite easy to interface to, since it is provided with its own power supply. (Figure 1a) It can be set up for a 20mA current loop and interfaced as follows (whether or not the teletype is strapped for full duplex or half duplex operation):

- a) The yellow wire and purple wire should both go to terminal 9 of Terminal Strip X. If the purple wire is going to terminal 8, then remove it and relocate it at terminal 9. This is necessary to change from the 60mA current loop to the 20mA current loop.
- b) Above Terminal Strip X is a connector socket identified as "2". Pin 8 is the input line + or high; Pin 7 is the input line - or low. This connector mates with a Molex receptacle model 1375 #03-09-2151 or #03-09-2153. Recommended terminals are Molex #02-09-2136. An alternate connection method is via spade lugs to Terminal Strip X, terminal 7 (the + input line) and 6 (the - input line).
- c) The following circuit can be built on a 16 pin DIP component carrier and then plugged into the Apple's 16 pin socket found at J-14: (The junction of the 3.3k resistor and the transistor base lead is floating). Pins 16 and 9 are used as tie points as they are unconnected on the Apple board. (Figure 1a).

The "RS - 232 Interface"

For this interface to be legitimate, it is necessary to twice invert the signal appearing at J-14 pin 15 and have it swing more than 5 volts both above and below ground. The following circuit does that but requires that both +12 and -12 supplies be used. (Figure 2) Snipping off pins on the DIP-component carrier will allow the spare terminals to be used for tie points. The output ground connects to pin 7 of the DB-25 connector. The signal output connects to pin 3 of the DB-25 connector. The "protective" ground wire normally found on pin 1 of the DB-25 connector may be connected to the Apple's base plate if desired. Placing a #4 lug under one of the four power supply mounting screws is perhaps the simplest method. The +12 volt supply is easily found on the auxiliary Video connector (see Figure S-11 or Figure 7 of the manual). The -12 volt supply may be found at pin 33 of the peripheral connectors (see Figure 4) or at the power supply connector (see Figure 5 of the manual).

A Serial Out Machine Center Language Program

Once the appropriate circuit has been selected and constructed a machine language program is needed to drive the circuit. Figure 3 lists such a teletype output machine language routine. It can be used in conjunction with an Integer BASIC program that doesn't require page \$300 hex of memory. This program resides in memory from \$370 to \$3E9. Columns three and four of the listing show the op-code used. To enter this program into the Apple II the following procedure is followed:

Entering Machine Language Program

1. Power up Apple II
2. Depress and release the "RESET" key. An asterick and flashing cursor should appear on the left hand side of the screen below the random text matrix.
3. Now type in the data from columns one, two and three for each line from \$370 to \$3E9. For example, type in "370: A9 82" and then depress and release the "RETURN" key. Then repeat this procedure for the data at \$372 and on until you complete entering the program.

Executing this Program

1. From BASIC a CALL 880 (\$370) will start the execution of this program. It will use the teletype or suitable 80 column printer as the primary output device.

2. PR#Ø will inactivate the printer transferring control back to the Video monitor as the primary output device.
3. In Monitor mode \$37ØG activates the printer and hitting the "RESET" key exits the program.

Saving the Machine Language Program

After the machine language program has been entered and checked for accuracy it should, for convenience, be saved on tape - that is unless you prefer to enter it by keyboard every time you want to use it.

The way it is saved is as follows:

1. Insert a blank program cassette into the tape recorder and rewind it.
2. Hit the "RESET" key. The system should move into Monitor mode. An asterick "*" and flashing cursor should appear on the left-hand side of the screen.
3. Type in "37Ø.Ø3E9W 37Ø.Ø3E9W".
4. Start the tape recorder in record mode and depress the "RETURN" key.
5. When the program has been written to tape, the asterick and flashing cursor will reappear.

The Program

After entering, checking and saving the program perform the following procedure to get a feeling of how the program is used:



1. BC (control B) into BASIC
2. Turn the teletype (printer on)
3. Type in the following

```
10 CALL 88Ø
15 PRINT "ABCD...XYZØ1123456789"
20 PR#Ø
25 END
```
4. Type in RUN and hit the "RETURN" key. The text in line 15 should be printed on the teletype and control is returned to the keyboard and Video monitor.

Line 10 activates the teletype machine routine and all "PRINT" statements following it will be printed to the teletype until a PR#0 statement is encountered. Then the text in line 15 will appear on the teletype's output. Line 20 deactivates the printer and the program ends on line 25.

Conclusion

With the circuits and machine language program described in this paper the user may develop a relatively simple serial output interface to an ASR-33 or RS-232 compatible printers. This circuit can be activated through BASIC or monitor modes. And is a valuable addition to any users program library.



(a)

(b)

FIGURE 1 ASR-33




FIGURE 2 RS-232

TELETYPE DRIVER ROUTINES

PAGE: 1

3:42 P.M., 11/18/1977

```

1      TITLE 'TELETYPE DRIVER ROUTINES'
2      ****
3      *
4      *      TTYDRIVER:      *
5      *      TELETYPE OUTPUT   *
6      *      ROUTINE FOR 72    *
7      *      COLUMN PRINT WITH *
8      *      BASIC LIST       *
9      *
10     *      COPYRIGHT 1977 BY:  *
11     *      APPLE COMPUTER INC. *
12     *          11/18/77        *
13     *
14     *      R. WIGGINTON      *
15     *      S. WOZNIAK        *
16     *
17     ****
18     WNDWDTH    EQU $21           ;FOR APPLE-II
19     CH         EQU $24           ;CURSOR HORIZ.
20     CSWL       EQU $36           ;CHAR. OUT SWITCH
21     YSAVE      EQU $778          ;COLUMN COUNT LOC.
22     COLCNT     EQU $7F8
23     MARK       EQU $C058
24     SPACE      EQU $C059
25     WAIT       EQU $FCA8
26     ORG        $370

***WARNING: OPERAND OVERFLOW IN LINE 27
0370: A9 82    27   TTINIT:    LDA #TTOUT
0372: 85 36    28   STA CSWL    ;POINT TO TTY ROUTINES
0374: A9 03    29   LDA #TTOUT/256 ;HIGH BYTE
0376: 85 37    30   STA CSWL+1
0378: A9 48    31   LDA #72      ;SET WINDOW WIDTH
037A: 85 21    32   STA WNDWDTH ;TO NUMBER COLUMNS ONLY
037C: A5 24    33   LDA CH      ;WHERE WE ARE NOW.
037E: 8D F8 07  34   STA COLCNT
0381: 60        35   RTS
0382: 48        36   TTOUT:    PHA ;SAVE TWICE
0383: 48        37   PHA ;ON STACK.
0384: AD F8 07  38   TTOUT2:   LDA COLCNT ;CHECK FOR A TAB.
0387: C5 24    39   CMP CH
0389: 68        40   PLA ;RESTORE OUTPUT CHAR.
038A: B0 03    41   BCS TESTCTRL ;IF C SET, NO TAB
038C: 48        42   PHA
038D: A9 A0    43   LDA #3AO ;PRINT A SPACE.
038F: 2C C0 03  44   TESTCTRL: BIT RTS1 ;TRICK TO DETERMINE
0392: F0 03    45   BEQ PRNTIT ;IF CONTROL CHAR.
0394: EE F8 07  46   INC COLCNT ;IF NOT, ADD ONE TO C
0397: 20 C1 03  47   PRNTIT:  JSR DOCHAR ;PRINT THE CHAR ON TTY
039A: 68        48   PLA ;RESTORE CHAR
039B: 48        49   PHA ;AND PUT BACK ON STACK
039C: 90 E6    50   BCC TTOUT2 ;DO MORE SPACES FOR TAB
039E: 49 0D    51   EOR #$0D ;CHECK FOR CAR RET.
03A0: 0A        52   ASL A ;SELIM PARITY
03A1: D0 0D    53   BNE FINISH ;IF NOT CR, DONE.

```

FIGURE 3a

TELETYPE DRIVER ROUTINES

PAGE: 2

3:42 P.M., 11/18/1977

03A3: 8D F8 07 54		STA COLCNT	;CLEAR COLUMN COUNT
03A6: A9 8A 55		LDA #\$8A	;NOW DO LINE FEED
03A8: 20 C1 03 56		JSR DOCHAR	
03AB: A9 58 57		LDA #\$58	
03AD: 20 A8 FC 58		JSR WAIT	;200MSEC DELAY FOR LID
03B0: AD F8 07 59	FINISH:	LDA COLCNT	;CHECK IF IN MARGIN
03B3: F0 08 60		BEQ SETCH	;FOR CR, RESET CH
03B5: E5 21 61		SBC WNDWDTH	;IF SO, CARRY SET.
03B7: E9 F7 62		SBC #\$F7	
03B9: 90 04 63		BCC RETURN	
03BB: 69 1F 64		ADC #\$1F	;ADJUST CH
03BD: 85 24 65	SETCH:	STA CH	
03BF: 68 66	RETURN:	PLA	
03C0: 60 67	RTSI:	RTS	;RETURN TO CALLER
68	* HERE IS THE TELETYPE PRINT A CHARACTER ROUTINE:		
03C1: 8C 78 07 69	DOCHAR:	STY YSAVE	
03C4: 08 70		PHP	;SAVE STATUS.
03C5: A0 0B 71		LDY #\$0B	;11 BITS (I START, 9 ■
03C7: 18 72		CLC	;BEGIN WITH SPACE (STE)
03C8: 48 73	TTOUT3:	PHA	;SAVE A REG AND SET FOA
03C9: B0 05 74		BCS MARKOUT	
03CB: AD 59 C0 75		LDA SPACE	;SEND A SPACE
03CE: 90 03 76		BCC TTOUT4	
03D0: AD 58 C0 77	MARKOUT:	LDA MARK	;SEND A MARK
03D3: A9 D7 78	TTOUT4:	LDA #\$D7	;DELAY 9.091 MSEC FOR
03D5: 48 79	DLY1:	PHA	;110 BAUD
03D6: A9 20 80		LDA #\$20	
03D8: 4A 81	DLY2:	LSR A	
03D9: 90 FD 82		BCC DLY2	
03DB: 68 83		PLA	
03DC: E9 01 84		SBC #\$01	
03DE: D0 F5 85		BNE DLY1	
03E0: 68 86		PLA	
03E1: 6A 87		ROR A	;NEXT BIT (STOP BITS ■
03E2: 88 88		DEY	LOOP 11 BITS.
03E3: D0 E3 89		BNE TTOUT3	
03E5: AC 78 07 90		LDY YSAVE	;RESTORE Y-REG.
03E8: 28 91		PLP	;RESTORE STATUS
03E9: 60 92		RTS	;RETURN

*****SUCCESSFUL ASSEMBLY: NO ERRORS

FIGURE 3b

CROSS-REFERNCE: TELETYPE DRIVER ROUTINES

CH	0024	0033 0039 0065
COLCNT	07F8	0034 0038 0046 0054 0059
CSWL	0036	0028 0030
DLY1	03D5	0085
DLY2	03D8	0082
DOCHAR	03C1	0047 0056
FINISH	03B0	0053
MARK	C058	0077
MARKOUT	03D0	0074
PRNTIT	0397	0045
RETURN	03BF	0063
RTS1	03C0	0044
SETCH	03BD	0060
SPACE	C059	0075
TESTCTRL	038F	0041
TTINIT	0370	
TTOUT	0382	0027 0029
TTOUT2	0384	0050
TTOUT3	03C8	0089
TTOUT4	03D3	0076
WAIT	FCA8	0058
WNDWDTH	0021	0032 0061
YSAVE	0778	0069 0090
ILE:		

FIGURE 3c

INTERFACING THE APPLE

This section defines the connections by which external devices are attached to the APPLE II board. Included are pin diagrams, signal descriptions, loading constraints and other useful information.

TABLE OF CONTENTS

1. CONNECTOR LOCATION DIAGRAM
2. CASSETTE DATA JACKS (2 EACH)
3. GAME I/O CONNECTOR
4. KEYBOARD CONNECTOR
5. PERIPHERAL CONNECTORS (8 EACH)
6. POWER CONNECTOR
7. SPEAKER CONNECTOR
8. VIDEO OUTPUT JACK
9. AUXILIARY VIDEO OUTPUT CONNECTOR

Figure 1A APPLE II Board-Complete View





Figure 1B Connector Location Detail

APPLE II PC BOARD
TOP VIEW



CASSETTE JACKS

A convenient means for interfacing an inexpensive audio cassette tape recorder to the APPLE II is provided by these two standard (3.5mm) miniature phone jacks located at the back of the APPLE II board.


CASSETTE DATA IN JACK: Designed for connection to the "EARPHONE" or "MONITOR" output found on most audio cassette tape recorders. $V_{IN}=1V_{pp}$ (nominal), $Z_{IN}=12K$ Ohms. Located at K12 as illustrated in Figure 1.

CASSETTE DATA OUT JACK: Designed for connection to the "MIC" or "MICROPHONE" input found on most audio cassette tape recorders. $V_{OUT}=25$ mV into 100 Ohms, $Z_{OUT}=100$ Ohms. Located at K13 as illustrated in Figure 1.

GAME I/O CONNECTOR

The Game I/O Connector provides a means for connecting paddle controls, lights and switches to the APPLE II for use in controlling video games, etc. It is a 16 pin IC socket located at J14 and is illustrated in Figure 1 and 2.

Figure 2 GAME I/O CONNECTOR



LOCATION J14

SIGNAL DESCRIPTIONS FOR GAME I/O

AN0-AN3: 8 addresses (C058-C05F) are assigned to selectively "SET" or "CLEAR" these four "ANNUNCIATOR" outputs. Envisioned to control indicator lights, each is a 74LSxx series TTL output and must be buffered if used to drive lamps.

C040 STB: A utility strobe output. Will go low during θ_2 of a read or write cycle to addresses C040-C04F. This is a 74LSxx series TTL output.

GND: System circuit ground. 0 Volt line from power supply.

NC: No connection.

PDL0-PDL3: Paddle control inputs. Requires a $0\text{-}150\text{K}$ ohm variable resistance and +5V for each paddle. Internal 100 ohm resistors are provided in series with external pot to prevent excess current if pot goes completely to zero ohms.


SW0-SW2: Switch inputs. Testable by reading from addresses C061-C063 (or C069-C06B). These are uncommitted 74LSxx series inputs.

+5V: Positive 5-Volt supply. To avoid burning out the connector pin, current drain MUST be less than 100mA.

KEYBOARD CONNECTOR

This connector provides the means for connecting an ASCII keyboard to the APPLE II board. It is a 16 pin IC socket located at A7 and is illustrated in Figures 1 and 3.

Figure 3 KEYBOARD CONNECTOR



LOCATION A7

SIGNAL DESCRIPTION FOR KEYBOARD INTERFACE

B1-B7: 7 bit ASCII data from keyboard, positive logic (high level= "1"), TTL logic levels expected.

GND: System circuit ground. Ø Volt line from power supply.

NC: No connection.

RESET: System reset input. Requires switch closure to ground.

STROBE: Strobe output from keyboard. The APPLE II recognizes the positive going edge of the incoming strobe.

+5V: Positive 5-Volt supply. To avoid burning out the connector pin, current drain MUST be less than 100mA.

-12V: Negative 12-Volt supply. Keyboard should draw less than 50mA.

PERIPHERAL CONNECTORS

The eight Peripheral Connectors mounted near the back edge of the APPLE II board provide a convenient means of connecting expansion hardware and peripheral devices to the APPLE II I/O Bus. These are Winchester #2HW25CØ-111 (or equivalent) 50 pin card edge connectors with pins on .10" centers. Location and pin outs are illustrated in Figures 1 and 4.

SIGNAL DESCRIPTION FOR PERIPHERAL I/O

A0-A15: 16 bit system address bus. Addresses are set up by the 6502 within 300nS after the beginning of Ø₁. These lines will drive up to a total of 16 standard TTL loads.

DEVICE SELECT: Sixteen addresses are set aside for each peripheral connector. A read or write to such an address will send pin 41 on the selected connector low during Ø₂ (500nS). Each will drive 4 standard TTL loads.

D0-D7: 8 bit system data bus. During a write cycle data is set up by the 6502 less than 300nS after the beginning of Ø₂. During a read cycle the 6502 expects data to be ready no less than 100nS before the end of Ø₂. These lines will drive up to a total of 8 total low power schottky TTL loads.

<u>DMA:</u>	Direct Memory Access control output. This line has a 3K Ohm pullup to +5V and should be driven with an open collector output.
<u>DMA IN:</u>	Direct Memory Access daisy chain input from higher priority peripheral devices. Will present no more than 4 standard TTL loads to the driving device.
<u>DMA OUT:</u>	Direct Memory Access daisy chain output to lower priority peripheral devices. This line will drive 4 standard TTL loads.
<u>GND:</u>	System circuit ground. Ø Volt line from power supply.
<u>INH:</u>	Inhibit Line. When a device pulls this line low, all ROM's on board are disabled (Hex addressed D000 through FFFF). This line has a 3K Ohm pullup to +5V and should be driven with an open collector output.
<u>INT IN:</u>	Interrupt daisy chain input from higher priority peripheral devices. Will present no more than 4 standard TTL loads to the driving device.
<u>INT OUT:</u>	Interrupt daisy chain output to lower priority peripheral devices. This line will drive 4 standard TTL loads.
<u>I/O SELECT:</u>	256 addresses are set aside for each peripheral connector (see address map in "MEMORY" section). A read or write of such an address will send pin 1 on the selected connector low during Ø ₂ (500nS). This line will drive 4 standard TTL loads.
<u>I/O STROBE:</u>	Pin 20 on all peripheral connectors will go low during Ø ₂ of a read or write to any address C800-CFFF. This line will drive a total of 4 standard TTL loads.
<u>IRQ:</u>	Interrupt request line to the 6502. This line has a 3K Ohm pullup to +5V and should be driven with an open collector output. It is active low.
<u>NC:</u>	No connection.
<u>NMI:</u>	Non Maskable Interrupt request line to the 6502. This line has a 3K Ohm pullup to +5V and should be driven with an open collector output. It is active low.
<u>Ø₃:</u>	A 1MHz (nonsymmetrical) general purpose timing signal. Will drive up to a total of 16 standard TTL loads.
<u>RDY:</u>	"Ready" line to the 6502. This line should change only during Ø ₁ , and when low will halt the microprocessor at the next READ cycle. This line has a 3K Ohm pullup to +5V and should be driven with an open collector output.
<u>RES:</u>	Reset line from "RESET" key on keyboard. Active low. Will drive 2 MOS loads per Peripheral Connector.

- R/W: READ/WRITE line from 6502. When high indicates that a read cycle is in progress, and when low that a write cycle is in progress. This line will drive up to a total of 16 standard TTL loads.
- USER 1: The function of this line will be described in a later document.
- \emptyset_0 : Microprocessor phase \emptyset clock. Will drive up to a total of 16 standard TTL loads.
- \emptyset_1 : Phase 1 clock, complement of \emptyset_0 . Will drive up to a total of 16 standard TTL loads.
- 7M: Seven MHz high frequency clock. Will drive up to a total of 16 standard TTL loads.
- +12V: Positive 12-Volt supply.
- +5V: Positive 5-Volt supply
- 5V: Negative 5-Volt supply.
- 12V: Negative 12-Volt supply.

POWER CONNECTOR

The four voltages required by the APPLE II are supplied via this AMP #9-35028-1,6 pin connector. See location and pin out in Figures 1 and 5.

PIN DESCRIPTION

- GND: (2 pins) system circuit ground. \emptyset Volt line from power supply.
- +12V: Positive 12-Volt line from power supply.
- +5V: Positive 5-Volt line from power supply.
- 5V: Negative 5-Volt line from power supply.
- 12V: Negative 12-Volt line from power supply.

Figure 4 PERIPHERAL CONNECTORS
(EIGHT OF EACH)





Figure 5 POWER CONNECTOR



SPEAKER CONNECTOR

This is a MOLEX KK 100 series connector with two .25" square pins on .10" centers. See location and pin out in Figures 1 and 6.


SIGNAL DESCRIPTION FOR SPEAKER

+5V: System +5 Volts

SPKR: Output line to speaker. Will deliver about .5 watt into 8 Ohms.

Figure 6

SPEAKER CONNECTOR



VIDEO OUTPUT JACK

This standard RCA phono jack located at the back edge of the APPLE II P.C. board will supply NTSC compatible, EIA standard, positive composite video to an external video monitor.

A video level control near the connector allows the output level to be adjusted from 0 to 1 Volt (peak) into an external 75 OHM load.

Additional tint (hue) range is provided by an adjustable trimmer capacitor.

See locations illustrated in Figure 1.


AUXILIARY VIDEO OUTPUT CONNECTOR

This is a MOLEX KK 100 series connector with four .25" square pins on .10" centers. It provides composite video and two power supply voltages. Video out on this connector is not adjustable by the on board 200 Ohm trim pot. See Figures 1 and 7.

SIGNAL DESCRIPTION

- GND: System circuit ground. Ø Volt line from power supply.
- VIDEO: NTSC compatible positive composite VIDEO. DC coupled emitter follower output (not short circuit protected). SYNC TIP is Ø Volts, black level is about .75 Volts, and white level is about 2.Ø Volts into 47Ø Ohms. Output level is non-adjustable.
- +12V: +12 Volt line from power supply.
- 5V: -5 Volt line from power supply.

Figure 7 AUXILIARY VIDEO OUTPUT CONNECTOR



INSTALLING YOUR OWN RAM

THE POSSIBILITIES

The APPLE II computer is designed to use dynamic RAM chips organized as 4096 x 1 bit, or 16384 x 1 bit called "4K" and "16K" RAMs respectively. These must be used in sets of 8 to match the system data bus (which is 8 bits wide) and are organized into rows of 8. Thus, each row may contain either 4096 (4K) or 16384 (16K) locations of Random Access Memory depending upon whether 4K or 16K chips are used. If all three rows on the APPLE II board are filled with 4K RAM chips, then 12288 (12K) memory locations will be available for storing programs or data, and if all three rows contain 16K RAM chips then 49152 (commonly called 48K) locations of RAM memory will exist on board!

RESTRICTIONS


It is quite possible to have the three rows of RAM sockets filled with any combination of 4K RAMs, 16K RAMs or empty as long as certain rules are followed:

1. All sockets in a row must have the same type (4K or 16K) RAMs.
2. There MUST be RAM assigned to the zero block of addresses.

ASSIGNING RAM

The APPLE II has 48K addresses available for assignment of RAM memory. Since RAM can be installed in increments as small as 4K, a means of selecting which address range each row of memory chips will respond to has been provided by the inclusion of three MEMORY SELECT sockets on board.

Figure 8
MEMORY SELECT SOCKETS



LOCATIONS D1, E1, F1

MEMORY

TABLE OF CONTENTS

1. INTRODUCTION
2. INSTALLING YOUR OWN RAM
3. MEMORY SELECT SOCKETS
4. MEMORY MAP BY 4K BLOCKS
5. DETAILED MAP OF ASSIGNED ADDRESSES

INTRODUCTION

APPLE II is supplied completely tested with the specified amount of RAM memory and correct memory select jumpers. There are five different sets of standard memory jumper blocks:

1. 4K 4K 4K BASIC
2. 4K 4K 4K HIRES
3. 16K 4K 4K
4. 16K 16K 4K
5. 16K 16K 16K

A set of three each of one of the above is supplied with the board. Type 1 is supplied with 4K or 8K systems. Both type 1 and 2 are supplied with 12K systems. Type 1 is a contiguous memory range for maximum BASIC program size. Type 2 is non-contiguous and allows 8K dedicated to HIRES screen memory with approximately 2K of user BASIC space. Type 3 is supplied with 16K, 20K and 24K systems. Type 4 with 30K and 36K systems and type 5 with 48K systems.

Additional memory may easily be added just by plugging into sockets along with correct memory jumper blocks.

The 6502 microprocessor generates a 16 bit address, which allows 65536 (commonly called 65K) different memory locations to be specified. For convenience we represent each 16 bit (binary) address as a 4-digit hexadecimal number. Hexadecimal notation (hex) is explained in the Monitor section of this manual.

In the APPLE II, certain address ranges have been assigned to RAM memory, ROM memory, the I/O bus, and hardware functions. The memory and address maps give the details.

MEMORY SELECT SOCKETS

The location and pin out for memory select sockets are illustrated in Figures 1 and 8.

HOW TO USE

There are three MEMORY SELECT sockets, located at D1, E1 and F1 respectively. RAM memory is assigned to various address ranges by inserting jumper wires as described below. All three MEMORY SELECT sockets MUST be jumpered identically! The easiest way to do this is to use Apple supplied memory blocks.

Let us learn by example:

If you have plugged 16K RAMs into row "C" (the sockets located at C3-C10 on the board), and you want them to occupy the first 16K of addresses starting at 0000 , jumper pin 14 to pin 10 on all three MEMORY SELECT sockets (thereby assigning row "C" to the 0000 -3FFF range of memory).

If in addition you have inserted 4K RAMs into rows "D" and "E", and you want them each to occupy the first 4K addresses starting at 4000 and 5000 respectively, jumper pin 13 to pin 5 (thereby assigning row "D" to the 4000 -4FFF range of memory), and jumper pin 12 to pin 6 (thereby assigning row "E" to the 5000 -5FFF range of memory). Remember to jumper all three MEMORY SELECT sockets the same.

Now you have a large contiguous range of addresses filled with RAM memory. This is the 24K addresses from 0000 -5FFF.

By following the above examples you should be able to assign each row of RAM to any address range allowed on the MEMORY SELECT sockets. Remember that to do this properly you must know three things:

1. Which rows have RAM installed?
2. Which address ranges do you want them to occupy?
3. Jumper all three MEMORY SELECT sockets the same!

If you are not sure think carefully, essentially all the necessary information is given above.

Memory Address Allocations in 4K Bytes

0000	text and color graphics display pages, 6502 stack, pointers, etc.	8000
1000		9000
2000	high res graphics display primary page	A000
3000	"	B000
4000	"	C000
5000	"	D000
6000	"	E000
7000	"	F000
		addresses dedicated to hardware functions " " ROM socket D0: spare " " ROM socket D8: spare " ROM socket E0: BASIC " ROM socket E8: BASIC " ROM socket F0: BASIC utility ROM socket F8: monitor

Memory Map Pages 0 to BFF

HEX ADDRESS(ES)	USED BY	USED FOR	COMMENTS
PAGE ZERO 0000-001F	UTILITY	register area for "sweet 16" 16 bit firmware processor.	
0020-004D	MONITOR		
004E-004F	MONITOR	holds a 16 bit number that is randomized with each key entry.	
0050-0055	UTILITY	integer multiply and divide work space.	
0055-00FF	BASIC		
00F0- 0OFF	UTILITY	floating point work space.	
PAGE ONE 0100-01FF	6502	subroutine return stack.	
PAGE TWO 0200-02FF		character input buffer.	
PAGE THREE 03F8	MONITOR	Y ^c (control Y) will cause a JSR to this location.	
03FB		NMI's are vectored to this location.	
03FE-03FF		IRQ's are vectored to the address pointed to by these locations.	
0400-07FF	DISPLAY	text or color graphics primary page.	
0800-0BFF	DISPLAY	text or color graphics secondary page.	BASIC initializes LOHMEM to location 0800.

I/O and ROM Address Detail

HEX ADDRESS	ASSIGNED FUNCTION	COMMENTS
C00X	Keyboard input.	Keyboard strobe appears in bit 7. ASCII data from keyboard appears in the 7 lower bits.
C01X	Clear keyboard strobe.	
C02X	Toggle cassette output.	
C03X	Toggle speaker output.	
C04X	"C040 STB"	Output strobe to Game I/O connector.
C050	Set graphics mode	
C051	" text "	
C052	Set bottom 4 lines graphics	
C053	" " " " text	
C054	Display primary page	
C055	" secondary page	
C056	Set high res. graphics	
C057	" color "	
C058	Clear "AN0"	Annunciator 0 output to Game I/O connector.
C059	Set "	
C05A	Clear "AN1"	Annunciator 1 output to Game I/O connector.
C05B	Set "	
C05C	Clear "AN2"	Annunciator 2 output to Game I/O connector.
C05D	Set "	
C05E	Clear "AN3"	Annunciator 3 output to Game I/O connector.
C05F	Set "	

HEX ADDRESS	ASSIGNED FUNCTION	COMMENTS
C060/8	Cassette input	State of "Cassette Data In" appears in bit 7.
C061/9	"SW1"	input on State of Switch 1 \wedge Game I/O connector appears in bit 7.
C062/A	"SW2"	State of Switch 2 input on Game I/O connector appears in bit 7.
C063/B	"SW3"	State of Switch 3 input on Game I/O connector appears in bit 7.
C064/C	Paddle 0 timer output	State of timer output for Paddle 0 appears in bit 7.
C065/D	" 1 " "	State of timer output for Paddle 1 appears in bit 7.
C066/E	" 2 " "	State of timer output for Paddle 2 appears in bit 7.
C067/F	" 3 " "	State of timer output for Paddle 3 appears in bit 7.
C07X	"PDL STB"	Triggers paddle timers during \emptyset_2 .
C08X	DEVICE SELECT 0	Pin 41 on the selected Peripheral Connector goes low during \emptyset_2 .
C09X	" 1	
COAX	" 2	
COBX	" 3	
COCX	" 4	
CODX	" 5	
COEX	" 6	
COFX	" 7	
C10X	" 8	Expansion connectors.
C11X	" 9	"
C12X	" A	"

HEX ADDRESS	ASSIGNED FUNCTION		COMMENTS
C13X	DEVICE SELECT	B	"
C14X	"	C	"
C15X	"	D	"
C16X	"	E	"
C17X	"	F	"
C1XX	I/O SELECT	1	Pin 1 on the selected Peripheral Connector goes low during ϕ_2 .
C2XX	"	2	
C3XX	"	3	NOTES: 1. Peripheral Connector 0 does not get this signal.
C4XX	"	4	
C5XX	"	5	2. I/O SELECT 1 uses the same addresses as DEVICE SELECT 8-F.
C6XX	"	6	
C7XX	"	7	
C8XX	"	8, I/O STROBE	Expansion connectors.
C9XX	"	9,	"
CAXX	"	A,	"
CBXX	"	B,	"
CCXX	"	C,	"
CDXX	"	D,	"
CEXX	"	E,	"
CFXX	"	F,	"
D000-D7FF	ROM socket	D0	Spare.
D800-DFFF	" "	D8	Spare.
E000-E7FF	" "	E0	BASIC.
E800-EFFF	" "	E8	BASIC.
F000-F7FF	" "	F0	1K of BASIC, 1K of utility.
F800-FFFF	" "	F8	Monitor.

SYSTEM TIMING

SIGNAL DESCRIPTIONS

14M: Master oscillator output, 14.318 MHz +/- 35 ppm. All other timing signals are derived from this one.

7M: Intermediate timing signal, 7.159 MHz.

COLOR REF: Color reference frequency used by video circuitry, 3.580 MHz.

Φ_0 : Phase Φ clock to microprocessor, 1.023 MHz nominal.

Φ_1 : Microprocessor phase 1 clock, complement of Φ_0 , 1.023 MHz nominal.

Φ_2 : Same as Φ_0 . Included here because the 6502 hardware and programming manuals use the designation Φ_2 instead of Φ_0 .

Φ_3 : A general purpose timing signal which occurs at the same rate as the microprocessor clocks but is nonsymmetrical.

MICROPROCESSOR OPERATIONS

ADDRESS: The address from the microprocessor changes during Φ_1 , and is stable about 300nS after the start of Φ_1 .


DATA WRITE: During a write cycle, data from the microprocessor appears on the data bus during Φ_2 , and is stable about 300nS after the start of Φ_2 .

DATA READ: During a read cycle, the microprocessor will expect data to appear on the data bus no less than 100nS prior to the end of Φ_2 .

SYSTEM TIMING DIAGRAM

TIMING CIRCUITRY
BLOCK DIAGRAM

TIMING RELATIONSHIPS






FIGURE S-1 APPLE II SYSTEM DIAGRAM




FIGURE S-2 MPU AND SYSTEM BUS




FIGURE S-3 REFERENCE OSCILLATOR AND SYSTEM TIMING




FIGURE S-4 SYNC COUNTER




FIGURE S-5 ROM MEMORY




FIGURE S-6 4K/16K RAM SELECT




FIGURE S-7 RAM ADDRESS MUX




FIGURE S-8 4K TO 48K RAM MEMORY WITH DATA LATCH

I/O CONNECTOR DETAIL




FIGURE S-9 PERIPHERAL I/O CONNECTOR PINOUT AND CONTROL LOGIC

SEE APP. NOTE ON HOW TO USE
OPTIONAL JUMPER




FIGURE S-10 ON-BOARD I/O




FIGURE S-11 VIDEO GENERATOR



10260 BANDLEY DRIVE
CUPERTINO, CALIFORNIA 95014 U.S.A.
TELEPHONE (408) 996-1010