Programming Assignment 1

CS422, IIT Kanpur 12/01/2018

Problem

In this problem, you will analyze a subset of the SPEC 2006 benchmark suite compiled for the ia32 (32-bit Intel architecture) ISA. Specifically, you will instrument each SPEC 2006 application binary with PIN and extract the percentages of various different instruction types. You will also use a very simple cycle accounting model to calculate the CPI for each application. Additionally, you will calculate the instruction and data footprints of each application. Finally, you will understand a few properties of the ia32 ISA.

In this assignment, we will be interested only in the following instruction types. At a very high level, we have two instruction types.

- Type A: Instructions with no memory operand
- Type B: Instructions with at least one memory operand

We would like to categorize instructions of Type A into the following fifteen classes. The internal category names used by PIN are shown in parentheses.

```
1. NOPs
                                                      (XED_CATEGORY_NOP)
  2. Direct calls
                                                      (XED_CATEGORY_CALL)
  3. Indirect calls
                                                      (XED_CATEGORY_CALL)
  4. Returns
                                                      (XED CATEGORY RET)
  5. Unconditional branches
                                              (XED_CATEGORY_UNCOND_BR)
  6. Conditional branches
                                                 (XED_CATEGORY_COND_BR)
  7. Logical operations
                                                  (XED_CATEGORY_LOGICAL)
                            ( XED_CATEGORY_ROTATE | XED_CATEGORY_SHIFT )
  8. Rotate and shift
                                                   (XED CATEGORY FLAGOP)
  9. Flag operations
                                 ( XED_CATEGORY_AVX | XED_CATEGORY_AVX2 |
  10. Vector instructions
XED_CATEGORY_AVX2GATHER)
  11. Conditional moves
                                                     (XED CATEGORY CMOV)
   12. MMX and SSE instructions
                                 ( XED_CATEGORY_MMX | XED_CATEGORY_SSE )
                                                  (XED CATEGORY SYSCALL)
  13. System calls
  14. Floating-point
                                                  (XED_CATEGORY_X87_ALU)
   15. Others: whatever is left
```

You should only instrument the instructions that actually execute i.e., have true predicates. As a result, you should always use INS_InsertPredicatedCall method when classifying instructions.

To identify the instructions with the category shown within parentheses in the aforementioned list, you should use the INS_Category method and compare the return value against the category type as shown in Listing 1 and Listing 2:

Listing 1: To identify if an instruction ins is a NOP you should do the following.

```
1
2 if (INS_Category(ins) == XED_CATEGORY_NOP) {
3   // Increment NOP count by one
4 }
```

Listing 2: To identify direct and indirect calls you should do the following.

```
1
2
  if (INS_Category(ins) == XED_CATEGORY_CALL) {
3
      if (INS_IsDirectCall(ins)) {
4
         // Increment direct call count by one
5
     }
6
     else {
7
         // Increment indirect call count by one
8
      }
9
  }
```

Next, let's turn to the Type B instructions. Each memory operand in such an instruction can be read and/or written to. We will view each such load or store operation within a Type B instruction as a separate micro-instruction and count it as a separate instruction. For example, a Type B instruction may have two load operations and a store operation. Further, each such load or store operation may access an arbitrary amount of data. However, in a 32-bit processor, it is not possible to transfer more than 32 bits of data in one shot. As a result, we will further break down each memory operation into several memory accesses of size at most 32 bits. For example, if a load operation accesses 101 bytes of data, it will be counted as 26 load operations. Finally, the instruction must be using these memory operands to carry out some operation of type A. This operation should be counted as a separate type A instruction and should also be categorized into one of the fifteen categories mentioned above.

Let us take an example of an x86 instruction that has three memory operands, two of which are loads and one is a store. The loads access one and ten bytes, respectively. The store accesses eleven bytes. This instruction will be accounted as follows.

· Number of loads: 4

Number of stores: 3

• Number of type A instruction: 1

Total instruction count increases by eight, whenever such an instruction is encountered.

We have discussed in the class how to identify the load and store operands of each memory instruction. To get the size of memory accessed by each operand, you should use the INS_MemoryOperandSize method.

PART A [25 points]

For each benchmark application, you need to report the dynamic counts and percentages of the following seventeen types of instructions. The total number of instructions (to be used as the denominator in the percentage) is the addition of all these seventeen counters.

- 1. Loads
- 2. Stores
- 3. NOPs
- 4. Direct calls
- 5. Indirect calls
- 6. Returns
- 7. Unconditional branches
- 8. Conditional branches
- 9. Logical operations
- 10. Rotate and shift
- 11. Flag operations
- 12. Vector instructions
- 13. Conditional moves
- 14. MMX and SSE instructions
- 15. System calls
- 16. Floating-point
- 17. The rest

Avoid double-counting an instruction in multiple categories. For this purpose, your instrumentation code should have the following structure as shown in Listing 3.

```
1
   if (memory instruction) {
 3
       # Count load and store instructions for type B
 4
   }
 5
 6 # Categorize all instructions for type A
 7 if (NOP) {
8
   . . .
   }
9
   else if (Calls) {
10
       if (Direct call) {
11
12
       . . .
13
       }
14
      else {
15
       . . .
16
       }
17 }
18 else if (Returns) {
19 ...
20 }
21
   . . .
22 else if (Floating-point) {
23
   . . .
24 }
25 else {
26
   . . .
27 }
```

In other words, go exactly in the order shown above. Identify and categorize instructions at instrumentation stage and pass a pointer to the appropriate counter. Do not try to run a switch-case or if-elseif-else chain at analysis time. If you can, do the instrumentation at basic block level to speed up analysis. Prepare a table showing these counts and percentages for the applications.

PART B [10 points]

The second part of the assignment involves **calculating the CPI for each benchmark**. You should charge each load and store operation a fixed latency of fifty cycles and every other instruction a latency of one cycle. Tabulate the CPI of the applications in a table.

PART C [35 points]

The third part of the assignment requires you to calculate the memory footprint of each benchmark application. The memory footprint of an application is the amount of memory the application uses when executing. Note that the footprint includes both instruction and data footprints. Usually, memory footprint is calculated assuming a certain granularity G of each access. This means that any access within the G bytes will be assumed to have accessed the entire G bytes even if certain parts of the G bytes may never be touched by the application. In this assignment, we will calculate the memory footprint at a granularity of 32 bytes. For each application benchmark, you need to calculate the number of unique 32-byte instruction and data chunks accessed. Report the instruction and data statistics separately. As an example, consider an application with the following memory accesses. Each element in the sequence has two tuples separated by a colon. The first tuple specifies the instruction address and the size of the instruction in bytes. The second tuple specifies the data address and the amount of data accessed in bytes.

(1000, 4):(0, 4), (1004, 4):(4, 4), (1008, 4):(8, 4), (1012, 2):(500, 2), (1014, 6):(200, 8), (1020, 1):(220, 8), (1021, 4):(80, 8).

This application touches five different 32-byte data chunks starting at addresses 0 (the first three accesses), 64 (the last access), 192 (the fifth and part of the sixth accesses), 224 (part of the sixth access), 480 (the fourth access). The application touches two instruction chunks starting at addresses 992 and 1024. Thus the application has a data footprint of 160 bytes (5*32 bytes) and instruction footprint of 64 bytes (2*32 bytes). Note that in this example, we have shown instructions involving at least one memory operand. Keep in mind to include instructions of Type A also in your instruction footprint. You can get the size of an instruction by calling INS_Size method. When calculating the instruction footprint, you should not use INS_InsertPredicatedCall because even the instructions with false predicates do get fetched, decoded, and executed up to the point of examining the predicate. So, you should count all instructions when calculating the instruction footprint. Prepare a table showing the instruction and data footprints of the applications.

PART D [30 points]

In this part, you will explore the following properties of the ia32 ISA. Tabulate the results for the applications appropriately.

- **1. Distribution of instruction length:** Report the number of instructions of various lengths (1, 2, ... bytes) in each benchmark applications. Use the INS_Size method to get the size of each instruction. Do not use INS_InsertPredicatedCall because you should take into account all instructions.
- **2. Distribution of the number of operands in an instruction:** Report the number of instructions with 0, 1, 2, ... operands. Use the INS_OperandCount method to get the number of operands in an instruction. Do not use INS_InsertPredicatedCall because you should take into account all instructions.

- **3. Distribution of the number of register read operands in an instruction:** An instruction reads a certain number of source registers to get the operand values. Report the number of instructions with 0, 1, 2, ... register read operands. Use the INS_MaxNumRRegs method to get the number of register read operands of an instruction. Do not use INS_InsertPredicatedCall because you should take into account all instructions.
- **4. Distribution of the number of register write operands in an instruction:** An instruction writes to a certain number of destination registers. Report the number of instructions with 0, 1, 2, ... register write operands. Use the INS_MaxNumWRegs method to get the number of register write operands of an instruction. Do not use INS_InsertPredicatedCall because you should take into account all instructions.
- **5. Distribution of the number of memory operands in an instruction:** Report the number of instructions with 0, 1, 2, ... memory operands. Instrument only the instructions with true predicates i.e., use INS_InsertPredicatedCall. Note that a memory operand that is read as well as written to within the same instruction, should be counted as two different operands.
- **6. Distribution of the number of memory read operands in an instruction:** Report the number of instructions with 0, 1, 2, ... memory read operands. Instrument only the instructions with true predicates i.e., use INS InsertPredicatedCall.
- **7. Distribution of the number of memory write operands in an instruction:** Report the number of instructions with 0, 1, 2, ... memory write operands. Instrument only the instructions with true predicates i.e., use INS_InsertPredicatedCall.
- 8. Report the maximum and average number of memory bytes touched (read and written) by any memory instruction: The denominator in the average should include only those instructions that have at least one memory operand. Instrument only the instructions with true predicates i.e., use INS_InsertPredicatedCall.
- 9. Report the maximum and minimum values of the immediate field in an instruction: Recall that in an instruction each operand may or may not use the immediate mode. To test if an operand is in immediate mode, use the INS_OperandIsImmediate method. The immediate value for an operand is relevant only if INS_OperandIsImmediate returns true. Use the INS_OperandImmediate method to get the immediate value in such a case. The return type of this method for a 32-bit binary is a signed 32-bit integer i.e., INT32. Since there is no IARG_INT32 type in PIN, you can pass the immediate value from the instrumentation routine to the analysis routine through IARG_ADDRINT. Make sure to use INT32 type in the analysis routine to recover the sign. Do not use INS_InsertPredicatedCall because you should take into account all instructions.
- 10. Report the maximum and minimum values of the displacement field in a memory instruction: Use the INS_OperandMemoryDisplacement method to get the value of the displacement field in a memory operand. Every ia32 memory operand can use a displacement+base+index*scale addressing. The memory displacement is of type ADDRDELTA which you can pass from from the instrumentation routine to the analysis routine through IARG_ADDRINT. Make sure to use ADDRDELTA type in the analysis routine to recover the sign. Instrument only the instructions with true predicates i.e., use INS_InsertPredicatedCall.

SETUP

Benchmark applications

You will be using the following eight applications drawn from the SPEC 2006 benchmark suite for this problem:

- 1. 400.perlbench diffmail.pl
- 2. 401.bzip2 input.source
- 3. 403.gcc cp-decl.i
- 4. 429.mcf
- 5. 450.soplex ref.mps
- 6. 456.hmmer nph3.hmm
- 7. 471.omnetpp
- 8. 483.xalancbmk

Optional (caution: executions take more than twelve hours):

- 9. 436.cactusADM
- 10. 437.leslie3d
- 11. 462.libquantum
- 12. 470.lbm
- 13. 482.sphinx3

The input and binary for each of the above applications are provided in a separate compressed archive: **spec_2006.zip**. Copy the archive into your home directory from:

/users/phd/mohdsalman/spec 2006.zip on

csecourses2.cse.iitk.ac.in (ssh cse-username@csecourses2.cse.iitk.ac.in).

Use the following command to unzip the archive:

unzip spec_2006.zip

This would create a directory *spec_2006*. The directory *spec_2006* contains a file *comman-dline.txt* and a sub-directory for each application. The sub-directory of each application contains its binary and inputs. The file *commandline.txt* provides the commandline to run the applications natively.

For each benchmark application, you will fast-forward it over a certain number of instructions (specified in the file *commandline.txt*). During this phase do not invoke any analysis code. After this phase, analyze the application for a total of one billion (10⁹) instructions (includes all instructions in this count, even those with false predicate) and then report the statistics.

Fast-forwarding can be implemented by keeping track of the number of instructions executed (even those with false predicates), and then checking in analysis routines when sufficient instructions have been executed. We have already discussed in class how to track the number of instructions executed.

Below (Listing 4) I show an extension of the instruction count PIN tool discussed in class for fast-forwarding.

Listing 4: Fast-Forwarding.

```
1 UINT64 fast-forward-count; # Should be a command line input to your PIN \leftarrow
       tool
2 \text{ UINT64 icount} = 0;
   # Analysis routine to track number of instructions executed
4
5 void InsCount() { icount++; }
6
7
   void MyPredicatedAnalysis(...) {
8
        # if fast-forward number of instructions have been executed and one \hookleftarrow
            billion
9
        # instructions after fast-forward have not been executed, then do the \leftrightarrow
            analysis
        if(icount >= fast-forward-count && icount < fast-forward-count + \leftrightarrow
10
            1,000,000,000)
11
        {
12
            // analysis code
13
        }
14 }
15
16 # Instrumentation routine
   Ins_InsertCall(ins, IPOINT_BEFORE, InsCount, IARG_END);
18 Ins_InsertPredicatedCall(ins, IPOINT_BEFORE, MyPredicatedAnalysis, ..., \leftarrow
       IARG_END);
```

The above implementation of fast-forwarding is not that efficient, as PIN cannot inline the the MyPredicatedAnalysis routine due to the conditional control flow in it.

This is a very common case, where an analysis routine has a single "if-then" test, and a small amount of analysis code plus the test is always executed but the "then" part is executed only once in a while.

To inline this common case, PIN provides a set of conditional instrumentation APIs for the tool writer to rewrite their analysis routines into a form that does not have control-flow changes. Below (Listing 5) I show how to rewrite the same fast-forwarding logic using the conditional instrumentation APIs of PIN.

Listing 5: Fast-Forwarding using Conditional Instrumentation APIs.

```
1 # Analysis routine to track number of instructions executed
2 void InsCount() { icount++; }
3
4 # Analysis routine to check fast-forward condition
5 ADDRINT FastForward(void) {
       return (icount >= fast-forward-count && icount < fast-forward-count + ←
6
           1,000,000,000);
7 }
8
9 # Predicated analysis routine
10 void MyPredicatedAnalysis(...) {
       // analysis code
11
12 }
13
14 # Instrumentation routine
15 Ins_InsertCall(ins, IPOINT_BEFORE, InsCount, IARG_END);
16
17 # FastForward() is called for every instruction executed
18 INS_InsertIfCall(ins, IPOINT_BEFORE, FastForward, IARG_END);
19
20 # MyPredicatedAnalysis() is called only when the last FastForward() \leftarrow
       returns a non-zero value.
21 INS_InsertThenPredicatedCall(ins, IPOINT_BEFORE, MyPredicatedAnalysis, ←
       ..., IARG_END);
```

As SPEC benchmark applications are long running applications we would like to stop the application, once we have measured statistics for 1 billion instructions after the fast-forwarding. Below (Listing 6) I show how to do this with fast forwarding using the conditional instrumentation APIs of PIN.

Listing 6: Stopping the application after Fast-Forwarding.

```
13 ADDRINT FastForward(void) {
        return (icount >= fast-forward-count && icount);
14
15 }
16
17 # Analysis routine to exit the application
   void MyExitRoutine(...) {
18
19
        # Do an exit system call to exit the application.
       # As we are calling the exit system call PIN would not be able to \leftarrow
20
           instrument application end.
21
       # Because of this, even if you are instrumenting the application end, \leftarrow
           the Fini function would not
22
       # be called. Thus you should report the statistics here, before doing \leftarrow
           the exit system call.
       # Results etc
23
       exit(0);
24
25 }
26
27 # Predicated analysis routine
   void MyPredicatedAnalysis(...) {
28
29
       # analysis code
30 }
31
32 # Instrumentation routine
33 INS_InsertIfCall(ins, IPOINT_BEFORE, (AFUNPTR) Terminate, IARG_END);
34
35 # MyExitRoutine() is called only when the last call returns a non-zero \leftarrow
36 INS_InsertThenCall(ins, IPOINT_BEFORE, MyExitRoutine, ..., IARG_END);
37
38 # FastForward() is called for every instruction executed
39 INS_InsertIfCall(ins, IPOINT_BEFORE, FastForward, IARG_END);
40
41 # MyPredicatedAnalysis() is called only when the last FastForward() \leftarrow
       returns a non-zero value.
42 INS_InsertThenPredicatedCall(ins, IPOINT_BEFORE, MyPredicatedAnalysis, \leftarrow
       ..., IARG END);
43
44 # Instrumentation routine
45 Ins_InsertCall(ins, IPOINT_BEFORE, InsCount, IARG_END);
```

Note on basic block-level instrumentation: If you want to do instrumentation at the level of basic blocks, some approximations may be necessary. Since the fast-forward may not end at a basic block boundary, you may overshoot the fast-forward amount a little bit. Similarly, the execution of one billion instructions may not end at a basic block boundary. So, you may overshoot this too. I will accept such an implementation also.

Setting up PIN environment and PIN tool

- Download the latest revision of pinkit (current revision 97503) for the Linux operating system from the PIN home "www.pintool.org".
- Extract the pinkit using the this command: tar -xvzf pin-3.5-97503-gcc-linux.tar.gz

 This would create the pin-3.5-97503-gcc-linux directory, which contains the pinkit.

Pinkit provides a sample setup for building custom tools in the *source/tools/MyPinTool* directory. The main benefit of using this setup is that it already contains *makefiles* for compiling PIN tools. You should use this sample setup for building your PIN tools.

Below I describe how to build a PIN tool called "HW1" using the sample setup:

- 1. Create a HW1 directory in the *source/tools/* directory of the pinkit:
- cd pin-3.5-97503-gcc.4.4.7-linux/source/tools/
- mkdir HW1
- 2. Copy MyPinTool.cpp, makefile and makefile.rules files from the source/tools/MyPinTool directory to HW1 directory:
 - cd HW1/
 - cp ../MyPinTool/MyPinTool.cpp ./
 - cp ../MyPinTool/makefile ./
 - cp ../MyPinTool/makefile.rules ./
 - 3. Rename the MyPinTool.cpp file in HW1 directory to HW1.cpp:
 - mv MyPinTool.cpp HW1.cpp
- 4. Edit line no 20 of makefile.rules file in HW1 directory from "TEST_TOOL_ROOTS := MyPinTool" to "TEST_TOOL_ROOTS := HW1"
 - 5. The file HW1.cpp is the source file of the HW1 PIN tool. Write your PIN tool in this file.
 - 6. Once you have written the PIN tool, you can build it using the make command as follows:
 - On a 32 bit system use the following make command: make obj-ia32/HW1.so
 - On a 64 bit system use to following make command:
 make TARGET=ia32 obj-ia32/HW1.so

This would create the obj-ia32 directory which contains the binary HW1.so for HW1 PIN tool. As we will be instrumenting 32-bit SPEC benchmark binaries we should create a 32-bit version of PIN tool. Thus on a 64-bit system we need to provide the extra TARGET=ia32 argument to make. To find out whether your Linux machine is a 32 bit or a 64 bit system run the following command on terminal:

· uname -m

If the output is "x86_64" then the machine is a 64 bit machine and if the output is "ia32" or "i686" then the machine is a 32 bit system.

To enable debugging support (only if needed), supply DEBUG=1 option to make while building PIN tools, as shown below:

On a 32 bit system use the following make command:

```
make DEBUG=1 obj-ia32/HW1.so
```

• On a 64 bit system use to following make command:

```
make TARGET=ia32 DEBUG=1 obj-ia32/HW1.so
```

- 7. Notice how knobs are used in HW1.cpp to pass command line arguments to the PIN tool. Your PIN tool will have two command line arguments, namely, the fast-forward amount and the output file name where all results should be written to at the end.
- 8. To run the PIN tool with the SPEC binaries, you first need to change directory to the application which you want to analyze and then invoke PIN. For example,

```
    cd /spec_2006/400.perlbench/
    /pin-3.5-97503-gcc-linux/pin -t
    /pin-3.5-97503-gcc-linux/source/tools/HW1/obj-ia32/HW1.so
```

- -f 207 -o perlbench.diffmail.out ./perlbench_base.i386 -l./lib diffmail.pl 4 800 10 17 19 300
- > perlbench.ref.diffmail.out
- 2> perlbench.ref.diffmail.err

Notice that I pass the fast-forward amount in billions of instructions using -f 207.

If you want to test your tool for smaller binaries such as /bin/ls, make sure to compile your PIN tool for the native ISA i.e., if you are running on a 64-bit machine, you should compile the PIN tool for 64 bits. This is because /bin/ls would have been compiled for 64 bits on such a machine.

- /pin-3.5-97503-gcc-linux/pin -t /pin-3.5-97503-gcc-linux/source/tools/HW1/obj-intel64/HW1.so
 -o Is-stats.out - /bin/Is
- 9. Your PIN tool will require at least the following analysis calls: one for keeping count of instructions executed, one for exit condition check, one for exiting the application, one for fast-forwarding condition check, one for instrumenting instructions with only true predicates, and one for instrumenting all instructions:

```
INS_InsertIfCall(ins, IPOINT_BEFORE, Terminate, IARG_END);
INS_InsertThenCall(ins, IPOINT_BEFORE, MyExitRoutine, ..., IARG_END);
INS_InsertIfCall(ins, IPOINT_BEFORE, FastForward, IARG_END);
INS_InsertThenPredicatedCall(ins, IPOINT_BEFORE, MyPredicatedAnalysis, ..., IARG_END);
```

```
INS_InsertIfCall(ins, IPOINT_BEFORE, FastForward, IARG_END);
INS_InsertThenCall(ins, IPOINT_BEFORE, MyAnalysis, ..., IARG_END);
INS_InsertCall(ins, IPOINT_BEFORE, InsCount, IARG_END);
```

WHAT TO SUBMIT

Prepare a PDF document containing the result tables. Share any additional information about your implementation that you would like to share. Put the document in your HW1 directory. Please note that we will not accept anything other than a PDF file. Archive your HW1 directory after removing all .o and .so files:

zip -r HW1_MYGROUPNO.zip HW1/

Please note that **we will not accept anything other than a .zip file**. Replace *MYGROUPNO* by your group number. Upload the *HW1_MYGROUPNO.zip* file to *canvas.cse.iitk.ac.in*.