ixnet

Library scope: global **Named arguments:** supported

Introduction

provides functions for IxNetwork

To use IxNetwork module, a IxNetwork TCL server should be started properly.

RENAT will connect to the App server and control the test ports. Test files and result will be insde the RENAT server.

In order to run RENAT test case with IxLoad, the TCLServer must be activated with Administrator privileges on the Ixia App server.

Notes: Ignore the self parameters when using those keywords.

Shortcuts

Add Port · Add Quicktest · Apply Traffic · Change Frame Rate · Change Frame Rate Dynamic · Change Frame Size · Close · Collect All Data · Collect Data · Csv Logging · Csv Snapshot · Get All Test Result · Get All Views All Csv Logs · Get All Views Csv Log · Get Csv Log · Get Quicktest List · Get Quicktest Result · Get Quicktest Result · Get Test Composer Result · Get Test Result · Get Test Result · Get View All Csv Logs · Get View Csv Log · Load And Start Traffic · Load Config · Load Traffic · Loss From File · Ping · Regenerate · Reset Config · Run Quicktest · Set All Traffic Item · Set Bgp Items · Set Bgp Neighbor · Set Capture Port · Set Traffic Item · Should Be Pingable · Start Capture · Start Protocol · Start Test Composer · Start Traffic · Stop All Protocols · Stop And Save Capture · Stop Quicktest · Stop Test Composer · Stop Traffic · Wait Until Connected

Keywords

Keyword	Arguments	Documentation
Add Port	self, force=True, time_out=2m, learn_time=2m	Add ports using the real-port information from active local config
		 time_out is the wait time until port is connected (default is 2m) learn_time is the time waiting for arp to be learned (default is 2m)
		Sample of local config tester:
		tester: device: ixnet03_8009 config: quicktest.ixncfg real-port:
		port: 4
		ip: 10.100.14.2 mask: 24 gw: 10.100.14.1
Add Quicktest	self, name, test_type=rfc2544throughput, tx_mode=interleaved, clear_all=True	Create a new Quicktest with default value
		Type could be one of following: rfc2544throughput, rfc2544frameLoss, rfc2544back2back. Use Tester. <u>Load Config</u> to load a customized quicktest
		When clear_all is True, any existed quicktests will be cleared.
		Transmit mode tx_mode takes following values: interleaved (default) or sequential. The mode should be identical with the transmit mod of the ports.
		Notes : The keyword does not create necessary ports. It should be used with a existed configuration by Tester. <i>Load Config</i> or Tester. <i>Add Port</i> keyword.
Apply Traffic	self, refresh=True	Applies the current traffic configuration
		refresh: Refreshed the learned information before apply the traffic or not Note: This is a blocking command
Change Frame Rate	self, value, pattern=.*, flow_pattern=.*	Changes the frame rate Parameter:
		 value: value to set. Depends on the current configuration, this could be percent line rate or bit per second etc. pattern: a regular expression to identify `traffic item name, default is everything .* flow_pattern: a regular expression to identify flow group inside the item
Change Frame	self, value, pattern=.*	Changes the traffic flow rate on-fly
Rate Dynamic		No need to stop the running traffic to change the rate
		Parameter:
		value: value to set. Depend on the current configuration, this could be percent line rate or bit per second etc.
		- matteres a regular augmentain to identify traffic item name default is accomplised t

		■ pattern: a regular expression to identify traffic item name, default is	everytning ."	
Change Frame	self, type, value, pattern=.*,	Changes the frame size		
Size	flow_pattern=.*	Parameter:		
		type: could be fixed size, increment_from`, increment_step or increment_step.	ent_to	
		■ value : value to set		
		 pattern: a regular expression to identify traffic item name, default is flow_pattern: a regular expression to identify flow group inside the it 		
Close	self			
Collect All Data	self, prefix=stat_	Disconnects the current tester client		
Collect Data		Depresented Use Cet Test Peault		
	self, view, prefix=stat_	Depricated. Use <u>Get Test Result</u>		
Csv Logging	self, enabled=True, *views	Toggles enable/disable CSV loggin for a view		
		Parameters:		
		views: is a list of views. None means all views.		
		Result files will have format <view name="">.index.csv, when index is auto</view>	matically increased everytime the	
		view is disable and re-enable again in the same test.		
		Samples:		
		Tester. <u>CSV Logging</u> \${TRUE} Flow Statistics		
		Sleep 10s Tester. CSV Logging \$FALSE} Flow Statistics		
Cov Cuanal -1	a alf profix annual + + + + + + + + + + + + + + + + + + +	Note: Long time enable for CSV loggin could returns in very big file		
Csv Snapshot	self, prefix=snapshot_, *views	Get current CSV snapshot		
		Parameters:		
		prefix: prefix that be added to the filename. Default is snapshot_	awia Nana, all aurront available	
		views: list of target views (eg: Port Statistics, Flow Statistics). If vi views will be target	ew is None, all current available	
		Samples:		
		Tester. CSV Snapshot snapshot03 # collect all views		
			ollect specific views	
		Note: the name of result file will be modified so space will be replaced by		
		Depending on the traffic status, the available views could be varied. For not available when there is no traffic.	example, the view <i>Flow Statistics</i> is	
Get All Test	self, prefix=stat_	Collects all Ixia traffic data after traffic is stopped.		
Result		Results are CSV files that are stored in result folder. The prefix prefix is appended to the original view no		
Get All Views	self, prefix=	Gets all CSV logs for all available views	·· ·	
All Csv Logs				
Get All Views Csv Log	self, prefix=	Gets the newest CSV log of all available views		
Get Csv Log	self, prefix=, index=0, *views	Gets all CSV log for a specific views or all from current test folder		
0.01 001 Log	con, prome , mack c, mone	Parameters:		
		 views is a list of views. None is all views. prefix will be appended automatically to the beginning of the result 		
		■ range: number of files from the newest data. 0 for only 1 newest and	-1 for all files.	
		Samples:		
		Tester. Get CSV all_ 0 # get the newest CSV logging data for all		
		<u>Log</u> views		
		Tester. <u>Get CSV</u> single Flow Statistics	# get all CSV logging data for one view	
Get Quicktest	self	Returns current loaded Quicktest list	100	
List		Totalino outront toudou Quiontost list		
Get Quicktest	self, test_index=-1, prefix=,	Get the result.csv file from the latest Quicktests		
Result	enable_all=True	test_index is a index of the current Quicktest1 means that last one.		
Get Quicktest	self, test_index=-1	Returns the path of the newest run of a Quicktest		
Result Path		test_index is a index of the current Quicktest1 means that last one.		
Get Test	self, result_file=composer.log	Get the result of test composer script		
Composer				
Result	colf	Consented and get report of the summer to the test 1 555 (
Get Test Report	self, local_name=ixnet_report.pdf,	Generates and get report of the current active test in PDF format		
	enable_all=True	local_name: name of the report on local machine. Default is ixnet_report.	pdf	
Get Test Result	self, view, prefix=stat_	Collects traffic data of a view and export to a CSV file in result folder		
	_	Currently, supported views are:		
		, supported rions are.		
		Port Statistics, Global Protocol Statistics, BGP Aggregated Statistics, BGP	Aggregated State Counts OSPE	

		Aggregated Statistics, OSPF Aggregated State Counts, OSPFv3 Aggregated Statistics, OSPFv3 Aggregated State Counts, L2-L3 Test Summary Statistics, Flow Statistics, Flow Detective, Data Plane Port Statistics, User Defined Statistics, Traffic Item Statistics
		Result were store as CSV files in result folder. If there is no valid data, view will be silently ignored
		The prefix prefix is appended to the view name for the CSV file.
		Note : the name of the result files are modified so that <i>space</i> will become <i>underbar</i> , <i>hyphen</i> will be deleted.
Get View All Csv Logs	self, view, prefix=	Gets the newest CSV log file of ALL available views
Get View Csv Log	self, view, prefix=	Gets the newest CSV log file of the specific view
Load And Start Traffic	self, wait_time1=10s, wait_time2=10s	Combines <u>Load Traffic</u> and <u>Start Traffic</u> to one keyword.
Load Config	self, config_name=,	loads traffic configuration, applies and start protocol if necessary.
	wait_time=2m, wait_time2=2m, apply=True, protocol=True, force=True, wait_time3=30s	The config file name was defined in the `local.yaml which is a Ixia Network configuration file and located in the config folder of the test.
		The keyword remap the vports to real port when data is specified in the local configuration file. For some reasons, the txMode is cleared when remapping happens. Use tx_mode to set the TxMode of the remapped ports.
		Parameters:
		 apply: applies traffic when True otherwise protocol: starts all protocols when True otherwise
		 force: force to reclaim the ports when True otherwise wait_time: wait time after applying protocols wait_time2: maximum wait time befor all ports become available. In common case, this is calculated automatically so user does not need to change this value. wait_time3: default waiting time after config file is loaded (30s)
		More information about ports could be define in real_port section like this:
		# tester information tester:
		tester: device: ixnet03_8009 config: bgp.ixncfg real-port: - chassis: 10.128.4.41 card: 4 port: 7 media: fiber tx_mode: interleaved
		Configurable port parameters ares:
		 tx_mode: sequential or interleaved(default) media: copper or fiber (Note: no default value)
		See Common for more details about the yaml configuration files.
Load Traffic	self, wait_time=2m, wait_time2=2m, apply=True, protocol=True, force=True, tx_mode=interleaved	
Loss From File	self,	Returns packet loss by miliseconds and delta frame.
	file_name=Flow_Statistics.csv, index=0	Parameters:
		 file_name: flow information (csv format). Default is Flow_Statistics.csv index: row index of the result(counted from zero)
		Samples:
		\$\{\text{LOSS}\} \$\{\text{DELTA}\}= \text{Tester.} \text{Loss From File} \text{Flow_Statistics.csv} \text{Flow_Statistics.csv} \text{Index_1} \text{Flow_Statistics.csv} \text{Index_2} \t
		Note: The calculation should be performed when traffic is stopped. The calculation supposed traffic is
Ping	self det in ere nort index-0	configured by frame per second.
· my	self, dst_ip, src_port_index=0, src_intf_index=0	Ping from Ixia to dst_ip The keyword return the output string as it is. The return could be
	SIC_IIII_IIIUEX=U	- Port <portname>: ping failed: port not assigned</portname>
		Response received from <sourcelp>/unknown . Sequence Number <sequencenumber> Ping request to <destinationlp>/unknown ip failed: <genericpingerror>/<error>: <genericerror>unknown reason Error: Couldn't find any source interface for Send Ping to <destinationlp> on <portname> Id <id>Error: Couldn't find any source IP for Send Ping to <destinationlp> on <portname> Id <id>Error: Couldn't find any source IP for Send Ping to <destinationlp> on <portname> Id <id>Error: Couldn't find any source IP for Send Ping to <destinationlp> on <portname> Id <id>Error: Couldn't find any source IP for Send Ping to <destinationlp> on <portname> Id <id>Error: Couldn't find any source IP for Send Ping to <destinationlp> on <portname> Id <id>Error: Couldn't find any source IP for Send Ping to <destinationlp> on <portname> Id <id>Error: Couldn't find any source IP for Send Ping to <destinationlp> on <portname> Id <id>Error: Couldn't find any source IP for Send Ping to <destinationlp> on <portname> Id <id>Error: Couldn't find any source IP for Send Ping to <destinationlp> on <portname> Id <id>Error: Couldn't find any source IP for Send Ping to <destinationlp> on <portname> Id <id>Error: Couldn't find any source IP for Send Ping to <destinationlp> on <portname> Id <id>Error: Couldn't find any source IP for Send Ping to <destinationlp> on <portname> Id <id>Error: Couldn't find any source IP</id></portname></destinationlp></id></portname></destinationlp></id></portname></destinationlp></id></portname></destinationlp></id></portname></destinationlp></id></portname></destinationlp></id></portname></destinationlp></id></portname></destinationlp></id></portname></destinationlp></id></portname></destinationlp></id></portname></destinationlp></id></portname></destinationlp></id></portname></destinationlp></genericerror></error></genericpingerror></destinationlp></sequencenumber></sourcelp>
		Parameters:
		 src_port_index: index of lxia port (starts from 0) src_intf_index: index of interface insides the port (starts from 0)
		Examples:

		Tester. Ping 1.1.1.1	
Regenerate	self	Regenerates all flow of current traffic items	
Reset Config	self	Clears current config and creates new blank config	
Run Quicktest	self, test_index=0, wait until finish=True	Runs the Quicktest and wait until it finishes	
		Warning: it could take a long time to finish a quicktest	
Set All Traffic Item	self, enabled=True	Enables/Disables all traffic items at once	
Set Bgp Items	self, port_index, neighbor_index, route_range_index, is_enable	Enables/Disables BGP entry by a set of port,neighbor,route_range index Parameters: port_index: index of the port neighbor_index: index of the neighbor or * route_range_index: index of the route range or * is_enable: \${TRUE} or \${FALSE} Note Examples: Tester.Set BGP Items 0 * * \${FALSE} Tester.Set BGP Items 0 * * \${TRUE}	
Set Bgp	self, *indexes, **kwargs	Enables/Disables BGP entry by neighbor index	
Neighbor	, 11115,	kwargs contains following parameters:	
		 indexes: is a list of index of BGP neighbor (index is started from zero) vport_index: is the target vport index enabled: TRUE or FALSE Examples: Tester.Set BGP Item 0 1 vport_index=0 enabled=\${FALSE} Tester.Set BGP Item 0 1 vport_index=1 enabled=\${TRUE} 	
Set Capture	self, data_mode=True,	Capture packets for follow port	
Port	control_mode=True, port_index=0	port_index: is a index of current test port (start from 0) data_mode: capture data packets and save in <intf>_HW.cap file control_mode: capture controls packets and save in <intf>_SW.cap file</intf></intf>	
		Note: control_mode saves all control packets and data_mode only saves data packet Examples: Tester. Set Capture Port 0 Tester. Set Capture Port control_mode=\${TRUE} 0 1	
Set Traffic Item	self, *items, **kwargs	Enables/Disables some traffic items items Parameters: Items: a list of Ixia traffic item name Items: True (enabled) Note: traffic item could be specified by :: <num> format. In this case the num is the order of traffic item count from zero. Returns: True if all items are set coordinately or otherwise Examples: Set Traffic Item Traffic Item 1 Traffic Item 2 Set Traffic Item Traffic Item 1 Items</num>	
Should Be Pingable	self, dst_ip, src_port_index=0, src_intf_index=0	Ping from Ixia and raise an error if ping fails The keyword return <i>True</i> if succeeds	
Start Capture	self, wait_time=30s	Start packet capture Target ports are set by the configuration file or by [Set Capture] keyword	
Start Protocol	self, wait_time=1m	Starts all protocols and wait for wait_time	
Start Test Composer	self, script_name=Main_Procedure, run_num=1, wait_for_test=True, parameter=, wait=10s	Default wait_time is 1 minute. Make sure wait_time is big engouh to start all protocols. Run a test composer script. The test composer script should be included in an Ixia Network configuration file and loaded properly with Load Config Parameters: script_name is the name of the script to run. Default value is Main_Procedure. wait_for_test: if \$TRUE} then wait until the script finishes. parameter: parameter that is passed to the script. Parameter could be in 2 formats: {{VAR1 VALUE1} {VAR2 VALUE2}} or simply as VALUE1 VALUE2.	

		The same of the sa	
		wait: wait time before go to next keyword	
		Examples:	
		Tester. Start Test Composer parameter=XXX YYY	
		Tester. Get Test Composer Result result_file=script1.log	
		Tester. Start Test Composer parameter={{VAR1 AAA} {VAR2 BBB}}	
		Tester. Get Test Composer Result result_file=script1.log	
Start Traffic	self, wait_time=30s	Starts the current traffic settiing and wait for wait_time.	
		Note: This is a asynchronus action. After called, the keyword finishes immediatly but it will take a while before traffic starts	
		By default the keyword will wait for 30 seconds.	
Stop All Protocols	self, wait_time=30s	Stop all running protocols	
Stop And Save Capture	self, prefix=, wait_until_finish=True, monitor_interval=5s	Stop current capture and save the resuls to folder specified by path Captured files will be saved in current result folder with prefix appended in their names.	
		Examples:	
		Tester. Start Capture	
		Sleep 10s	
		Tester. Stop And Save Capture \${RESULT_FOLDER}/capture.zip	
Stop Quicktest	self, test_index=0	Stops a running test	
Stop Test	self, wait=10s	Stop a running composer	
Composer		Do nothing when a test composer has already stopped or no composer has been prepared.	
Stop Traffic	self, stop_protocol=False, wait_time=10s	Stops the current traffic and wait for wait_time Parameters:	
		 stop_protocol: if True also stops all running protocols wait_time: time to wait after apply the command 	
Wait Until Connected	self, timeout_str=5m	Waits until ports become enabled and connected	

Altogether 47 keywords.
Generated by <u>Libdoc</u> on 2019-01-31 10:22:40.

