

Test Plan Reference

PLT

0.4.9

2019-03-28

Copyright ©2016, 2019 Blue Clover Devices

Revision History

Revision H	istory
-------------------	--------

Revision 0.4.9 2019-03-28

• Document `serial request` command

• Update UART port names

Revision 0.4.8 2019-03-08

Renamed to Test Plan Reference

Revision 0.4.7 2019-03-08

Split off from System Manual

Table of Contents

- Preface
- 1. Test Suite Reference
 - 1.1. Test Suites
 - 1.1.1. Test Suite Structure
 - 1.1.1.1. Test Items
 - 1.1.1.2. Test Item Steps
 - 1.1.2. Basic Example
 - 1.2. Test Commands
 - 1.2.1. bledis Test BLE Discovery
 - 1.2.2. erase Erase DUT Flash
 - 1.2.3. extflash_write Write Peripheral Flash
 - 1.2.4. identify Identify DUT
 - 1.2.5. operator Operator Test
 - 1.2.6. program Program DUT
 - 1.2.7. scan Scan Barcode
 - 1.2.8. serial Request serial number
 - 1.2.9. sleepms Delay
 - 1.2.10. uart Send and Extract UART response
 - 1.2.11. uartAwait Await UART response
 - 1.2.12. uartExpect Set expectation for uartAwait
 - 1.2.13. uartReadTimeout Test if UART is not transmissing
 - o 1.3. Targets

Preface

Document describing the test suite definition for use with the Production Line Tool.

1. Test Suite Reference

1.1 Test Suites

Examples:

A minimal test suite, with a single test item, scanning a bar code.

```
title: "LY10-PLT demo: Scan"
suite:
   - ident: SCAN-T1
```

title: Scan MAC address

steps:

- command: scan MAC_ADDRESS

1.1.1 Test Suite Structure

PLT test suites are encoded as YAML text files, starting with the test suite title.

```
title: "LY10-PLT demo: Scan"
```

The title is followed by the suite: section, containing the test items in the test plan.

1.1.1.1 Test Items

Test items are identified with an ident: line, can contain a descriptive title, and should contain one or more test item steps.

During test execution, all test item steps need to complete successfully for the test item to succeed.

1.1.1.2 Test Item Steps

Test item steps consist of command: or uartcmd: blocks. A Test Item can contain multiple Test Item steps.

1.1.2 Basic Example

A basic In-Circuit Test suite for the PLT demo board.

```
title: "v0.1.8 (Green)"
suite:
  - ident: ICT-T1
   title: Identify DUT
   steps:
      - command: identify nRF52
  - ident: ICT-T2
    title: Erase nRF52 with FT2232H Mini Module
   steps:
      - command: erase nRF52
  - ident: ICT-T3
    title: Program LY10-DEMO-BOARD FW nRF52 with FT2232H Mini Module
    steps:
      - command: program nRF52 s132_nrf52_6.0.0_softdevice.hex,ly10-demo-fw-
0.1.8.hex, none
  - ident: ICT-T4
    title: BLE discovery
    steps:
      - command: bledis %BLEMAC% 30 # Wait up to 30 seconds for BLE discovery to
complete
```

1.2 Test Commands

1.2.1 bledis - Test BLE Discovery

Establishes a BLE connection to the DUT and discovers GATT services.

Usage:

bledis %BLEMAC%|<name> [timeout] [minRSSI]

Argument	Description
name	GAP name advertised by DUT. %BLEMAC% to specify the DUT's BLE MAC address instead.
timeout	Timeout, in seconds.
minRSSI	RSSI treshold (optional)

Example: BLE discovery of identified BLE HW MAC address.

- ident: ICT-T1

title: Identify DUT

steps:

- command: identify nRF52

- ident: ICT-T2

title: BLE Discovery

steps:

- command: bledis %BLEMAC% 30 -60

1.2.2 erase - Erase DUT Flash

Erase DUT MCU on-board flash.

Usage:

erase <target>

Argument	Description
target	Target to erase.

Example: Erase STM32L4 on-board flash.

- ident: ICT-T1 title: Erase

steps:

- command: erase STM32L4

1.2.3 extflash_write - Write Peripheral Flash

Write DUT periperal flash.

Usage:

extflash_write <port> <filename>

Argument	Description
port	UART port
filename	Firmware Element Filename

1.2.4 identify - Identify DUT

Identify DUT MCU and/or RF peripherals.

Usage:

identify <target>

Argument	Description
target	Target to identify

1.2.5 operator - Operator Test

Instruct operator to perform a manual test step.

Usage:

operator <message>

Example: Instruct operator inspect housing.

- ident: ICT-T1
- ident: FAT-T1

title: Visual Inspection (manual)

steps:

- command: operator "Inspect Housing"

1.2.6 program - Program DUT

Erase and Program DUT MCU on-board flash.

Usage:

program <target> <bootFw>, <appFw>, <parts>

Argument	Description
target	Target to program.
bootFw	Bootloader Firmware Element
appFw	Application Firmware Element
parts	Partition Table Firmware Element

1.2.7 scan - Scan Barcode

Scan a barcode using USB-attached barcode scanner.

Usage:

scan <format>

Argument	Description
format	Format of code to scan

1.2.8 serial - Request serial number

Request a serial number through PLTcloud. Under Project Settings in PLTcloud, serial number allocation can be configured to use either monotonic counters, or through a WebHook.

Usage:

serial request

When a webhook is selected, the a JSON request will be sent containing:

```
{
    "dut_id": "<DUT IDENTIFIER>",
        "serial_number": "<SERIAL NUMBER>",
        "ble_mac": "<BLE MAC>",
        "mcu_id": "<MCU ID>",
        "MYCUSTOMKEY": "my custom value"
}
And PLTcloud should return something like:
{
    "serial_number": "<SERIAL NUMBER>"
}
```

1.2.9 sleepms - Delay

Temporarily suspend test suite execution.

Usage:

sleepms <duration>

Argument	Description
duration	Duration, in milliseconds

1.2.10 uart - Send and Extract UART response

Extract data from UART.

Usage:

```
uartcmd: uart <port>
  [[expect: <expectText>]
  [extract: <extractText>
    extractKey: <extractKey>]]
[send: <sendText>]
```

Argument	Description
port	UART port
expectText	Text to expect, prior to extraction
extractText	Regular expression to extract
extractKey	Key in which to store extracted text
sendText	Text to send prior to extaction

Example: extract ICCID from cellular modem.

- uartcmd: uart UART0
expect: "+CCID:"

extract: "CCID: (\\d{20})\r\n"

extractKey: ICCID
send: "AT+ICCID\r\n"

1.2.11 uartAwait - Await UART response

Wait for a specific UART response.

Usage:

uartAwait <port> <seconds>

Argument	Description
port	UART port

Argument	Description
seconds	Time to await response, in seconds

Example:

command: uartExpect UARTO Pressedcommand: operator "Press button"

- command: uartAwait UART0 1

1.2.12 uartExpect - Set expectation for uartAwait

Set a UART response to wait for with uartAwait.

Usage:

uartExpect <port> <expect>

Argument	Description
port	UART port
expect	String to expect with subsequent uartAwait command

Example:

command: uartExpect UARTO Pressedcommand: operator "Press button"

- command: uartAwait UART0 1

1.2.13 uartReadTimeout - Test if UART is not transmissing

Test if nothing is received from UART.

Usage:

uartReadTimeout <port> <seconds> [<sendText>]

Argument	Description
port	UART port
seconds	Number of seconds to wait for incoming data
sendText	Text to send before waiting

Example: Test if modem is shut down.

- command: uartReadTimeout UART0 1 "AT"

1.3 Targets

target	Description
DA14580	Dialog DA14580 RFSoC
ESP32	Espressif ESP32 RFSoC (JTAG)
ESP32_HomeKit	Espressif ESP32 RFSoC (JTAG; HomeKit)
ESP32_JTAG	Espressif ESP32 RFSoC (JTAG)
ESP32_UART	Espressif ESP32 RFSoC (esptool)
nRF52	Nordic nRF52 RFSoC (SWD)
nRF52_DevKit	Nordic nRF52 RFSoC (USB, JLink)
STM32F4	ST STM32F4xx MCU (SWD)
STM32F4_DevKit	ST STM32F4xx MCU (USB, JLink)
STM32L4	ST STM32L4xx MCU (SWD)
STM32L4_DevKit	ST STM32L4xx MCU (USB, JLink)