
Exercise 1

Sending and receiving LoRa packets

In this exercise we are going to use two different IoT DevKits

- Pomme-Pi ONE LoRa DevKit and
- CubleCell: LoRa/LoRaWAN Devkit

as shown on the following figure:



Both boards are programmed with **Arduino IDE** or **PlatformIO**.

Attention:

This exercise is the **starting point** for our 4 hours lab including the development of complete IoT architecture with low power terminal nodes and IoT gateway with Lora to WiFi relay. The gateway sends the data to MQTT and TS IoT servers.

1.1 Receiver side on Lolin D32

The following is the code for receiver on Pomme-Pi ONE LoRa board. Note the use of union construct to send/receive LoRa packets in a simple but formatted way.

```
union pack
{
  uint8_t frame[16]; // trames avec octets
  float data[4]; // 4 valeurs en virgule flottante
} rdp; // paquet d'émission
```

The same union should be used at the sender side.

```
void setup() {
  Serial.begin(9600);
  delay(1000);
  SPI.begin(SCK, MISO, MOSI, SS);
  LoRa.setPins(SS,RST,DI0);
  Serial.println(); delay(100); Serial.println();
  if (!LoRa.begin(freq)) {
    Serial.println("Starting LoRa failed!");
    while (1);
Serial.println("Starting LoRa OK!");
delay(1000);
LoRa.setSpreadingFactor(sf);
LoRa.setSignalBandwidth(sb);
LoRa.setCodingRate4(5);
float d1=0.0, d2=0.0;
int rssi;
void loop()
int packetLen;
packetLen=LoRa.parsePacket();
if(packetLen==16)
  {
  int i=0;
  while (LoRa.available()) {
    rdp.frame[i]=LoRa.read();i++;
  d1=rdp.data[0];d2=rdp.data[1];
  rssi=LoRa.packetRssi(); // force du signal en réception en dB
  Serial.printf("Received packet: %2.2f, %2.2f\n", d1, d2);
  Serial.printf("RSSI=%d\n",rssi);
  }
}
```

1.2 Sender side on CubeCell board

```
#include "LoRaWan_APP.h"
#include "Arduino.h"
#ifndef LoraWan_RGB
#define LoraWan_RGB 0
#endif
                                                       868500000 // Hz
#define RF_FREQUENCY
#define TX_OUTPUT_POWER
                                                                  // dBm
                                                       14
#define LORA_BANDWIDTH
                                                       0
                                                                  // [0: 125 kHz,
                                                                  // 1: 250 kHz,
                                                                  // 2: 500 kHz,
                                                                  // 3: Reserved]
// [SF7..SF12]
#define LORA SPREADING FACTOR
#define LORA_CODINGRATE
                                                                  // [1: 4/5,
                                                       1
                                                                  // 2: 4/6,
// 3: 4/7,
                                                                  // 4: 4/8]
// Same for Tx and Rx
#define LORA_PREAMBLE_LENGTH
                                                       Ω
#define LORA_SYMBOL_TIMEOUT
                                                                  // Symbols
#define LORA_FIX_LENGTH_PAYLOAD_ON
                                                       false
#define LORA_IQ_INVERSION_ON
                                                       false
#define RX_TIMEOUT_VALUE
                                                       1000
#define BUFFER_SIZE
                                                       128 // Define the payload size here
char txPacket[BUFFER_SIZE];
static RadioEvents_t RadioEvents;
void OnTxDone( void );
void OnTxTimeout( void );
typedef enum
    LOWPOWER, ReadVoltage, TX // 3 states (1,2,3)
} States_t;
States_t state;
bool sleepMode = false;
int16_t rssi,rxSize;
uint16_t voltage;
union pack
uint8_t frame[16]; // trames avec octets
  float data[4]; // 4 valeurs en virgule flottante
} sdp ; // paquet d'émission
void setup()
{
    Serial.begin(9600);
    voltage = 0;
    rssi=0;
    RadioEvents.TxDone = OnTxDone;
    RadioEvents.TxTimeout = OnTxTimeout;
    Radio.Init( &RadioEvents );
    Radio.SetChannel( RF_FREQUENCY );
    Radio.SetTxConfig( MODEM_LORA, TX_OUTPUT_POWER, 0, LORA_BANDWIDTH,
                                     LORA_SPREADING_FACTOR, LORA_CODINGRATE, LORA_PREAMBLE_LENGTH, LORA_FIX_LENGTH_PAYLOAD_ON,
                                     true, 0, 0, LORA_IQ_INVERSION_ON, 3000 );
    state=ReadVoltage;
}
void loop()
  switch(state)
  {
    case TX:
      memset(txPacket,0x00,BUFFER_SIZE);
      sprintf(txPacket, "%s", "ADC_battery (mV): ");
      int plen= strlen(txPacket);
      sprintf(txPacket+plen, "%d", voltage);
      sdp.data[0] = (float)voltage;
      if(voltage<(uint16_t)3680)turnOnRGB(COLOR_SEND,0);</pre>
      else turnOnRGB(COLOR_RECEIVED, 200);
      Serial.printf("\r\nsending packet \"%s\"\r\n",txPacket);
```

```
// Radio.Send( (uint8_t *)txPacket, strlen(txPacket) );
      Radio.Send(sdp.frame, 16);
      Serial.println(strlen(txPacket)); delay(100);
      state=LOWPOWER;
      break;
    case LOWPOWER:
      lowPowerHandler(); delay(100);
      turnOffRGB();
      delay(2000);
                    //LowPower time
      state = ReadVoltage;
     break;
    }
    case ReadVoltage:
      pinMode(VBAT_ADC_CTL,OUTPUT);
      digitalWrite(VBAT_ADC_CTL, LOW);
      voltage=analogRead(ADC)+550; //*2;
      pinMode(VBAT_ADC_CTL, INPUT);
      state = TX;
     break;
     default:
          break;
  Radio.IrqProcess();
void OnTxDone( void )
  Serial.print("TX done!");
  turnOnRGB(0,0);
void OnTxTimeout( void )
    Radio.Sleep();
    Serial.print("TX Timeout....");
    state=ReadVoltage;
    Serial.print(state);
```

To do:

Analyze both codes:

- · LoRa modem initialization
- LoRa radio parameters
- · Lora packets structure and content

Modify the Lora radio parameters

Add a sensor to send second value (the first is battery voltage)

Then you can start the main lab - Building complete IoT architecture with LoRa and WiFi links

Documents to be used:

IoT.Labs.1.and2.Low.Power.IoT.Architectures.2023

and

IoT.Labs.ESP32.D32.arduino.2023