# OdimH5 User's Guide

Version 2.6 July 1, 2010

This document is a user's guide on how to use OdimH5. It's still under development.

OdimH5 is a console utility designed to work on radar data files. It provides XML descriptor handler, HDF5 converter, Baltrad feeder mode.

# 1 Introduction

#### 1.1 Overview

The OdimH5 is a Java-based tool working on meteorological radar data. It allows users to create an XML descriptor which contains all major information require to create a HDF5 file. The application also allows users to convert specific radar data to HDF5 format based on the descriptor. For Baltrad users it provides automatic online mode which feeds BaltradDex with actual data.

The application was implemented using the Java  $^{\rm TM}$  2 Platform, which is machine-independent.

#### HDF libraries

This release was built and tested with HDF5-1.8.4 Patch 1 with HDF5 1.6 compatibility flag. For information on new features in HDF5 Release 1.8.0 and format compatibility considerations, please visit

http://www.hdfgroup.org/HDF5/doc/ADGuide/CompatFormat180.html.

#### Platforms

This release was built and tested for the following platforms:

- Linux
- Linux x86\_64
- Windows

#### 1.2 Supported radar systems

This version can work with limited radar systems and products listed below.

#### **Platforms**

• Gematronik RAINBOW

### Type of product

- Polar Volume Scan
  - dBZ Reflectivity
  - uPhiDP Differential Phase Shift
  - KDP Specific Differential Phase Shift
  - RhoHV Correlation Coefficient
- Cartesian image and composite
  - PPI Plan Position Indicator
  - CAPPI Constant Altitude PPI
  - MAX Maximum Display
  - EHT Echo Height
  - SRI Surface Rainfall Intensity
  - PAC Precipitation Accumulation
  - VIL Vertical Integrated Liquid
  - HSHEAR Horizontal Shear
- Vertical profile (Not implemented)
- Range-height indicator
  - RHI Range Height Indicator

# 2 Getting Started

#### 2.1 Installation

To get newest version of OdimH5 use Git a distributed revision control system and clone project from baltrad sever. To do this use following command

```
git clone gitosis@git.baltrad.eu:OdimH5.git
```

or download it from Opera FTP server (ftppro.knmi.nl). After downloading use Apache Ant to compile sources.

ant install

Administrator privilegies might be needed

Program will be installed in /opt/OdimH5 folder.

Program uses HDF5 libraries, which are mostly included to the .jar file. For Linux platforms the JNI interfaces files need separate installation. The libjhdf.so and libjhdf5.so files which are provided with main program must be included to the LD\_LIBRARY\_PATH for running.

#### 2.2 Convertion mode

OdimH5 provides two convertion modes. First one creates XML descriptor, that can be used later to create HDF file. Second mode converts raw data directly to HDF5.

#### Prepare descriptor

Descriptor is an XML file, which structure corresponds to HDF5 file. To prepare descriptor use the following parameters:

-i Input file's path.

Program can work with only one file simultaneously.

-o Output file's path.

It is suggested to use .xml filename extension.

-p Radar platform's name.

At the moment only Gematronik's RAINBOW software is supported.

-f Product format.

Use one of the formats listed above according to input data type.

-v Verbose mode.

It is optional and displays status of progress of program work.

Example of use:

```
java -jar OdimH5.jar -i input.ppi -o ppi.xml -p RAINBOW -f IMAGE -v
```

#### Prepare HDF5 file from descriptor

It requires XML descriptor as an input file. To prepare HDF5 use the following parameters:

-i Input file's path.

Program can work with only one file simultaneously.

-o Output file's path.

It is suggested to use .h5 filename extension.

-v Verbose mode.

It is optional and displays status of progress of program work.

Example of use:

```
java -jar OdimH5.jar -i ppi.xml -o output.h5 -v
```

#### Prepare HDF5 file directly from raw file

It has the same parameters as descriptor preparation mode, but output file name has to end with .h5.

Example of use:

```
java -jar OdimH5.jar -i input.ppi -o ppi.h5 -p RAINBOW -f PVOL -v
```

#### 2.3 Baltrad Feeder

OdimH5 allows users to send HDF5 files into BaltradDex system. To send a file use following command:

```
java -jar OdimH5.jar -i input.h5 -r Brzuchania -s IMGW.pl
-a http://172.30.9.34:8084/BaltradDex/transmitter.htm
```

It sends a single HDF5 file to server but it can work as a continuous Baltrad feeder aswell with online convertion to HDF5 format. It works automatically with specific options provided by user. The program reads options from options.xml file stored in the main folder. The following options are required for proper work:

- Radar name. Every radar is represented by radar element in XML.
- Repetition time in minutes. Program wakes up every this repetition time and downloads all files that match criterium. E.g. if repetition time equals 10 minutes, program will download files that were created during last 10-minute period and will start again in 10 minutes.
- Address of HTTP server.
- Sender name.

Optional entry for FTP server handling:

• IP address of FTP server where actual data are stored.

- Login to FTP server.
- Password to FTP server.
- Remote directory on FTP server.

Example options.xml file:

To run feeder use -c option with one of following parameters:

- RVOL for RAINBOW volume files.
- H5 for HDF5 files.

Example of use:

```
java -jar OdimH5.jar -c RVOL -v
```

## 2.4 Help

To display help menu in program use following parameter:

```
java -jar OdimH5.jar -h
```

### 2.5 Troubleshooting

Application is in its developing state and have not been tested thoroughly. To report a bug please send information to lukasz.wojtas@imgw.pl

# 3 Major Improvements and bug fixes

Version 2.6 (Release date: 2010-06-10)

- Added baltrad feeder.
- $\bullet\,$  Added direct HDF5 converter.