theia

API Documentation

August 24, 2017

Contents

C	ontents	1
1	Package theia 1.1 Modules	2
2	Package theia.helpers 2.1 Modules	4
3	Module theia.helpers.core3.1 Functions3.2 Variables	5 5
4	Module theia.helpers.geometry 4.1 Functions	6 6 8
5	Module theia.helpers.interaction 5.1 Variables	9
6	6.1 Functions	10 10 10
7	7.1 Functions 7.2 Variables 7.3 Class TotalReflectionError 7.3.1 Methods 7.3.2 Properties 7.4 Class InputError 7.4.1 Methods	11 11 11 12 12 13 13
8		14 14
9		15

CONTENTS

9	0.2 Vari	ables							 		 		 		•	15
		theia.optics														1 6 16
				• •		• • •			 • •		 	 •	 	•		
		${ m theia.optics.beam}$														١7
		ctions														17
		ables														17
1		s GaussianBeam .														17
	11.3	.1 Methods							 		 		 			18
	11.3	.2 Properties							 		 		 		. :	20
	11.3	.3 Class Variables							 		 		 		. :	20
12 N	Module	theia.optics.bean	ndumn												•	21
		ables														21
		s BeamDump														21
_		.1 Methods														22
		.2 Properties														22 23
		.3 Class Variables														23 23
	12.2	.o Class variables				• •	• • •	• •	 • •	• •	 	 •	 	•	•	20
13 ľ	Module	theia.optics.bean	splitte	\mathbf{r}											2	24
1	3.1 Vari	ables							 		 		 		. :	24
1	3.2 Clas	s BeamSplitter							 		 		 		. :	24
	13.2	.1 Methods							 		 		 		. :	25
	13.2	.2 Properties							 		 		 			26
	13.2	3 Class Variables							 		 		 		. :	26
	Madula	41 · 4 ·	onont												•	27
14 N															4	
		theia.optics.comp														7
1	4.1 Vari	ables														27 27
1	4.1 Vari 4.2 Clas	ables s SetupComponent							 		 		 			27
1	4.1 Vari 4.2 Clas 14.2	ables s SetupComponent .1 Methods	 		 				 	 	 		 			27 28
1	4.1 Vari 4.2 Clas 14.2 14.2	ables s SetupComponent		• • •	 				 		 	 	 			27 28 29
1	4.1 Vari 4.2 Clas 14.2 14.2	ables s SetupComponent .1 Methods		• • •	 				 		 	 	 			27 28
1 1	4.1 Vari 4.2 Clas 14.2 14.2 14.2	ables s SetupComponent		• • •	 				 		 	 	 			27 28 29
1 1 15 I	4.1 Vari 4.2 Clas 14.2 14.2 14.2 Module	ables s SetupComponent		• • •	· · ·				 		 		 			27 28 29 29
1 1 15 N	4.1 Vari 4.2 Clas 14.2 14.2 14.2 Module 5.1 Vari	ables									 	 	 			27 28 29 29
1 1 15 N	4.1 Vari 4.2 Clas 14.2 14.2 14.2 Module 5.1 Vari 5.2 Clas	ables									 	 •	 			27 28 29 29 30
1 1 15 N	4.1 Vari 4.2 Clas 14.2 14.2 14.2 Vodule 5.1 Vari 5.2 Clas 15.2	ables									 		 			27 28 29 29 30 30
1 1 15 N	4.1 Vari 4.2 Clas 14.2 14.2 14.2 14.2 Module 5.1 Vari 5.2 Clas 15.2 15.2	ables									 		 			27 28 29 29 30 30 31
1 1 15 I 1 1	4.1 Vari 4.2 Clas 14.2 14.2 14.2 Module 5.1 Vari 5.2 Clas 15.2 15.2	ables	t								 		 			27 28 29 29 30 30 31 32 32
16 M	4.1 Vari 4.2 Clas 14.2 14.2 14.2 Module 5.1 Vari 5.2 Clas 15.2 15.2 Module	ables	t								 		 			27 28 29 29 30 30 31 32 32
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	4.1 Vari 4.2 Clas 14.2 14.2 14.2 14.2 Module 5.1 Vari 5.2 Clas 15.2 15.2 15.2 Vodule 6.1 Vari	ables	t													27 28 29 29 30 30 31 32 32 33
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	4.1 Vari 4.2 Clas 14.2 14.2 14.2 Module 5.1 Vari 5.2 Clas 15.2 15.2 Vodule 6.1 Vari 6.2 Clas	ables	t													27 28 29 30 30 31 32 32 33
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	4.1 Vari 4.2 Clas 14.2 14.2 14.2 14.2 Module 5.1 Vari 5.2 Clas 15.2 15.2 Vodule 6.1 Vari 6.2 Clas 16.2	ables	t													27 28 29 29 30 30 31 32 32 33 33
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	4.1 Vari 4.2 Clas 14.2 14.2 14.2 14.2 Module 5.1 Vari 5.2 Clas 15.2 15.2 Vodule 6.1 Vari 6.2 Clas 16.2 16.2	ables	t													27 28 29 30 30 31 32 32 33 33 34 35
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	4.1 Vari 4.2 Clas 14.2 14.2 14.2 14.2 Module 5.1 Vari 5.2 Clas 15.2 15.2 Vodule 6.1 Vari 6.2 Clas 16.2 16.2	ables	t													27 28 29 29 30 30 31 32 32 33 33
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	4.1 Vari 4.2 Clas 14.2 14.2 14.2 14.2 Module 5.1 Vari 5.2 Clas 15.2 15.2 15.2 4 Clas 16.2 Clas 16.2 16.2 16.2	ables	b													27 28 29 29 30 30 31 32 32 33 34 35
15 M 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	4.1 Vari 4.2 Clas 14.2 14.2 14.2 14.2 Module 5.1 Vari 5.2 Clas 15.2 15.2 15.2 16.2 Clas 16.2 Clas 16.2 Clas 16.2 Clas 16.2 Clas	ables	b													27 28 29 30 30 31 32 33 33 34 35 35
11 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	4.1 Vari 4.2 Clas 14.2 14.2 14.2 14.2 Module 5.1 Vari 5.2 Clas 15.2 15.2 16.2 16.2 Clas 16.2 16.2 16.2 16.2 Vari 16.2 Clas	ables	or													27 28 29 29 30 31 32 33 33 34 35 35
11 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	4.1 Vari 4.2 Clas 14.2 14.2 14.2 14.2 Module 5.1 Vari 5.2 Clas 15.2 15.2 Module 6.1 Vari 6.2 Clas 16.2 16.2 16.2 Module 7.1 Vari 7.2 Clas	ables	b													27 28 29 30 30 31 32 33 33 34 35 36

CONTENTS

	17.2.3	Class Variables	 	 	 	 	. 41
18 Mo	dule th	neia.optics.special					42
		oles	 	 	 	 	. 42
18.2	2 Class S	Special	 	 	 	 	. 42
		Methods					
		Properties					
		Class Variables					
19 Mo	dule th	neia.optics.thicklens					45
		ThickLens					
10.2		Methods					
		Properties					
		Class Variables					
			 	 	 • •	 	
		$egin{aligned} \mathbf{neia.optics.thinlens} \ \mathbf{neis.} \end{aligned}$. 48
		Γ hin Γ Lens					
20.2							
		Methods					
		Properties					
	20.2.3	Class Variables	 	 	 	 	. 50
		heia.rendering					51
21.1	l Modul	es	 	 	 	 	. 51
22 Mo	dule th	neia.rendering.features					52
		FCObject	 	 	 	 	. 52
		Methods					
		Properties					
		Class Variables					
22.2		FCMirror					
		Methods					
		Properties					
		Class Variables					
22.3		FCSpecial					
		Methods					
		Properties					
		Class Variables					
22.4		FCBeamSplitter					
22.		Methods					
		Properties					
		Class Variables					
22 5		FCLens					
22.0		Methods					
		Properties					
		Class Variables					
22 6		FCBeamDump					
۷۷.(Methods					
		Properties					
		Class Variables					
99 5		FCBeam					
44.1	Ciass	. Оъсан	 	 	 	 	. 51

CONTENTS

	22.7.1 Methods	57
	22.7.2 Properties	
	22.7.3 Class Variables	57
23	Module theia.rendering.shapes	58
	23.1 Functions	58
24	Module theia.rendering.writer	59
	4.1 Functions	59
25	Package theia.running	60
	5.1 Modules	60
26	Module theia.running.parser	61
	26.1 Functions	61
	26.2 Variables	61
	Module theia.running.simulation	63
	7.1 Variables	63
	P7.2 Class Simulation	63
	27.2.1 Methods	64
	27.2.2 Properties	65
	Package theia.tree	66
	8.1 Modules	66
2 9	Module theia.tree.beamtree	67
	9.1 Functions	67
	9.2 Variables	67
	29.3 Class BeamTree	67
	29.3.1 Methods	68
	29.3.2 Properties	68
	29.3.3 Class Variables	68
Inc	$e\mathbf{x}$	70

1 Package theia

This is theia, a Python package for Gaussian ray tracing in 3D optical setups.

Version: 0.1.3

Author: Raphaël Duque

Copyright: Copyright 2017, Raphaël Duque

License: GNU GPLv3+

1.1 Modules

• helpers: This is the helpers sub-package of theia.

(Section 2, p. 4)

core: Defines some additional spice for theia.

(Section 3, p. 5)

- **geometry**: Geometry module for theia.

(Section 4, p. 6)

- **interaction**: Module to define interaction functions for theia.

(Section 5, p. 9)

- **settings**: Module to initiate all global variables for theia.

(Section 6, p. 10)

- **tools**: Defines some generic functions for theia.

(Section 7, p. 11)

- units: Various units for theia.

(Section 8, p. 14)

• main: Main module of theia, defines the main function.

(Section 9, p. 15)

• optics: This is the optics sub-package of theia.

(Section 10, p. 16)

- **beam**: Defines the GaussianBeam class for theia.

(Section 11, p. 17)

- beamdump: Defines the BeamDump class for theia.

(Section 12, p. 21)

beamsplitter: Defines the BeamSplitter class for theia.

(Section 13, p. 24)

- **component**: Defines the SetupComponent class for theia.

(Section 14, p. 27)

- **ghost**: Defines the Ghost class for theia.

(Section 15, p. 30)

- mirror: Defines the Mirror class for theia.

(Section 16, p. 33)

- **optic**: Defines the Optic class for theia.

(Section 17, p. 36)

- **special**: Defines the Special class for theia.

(Section 18, p. 42)

thicklens: Defines the ThickLens class for theia.

(Section 19, p. 45)

- thinlens: Defines the ThinLens class for theia.

Modules Package theia

(Section 20, p. 48)

• rendering: This is the rendering sub-package of theia.

(Section 21, p. 51)

- features: Features module or theia, to represent objects as FreeCAD Python features.
 (Section 22, p. 52)
- shapes: Shapes module for theia, provides shape-calculating for 3D rendering. (Section 23, p. 58)
- writer: Writer module for theia, to write CAD content to files.
 (Section 24, p. 59)
- running: This is the running sub-package of theia.

(Section 25, p. 60)

- **parser**: Module for the parsing on input data from .tia file. (Section 26, p. 61)
- simulation: Defines the Simulation class for theia.
 (Section 27, p. 63)
- $\bullet~{\bf tree} :$ This is the tree sub-package of the ia.

(Section 28, p. 66)

- beamtree: Defines the BeamTree class for theia. (Section 29, p. 67)

2 Package theia.helpers

This is the helpers sub-package of theia.

It provides it provides all sorts of generic functions for theia.

Version: 0.1.3

Author: Raphaël Duque

Copyright: Copyright 2017, Raphaël Duque

License: GNU GPLv3+

2.1 Modules

• **core**: Defines some additional spice for theia. (Section 3, p. 5)

• **geometry**: Geometry module for theia.

(Section 4, p. 6)

• interaction: Module to define interaction functions for theia. $(Section\ 5,\ p.\ 9)$

• settings: Module to initiate all global variables for theia. (Section 6, p. 10)

• **tools**: Defines some generic functions for theia. (Section 7, p. 11)

• units: Various units for theia. (Section 8, p. 14)

${\bf 3}\quad {\bf Module\ theia. helpers. core}$

Defines some additional spice for theia.

3.1 Functions

$\mathbf{gbeamInit}(menu)$
Pick in the menu.
$\mathbf{hang}()$
The whole hangman game, from welcome to exit.
$\mathbf{magazzu}()$
$\mathbf{pong}()$
$\mathbf{pendu}()$

3.2 Variables

Name	Description
package	Value: 'theia.helpers'

4 Module theia.helpers.geometry

Geometry module for theia.

4.1 Functions

refrAngle(theta, n1, n2)

Returns the refraction angle at n1/n2 interface for incoming theta.

May raise a TotalReflectionError.

linePlaneInter(pos, dirV, planeC, normV, diameter)

Computes the intersection between a line and a plane.

pos: position of the begining of the line. [3D vector]

dirV: directing vector of the line. [3D vector]

planeC: position of the center of the plane. [3D vector]

normV: vector normal to the plane. [3D vector]

diameter: diameter of the plane.

Returns a dictionary with keys:

'isHit': whether of not the plane is hit. [boolean]

'distance': geometrical distance from line origin to intersection point.

[float]

'intersection point': position of intersection point. [3D vector]

lineSurfInter(pos, dirV, chordC, chordNorm, kurv, diameter) Computes the intersection between a line and a spherical surface. The spherical surface is supposed to have a cylindrical symmetry around the vector normal to the 'chord', ie the plane which undertends the surface. Note: the normal vector always looks to the center of the sphere and the surface is supposed to occupy less than a semi-sphere pos: position of the begingin of the line. [3D vector] dirV: direction of the line. [3D vector] chordC: position of the center of the 'chord'. [3D vector] chordNorm: normal vector the the chord in its center. [3D vector] kurv: curvature (1/ROC) of the surface. [float] diameter: diameter of the surface. [float] Returns a dictionary with keys: 'is Hit': whether the surface is hit or not. [boolean] 'distance': distance to the intersection point from pos. [float] 'intersection point': position of intersection point. [3D vector]

```
lineCylInter(pos, dirV, faceC, normV, thickness, diameter)
Computes the intersection of a line and a cylinder in 3D space.
The cylinder is specified by a disk of center faceC, an outgoing normal
normV, a thickness (thus behind the normal) and a diameter.
pos: origin of the line. [3D vector]
dirV: directing vector of the line. [3D vector]
faceC: center of the face of the cylinder where lies the normal vector.
    [3D vector]
normV: normal vector to this face (outgoing). [3D vector]
thickness: thickness of the cylinder (counted from faceC and behind normV)
diameter: of the cylinder. [float]
Returns a dictionary with keys:
    'isHit': whether of not. [boolean]
    'distance': geometrical distance of the intersection point from pos.
        [float]
    'intersection point': point of intersection. [3D vector]
```

newDir(inc, nor, n1, n2)

Computes the refl and refr directions produced by inc at interface n1/n2.

inc: director vector of incoming beam. [3D vector]

nor: normal to the interface at the intersection point. [3D vector]

n1: refractive index of the first medium. [float]

n2: idem.

Returns a dictionary with keys:

 $\ensuremath{^{\prime}}\ens$

't': normalized direction of refracted beam. [3D vector]

'TR': was there total reflection?. [boolean]

Note: if total reflection then refr is None.

rotMatrix(a, b)

Provides the rotation matrix which maps a (unit) to b (unit).

a,b: unit 3D vectors. [3D np.arrays]

Returns an np.array such that np.dot(M,a) == b.

$\mathbf{basis}(a)$

Returns two vectors u and v such that (a, u, v) is a direct ON basis.

rectToSph(array)

Returns the spherical coordinates of the unitary vector given by array.

array: 3D vector (unitary). [float]

Returns the theta and phi angles in radians with theta in [0, pi] and phi in [-pi, pi]

4.2 Variables

Name	Description
package	Value: 'theia.helpers'

${\bf 5}\quad {\bf Module\ theia. helpers. interaction}$

Module to define interaction functions for theia.

5.1 Variables

Name	Description
usage	Value: 'Usage: theia [options]
	FNAME\n\nArguments:\n FNAME\t\t
lhelp	Value: 'specify the FreeCAD library location.
	If none is specifi
shelp	Value: 'Exclude beams propagating inside optics
	from text output
welcome	Value:
errorRecursion	Value: '\n\nIt looks like you reached the
	maximum recursion dept
errorAtSpecifiedLocation	Value: 'theia: Error: The FreeCAD library was
	not found at the s
errorWhereIs	Value: 'theia: Error: Unix command \'whereis
	freecad\' did not y
errorWhereIsNotFound	Value: 'theia: Error: It seems that the Unix
	utility 'whereis '
errorUnknown	Value: 'theia: Error: %s was used as the
	source directory for th
package	Value: None

${\bf 6}\quad {\bf Module\ theia. helpers. settings}$

Module to initiate all global variables for the ia. $\,$

6.1 Functions

$\mathbf{init}(dic)$	
Initiate globals with dictionary.	
dic: dictionary holding values for globals. [dictionary]	

6.2 Variables

Name	Description
package	Value: None

7 Module theia.helpers.tools

Defines some generic functions for theia.

7.1 Functions

. •	/ P	1
$_{ m timer}$	(tun	c
OTITICE	(] wie	v,

Decorator function to log execution time of other functions.

formatter(stringList)

Returns a formatted version of the text formed by the list of lines.

$\mathbf{shortRef}(inStr)$

Returns the short reference corresponding to string.

Change all 't2nrt' in 'R', all 't(2n+1)rt' in 'T' and 'r' in 'R' in string. Used to write short references to beams.

7.2 Variables

Name	Description
package	Value: 'theia.helpers'

7.3 Class TotalReflectionError

```
object —
exceptions.BaseException —
exceptions.Exception —
theia.helpers.tools.TotalReflectionError
```

TotalReflectionError class.

Is raised when an interaction results in total reflection.

=== Attributes ==== Message: exception message. [string]

7.3.1 Methods

init(self, message)	ĺ
TotalReflectionError exception initializer.	
Overrides: objectinit	
	1
$\underline{\phantom{aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa$	ĺ
Printing error function.	ĺ
Overrides: objectstr	ĺ
Inherited from exceptions. Exception	
new()	
$Inherited\ from\ exceptions. Base Exception$	
delattr(),getattribute(),getitem(),getslice(),rduce(),repr(),setattr(),setstate(),unicode()	e-
Inherited from object	
$__format__(), __hash__(), __reduce_ex__(), __sizeof__(), __subclasshopsing and a subclasshopsing a subclass $	ook

7.3.2 Properties

Name	Description
Inherited from exceptions.Bo	$\overline{iseException}$
args, message	
Inherited from object	
class	

7.4 Class InputError

object —	
exceptions. BaseException $\overline{}$	
exceptions.Exception	
	theia.helpers.tools.InputError

 ${\bf Input Error\ class.}$

Is raised when the input .tia file parsing to input data failed.

=== Attributes ==== Message: exception message. [string]

7.4.1 Methods

init(self, message)
nputError exception initializer.
Overrides: objectinit
$__str__(self)$
Printing error function
Overrides: objectstr

$Inherited\ from\ exceptions. Exception$

___new___()

$Inherited\ from\ exceptions. Base Exception$

delatt	$\operatorname{rr}(),$	getat	tribute($(), \underline{\hspace{1cm}}$	$getitem_{__}$	$(), \; __$	$_{ m getslice}$.(),	_re-
duce()),rep	or(), _	$__$ setattr $_$	(), _	$_$ setstate $_$	(), _	unicode_	()	

$Inherited\ from\ object$

$__format___$	(),ha	sh(), _	reduce_ex	x(), _	sizeof_	(), _	$__$ subclasshook $_$	(
--------------------	-------	---------	-----------	--------	---------	-------	--------------------------	---

7.4.2 Properties

Name	Description
Inherited from exceptions. Bo	iseException
args, message	
Inherited from object	
class	

${\bf 8}\quad {\bf Module\ theia. helpers. units}$

Various units for theia.

8.1 Variables

Name	Description
km	Value: 1000.0
m	Value: 1.0
cm	Value: 0.01
mm	Value: 0.001
um	Value: 1e-06
nm	Value: 1e-09
kW	Value: 1000.0
W	Value: 1.0
mW	Value: 0.001
uW	Value: 1e-06
nW	Value: 1e-09
THz	Value: 1e+12
GHz	Value: 1000000000.0
MHz	Value: 1000000.0
kHz	Value: 1000.0
Hz	Value: 1.0
mHz	Value: 0.001
uHz	Value: 1e-06
ppm	Value: 1e-06
rad	Value: 1.0
deg	Value: 0.0174532925199
pi	Value: 3.14159265359
package	Value: None

Variables Module theia.main

9 Module theia.main

Main module of theia, defines the main function.

9.1 Functions

$\mathbf{main}(options, args)$	
Main function of theia.	

9.2 Variables

Name	Description
package	Value: 'theia'

10 Package theia optics

This is the optics sub-package of theia.

It provides the necessary classes and functions in order to calculate the gaussian beams of the setup.

Version: 0.1.3

Author: Raphaël Duque

Copyright: Copyright 2017, Raphaël Duque

License: GNU GPLv3+

10.1 Modules

• beam: Defines the GaussianBeam class for theia. (Section 11, p. 17)

• beamdump: Defines the BeamDump class for theia. (Section 12, p. 21)

• beamsplitter: Defines the BeamSplitter class for theia. (Section 13, p. 24)

• component: Defines the SetupComponent class for theia. (Section 14, p. 27)

• **ghost**: Defines the Ghost class for theia. (Section 15, p. 30)

• mirror: Defines the Mirror class for theia. (Section 16, p. 33)

• optic: Defines the Optic class for theia. (Section 17, p. 36)

• **special**: Defines the Special class for theia. (Section 18, p. 42)

• thicklens: Defines the ThickLens class for theia. (Section 19, p. 45)

• thinlens: Defines the ThinLens class for theia. (Section 20, p. 48)

11 Module theia.optics.beam

Defines the GaussianBeam class for theia.

11.1 Functions

 $\begin{array}{l} \textbf{userGaussianBeam}(\textit{Wx} = \texttt{0.001}, \textit{Wy} = \texttt{0.001}, \textit{WDistx} = \texttt{0.0}, \textit{WDisty} = \texttt{0.0}, \\ \textit{Wl} = \texttt{1.064e-06}, \textit{P} = \texttt{1.0}, \textit{X} = \texttt{0.0}, \textit{Y} = \texttt{0.0}, \textit{Z} = \texttt{0.0}, \textit{Theta} = \texttt{1.57079632679}, \\ \textit{Phi} = \texttt{0.0}, \textit{Alpha} = \texttt{0.0}, \textit{Ref} = \texttt{None}) \end{array}$

Constructor used for user inputed beams, separated from the class initializer because the internal state of a beam is very different from the input of this user-defined beam.

Input parameters are processed to make arguments for the class contructor and then the corresponding beam is returned.

11.2 Variables

Name	Description
package	Value: 'theia.optics'

11.3 Class GaussianBeam

object — theia.optics.beam.GaussianBeam

GaussianBeam class.

This class represents general astigmatic Gaussian beams in 3D space. These are the objects that are intended to interact with the optical components during the ray tracing and that are rendered in 3D thanks to FreeCAD.

```
*=== Attributes ===*
```

BeamCount: class attribute, counts beams. [integer]

Name: class attribute. [string]

QTens: general astigmatic complex curvature tensor at the origin.

[np. array of complex]

N: Refraction index of the medium in which the beam is placed. [float] W1: Wave-length in vacuum of the beam (frequency never changes). [float] P: Power of the beam. [float] Pos: Position in 3D space of the origin of the beam. [3D vector] Dir: Normalized direction in 3D space of the beam axis. [3D vector] U: A tuple of unitary vectors which along with Dir form a direct orthonormal basis in which the Q tensor is expressed. [tuple of 3D vectors] Ref: Reference to the beam. [string] OptDist: Optical length. [float] Length: Geometrical length of the beam. [float] StrayOrder: Number representing the *strayness* of the beam. If the beams results from a transmission on a HR surface or a reflection on a AR surface, then its StrayOrder is the StrayOrder of the parent beam + 1. [integer] Optic: Ref of optic where the beam departs from ('Laser' if laser). [string] Face: Face of the optic where the beam departs from. [string] TargetOptic: Ref of the optic where the beam terminates (None if open beam). [string] TargetFace: Face of the target optic where the beam terminates. [string] DWx: Distance of waist on X. [float] DWy: Distance of waist on Y. [float] Wx: Waist on X. [float] Wy: Waist on Y. [float] IWx: Width of beam on X at origin. [float] IWy: Width of beam on Y at origin. [float]

11.3.1 Methods

<u>___init___</u>(self, Q, N, Wl, P, Pos, Dir, Ux, Uy, Ref, OptDist, Length, StrayOrder, Optic, Face)

TWx: Width of beam on X at target surface (None if open beam). [float]

TWy: Width of beam on Y at target surface (None if open beam).

Beam initializer.

This is the initializer used internally for beam creation, for user inputed beams, see function userGaussianBeam.

Returns a Gaussian beam with attributes as the parameters.

Overrides: object.___init__

 $__\mathbf{str}__(self)$

String representation of the beam, when calling print(beam).

Overrides: object.___str___

lines(self)

Returns the list of lines necessary to print the object.

$\mathbf{Q}(self, d=0.0)$

Return the Q tensor at a distance d of origin.

$\mathbf{QParam}(self, d=0.0)$

Compute the complex parameters q1 and q2 and theta of beam.

What is implemented here is a straightforward calculation to extract the q1, q2, and theta of the normal form of Q.

Returns a tuple q1, q2, theta

ROC(self, dist=0.0)

Return the tuple of ROC of the beam.

$\mathbf{waistPos}(self)$

Return the tuple of positions of the waists of the beam along Dir.

rayleigh(self)

Return the tuple of Rayleigh ranges of the beam.

$\mathbf{width}(self, d=0.0)$

Return the tuple of beam widths at distance d.

waistSize(self)

Return a tuple with the waist sizes in x and y.

gouy(self, d=0.0)

Return the tuple of Gouy phases.

${\bf initGaussianData}(\mathit{self})$

Writes the relevant DW, W, IW data with Q.

Is called upon construction to write the data of waist position and size, initial widths once and for all.

$$translate(self, X=0.0, Y=0.0, Z=0.0)$$

Move the beam to (current position +(X, Y, Z)).

X, Y, Z: components of the translation vector.

No return value.

$Inherited\ from\ object$

$\underline{}$ delattr $\underline{}$ (), $\underline{}$	$_{ m format}_{}$	(),	_getattrib	$ute_{\underline{}}()$	$),$ hash_	(), _	new	():
reduce(),	_reduce_	_ex(),	,repr_	(),	$_{ m setattr}_{}$	_(),	_sizeof	_(),
$__subclasshook__$	_()							

11.3.2 Properties

Name	Description
Inherited from object	
class	

11.3.3 Class Variables

Name	Description
BeamCount	Value: 0
Name	Value: 'Beam'

12 Module theia.optics.beamdump

Defines the BeamDump class for theia.

12.1 Variables

Name	Description
package	Value: 'theia.optics'

12.2 Class BeamDump

```
object — theia.optics.component.SetupComponent — theia.optics.beamdump.BeamDump
```

BeamDump class.

This class represents components on which rays stop. They have cylindrical symmetry and stop beams on all their faces. They can represent baffles for example.

```
*=== Attributes ===*
SetupCount (inherited): class attribute, counts all setup components.
    [integer]
Name: class attribute. [string]
HRCenter (inherited): center of the principal face of the BeamDump in space.
    [3D vector]
ARCenter (inherited): center of the secondary face of the BeamDump in space.
    [3D vector]
HRnorm (inherited): normal unitary vector the this principal face,
    supposed to point outside the media. [3D vector]
Thick (inherited): thickness of the dump, counted in opposite direction to
    HRNorm. [float]
Dia (inherited): diameter of the component. [float]
Ref (inherited): reference string (for keeping track with the lab). [string]
```

12.2.1 Methods

 $\underline{\underline{\text{nit}}}\underline{\underline{\text{(self, X=0.0, Y=0.0, Z=0.0, Theta=1.57079632679, Phi=0.0, Ref=None, Thickness=0.02, Diameter=0.05)}}$

BeamDump initializer.

Parameters are the attributes.

Returns a BeamDump.

Overrides: object.___init___

lines(self)

Return the list of lines needed to print the object.

Overrides: theia.optics.component.SetupComponent.lines

isHit(self, beam)

Determine if a beam hits the BeamDump.

This uses the line***Inter functions from the geometry module to find characteristics of impact of beams on beamdumps.

beam: incoming beam. [GaussianBeam]

Returns a dictionary with keys:

'isHit': whether the beam hits the dump. [boolean]

'intersection point': point in space where it is first hit. [3D vector]

'face': to indicate which face is first hit, can be 'HR', 'AR' or 'side'. [string]

'distance': geometrical distance from beam origin to impact. [float]

Overrides: theia.optics.component.SetupComponent.isHit

hit(self, beam, order, threshold)	
Compute the refracted and reflected beams after interaction.	
BeamDumps always stop beams.	
beam: incident beam. [GaussianBeam] order: maximum strayness of daughter beams, which are not returned their strayness is over this order. [integer] threshold: idem for the power of the daughter beams. [float]	if
Returns a dictionary of beams with keys: 't': None 'r': None	
Overrides: theia.optics.component.SetupComponent.hit	

$Inherited\ from\ theia. optics. component. Setup Component (Section\ 14.2)$

___str___(), translate()

Inherited from object

$\underline{}$ delattr $\underline{}$ (), $\underline{}$	$_$ format $_$ (),	getattribute	(),hash	(),new_	(),
reduce(), _	reduce_ex	_(),repr()),setattr	_(),sizeof	_(),
subclasshook	()				

12.2.2 Properties

Name	Description
Inherited from object	
class	

12.2.3 Class Variables

Name	Description	
Name	Value: 'BeamDump'	
abstractmethods	Value: frozenset([])	
Inherited from theia.optics.component.SetupComponent (Section 14.2)		
SetupCount		

13 Module theia.optics.beamsplitter

Defines the BeamSplitter class for theia.

13.1 Variables

Name	Description
package	Value: 'theia.optics'

13.2 Class BeamSplitter

object — theia.optics.component.SetupComponent — theia.optics.optic.Optic — theia.optics.beamsplitter.BeamSplitter

Beamsplitter class.

This class represents beam splitters composed of two faces (HR, AR) and with a wedge angle. These are the objects with which the beams will interact during the ray tracing. Please see the documentation for details on the geometric construction of these optics.

Beam Splitters behave exactly like mirrors, except that:

- * The default values for transmittances and reflectivities are different
- * Beam splitters never increase the order upon interaction of beams.

Actions:

- * T on HR: 0
- * R on HR: 0
- * T on AR: 0
- * R on AR: 0

=== Additional attributes with respect to the Optic class ===

None

=== Name ===

BeamSplitter

Note: the curvature of any surface is positive for a concave surface (coating inside the sphere).

Thus kurv*HRNorm/|kurv| always points to the center

of the sphere of the surface, as is the convention for the lineSurfInter of geometry module. Same for AR.

*****	HRK > 0 and $ARK > 0$	*****	HRK > 0 and $ARK < 0$
****		*****	and $ ARK > HRK $
H***A		H******A	
****		*****	
*****		*****	

13.2.1 Methods

BeamSplitter initializer.

Parameters are the attributes.

Returns a beam splitter.

Overrides: object.___init

lines(self)

Returns the list of lines necessary to print the object.

Overrides: theia.optics.component.SetupComponent.lines

Inherited from theia.optics.optic.Optic(Section 17.2)

apexes(), collision(), geoCheck(), hit(), hitAR(), hitHR(), hitSide(), isHit(), isHit-Dics(), translate()

Inherited from theia.optics.component.SetupComponent(Section 14.2)

___str___()

Inherited from object

delattr(),	$_{format}$	(),	_getattrib	ute(),hash_	(), _	new_	()
reduce(),	_reduce_	_ex()),repr_	(),	_setattr	_(),	_sizeof	_(),
subclasshook_	_()							

13.2.2 Properties

Name	Description
Inherited from object	
class	

13.2.3 Class Variables

Name	Description	
Name	Value: 'BeamSplitter'	
abstractmethods	Value: frozenset([])	
Inherited from theia.optics.optic.Optic (Section 17.2)		
OptCount		
Inherited from theia.optics.component.SetupComponent (Section 14.2)		
SetupCount		

14 Module theia.optics.component

Defines the SetupComponent class for theia.

14.1 Variables

Name	Description
package	Value: 'theia.optics'

14.2 Class SetupComponent

```
object — theia.optics.component.SetupComponent
```

SetupComponent class.

This is an Abstract Base Class for all the components (optical or not) of the setup. Its methods may be implemented in daughter classes.

```
*=== Attributes ===*
```

SetupCount: class attribute, counts setup components. [integer]

HRCenter: center of the principal face of the component in space.

[3D vector]

ARCenter: center of the secondary face of the component in space.

[3D vector]

HRNorm: normal unitary vector the this principal face, supposed to point outside the media. [3D vector]

Thick: thickness of the component, counted in opposite direction to HRNorm. [float]

Dia: diameter of the component. [float] Name: name of the component. [string]

InBeams: list of all beams incident on the component. [list of GaussianBeam]

OutBeams: list of all beams out

Ref: reference string (for keeping track with the lab). [string]

14.2.1 Methods

(self, HRCenter, HRNorm, Ref, Thickness, Diameter, ARCenter) SetupComponent initializer. Parameters are the attributes of the object to construct. Returns a setupComponent. Overrides: object. init str (self)String representation of the component, when calling print(object). Overrides: object.___str__ **hit**(self, beam, order, threshold) Compute the refracted and reflected beams after interaction. Abstract (pure virtual) method. **isHit**(self, beam) Method to determine if component is hit by a beam. Abstract (pure virtual) method. lines(self)Method to return the list of strings to ___str___. Abstract (pure virtual) method. translate(self, X=0.0, Y=0.0, Z=0.0)Move the component to (current position +(X, Y, Z)). This version only takes care of the HRCenter, version of sub classes take care of ARCenter if relevant. X, Y, Z: components of the translation vector. No return value. Inherited from object

___delattr__(), ___format__(), ___getattribute__(), ___hash__(), ___new__(),

reduce(),	reduceex	(), _	repr_	(), _	_setattr_	(), _	sizeof	(),
subclasshook_	()							

14.2.2 Properties

Name	Description
Inherited from object	
class	

14.2.3 Class Variables

Name	Description
Name	Value: 'SetupComponent'
SetupCount	Value: 0
abstractmethods	Value: frozenset(['hit', 'isHit',
	'lines'])

15 Module theia.optics.ghost

Defines the Ghost class for theia.

15.1 Variables

Name	Description
package	Value: 'theia.optics'

15.2 Class Ghost

```
object — theia.optics.component.SetupComponent — theia.optics.ghost.Ghost
```

Ghost class.

This class represents surfaces which don't interact with the beams. They just transmit the same beam, and may be useful to monitor the beams on their way, without having to calculate the Q yourself if you're looking for the Q at another place than the origin of the beam.

Ghost surfaces basically have a null thickness and transmit the beams.

```
*=== Attributes ===*
SetupCount (inherited): class attribute, counts all setup components.
    [integer]
Name: class attribute. [string]
HRCenter (inherited): center of the principal face of the Ghost in space.
    [3D vector]
ARCenter (inherited): center of the secondary face of the Ghost in space.
    [3D vector]
HRnorm (inherited): normal unitary vector the this principal face,
    supposed to point outside the media. [3D vector]
Thick (inherited): thickness of the dump, counted in opposite direction to
    HRNorm. [float]
Dia (inherited): diameter of the component. [float]
Ref (inherited): reference string (for keeping track with the lab). [string]
```

15.2.1 Methods

 $\underline{\underline{\text{nit}}}\underline{\underline{\text{(self, X=0.0, Y=0.0, Z=0.0, Theta=1.57079632679, Phi=0.0, Ref=None, Diameter=0.5)}}$

Ghost initializer.

Parameters are the attributes.

Returns a Ghost.

Overrides: object.___init__

lines(self)

Return the list of lines needed to print the object.

Overrides: theia.optics.component.SetupComponent.lines

isHit(self, beam)

Determine if a beam hits the Ghost surface.

This uses the linePlaneInter function from the geometry module to find characteristics of impact of beams on ghost surfaces.

beam: incoming beam. [GaussianBeam]

Returns a dictionary with keys:

'isHit': whether the beam hits the dump. [boolean]

'intersection point': point in space where it is first hit.
[3D vector]

'face': to indicate which face is first hit, can be 'HR', 'AR' or 'side'. [string]

'distance': geometrical distance from beam origin to impact. [float]

Overrides: theia.optics.component.SetupComponent.isHit

hit(self, beam, order, threshold)	
Return the beam simply transmitted by the ghost surface.	
beam: incident beam. [GaussianBeam] order: maximum strayness of daughter beams, which are not returned their strayness is over this order. [integer] threshold: idem for the power of the daughter beams. [float]	if
Returns a dictionary of beams with keys: 't': Gaussian beam which is the continuity of the incident bear Overrides: theia.optics.component.SetupComponent.hit	1.
Returns a dictionary of beams with keys:	1.

$Inherited\ from\ theia.optics.component. Setup Component (Section\ 14.2)$

__str__(), translate()

$Inherited\ from\ object$

delattr(),	$_{ m format}$	(),	_getattrib	$ute_{\underline{}}()$),hash	$__(),$ $_$	new_	(),
reduce(),	$_{ m reduce}$	_ex()	,repr_	(),	$_{ m setattr}\{ m }$	_(),	_sizeof	_(),
subclasshook_	_()							

15.2.2 Properties

Name	Description
Inherited from object	
class	

15.2.3 Class Variables

Name	Description		
Name	Value: 'Ghost'		
abstractmethods	Value: frozenset([])		
Inherited from theia.optics.component.SetupComponent (Section 14.2)			
SetupCount			

16 Module theia.optics.mirror

Defines the Mirror class for theia.

16.1 Variables

Name	Description
package	Value: 'theia.optics'

16.2 Class Mirror

```
object —
theia.optics.component.SetupComponent —
theia.optics.optic.Optic —
theia.optics.mirror.Mirror
```

Mirror class.

This class represents semi reflective mirrors composed of two faces (HR, AR) and with a wedge angle. These are the objects with which the beams will interact during the ray tracing. Please see the documentation for details on the geometric construction of these mirrors.

Actions:

- * T on HR: + 1
- * R on HR: 0
- * T on AR: 0
- * R on AR: + 1

=== Additional attributes with respect to the Optic class ===

None

=== Name ===

Mirror


Note: the curvature of any surface is positive for a concave surface (coating inside the sphere).

Thus kurv*HRNorm/|kurv| always points to the center

of the sphere of the surface, as is the convention for the lineSurfInter of geometry module. Same for AR.



16.2.1 Methods



Inherited from theia.optics.optic.Optic(Section 17.2)

apexes(), collision(), geoCheck(), hit(), hitAR(), hitHR(), hitSide(), isHit(), isHit-Dics(), translate()

 $Inherited\ from\ theia.optics.component. Setup Component (Section\ 14.2)$

```
___str___()
```

Inherited from object

```
___delattr__(), ___format__(), __getattribute__(), __hash__(), __new__(), __reduce__(), __reduce_ex__(), __repr__(), __setattr__(), __sizeof__(), __subclasshook__()
```

16.2.2 Properties

Name	Description
Inherited from object	
class	

16.2.3 Class Variables

Name	Description	
Name	Value: 'Mirror'	
abstractmethods	Value: frozenset([])	
Inherited from theia.optics.optic.Optic (Section 17.2)		
OptCount		
Inherited from theia.optics.component.SetupComponent (Section 14.2)		
SetupCount		

17 Module theia.optics.optic

Defines the Optic class for theia.

17.1 Variables

Name	Description
package	Value: 'theia.optics'

17.2 Class Optic

object — theia.optics.component.SetupComponent — theia.optics.optic.Optic

Known Subclasses: theia.optics.mirror.Mirror, theia.optics.thicklens.ThickLens, theia.optics.thinlens.Th theia.optics.beamsplitter.BeamSplitter, theia.optics.special.Special

Optic class.

This class is a base class for optics which may interact with Gaussian beams and return transmitted and reflected beams (mirrors, lenses, etc.)

The way an optic interacts with a beam (if it adds to the order of a beam upon reflection or transmission on HR or AR etc) is specified by the action integers RonHR, TonHR, RonAR, TonAR of the optic. A beam which reflects on HR will have its order increased by RonHR, etc.

All the optics which transmit or reflect beams (beam splitters, mirrors, thin and thick lenses and special optics) inherit from this class. A particular type of optic is characterized by its action integers and by the inputs provided to the constuctors by the users. Everything else of the optics follow the shape of this Optic class.

```
*=== Attributes ===*
SetupCount (inherited): class attribute, counts all setup components.
  [integer]
```

OptCount: class attribute, counts optical components. [integer]

Name: class attribute. [string]

HRCenter (inherited): center of the 'chord' of the HR surface. [3D vector]

ARCenter (inherited): center of the 'chord' of the AR surface. [3D vector]

HRNorm (inherited): unitary normal to the 'chord' of the HR (always pointing towards the outside of the component). [3D vector]

Thick (inherited): thickness of the optic, counted in opposite direction to HRNorm. [float]

Dia (inherited): diameter of the component. [float]

Ref (inherited): reference string (for keeping track with the lab). [string]

ARNorm: unitary normal to the 'chord' of the AR (always pointing

towards the outside of the component). [3D vector]

N: refraction index of the material. [float]

HRK, ARK: curvature of the HR, AR surfaces. [float]

HRr, HRt, ARr, ARt: power reflectance and transmission coefficients of the HR and AR surfaces. [float]

KeepI: whether of not to keep data of rays for interference calculations on the HR. [boolean]

Wedge: wedge angle on the optic. [float]

Alpha: angle of the rotation to describe the orientation of the wedge. See the documentation for details on this angle. [float]

TonHR, RonHR, TonAR, RonAR: amount by which the orders of the beams will be increased upon relfection or transmission on AR or HR surfaces.

These are the principal parameters which distinguish mirrors and lenses and beamsplitters, etc.

Note: the curvature of any surface is positive for a concave surface (coating inside the sphere).

Thus kurv*HRNorm/|kurv| always points to the center

of the sphere of the surface, as is the convention for the lineSurfInter of geometry module. Same for AR.

17.2.1 Methods

<u>init</u> (self, ARCenter, HRCenter, HRNorm, ARNorm, N, HRK, ARK, ARr, ARt, HRr, HRt, KeepI, Thickness, Diameter, Wedge, Alpha, RonHR, TonHR, RonAR, TonAR, Ref)

Optic base initializer.

Parameters are the attributes of the object to construct.

Returns an Optic.

Overrides: object.___init__

apexes(self)

Returns the positions of the apexes of HR and AR as a tuple.

collision(self)

Determine whether the HR and AR surfaces intersect.

Returns True if there is an intersection, False if not.

geoCheck(self, word)

Makes geometrical checks on surfaces and warns when necessary.

hit(self, beam, order, threshold)

Compute the refracted and reflected beams after interaction.

The beams returned are those selected after the order and threshold criterion.

beam: incident beam. [GaussianBeam]

order: maximum strayness of daughter beams, which are not returned if their strayness is over this order. [integer]

threshold: idem for the power of the daughter beams. [float]

Returns a dictionary of beams with keys:

't': refracted beam. [GaussianBeam]
'r': reflected beam. [GaussianBeam]

Overrides: theia.optics.component.SetupComponent.hit

hitAR(self, beam, point, order, threshold)

Compute the daughter beams after interaction on AR at point.

beam: incident beam. [GaussianBeam]

point: point in space of interaction. [3D vector]

order: maximum strayness of daughter beams, which are not returned if

their strayness is over this order. [integer]

threshold: idem for the power of the daughter beams. [float]

Returns a dictionary of beams with keys:

't': refracted beam. [GaussianBeam]

'r': reflected beam. [GaussianBeam]

hitHR(self, beam, point, order, threshold)

Compute the daughter beams after interaction on HR at point.

beam: incident beam. [GaussianBeam]

point: point in space of interaction. [3D vector]

order: maximum strayness of daughter beams, which are not returned if

their strayness is over this order. [integer]

threshold: idem for the power of the daughter beams. [float]

Returns a dictionary of beams with keys:

't': refracted beam. [GaussianBeam]

'r': reflected beam. [GaussianBeam]

hitSide(self, beam)

Compute the daughter beams after interaction on Side at point.

Generic function: all sides stop beams.

beam: incident beam. [GaussianBeam]

Returns {'t': None, 'r': None}

isHit(self, beam)

Determine if a beam hits the Optic.

This is a function uses the dictionaries provided by isHitDics to find the closest face hit by the beam.

beam: incoming beam. [GaussianBeam]

Returns a dictionary with keys:

'isHit': whether the beam hits the optic. [boolean]

'intersection point': point in space where it is first hit.

[3D vector]

'face': to indicate which face is first hit, can be 'HR', 'AR' or

'Side'. [string]

'distance': geometrical distance from beam origin to impact. [float]

Overrides: theia.optics.component.SetupComponent.isHit

isHitDics(self, beam)

Determine the dictionaries to evaluate if a beam hits the optic.

Uses the line***Inter functions from the geometry module to calculate the dictionaries of data on interaction with HR and AR and side of optics.

Returns a tuple of 3 dictionaries with keys:

'isHit': whether the optic is hit by the beam. [bool]

'intersection point': 3D point where the beam impacts.

[3D np-array]

'distance': distance from beam origin to interaction point. [float]

translate(self, X=0.0, Y=0.0, Z=0.0)

Move the optic to (current position +(X, Y, Z)).

This version takes care of HRcenter and ARCenter and overwrites the SetupComponent version.

X, Y, Z: components of the translation vector.

No return value.

Overrides: theia.optics.component.SetupComponent.translate

$Inherited\ from\ theia. optics. component. Setup Component (Section\ 14.2)$
str(), lines()
Inherited from object
delattr(),format(),getattribute(),hash(),new(),reduce(),reduceex(),repr(),setattr(),sizeof(),subclasshook()

17.2.2 Properties

Name	Description
Inherited from object	
class	

17.2.3 Class Variables

Name	Description	
Name	Value: 'Optic'	
OptCount	Value: 0	
abstractmethods	Value: frozenset(['lines'])	
Inherited from theia.optics.component.SetupComponent (Section 14.2)		
SetupCount		

18 Module theia.optics.special

Defines the Special class for theia.

18.1 Variables

Name	Description
package	Value: 'theia.optics'

18.2 Class Special

```
object —
theia.optics.component.SetupComponent —
theia.optics.optic.Optic —
theia.optics.special.Special
```

Special class.

This class represents general optics, as their actions on R and T are left to the user to input. They are useful for special optics which are neither reflective nor transmissive.

Actions:

```
* T on HR: user input

* R on HR: user input

* T on AR: user input

* R on AR: user input
```

Note: by default the actions of these objects are those of beamsplitters $(0,\ 0,\ 0,\ 0)$

=== Additional attributes with respect to the Optic class ===

None

=== Name ===

Special


Note: the curvature of any surface is positive for a concave surface (coating inside the sphere).

Thus kurv*HRNorm/|kurv| always points to the center

of the sphere of the surface, as is the convention for the lineSurfInter of geometry module. Same for AR.

*****	HRK > 0 and $ARK > 0$	*****	HRK > 0 and $ARK < 0$
****		*****	and ARK > HRK
H***A		H******A	
****		*****	
*****		*****	

18.2.1 Methods



Inherited from theia.optics.optic.Optic(Section 17.2)

apexes(), collision(), geoCheck(), hit(), hitAR(), hitHR(), hitSide(), isHit(), isHit-Dics(), translate()

 $Inherited\ from\ theia.optics.component. Setup Component (Section\ 14.2)$

Inherited from object

```
___delattr__(), __format__(), __getattribute__(), __hash__(), __new__(), __reduce__(), __repr__(), __setattr__(), __sizeof__(),
```

	11.	1	1 /	$\langle \cdot \rangle$
su	.bcta	asshoo	K ()

18.2.2 Properties

Name	Description
Inherited from object	
class	

18.2.3 Class Variables

Name	Description	
Name	Value: 'Special'	
abstractmethods	Value: frozenset([])	
Inherited from theia.optics.optic.Optic (Section 17.2)		
OptCount		
Inherited from theia.optics.component.SetupComponent (Section 14.2)		
SetupCount		

19 Module theia.optics.thicklens

Defines the ThickLens class for theia.

19.1 Variables

Name	Description
package	Value: 'theia.optics'

19.2 Class ThickLens

```
object —
theia.optics.component.SetupComponent —
theia.optics.optic.Optic —
theia.optics.thicklens.ThickLens
```

ThickLens class.

This class represents thick lenses, specified by curvatures and thickness instead of focal length.

Actions:

- * T on HR: 0
- * R on HR: + 1
- * T on AR: 0
- * R on AR: + 1

=== Additional attributes with respect to the Optic class ===

None

=== Name ===

ThickLens

Note: the curvature of any surface is positive for a concave surface (coating inside the sphere).

Thus kurv*HRNorm/|kurv| always points to the center of the sphere of the surface, as is the convention for the lineSurfInter of geometry module. Same for AR.

Note: in the case of thicklenses, the thickness provided to and by the initializer is the thickness *on the optical axis*, and not the thickness on the side of the component (like mirrors).

Note: in the case of thicklenses, the center provided to the initializer is the *apex* of the principal face, and not the chord of the HR surface.

19.2.1 Methods

ThickLens initializer.

Parameters are the attributes.

Returns a ThickLens.

Overrides: object.___init__

lines(self)

Returns the list of lines necessary to print the object.

Overrides: theia.optics.component.SetupComponent.lines

Inherited from theia.optics.optic.Optic(Section 17.2)

apexes(), collision(), geoCheck(), hit(), hitAR(), hitHR(), hitSide(), isHit(), isHit-Dics(), translate()

Inherited from theia.optics.component.SetupComponent(Section 14.2)

Inherited from object

delattr(),	$_{format}$	(),	_getattrik	oute($(), \underline{\hspace{1cm}}$ hash	(), _	new_	()
reduce(),	_reduce_	_ex()),repr_	(),	_setattr	_(),	_sizeof	_(),
subclasshook	()							

19.2.2 Properties

Name	Description
Inherited from object	
class	

19.2.3 Class Variables

Name	Description			
Name	Value: 'ThickLens'			
abstractmethods	Value: frozenset([])			
Inherited from theia.optics.optic.Optic (Section 17.2)				
OptCount				
Inherited from theia.optics.component.SetupComponent (Section 14.2)				
SetupCount				

20 Module theia.optics.thinlens

Defines the ThinLens class for theia.

20.1 Variables

Name	Description
package	Value: 'theia.optics'

20.2 Class ThinLens

```
object —
theia.optics.component.SetupComponent —
theia.optics.optic.Optic —
theia.optics.thinlens.ThinLens
```

ThinLens class.

This class represents thin lenses, which are specified only by their focal lengths, diameter, position and orientation. Only the initializer and the printing distinguishes thin lenses (in implementation) from other lenses.

Actions:

- * T on HR: 0
- * R on HR: + 1
- * T on AR: 0
- * R on AR: + 1

=== Additional attributes with respect to the Optic class ===

Focal: focal length of the lens as given in initializer. [float]

=== Name ===

ThinLens

Note: the curvature of any surface is positive for a concave surface

(coating inside the sphere).

Thus kurv*HRNorm/|kurv| always points to the center

of the sphere of the surface, as is the convention for the lineSurfInter of geometry module. Same for AR.

*****	HRK > 0 and $ARK > 0$	*****	HRK > 0 and $ARK < 0$
****		******	and $ ARK > HRK $
H***A		H******A	
****		******	
*****		*****	

20.2.1 Methods

```
lines(self)
Returns the list of lines necessary to print the object.
Overrides: theia.optics.component.SetupComponent.lines
```

Inherited from theia.optics.optic.Optic(Section 17.2)

apexes(), collision(), geoCheck(), hit(), hitAR(), hitHR(), hitSide(), isHit(), isHit-Dics(), translate()

$Inherited\ from\ theia.optics.component. Setup Component (Section\ 14.2)$

___str___()

$Inherited\ from\ object$

$\underline{}$ delattr $\underline{}$ ($), \underline{\qquad} format \underline{\qquad} (), \underline{\qquad}$	getattribute	$(), \underline{\qquad} hash \underline{\qquad} (),$	new()
reduce(),reduce_ex	_(),repr(), _	setattr(),	$_{\text{sizeof}}()$
subclasshoo	ok()			

20.2.2 Properties

Name	Description
Inherited from object	
class	

20.2.3 Class Variables

Name	Description			
Name	Value: 'ThinLens'			
abstractmethods	Value: frozenset([])			
Inherited from theia.optics.optic.Optic (Section 17.2)				
OptCount				
Inherited from theia.optics.component.SetupComponent (Section 14.2)				
SetupCount				

21 Package theia.rendering

This is the rendering sub-package of theia.

It allows to write the physical objects to FreeCAD format files for 3D rendering.

Version: 0.1.3

Author: Raphaël Duque

Copyright: Copyright 2017, Raphaël Duque

License: GNU GPLv3+

21.1 Modules

• **features**: Features module or theia, to represent objects as FreeCAD Python features. (Section 22, p. 52)

• shapes: Shapes module for theia, provides shape-calculating for 3D rendering. (Section 23, p. 58)

• writer: Writer module for theia, to write CAD content to files. (Section 24, p. 59)

22 Module theia.rendering.features

Features module or theia, to represent objects as FreeCAD Python features.

22.1 Class FCObject

object — theia.rendering.features.FCObject

Mother class for all FreeCAD objects.

fact: Factor to compensate for unit difference with FreeCAD. [float]

22.1.1 Methods

init(self, obj)	
Custom properties of the object.	_
Overrides: objectinit	

Inherited from object

delattr()	,format	(),g	etattrib	ute	$(), \underline{\hspace{1cm}}$ hash	n(),	new_	().
reduce(),	,reduce_ex	(), _	repr_	(),	$_$ setattr $_$	_(),	_sizeof	_(),
str(),	_subclasshook_	()						


22.1.2 Properties

Name	Description
Inherited from object	
class	


22.1.3 Class Variables

Name	Description
fact	Value: settings.FCFactor

22.2 Class FCMirror



22.2.1 Methods



$Inherited\ from\ object$

delattr(),	_format()	,get	tattribu	ite(),hash	(), _	new_	().
reduce(),	_reduce_ex_	_(),	_repr	_(),	_setattr	_(),	_sizeof	_(),
str(),sul	bclasshook	_()						

22.2.2 Properties

Name	Description
Inherited from object	
class	


22.2.3 Class Variables

Name	Description		
Inherited from theia.rendering.features.FCObject (Section 22.1)			
fact			

22.3 Class FCSpecial

object —	
theia.rendering.features.FCObject	
	theia.rendering.features.FCSpecial

22.3.1 Methods



Inherited from object

```
___delattr__(), __format__(), __getattribute__(), __hash__(), __new__(), __reduce__(), __reduce__ex__(), __repr__(), __setattr__(), __sizeof__(), __str__(), __subclasshook__()
```

22.3.2 Properties

Name	Description
Inherited from object	
class	

22.3.3 Class Variables

Name	Description
Inherited from theia.rendering.features.FCObject (Section 22.1)	
fact	

22.4 Class FCBeamSplitter

object —	
the ia. rendering. features. FCO bject	
	theia.rendering.features.FCBeamSplitter

22.4.1 Methods

init(self, obj, beamSplitter)						
Custom properties of the object.						
Overrides: objectinit extit(inherited documentation)						

Inherited from object

delattr($), \underline{\hspace{1cm}} format_{\underline{\hspace{1cm}}}$	(),{	getattrib	ute((),hash	(), _	new_	().
reduce()	$, _{}$ reduce_	_ex(), _	repr_	(),	_setattr	_(),	_sizeof	_(),
str(),	_subclasshoo	ok()						

22.4.2 Properties

Name	Description
Inherited from object	
class	

22.4.3 Class Variables

Name	Description		
Inherited from theia.rendering.features.FCObject (Section 22.1)			
fact			

22.5 Class FCLens

22.5.1 Methods

$__$ init $__$ (self, obj, lens)	
Custom properties of the object.	
Overrides: objectinit extit(inherited documentation)	

Inherited from object

$\underline{}$ delattr $\underline{}$ (), $\underline{}$ format $\underline{}$ (), $\underline{}$	_getattribute	$(), \underline{\hspace{1cm}} \operatorname{hash} \underline{\hspace{1cm}} ()$,new()
$\underline{}$ reduce $\underline{}$ (), $\underline{}$ reduce $\underline{}$ ex $\underline{}$ ()	,repr(),	$_$ setattr $__(), _$	$_$ sizeof $_$ (),
str(),subclasshook()			

22.5.2 Properties

Name	Description
Inherited from object	
class	

22.5.3 Class Variables

Name	Description	
Inherited from theia rendering features. FCObject (Section 22.1)		
fact		

22.6 Class FCBeamDump

object —	
the ia. rendering. features. FCO bject	
	theia.rendering.features.FCBeamDump

22.6.1 Methods

init(self, obj, beamDump)
Custom properties of the object.
Overrides: objectinit extit(inherited documentation)

$Inherited\ from\ object$

$__delattr_$	$(), $ format_	(),g	etattribu	ite(),hash	(), _	new_	()
reduce	(), reduce $($	_ex(), _	repr	_(),	_setattr	_(),	_sizeof	_(),
str (),	subclasshoo	ok ()						

22.6.2 Properties

Name	Description
Inherited from object	
class	

22.6.3 Class Variables

Name Description		
Inherited from theia.rendering.features.FCObject (Section 22.1)		
fact		

22.7 Class FCBeam

object —	
the ia. rendering. features. FCO bject	
	theia.rendering.features.FCBeam

22.7.1 Methods

init(self, obj, beam)			
Custom properties of the object.			
Overrides: objectinit extit(inherited documentation)			

$Inherited\ from\ object$

delattr($), \underline{\hspace{1cm}} format \underline{\hspace{1cm}} (), \underline{\hspace{1cm}}$	_getattribute	$(), \underline{\hspace{1cm}} hash \underline{\hspace{1cm}} (),$	new()
reduce($), \underline{\qquad}$ reduce $\underline{\qquad}$ ($),$	repr(), _	$__$ setattr $__(), _$	$_sizeof__(),$
str(),	$_subclasshook__()$			

22.7.2 Properties

Name	Description
Inherited from object	
class	

22.7.3 Class Variables

Name	Description	
Inherited from theia rendering features. FCObject (Section 22.1)		
fact		

23 Module theia.rendering.shapes

Shapes module for theia, provides shape-calculating for 3D rendering.

23.1 Functions

mirrorShape(mirror)

Computes the 3D representation of the mirror, a shape for a CAD file obj.

beam: beam to represent. [GaussianBeam]

Returns a shape for a CAD file object.

beamSplitterShape(bs)

Computes the 3D representation of the beamsplitter, for a CAD file obj.

beam: beam to represent. [GaussianBeam]

Returns a shape for a CAD file object.

lensShape(lens)

Computes the 3D representation of the lens, a shape for a CAD file obj.

lens: lens to represent. [GaussianBeam]

Returns a shape for a CAD file object.

beamDumpShape(beamDump)

Computes the 3D representation of the beamdump, for a CAD file obj.

beam: beam to represent. [GaussianBeam]

Returns a shape for a CAD file object.

beamShape(beam)

Computes the 3D representation of the beam, a shape for a CAD file obj.

beam: beam to represent. [GaussianBeam]

Returns a shape for a CAD file object.

24 Module theia.rendering.writer

Writer module for theia, to write CAD content to files.

24.1 Functions

writeToCAD(component, doc)

Write the relevant FreeCAD objects of components in CAD file.

This function is for everything except for beams.

To the doc .fcstd file are added one object per optic and beam, they are of type Part::FeaturePython to allow for shapes and features.

The important functions are the PythonFeatures constructors found in features, and the shape functions found in shapes.

component: component to represent. [Mirror, Lens, BeamDump, Ghost, Beam] doc: CAD file to write to. [CAD file]

No return value.

writeTree(tree, doc)

Recursively write the shape and feature content of the beams of a tree.

If the tree's root is not None, write the shape and feature for tree.Root and start over for the daughter trees.

tree: beamtree to write the info. [BeamTree]

doc: CAD file to write to. [CAD file]

No return value.

25 Package theia.running

This is the running sub-package of theia.

It provides the necessary classes and functions to allow the input, output and encapsulation of simulation data.

Version: 0.1.3

Author: Raphaël Duque

Copyright: Copyright 2017, Raphaël Duque

License: GNU GPLv3+

25.1 Modules

• parser: Module for the parsing on input data from .tia file. (Section 26, p. 61)

• simulation: Defines the Simulation class for theia. (Section 27, p. 63)

26 Module theia.running.parser

Module for the parsing on input data from .tia file.

26.1 Functions

```
dicOf(st, line, fileName, lineNumber)

Extract the initializer dictionary from a line.

st: object tag, 'bm', 'th', ... [string]
line: line of data in .tia format (supposed no spaces nor tabs nor and without the obect tag. [string]
fileName: name of file (used to write errors). [string]
lineNumber: number fo this line in the file (used to write errors). [int]

May raise an InputError
Returns a dictionary ready for construction.
```

readIn(name)

Finds the input data in a file.

Returns a list of tuples where tuple[0] identifies the object of which data has been found and tuple[1] the data itself. tuple[1] may be a simple value or a dictionary for constructors, etc.

```
Example return value: [ ('bd', {'X': 0., 'Y': 0., 'Z': 1.}), #constructor ('LName', 'foo')] #string data.
```

name: file to read. [string]

May raise an InputError.

Returns a list of tuples.

26.2 Variables

Name	Description
GHz	Value: 1000000000.0
Hz	Value: 1.0

continued on next page

Name	Description
MHz	Value: 1000000.0
THz	Value: 1e+12
W	Value: 1.0
package	Value: 'theia.running'
arccos	Value: <ufunc 'arccos'=""></ufunc>
arcsin	Value: <ufunc 'arcsin'=""></ufunc>
arctan	Value: <ufunc 'arctan'=""></ufunc>
cm	Value: 0.01
cos	Value: <ufunc 'cos'=""></ufunc>
deg	Value: 0.0174532925199
exp	Value: <ufunc 'exp'=""></ufunc>
kHz	Value: 1000.0
kW	Value: 1000.0
km	Value: 1000.0
m	Value: 1.0
mHz	Value: 0.001
mW	Value: 0.001
mm	Value: 0.001
nW	Value: 1e-09
nm	Value: 1e-09
pi	Value: 3.14159265359
ppm	Value: 1e-06
rad	Value: 1.0
sin	Value: <ufunc 'sin'=""></ufunc>
sqrt	Value: <ufunc 'sqrt'=""></ufunc>
tan	Value: <ufunc 'tan'=""></ufunc>
uHz	Value: 1e-06
uW	Value: 1e-06
um	Value: 1e-06

27 Module theia.running.simulation

Defines the Simulation class for theia.

Version: 0.1.3

27.1 Variables

Name	Description
package	Value: 'theia.running'

27.2 Class Simulation

object — theia.running.simulation.Simulation

Simulation class.

This class is a wrapper for all the metadata (names of setup and of files, etc.) as well as for the high level functions of a simulation.

```
*=== Attributes ===*
```

LName: name of the simulation [string]

FName: name of the file for outputs (without extension) [string]

OptList: list of optical components of the setup [list of optics]

InBeams: list of input beams [list of beams]

BeamTreeList: list of binary trees of beams [list of BeamTree]

Order: order of the simulation, beams transmitted by HRs or reflected by ARs have their orders augmented by 1, and simulation calculates only until this Order attribute. [int]

Threshold: Power under which beams are no longer traced. [float]

Date: string of the date-time when the simulation was created (not run). [string]

27.2.1 Methods

init(self, FName='simulationinput')
Simulation initializer.
FName: output files name without extension. [string] Overrides: objectinit

___str___(self)
String representation of the simulation, for print(simulation).
Overrides: object.___str___

numberOfOptics(self)

Calculate the number of optics of OptList.

Returns the number of optics (not components, optics).

load(self)

Initialize simulation attributes by input from .tia file.

See documantation for the format of the input file.

No return value.

$\mathbf{run}(self)$

Run simulation with input as read by load.

threshold: power of beam below which the simulation stops tracing child beams. [float]

order: maximum order to keep daughter beams. [integer]

No return value.

writeOut(self)

Write the results from the simulation in the .out file.

writeCAD(self)

Write the CAD .fcstd file by calling rendering functions.

Inherited from object

$\underline{}$ delattr $\underline{}$ (), $\underline{}$	$_{format}_$	(),	getattrib	ute()),hash_	(), _	new_	().
reduce(),	_reducee	ex(),	repr_	(),	_setattr	_(),	_sizeof	_(),
subclasshook	_()							

27.2.2 Properties

Name	Description
Inherited from object	
class	

28 Package theia.tree

This is the tree sub-package of theia.

It provides the necessary classes and functions to allow the reverse ray tracing and stray light hunting features of theia.

Version: 0.1.3

Author: Raphaël Duque

Copyright: Copyright 2017, Raphaël Duque

License: GNU GPLv3+

28.1 Modules

• beamtree: Defines the BeamTree class for theia. (Section 29, p. 67)

29 Module theia.tree.beamtree

Defines the BeamTree class for theia.

29.1 Functions

treeOfBeam(srcBeam, optList, order, threshold)

Function to calculate the tree of daughter beams of srcBeam.

srcBeam: Input beam. [GaussianBeam] optList: List of optical components of the setup. [list of OpticalComponent] order: order of simulation. [integer]

threshold: power threshold for daughter beams. [float]

Returns a BeamTree.

29.2 Variables

Name	Description
package	Value: 'theia.tree'

29.3 Class BeamTree

object — theia.tree.beamtree.BeamTree

BeamTree class.

A BeamTree is a binary tree which allows to keep track of the beams as they are traced throughout the optical setup. The Root of the tree is a Gaussian beam and the other attributes are the daughter trees and all the data of the interaction producing these with the Root beam

=== Attributes ==== Name: class attribute, name of object. [string] Root: beam of this node of the tree. [GaussianBeam] T: beam resulting from the transmission of the Root beam. [BeamTree] R: beam resulting from the reflection of the Root beam. [BeamTree]

29.3.1 Methods

$\boxed{\underline{\hspace{0.5cm}} \texttt{init}\underline{\hspace{0.5cm}} (\textit{self}, \textit{Root} = \texttt{None}, \textit{T} = \texttt{None}, \textit{R} = \texttt{None})}$
BeamTree initializer.
Overrides: objectinit
str(self)
String representation of a BeamTree, for print(tree).
Overrides: objectstr
lines(self)
Returns the list of lines necessary to print the object.
$\boxed{\mathbf{beamList}(\textit{self})}$
Returns the string representation the tree of beams.
$\boxed{\mathbf{beamLines}(\mathit{self})}$
Returns the list of lines necessary to print the list of beams.
Return the total number of beams.
outputLines $(self)$

$Inherited\ from\ object$

delattr(),	$_{ m format}_{ m }$	(),	$_$ getattrib	$ute__()$,hash_	(), _	new_	()
reduce(),	_reduce_	_ex()	,repr_	(),	_setattr	_(),	_sizeof	_(),
subclasshook_	_()							

Return the list of lines to write the output of simulation.

29.3.2 Properties

Name	Description
Inherited from object	
class	

29.3.3 Class Variables

Name	Description
Name	Value: 'BeamTree'

Index

```
theia (package), 2-3
    theia.helpers (package), 4
     theia.helpers.core (module), 5
      theia.helpers.geometry (module), 6–8
     theia.helpers.interaction (module), 9
      theia.helpers.settings (module), 10
      theia.helpers.tools (module), 11–13
     theia.helpers.units (module), 14
    theia.main (module), 15
     theia.main.main (function), 15
    theia.optics (package), 16
     theia.optics.beam (module), 17–20
      theia.optics.beamdump (module), 21–23
      theia.optics.beamsplitter (module), 24–
      theia.optics.component (module), 27–29
      theia.optics.ghost (module), 30–32
      theia.optics.mirror (module), 33–35
      theia.optics.optic (module), 36-41
      theia.optics.special (module), 42–44
      theia.optics.thicklens (module), 45–47
      theia.optics.thinlens (module), 48–50
    theia.rendering (package), 51
     theia.rendering.features (module), 52-
        57
     theia.rendering.shapes (module), 58
     theia.rendering.writer (module), 59
    theia.running (package), 60
     theia.running.parser (module), 61–62
     theia.running.simulation (module), 63–
       65
    theia.tree (package), 66
     theia.tree.beamtree (module), 67–69
```